

Diagnostic List Fuwa Machinery_v5.58

Remark:
 1. ✓ : means that the system has this function
 2. - : means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

Engine type	System	Function					Remark(Other functions)
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	
BOSCH common rail EDC16C40	Static diagnosis data	✓	✓	✓	-	-	Oil balance matching, read freeze frame
BOSCH common rail EDC16C40	Dynamic diagnosis data	✓	-	-	✓	✓	Function test
BOSCH common rail EDC7	Static diagnosis data	✓	✓	✓	-	-	Troubleshoot guide, read freeze frame
BOSCH common rail EDC7	Dynamic diagnosis data	✓	-	-	✓	✓	Function test
DELPHI common rail system	DELPHI common rail system_12V	✓	✓	✓	✓	✓	Injector data, write VIN, leak test
DELPHI common rail system	DELPHI common rail system Euro III	✓	✓	✓	✓	✓	Injector data, write VIN, leak test
Hino Denso engine	E13CTJ Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CK Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CM Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CL Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CN Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CP Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CR Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CS Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CT Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08TB Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08TE Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08TA Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	J05DTA Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	J05DTA Engine trial	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	P11CH Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	P11CUJ Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CN Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUR Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CK Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUL Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUP Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J07TB Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J05DTA Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CVT Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUT Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function

Diagnostic List Fuwa Machinery_v5.58

Remark:
 1. ✓ : means that the system has this function
 2. - : means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

Engine type	System	Function					Remark(Other Functions)
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	
Hino Denso engine	J08ETN Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETT Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETL Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETU Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUU Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUM Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUS Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EB Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EA Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EB Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EC Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ED Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EE Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J05DTG Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J05ETC Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J05ETD Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETW Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EJ Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EV Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J05DTF Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUY Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	P11CUR Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ER Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CYA Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CVB Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	P11CUV Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EP Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ES Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EL Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ET Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EU Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J05ETF Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CVC Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	Training Board	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	A09C	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	A09CTJ	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	A09CTK	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	U2 Engine	✓	✓	✓	-	-	-