

Diagnostic List Maruti_v8.62

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu		Function					
Enter Type	System	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function
Test by System	Engine/ Powertrain	✓	✓	✓	✓	✓	✓
Test by System	TCM	✓	✓	✓	✓	✓	✓
Test by System	ABS/ESP	✓	✓	✓	-	✓	✓
Test by System	Power Steering	✓	✓	✓	✓	✓	✓
Test by System	Airbag	✓	✓	✓	✓	✓	✓
Test by System	AC	✓	✓	✓	✓	✓	✓
Test by System	AC2	✓	✓	✓	✓	✓	✓
Test by System	BCM	✓	✓	✓	✓	✓	✓
Test by System	EMCD	✓	✓	✓	✓	✓	-
Test by System	4WD	✓	✓	✓	✓	✓	-
Test by System	Keyless Start	✓	✓	✓	✓	✓	-
Test by System	Combination Meter / Meter/M&A	✓	✓	✓	✓	✓	-
Test by System	ACCM	✓	✓	✓	✓	✓	-
Test by System	Immobi and/or Keyless System	✓	✓	✓	✓	✓	✓
Test by System	Immobilizer Engine/ Powertrain	✓	✓	✓	-	-	✓
Test by System	Immobilizer BCM	✓	✓	✓	-	-	-
Test by System	I-KEY	✓	✓	✓	✓	✓	✓
Test by System	EV_MOTOR	✓	✓	✓	✓	✓	-
Test by System	Engine Auto Stop and Start	✓	✓	✓	✓	✓	✓
Test by System	ISG	✓	✓	✓	✓	✓	-
Test by System	Auxiliary Power	✓	✓	✓	✓	✓	-
Test by System	Headlight Auto Leveling	✓	✓	✓	✓	✓	✓