

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3.compared with the last version, the new added function is marked in red color.

System type	System	System	Function					Remark (other functions)
			Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	Actuation Test	
EDC16UC40 Universal	-	-	√	√	√	√	√	-
Witt unit pump	Witt unit pump system(ECU25)	-	-	√	√	√	√	Read and write injector data, etc.
Witt unit pump	Witt unit pump system(RS232)	-	-	√	√	√	-	-
Witt unit pump	Witt unit pump system(J1939)	-	-	√	√	√	-	-
Witt unit pump	Witt unit pump system(Perkins)	-	-	√	√	√	-	-
Nanyue unit pump	Nanyue unit pump system(J1939)	-	-	√	√	√	-	-
Nanyue unit pump	Nanyue unit pump system_R01 4-cylinder	-	-	√	√	√	√	-
Nanyue unit pump	Nanyue unit pump system_R01 6-cylinder	-	-	√	√	√	√	-
Nanyue unit pump	Nanyue unit pump system_R02 4-cylinder Hall	-	-	√	√	√	√	-