

Diagnostic List Case_v6.51

Remark:
 1. ✓ : means that the system has this function
 2. - : means that the system does not have this function
 3. Compared with the last version, the new added function is marked in red color.

| Dealer | Category | Model | System | Function | | | | Actuation Test | Special Function |
|------------|----------|---|----------------------------------|----------------------|-----------------|------------------|-----------|--|------------------|
| | | | | Read ECU Information | Read Fault Code | Erase Fault Code | Live Data | | |
| CASE IH AG | TRACTORS | MAXXUM Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBExxxxx) | 4WD 4WD,Diff Lock Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | MAXXUM Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBExxxxx) | ADIC Analog/Digital Inst Cluster | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | MAXXUM Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBExxxxx) | GA Power Take-Off Module | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | MAXXUM Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBExxxxx) | Steer Steering Controller | ✓ | ✓ | ✓ | - | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | 4WD 4WD,Diff Lock Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | ACM Armrest Control Module | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | ACT Auto Temperature Controller | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | ECM Engine Control Module | - | - | - | ✓ | Engine - Urea Dosing Leakage Check (UDLC); Engine - Urea Dosing Pump Check (UDPC) - SM with 12kg/h; Engine - Urea Dosing Pump Check (UDPC) - SM with 7.2kg/h; Engine - Urea Dosing System Test (UDST); Engine - Urea Dosing Valve Check (UDVC) | ✓ |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | EDC Electronic Draft Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | ENG Electronic Engine Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | EPL Electronic Park Lock | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | FEHR Front Hydraulic Remote | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | ICP Integrated Control Panel | ✓ | - | - | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | Inst Tractor Monitor | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | REHR Rear Hydraulic Remote | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | RPTO Rear PTO Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | SFA Suspension Front Axle | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | TCU Tractor Control Unit | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | ECM Engine | - | - | - | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | Engine | - | - | - | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000) | Trans Transmission Control | - | ✓ | ✓ | ✓ | CVT Transmission Hydrostatic Unit Test | ✓ |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | 4WD 4WD,Diff Lock Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | ACM Armrest Control Module | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | ACT Auto Temperature Controller | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | ECM Engine Control Module | - | - | - | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | EDC Electronic Draft Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | ENG Electronic Engine Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | EPL Electronic Park Lock | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | FEHR Front Hydraulic Remote | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | ICP Integrated Control Panel | ✓ | - | - | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | Inst Tractor Monitor | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | REHR Rear Hydraulic Remote | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor(Models 185, 200, 220, 240) (with CVT Transmission)(Tier 4B) (P. I. N. ZxES00001 - ZxES99999) | RPTO Rear PTO Control | - | ✓ | ✓ | ✓ | - | - |

Diagnostic List Case_v6.51

Remark:
 1. ✓ : means that the system has this function
 2. - : means that the system does not have this function
 3. Compared with the last version, the new added function is marked in red color.

| Dealer | Category | Model | System | Function | | | | Actuation Test | Special Function |
|---------------------|-----------------|--|---------------------------------|----------------------|-----------------|------------------|-----------|--|---|
| | | | | Read ECU Information | Read Fault Code | Erase Fault Code | Live Data | | |
| CASE IH AG | TRACTORS | Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999) | SFA Suspension Front Axle | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999) | TCU Tractor Control Unit | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999) | Trans Transmission Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | ECM Engine Control Module | - | - | - | ✓ | ✓ | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | Trans Transmission Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | ACM Armrest Control Module | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | RPTO Rear PTO Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | 4WD 4WD, Diff Lock Control | - | ✓ | ✓ | - | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | SSS Secondary Steering System | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | SFA Suspension Front Axle | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | Inst Tractor Monitor | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | ACT Auto Temperature Controller | ✓ | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | REHR Rear Hydraulic Remote | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | Hitch Electronic Hitch Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | ENG Electronic Engine Control | - | ✓ | ✓ | ✓ | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | FHC Front Hitch Control | - | ✓ | ✓ | - | - | - |
| CASE IH AG | TRACTORS | Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P.I.N. ZDRF00801 and Above) | ICP Integrated Control Panel | - | - | - | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B) | Tier 4 F5C (EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B) | ECM Engine Control Module | - | - | - | ✓ | Glow Plugs Activation Test; DPF Service Regeneration Test | Engine Restart Counter Reset/Unlock Inducement; Replacement of the Engine Oil/Filter-Reset Change Reminder; Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data; Replacement of the Lambda Sensor-Reset ECU Data; Replacement of the Oxidant Cayalyst(OxiCat) - Reset ECU Data; Replacement of the Particulate Filter(DPF/PM-Cat) - Reset ECU Data; Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data; |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B) | VCM Vehicle Control/Display/Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR) | Tier 4 F5C (EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR) | ECM Engine Control Module | - | - | - | ✓ | Glow Plugs Activation Test; Desulfurization/Thermal Conditioning Procedure; Engine - Urea Dosing System Test (UDST); | Engine Restart Counter Reset/Unlock Inducement; Replacement of the EGR Cooler - Reset ECU Data; Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data; Replacement of the Oxidant Cayalyst(OxiCat) - Reset ECU Data; Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data; Replacement of the Rail Pressure Sensor - Reset ECU Data; Replacement of the SCR Catalyst - Reset ECU Data; |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR) | VCM Vehicle Control/Display/Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A) | Tier 4 F5C (EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |

Diagnostic List Case_v6.51

Remark:
 1. ✓ : means that the system has this function
 2. - : means that the system does not have this function
 3. Compared with the last version, the new added function is marked in red color.

| Dealer | Category | Model | System | Function | | | | Actuation Test | Special Function |
|---------------------|-----------------------|---|---------------------------------|----------------------|-----------------|------------------|-----------|--|--|
| | | | | Read ECU Information | Read Fault Code | Erase Fault Code | Live Data | | |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A) | ECM Engine Control Module | - | - | - | ✓ | Glow Plugs Activation Test; DPF Service Regeneration Test | DPF Ash Cleaning Service - Reset ECU Data; Replacement of the Particulate Filter(DPF) - Reset ECU Data; Replacement of the Differential Pressure Sensor(Delta P)- Reset ECU Data; Replacement of the Engine Oil/Filter-Reset Change Reminder; Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data; Replacement of the Lambda Sensor-Reset ECU Data; Replacement of the Oxidant Cayalyst(OxiCat) - Reset ECU Data; Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data; |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A) | VCM Vehicle Control/Display/Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3) | Tier 3 NEF (EDC7UC31) | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3) | Eng Engine Controller | - | - | - | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3) | VCM Vehicle Control/Display Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N < NFC719059, 580SN < NFC722013, 580SNWT < NFC723500, 590SN < NFC725011) (Tier 3) | Tier 3 NEF (EDC7UC31) | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N < NFC719059, 580SN < NFC722013, 580SNWT < NFC723500, 590SN < NFC725011) (Tier 3) | Eng Engine Controller | - | - | - | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580N < NFC719059, 580SN < NFC722013, 580SNWT < NFC723500, 590SN < NFC725011) (Tier 3) | VCM Vehicle Control/Display Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A) | Tier 4 F5C (EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A) | ECM Engine Control Module | - | - | - | ✓ | Glow Plugs Activation Test; DPF Service Regeneration Test | DPF Ash Cleaning Service - Reset ECU Data; Replacement of the Particulate Filter(DPF) - Reset ECU Data; Replacement of the Differential Pressure Sensor(Delta P)- Reset ECU Data; Replacement of the Engine Oil/Filter-Reset Change Reminder; Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data; Replacement of the Lambda Sensor-Reset ECU Data; Replacement of the Oxidant Cayalyst(OxiCat) - Reset ECU Data; Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data; |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A) | VCM Vehicle Control/Display/Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (Models 580SR+, 590SR, 695SR, 580ST, 590ST, 695ST) | Tier 3 NEF (EDC7UC31) | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (580SM, 580SM+, 590SM, 590SM+) | Tier 3 NEF (EDC7UC31) | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (580SM, 580SM+, 590SM, 590SM+) | Tier 3 NEF (EDC7UC31) | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (580SM, 580SM+, 590SM, 590SM+) | VCM Vehicle Control/Display/Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (580SM, 580SM+, 590SM, 590SM+) | Eng Engine Controller | - | - | - | ✓ | - | - |
| Case CE EUR (Light) | LOADER BACKHOES | Loader Backhoe (580SM, 580SM+, 590SM, 590SM+) | Trans Transmission Controller | ✓ | - | - | ✓ | - | - |
| Case CE EUR (Light) | COMPACT WHEEL LOADERS | Wheel Loaders (Models 021F, 121F, 221F STD, 221F HS, 321F STD, 321F HS) | Tier 4 F5C (EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Case CE EUR (Light) | SKID STEER LOADERS | TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM-CAT) | Tier 4 F5C (EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Case CE EUR (Light) | SKID STEER LOADERS | TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM-CAT) | ECM Engine Control Module | - | - | - | ✓ | Glow Plugs Activation Test; DPF Service Regeneration Test | DPF Ash Cleaning Service - Reset ECU Data; Replacement of the Particulate Filter(DPF) - Reset ECU Data; Replacement of the Differential Pressure Sensor(Delta P)- Reset ECU Data; Replacement of the Engine Oil/Filter-Reset Change Reminder; Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data; Replacement of the Lambda Sensor-Reset ECU Data; Replacement of the Oxidant Cayalyst(OxiCat) - Reset ECU Data; Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data; |
| Case CE EUR (Light) | SKID STEER LOADERS | TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM-CAT) | IC Instrument Cluster | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | SKID STEER LOADERS | TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR) | Tier 4 F5C (EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Case CE EUR (Light) | SKID STEER LOADERS | TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR) | ECM Engine Control Module | - | - | - | ✓ | Glow Plugs Activation Test; DPF Service Regeneration Test | Engine Restart Counter Reset/Unlock Inducement; Replacement of the EGR Cooler - Reset ECU Data; Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data; Replacement of the Oxidant Cayalyst(OxiCat) - Reset ECU Data; Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data; Replacement of the Rail Pressure Sensor - Reset ECU Data; Replacement of the SCR Catalyst - Reset ECU Data; |
| Case CE EUR (Light) | SKID STEER LOADERS | TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR) | IC Instrument Cluster | ✓ | ✓ | ✓ | ✓ | - | - |

Diagnostic List Case_v6.51

Remark:
 1. ✓ : means that the system has this function
 2. - : means that the system does not have this function
 3. Compared with the last version, the new added function is marked in red color.

| Dealer | Category | Model | System | Function | | | | Actuation Test | Special Function |
|---------------------|---------------|---|----------------------------------|----------------------|-----------------|------------------|-----------|---|---|
| | | | | Read ECU Information | Read Fault Code | Erase Fault Code | Live Data | | |
| Case CE EUR (Light) | FORKLIFTS | Fork Lift (Models 586H, 588H) (Tier 4B) | Tier 4 F5C(EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Case CE EUR (Light) | FORKLIFTS | Fork Lift (Models 586H, 588H) (Tier 4B) | ECM Engine Control Module | - | - | - | ✓ | Glow Plugs Activation Test; DPF Service Regeneration Test | Engine Restart Counter Reset/Unlock Inducement; Replacement of the Engine Oil/Filter-Reset Change Reminder; Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data; Replacement of the Lambda Sensor-Reset ECU Data; Replacement of the Oxidant Cayalyst(OxiCat) - Reset ECU Data; Replacement of the Particulate Filter(DPF/PM-Cat) - Reset ECU Data; Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data; |
| Case CE EUR (Light) | FORKLIFTS | Fork Lift (Models 586H, 588H) (Tier 4B) | VCM Vehicle Control/Display/Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE EUR (Light) | FORKLIFTS | Fork Lift (Models 586H, 588H) (Tier 4A) | Tier 4 F5C(EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Case CE EUR (Light) | FORKLIFTS | Fork Lift (Models 586H, 588H) (Tier 4A) | ECM Engine Control Module | - | - | - | ✓ | Glow Plugs Activation Test; DPF Service Regeneration Test | DPF Ash Cleaning Service - Reset ECU Data; Replacement of the Particulate Filter(DPF) - Reset ECU Data; Replacement of the Differential Pressure Sensor(Delta P) - Reset ECU Data; Replacement of the Engine Oil/Filter-Reset Change Reminder; Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data; Replacement of the Lambda Sensor-Reset ECU Data; Replacement of the Oxidant Cayalyst(OxiCat) - Reset ECU Data; Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data; |
| Case CE EUR (Light) | FORKLIFTS | Fork Lift (Models 586H, 588H) (Tier 4A) | VCM Vehicle Control/Display/Mod | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE NA (Heavy) | WHEEL LOADERS | Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B) | ATC Instrument Cluster Unit | ✓ | ✓ | ✓ | ✓ | - | - |
| Case CE NA (Heavy) | WHEEL LOADERS | Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B) | ECM Engine Control Module | - | - | - | ✓ | - | - |
| Case CE NA (Heavy) | WHEEL LOADERS | Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B) | ENG Electronic Engine Control | - | - | - | ✓ | - | - |
| Case CE NA (Heavy) | WHEEL LOADERS | Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B) | JSC Joystick Steering Controller | ✓ | - | - | ✓ | - | - |
| Case CE NA (Heavy) | WHEEL LOADERS | Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B) | TECM Transmission Controller | - | - | - | - | Engine - Urea Dosing Leakage Check (UDLC); Engine - Urea Dosing Pump Check (UDPC) - SM with 12kg/h; Engine - Urea Dosing Pump Check (UDPC) - SM with 7.2kg/h; Engine - Urea Dosing Valve Check (UDVC); | - |
| Engine Type | - | - | Tier 3 NEF(EDC7UC31) | ✓ | ✓ | ✓ | ✓ | - | - |
| Engine Type | - | - | Tier 4 F5C(EDC17C49) | ✓ | ✓ | ✓ | ✓ | Compressor Air-Conditioner Relay; Injector 1 Cut Out; Heated fuel filter relay; EOBD W/Light; Fuel Pump Relay; Cooling Fan Relay; | Engine injector code configuration(original screen with no vehicle controller backup) |
| Engine Type | - | - | MS6.2 | ✓ | ✓ | ✓ | ✓ | - | - |

Remarks: ✓ means the system has this function - means not supported at this moment.