

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function		
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data			
BELL	Truck	Articulated Dump	B25C	✓	✓	✓	✓	1	9.0L VGT Calibration	-
BELL	Truck	Articulated Dump	B30C	✓	✓	✓	✓	2	Actuator Test	✓
BELL	Truck	Articulated Dump	B35C	✓	✓	✓	✓	3	Air Throttle Actuator Learn Value Reset	✓
BELL	Truck	Articulated Dump	B40C	✓	✓	✓	✓	4	Clear Aftertreatment Latched DTC	-
Euclid	Truck	Rigid Frame	EH1000	✓	✓	✓	✓	5	Cold Climate Low Idle Calibration	-
Euclid	Truck	Rigid Frame	EH1100	✓	✓	✓	✓	6	Communication Error Test	✓
Euclid	Truck	Rigid Frame	EH1100-3	✓	✓	✓	✓	7	Control Unit Information	✓
Euclid	Truck	Rigid Frame	EH1100-5	✓	✓	✓	✓	8	Cylinder Cutout Test	✓
Euclid	Truck	Rigid Frame	EH1600	✓	✓	✓	✓	9	Cylinder Electronic Compression Test	✓
Euclid	Truck	Rigid Frame	EH1700	✓	✓	✓	✓	10	Cylinder Misfire Test	✓
Euclid	Truck	Rigid Frame	EH1700-3	✓	✓	✓	✓	11	DEF Header Coolant Purge	-
Euclid	Truck	Rigid Frame	EH3000	✓	✓	✓	✓	12	DEF Pump Diagnostic Test	-
Euclid	Truck	Rigid Frame	EH3500	✓	✓	✓	✓	13	DEF Quantity Test	-
Euclid	Truck	Rigid Frame	EH4500	✓	✓	✓	✓	14	Diagnostics Idle Shutdown Override	-
Euclid	Truck	Rigid Frame	EH4500-1	✓	✓	✓	✓	15	DOC Calibration	-
Euclid	Truck	Rigid Frame	EH4500-2	✓	✓	✓	✓	16	DOC Outlet Temperature Transient Test	-
Euclid	Truck	Rigid Frame	EH5000	✓	✓	✓	✓	17	DPF Calibration	-
Euclid	Truck	Rigid Frame	EH700	✓	✓	✓	✓	18	EGR Valve Clean Test	✓
Euclid	Truck	Rigid Frame	EH700-2	✓	✓	✓	✓	19	EGR Valve Learn Value Reset	✓
Euclid	Truck	Rigid Frame	EH750	✓	✓	✓	✓	20	EGR Valve Recalibration	✓
Euclid	Truck	Rigid Frame	EH750-2	✓	✓	✓	✓	21	Enable Low Pressure Fuel Pump	-
Euclid	Truck	Rigid Frame	EH750-3	✓	✓	✓	✓	22	Engine Fan Speed Change Test	✓
Frontier	Combines and Headers	Header Transports	HT1124	✓	✓	✓	✓	23	Engine Hourmeter	✓

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function		
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data			
Frontier	Combines and Headers	Header Transports	HT1128	✓	✓	✓	✓	24	Engine Load Profile Information	-
Frontier	Combines and Headers	Header Transports	HT1132	✓	✓	✓	✓	25	Engine Overspeed Verification Test	-
Frontier	Combines and Headers	Header Transports	HT1138	✓	✓	✓	✓	26	Engine Speed Change Test	✓
Frontier	Combines and Headers	Header Transports	HT1142	✓	✓	✓	✓	27	Exhaust Filter Product Improvement Program	-
Frontier	Combines and Headers	Header Transports	HT1224	✓	✓	✓	✓	28	Exhaust Temperature Management Test	-
Frontier	Combines and Headers	Header Transports	HT1228	✓	✓	✓	✓	29	Exhaust Throttle Actuator Learn Value Reset	-
Frontier	Combines and Headers	Header Transports	HT1232	✓	✓	✓	✓	30	Fuel Dosing Injector Test	-
Frontier	Combines and Headers	Header Transports	HT1238	✓	✓	✓	✓	31	Fuel Dosing Pump Diagnostic Test	-
Frontier	Combines and Headers	Header Transports	HT1242	✓	✓	✓	✓	32	Fuel Dosing System Air Purge	-
Frontier	Combines and Headers	Header Transports	HT1248	✓	✓	✓	✓	33	Fuel Pump Calibration	-
Frontier	Combines and Headers	Platforms	620VS	✓	✓	✓	✓	34	Fuel Rail Pressure Relief Valve Counter Reset	✓
Frontier	Combines and Headers	Platforms	622VS	✓	✓	✓	✓	35	Harness Diagnostic Mode Test	✓
Frontier	Combines and Headers	Platforms	625VS	✓	✓	✓	✓	36	Injector	✓
Frontier	Combines and Headers	Platforms	630VS	✓	✓	✓	✓	37	Injector Cleaning Test	✓
Frontier	Combines and Headers	Platforms	SH1206	✓	✓	✓	✓	38	Injector Cutout	✓
Frontier	Combines and Headers	Platforms	SH1208	✓	✓	✓	✓	39	Internal Data Monitor	-
Frontier	Combines and Headers	Platforms	SH1210	✓	✓	✓	✓	40	OEM Variable Fan Speed Test	-
Frontier	Combines and Headers	Platforms	SH1212	✓	✓	✓	✓	41	Oxygen Sensor Calibration	-
Frontier	Combines and Headers	Platforms	SH1216	✓	✓	✓	✓	42	Regeneration Abort Source Identification Test	-
Frontier	Combines and Headers	Platforms	SH1306	✓	✓	✓	✓	43	SCR Catalyst Calibration	-
Frontier	Combines and Headers	Platforms	SH1308	✓	✓	✓	✓	44	Service	✓
Frontier	Combines and Headers	Wide-Row Cornhead PIN Prefix XF	CH2112	✓	✓	✓	✓	45	Soot Selection Tool	-
Frontier	Combines and Headers	Wide-Row Cornhead PIN Prefix XF	CH2208	✓	✓	✓	✓	46	Spark Cutout Test	✓

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function		
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data			
Frontier	Cotton Harvesting	Module Handler	CM1100	✓	✓	✓	✓	47	Throttle Calibration Tractor Applications	-
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM1012	✓	✓	✓	✓	48	Tractor Torque Curve Change Test	-
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM1015	✓	✓	✓	✓	49	UEGO Sensor Calibration	✓
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM1017	✓	✓	✓	✓	50	VGT Actuator Travel Range Test	-
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM2012	✓	✓	✓	✓	51	VGT Learn Value Reset	✓
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM2015	✓	✓	✓	✓	52	VGT or Exhaust Throttle Learn Value Reset	-
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM2017	✓	✓	✓	✓	53	View Non-Clearable DTCs	-
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM2112	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM2115	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM2117	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM2120	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Flex-Wing Grooming Mower	FM3012	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM1048E	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM1060	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM1060E	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM1072	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM1072E	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM1084	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM1190	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM2060	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM2072	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM2084	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM2109	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM2190	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM3054	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM3060	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rear Discharge Rotary Mower	GM3072	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rotary Cutters	RC1048	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rotary Cutters	RC1060	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rotary Cutters	RC1072	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rotary Cutters	RC2048	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rotary Cutters	RC2060	✓	✓	✓	✓			
Frontier	Cutting and Mowing	Rotary Cutters	RC2072	✓	✓	✓	✓			

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Cutting and Mowing	Rotary Cutters	RC2084	✓	✓	✓	✓	
Frontier	Cutting and Mowing	Side Discharge Rotary Mower	GM1060S	✓	✓	✓	✓	
Frontier	Cutting and Mowing	Side Discharge Rotary Mower	GM1072S	✓	✓	✓	✓	
Frontier	Golf and Turf Products	Grinders	BG1000	✓	✓	✓	✓	
Frontier	Golf and Turf Products	Grinders	BG1500	✓	✓	✓	✓	
Frontier	Golf and Turf Products	Grinders	RG5000	✓	✓	✓	✓	
Frontier	Golf and Turf Products	Grinders	RG5500	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Carrier	BC1104	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Carrier	BC1108	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Carrier	BC1110	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Mover	BU1060	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Spear	HS1001	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Spear	HS1002	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Spear	HS2001	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Spear	HS2002	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Spear	HS2003	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Spear	HS2004	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Wrapper	LW1166	✓	✓	✓	✓	
Frontier	Hay and Forage	Bale Wrapper	LW1266	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR0008	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR0010	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR0012	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR1008	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR1010	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR1012	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR1108	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR1112	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR1116	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR3008	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR3010	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR3012	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR6008	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR6010	✓	✓	✓	✓	
Frontier	Hay and Forage	Carted Wheel	WR6012	✓	✓	✓	✓	
Frontier	Hay and Forage	Disc Mower Caddy	DC1000	✓	✓	✓	✓	
Frontier	Hay and Forage	Hay Merger	HM1109	✓	✓	✓	✓	
Frontier	Hay and Forage	Hay Merger	HM1209	✓	✓	✓	✓	
Frontier	Hay and Forage	Hay Merger	HM1212	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	DM1130	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	DM1140	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	DM1150	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	DM1160	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	DM1270	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	DM5050	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	DM5060	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	DM5070	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	SB1106	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	SB1107	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	SB3106	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	SB3107	✓	✓	✓	✓	
Frontier	Hay and Forage	Mowers	SB3108	✓	✓	✓	✓	
Frontier	Hay and Forage	Processor	BP1166	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR1212	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR1214	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR1216	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR1218	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR1417	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2010E	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2012E	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2014E	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2110	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2112	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2114	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2212	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2214	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2316	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR2318	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR3310	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR3312	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR3313	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR3315	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR3414	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR3416	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR3417	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR3419	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR4106	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR4109	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR4313	✓	✓	✓	✓	
Frontier	Hay and Forage	Pull-Type Wheel Rakes	WR5417	✓	✓	✓	✓	
Frontier	Hay and Forage	Rotary Rake	RR1012E	✓	✓	✓	✓	
Frontier	Hay and Forage	Rotary Rake	RR2109	✓	✓	✓	✓	
Frontier	Hay and Forage	Rotary Rake	RR2211	✓	✓	✓	✓	
Frontier	Hay and Forage	Rotary Rake	RR2313	✓	✓	✓	✓	
Frontier	Hay and Forage	Rotary Rake	RR2324	✓	✓	✓	✓	
Frontier	Hay and Forage	Tedders	TD1010E	✓	✓	✓	✓	
Frontier	Hay and Forage	Tedders	TD1123	✓	✓	✓	✓	
Frontier	Hay and Forage	Tedders	TD1316	✓	✓	✓	✓	
Frontier	Hay and Forage	Tedders	TD2418	✓	✓	✓	✓	
Frontier	Hay and Forage	Tedders	TD2427	✓	✓	✓	✓	
Frontier	Hay and Forage	Tedders	TD3418	✓	✓	✓	✓	
Frontier	Hay and Forage	Tedders	TD3427	✓	✓	✓	✓	
Frontier	Hydraulic Power Pack	Hydraulic Power Pack	HP2025	✓	✓	✓	✓	
Frontier	Hydraulic Power Pack	Hydraulic Power Pack	HP2134	✓	✓	✓	✓	
Frontier	Landscaping	Aerator	CA1048	✓	✓	✓	✓	
Frontier	Landscaping	Aerator	CA1060	✓	✓	✓	✓	
Frontier	Landscaping	Aerator	CA1072	✓	✓	✓	✓	
Frontier	Landscaping	Aerator	CA2048E	✓	✓	✓	✓	
Frontier	Landscaping	Aerator	CA2060	✓	✓	✓	✓	
Frontier	Landscaping	Aerator	CA2060E	✓	✓	✓	✓	
Frontier	Landscaping	Aerator	CA2072	✓	✓	✓	✓	
Frontier	Landscaping	Aerator	CA2072E	✓	✓	✓	✓	
Frontier	Landscaping	Arena Rake	RA1084	✓	✓	✓	✓	
Frontier	Landscaping	Arena Rake	RA1108	✓	✓	✓	✓	
Frontier	Landscaping	Arena Rake	RA1110	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1048	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Landscaping	Blade	BB1048L	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1060	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1065	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1072	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1160	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1165	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1172	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1184	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1284	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1354	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1360	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1365	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1372	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1472	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB1484	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2048	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2048L	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2060	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2065	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2072	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2172	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2184	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2272	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB2284	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB3272	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB3284	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB3296	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB3384	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4160	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4166	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4172	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4178	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4184	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4196	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4278	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4278C	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4284	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB4296	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB5048L	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB5060	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB5060L	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB5072	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB5084	✓	✓	✓	✓	
Frontier	Landscaping	Blade	BB5096	✓	✓	✓	✓	
Frontier	Landscaping	Blower	BL1130	✓	✓	✓	✓	
Frontier	Landscaping	Blower	BL2130	✓	✓	✓	✓	
Frontier	Landscaping	Chipper Shredder	WC1103	✓	✓	✓	✓	
Frontier	Landscaping	Chipper Shredder	WC1105	✓	✓	✓	✓	
Frontier	Landscaping	Chipper Shredder	WC1205	✓	✓	✓	✓	
Frontier	Landscaping	Chipper Shredder	WC1208	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1048	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1060	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1160	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1172	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1184	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1184C	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1196	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1196C	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1207	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1208	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1210	✓	✓	✓	✓	
Frontier	Landscaping	Land Plane	LP1210	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR1060L	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR1072	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR1172	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR1184	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR1196	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR2060L	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR2072	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Landscaping	Landscape Rake	LR2084	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR2172	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR2184	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR2196	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR5048L	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR5060	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR5060L	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR5072	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR5084	✓	✓	✓	✓	
Frontier	Landscaping	Landscape Rake	LR5096	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Auger	PHA006	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Auger	PHA009	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Auger	PHA012	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Auger	PHA106	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Auger	PHA109	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Auger	PHA112	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Auger	PHA118	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Auger	PHA124	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Digger	PHD100	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Digger	PHD200	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Digger	PHD300	✓	✓	✓	✓	
Frontier	Landscaping	Post Hole Digger	PHD400	✓	✓	✓	✓	
Frontier	Landscaping	Power Rake	PR1148	✓	✓	✓	✓	
Frontier	Landscaping	Power Rake	PR1160	✓	✓	✓	✓	
Frontier	Landscaping	Power Rake	PR1172	✓	✓	✓	✓	
Frontier	Landscaping	Power Rake	PR1184	✓	✓	✓	✓	
Frontier	Landscaping	Power Rake	PR1184F	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB1060	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB1060L	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB1072	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB1084	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB1172	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB1184	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB1196	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2060	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2060L	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2072	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2084	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2160	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2160H	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2172	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2172H	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2184	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2184H	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2196	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2196H	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2272	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Landscaping	Rear Mounted Blades	RB2284	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2296	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2307	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2307C	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2308	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2308C	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2309	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2309C	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2310	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2310C	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2408	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2408C	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2409	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2409C	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2410	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB2410C	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB5048L	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB5060	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB5060L	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB5072	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB5084	✓	✓	✓	✓	
Frontier	Landscaping	Rear Mounted Blades	RB5096	✓	✓	✓	✓	
Frontier	Landscaping	ROTARY BROOM	SW2160	✓	✓	✓	✓	
Frontier	Landscaping	ROTARY BROOM	SW2172	✓	✓	✓	✓	
Frontier	Landscaping	ROTARY BROOM	SW2184	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1060E	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1070E	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1080E	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1140	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1142	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1149	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1150	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1157	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1160	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1165	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1170	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1173	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1180	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1181	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1207	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1208	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1240	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1250	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1260	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1265	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1270	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Landscaping	Rotary Tiller	RT1273	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1280	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1280C	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1307	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1307R	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1308	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1308R	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1310	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1310R	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1360	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1370	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1370R	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1380	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT1380R	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT2210	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT2283	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT2293	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT2308	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT2310	✓	✓	✓	✓	
Frontier	Landscaping	Rotary Tiller	RT2383	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1160	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1172	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1208	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1210	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1212	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1372	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1372C	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1384	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1384C	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1396	✓	✓	✓	✓	
Frontier	Landscaping	Scrapers	LL1396C	✓	✓	✓	✓	
Frontier	Landscaping	seeders	TR1048	✓	✓	✓	✓	
Frontier	Landscaping	seeders	TR1060	✓	✓	✓	✓	
Frontier	Landscaping	seeders	TR1072	✓	✓	✓	✓	
Frontier	Landscaping	seeders	TR2058	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP1048	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP1060	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP1272	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP1272B	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP1284	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP1284B	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP2048B	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP2060B	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP2072B	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP2272B	✓	✓	✓	✓	
Frontier	Landscaping	Soil Pulverizor	SP2284B	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1022B	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1023B	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1035B	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1036B	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1067B	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1079P	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1116P	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1180P	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS1220P	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS2036B	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS2067B	✓	✓	✓	✓	
Frontier	Landscaping	Spreader	SS3067B	✓	✓	✓	✓	
Frontier	Landscaping	Trencher	DT1136	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Attachment	MJ4058	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Attachment	MJ4084	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Attachment	MJ4085	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Attachment	MJ4090	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Attachment	MJ4091	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Attachment	QC1072	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Carrier	AB17K	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Hugger	AH11A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Hugger	AH11D	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Mate. Hand Cut. and Shredders	Bale Hugger	AH11G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Hugger	MJ4099	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB11D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB11E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB11G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB12A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB12D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB12E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB12G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB13D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB13E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB13G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB13K	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB14A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB14D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB14G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB14K	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB15A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB15K	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB16A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB16D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB16G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	AB18K	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	BF1102S	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	MJ4037	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	MJ4060A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	MJ4074	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bale Spear	MJ4081	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AD11E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AD11H	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AD12D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AD12G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AT2016G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AT2016U	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AY11E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AY11H	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	AY12D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	MJ4059A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	MJ4061A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	MJ4062	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	MJ4063A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	MJ4079A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Bucket	MJ4118	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Free Stall	AE11E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Front Blade	AF11D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Front Blade	AF11E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Front Blade	AF11G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Front Blade	AF12D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Front Blade	AF12G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Grapple	AT1096G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Grapple	AV20D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Grapple	AV20E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Grapple	AV20G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Grapple	AV20H	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Grapple	BG1096	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Grinder Mixers	GX1117	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Manure Fork & Grapple	AM11D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Manure Fork & Grapple	AM11E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Manure Fork & Grapple	AM11G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Manure Fork & Grapple	AM11H	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Manure Fork & Grapple	MJ4076	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Manure Fork & Grapple	MJ4077	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP12A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP12D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP12F	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP12G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP12K	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP13D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP13F	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP13G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Pallet Fork	AP13K	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Rock Bucket	AR10D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Rock Bucket	AR10E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Rock Bucket	AR10G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Rock Bucket	AR10H	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Rock Bucket	AR12A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Rock Bucket	AR12D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Rock Bucket	AR12G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Roller	CR1448	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Roller	CR1448C	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Roller	CR1460	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Roller	CR1460C	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Scrapers	LL1410	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Scrapers	LL1410C	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Scrapers	LL1412	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Scrapers	LL1412C	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Scrapers	LL1414	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Scrapers	LL1414C	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Scrapers	LL1416	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Scrapers	LL1416C	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Silage Defacer	AG10A	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Silage Defacer	AG10D	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Silage Defacer	AG10G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Silage Defacer	AG11S	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Silage Defacer	AG12S	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Silage Defacer	SD1096	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Snow Push	AS10H	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Snow Push	AS11E	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1102G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1105G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1108	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1108G	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1112	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1117	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1223	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1227	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1231	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1237	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1243	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1256	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1266	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1337	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1354	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1368	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1442	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS1455	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS2320	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS2326	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS2334	✓	✓	✓	✓	
Frontier	Mate. Hand Cut. and Shredders	Spreader	MS2342	✓	✓	✓	✓	
Frontier	Planting and Seeding	Drills	BD1307	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	CS1360	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	CS1384	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	FP1204	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	FP1204P	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	FP1206	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	FP1208	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	FP2204	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	FP2204L	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	FP2204P	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Planting and Seeding	seeders	FP2206	✓	✓	✓	✓	
Frontier	Planting and Seeding	seeders	FP2208	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Loader Mounted	SB2164	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Loader Mounted	SB2176	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1148	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1154	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1164	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1174	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1184	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1194	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1274	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1280	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1308	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1308R	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1309R	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1388	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1388R	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1392	✓	✓	✓	✓	
Frontier	Snow Products	Snowblowers Rear Mounted	SB1392R	✓	✓	✓	✓	
Frontier	Sprayers	Fertilizer Spreader	FS1124	✓	✓	✓	✓	
Frontier	Sprayers	Fertilizer Spreader	FS1128	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1010	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1015	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1020	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1110	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1115	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1120	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1130	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1210	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1215	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1220	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB1230	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB2020	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB2030	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB2120	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB2130	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB2220	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB2230	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5010	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5015	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5020	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5110	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5115	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5120	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	ab5130	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5210	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5215	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB5220	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	ab5230	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB7020	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB7030	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB7120	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	AB7130	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	CN4106	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	CN4108	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	CN4110	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB3110	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB3115	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB3120	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB3210	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB3215	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB3220	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6010	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6015	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6020	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6110	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6115	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6120	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6210	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6215	✓	✓	✓	✓	
Frontier	Sprayers	Orchard & Vineyard Sprayers	MB6220	✓	✓	✓	✓	
Frontier	Tillage	Cultivator	PC1001	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1048	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1066	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1166	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1176	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1180	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1276	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1280	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1296	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1376	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1380	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1396	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1508	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1509	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1510	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1512	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1610	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1612	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1613	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH1615	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3263	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3272	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3280	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3290	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3299	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3409	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3409C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3474	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3474C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3480	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3480C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3490	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3490C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3499	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH3499C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4108	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4110	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4112	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4114	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4115	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4116	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4117	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4119	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4119R	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4121	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4122	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4125	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4218	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4221	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4307	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4309	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4311	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4315	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4317	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4320	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4411	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4413	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4413C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4414	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4414C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4415	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4415C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4420	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH4420C	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Tillage	Disks	DH5108	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5110	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5112	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5114	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5116	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5210	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5212	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5214	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5216	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5217	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5219	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5221	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5221F	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5222F	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5224F	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5308	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5310	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5312	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5314	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5316	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5410	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5410C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5411	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5411C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5412	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5412C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5413	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5413C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5414	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5414C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5510	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5510C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5511	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5511C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5513	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5513C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5514	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5514C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5610	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5610C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5612	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5612C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5613	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5613C	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5615	✓	✓	✓	✓	
Frontier	Tillage	Disks	DH5615C	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM4124	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM4125	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM4130	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM5118	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM5120	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM5121	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM5124	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM5129	✓	✓	✓	✓	
Frontier	Tillage	Disks	TM5132	✓	✓	✓	✓	
Frontier	Tillage	Field Cultivators	PC1072	✓	✓	✓	✓	
Frontier	Tillage	Mulch Finishers	MF1204	✓	✓	✓	✓	
Frontier	Tillage	Mulch Finishers	MF1204P	✓	✓	✓	✓	
Frontier	Tillage	Mulch Finishers	MF1206	✓	✓	✓	✓	
Frontier	Tillage	Mulch Finishers	MF1208	✓	✓	✓	✓	
Frontier	Tillage	Mulch Finishers	MF2204	✓	✓	✓	✓	
Frontier	Tillage	Mulch Finishers	MF2206	✓	✓	✓	✓	
Frontier	Tillage	Mulch Finishers	MF2208	✓	✓	✓	✓	
Frontier	Tillage	Plows	CP1104	✓	✓	✓	✓	
Frontier	Tillage	Plows	CP1106	✓	✓	✓	✓	
Frontier	Tillage	Plows	PB1001	✓	✓	✓	✓	
Frontier	Tillage	Plows	PB1002	✓	✓	✓	✓	
Frontier	Tillage	Rippers	PM1001	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Frontier	Tillage	Rippers	PS1001	✓	✓	✓	✓	
Frontier	Tillage	Rotary Tiller	RC1208	✓	✓	✓	✓	
Frontier	Tillage	Rotary Tiller	RC1208R	✓	✓	✓	✓	
Frontier	Tillage	Rotary Tiller	RC1210	✓	✓	✓	✓	
Frontier	Tillage	Rotary Tiller	RC1210R	✓	✓	✓	✓	
Frontier	Tillage	Rotary Tiller	RC1310	✓	✓	✓	✓	
Frontier	Tillage	Rotary Tiller	RC1310R	✓	✓	✓	✓	
Frontier	Tillage	Rotary Tiller	RC1313	✓	✓	✓	✓	
Frontier	Tillage	Rotary Tiller	RC1313R	✓	✓	✓	✓	
GreenSystem	Harvester	Row-Crop Harvesting Units	PH1101B	✓	✓	✓	✓	
GreenSystem	Harvester	Row-Crop Harvesting Units	PH1101T	✓	✓	✓	✓	
GreenSystem	Harvester	Row-Crop Harvesting Units	PH1102T	✓	✓	✓	✓	
GreenSystem	Harvester Head	Attachment	CK5018	✓	✓	✓	✓	
GreenSystem	Harvester Head	Attachment	CK5024	✓	✓	✓	✓	
GreenSystem	Harvester Head	Attachment	CK7024	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Attachment	BH1112G	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Flail Shredders	SS1001	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Front Blade	AF2196G	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Front Blade	fb1016	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Front Blade	FB1018	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Front Blade	FB1021	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Front Blade	FB1024	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Front Blade	FB1121	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Pallet Fork	AP2142G	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Wagons	FT1006	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Wagons	FT1010	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Wagons	tt1003	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Wagons	TT1005	✓	✓	✓	✓	
GreenSystem	Mate. Hand Cut. and Shredders	Wagons	TT1006	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Drills	RS1220	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Drills	SD1009	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Drills	SD1009G	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Drills	SD1011	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Drills	SD1011G	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Drills	SD1013	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Drills	SD1013G	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Planters	PP1102	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	Planters	VP1014	✓	✓	✓	✓	
GreenSystem	Planting and Seeding	seeders	DC1102	✓	✓	✓	✓	
GreenSystem	Sprayers	Fertilizer Spreader	FS1003B	✓	✓	✓	✓	
GreenSystem	Sprayers	Mounted Sprayers	MS1004	✓	✓	✓	✓	
GreenSystem	Sprayers	Mounted Sprayers	MS1006	✓	✓	✓	✓	
GreenSystem	Sprayers	Mounted Sprayers	MS2104	✓	✓	✓	✓	
GreenSystem	Sprayers	Mounted Sprayers	MS2106	✓	✓	✓	✓	
GreenSystem	Sprayers	Mounted Sprayers	MS2108	✓	✓	✓	✓	
GreenSystem	Sprayers	Mounted Sprayers	MS2110	✓	✓	✓	✓	
GreenSystem	Sprayers	Trailed Sprayers	DS1120	✓	✓	✓	✓	
GreenSystem	Sugar Cane Planter	PIN Prefix 1XG	SP3030	✓	✓	✓	✓	
GreenSystem	Sugar Cane Planter	PIN Prefix 1XG	SP3040	✓	✓	✓	✓	
GreenSystem	Sugar Cane Planter	PIN Prefix 1XG	SP3130	✓	✓	✓	✓	
GreenSystem	Sugar Cane Planter	PIN Prefix 1XG	SP3140	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	RC1009	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	RC1011	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	RC1013	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	RC1209	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	RC1211	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	RC1213	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	SC1009	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	SC1011	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	SC1013	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	SC1209	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	SC1211	✓	✓	✓	✓	
GreenSystem	Tillage	Cultivator	SC1213	✓	✓	✓	✓	
GreenSystem	Tillage	Disc Ridger	DR1002	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
GreenSystem	Tillage	Disc Ridger	DR1004	✓	✓	✓	✓	
GreenSystem	Tillage	Disk	DH6016	✓	✓	✓	✓	
GreenSystem	Tillage	Disk	DH6022	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	dh4105	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	dh4106	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP1002	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP1003	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP1004	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP3203	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP4205	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP4206	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP5203	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP5204	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP5303	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP5304	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP5403	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP5404	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP5503	✓	✓	✓	✓	
GreenSystem	Tillage	Disk Plows	DP5504	✓	✓	✓	✓	
GreenSystem	Tillage	Disks	DH7205	✓	✓	✓	✓	
GreenSystem	Tillage	Disks	DH7206	✓	✓	✓	✓	
GreenSystem	Tillage	Disks	DH7207	✓	✓	✓	✓	
GreenSystem	Tillage	Disks	DH7305	✓	✓	✓	✓	
GreenSystem	Tillage	Disks	DH7406	✓	✓	✓	✓	
GreenSystem	Tillage	Disks	DH7407	✓	✓	✓	✓	
GreenSystem	Tillage	Disks	DH7508	✓	✓	✓	✓	
GreenSystem	Tillage	Moldboard Plows	MB2002H	✓	✓	✓	✓	
GreenSystem	Tillage	Moldboard Plows	RP1105	✓	✓	✓	✓	
GreenSystem	Tillage	Rippers	TS1001	✓	✓	✓	✓	
GreenSystem	Tillage	Rippers	TS1002	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1004	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1005	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1006	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1007	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1014	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1015	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1016	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1017	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1024	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1025	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1026	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1027	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1028	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1204	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1205	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1206	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1207	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1214	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1215	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1216	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1225	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1226	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1227	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1228	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT1229	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT2225	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT2225R	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT2330	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT3016	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT3018	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT3220	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT3223	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT4019	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT5224	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT5225	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT5226	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT6220C	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT6220R	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
GreenSystem	Tillage	Rotary Tiller	rt6220S	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT6323C	✓	✓	✓	✓	
GreenSystem	Tillage	Rotary Tiller	RT6323R	✓	✓	✓	✓	
GreenSystem	Tillage	Row-Crop Cultivators	CR2220	✓	✓	✓	✓	
GreenSystem	Tillage	Row-Crop Cultivators	CR2222	✓	✓	✓	✓	
GreenSystem	Tillage	Row-Crop Cultivators	CR2231	✓	✓	✓	✓	
GreenSystem	Tillage	Row-Crop Cultivators	CR2232	✓	✓	✓	✓	
GreenSystem	Tillage	Row-Crop Cultivators	CR2240	✓	✓	✓	✓	
GreenSystem	Tillage	Row-Crop Cultivators	CR2251	✓	✓	✓	✓	
GreenSystem	Tillage	Row-Crop Cultivators	CR2260	✓	✓	✓	✓	
GreenSystem	Tillage	Row-Crop Cultivators	CR2280	✓	✓	✓	✓	
HITACHI	Compact Excavator	HCMABC60_0225005	Zaxis17u-5N	✓	✓	✓	✓	
HITACHI	Compact Excavator	HCMACB60_0260005	Zaxis26u-5N	✓	✓	✓	✓	
HITACHI	Compact Excavator	HCMADG60P00270001 - (FT4)	Zaxis35u-5N	✓	✓	✓	✓	
HITACHI	Compact Excavator	HCMAD60L00280001 - (FT4)	Zaxis50u-5N	✓	✓	✓	✓	
HITACHI	Compact Excavator	HCM AFC60T00285001 - (FT4)	Zaxis60USB-5N	✓	✓	✓	✓	
HITACHI	Compact Excavator	None	Zaxis17u-2	✓	✓	✓	✓	
HITACHI	Compact Excavator	None	Zaxis27u-2	✓	✓	✓	✓	
HITACHI	Compact Excavator	None	Zaxis27u-3	✓	✓	✓	✓	
HITACHI	Compact Excavator	None	Zaxis35u-3	✓	✓	✓	✓	
HITACHI	Compact Excavator	None	Zaxis50u-3	✓	✓	✓	✓	
HITACHI	Compact Excavator	None	Zaxis60USB-3	✓	✓	✓	✓	
HITACHI	Excavators	1F9DBGG0_C230001	Zaxis160LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1F9DCDG1_C330001 (T2/S2)	Zaxis210LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1F9DCEG1_C430001 (T2/S2)	Zaxis250LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1F9DDEG1_C930001	Zaxis350LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1FFDAB70_E130001 (iT4/S3B)	Zaxis130-5N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDAGH0_C130001	Zaxis130-5G	✓	✓	✓	✓	
HITACHI	Excavators	1FFDAP70_F140001	Zaxis130-6N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDBC70_E230001 (iT4/S3B)	Zaxis160LC-5N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDBD70_E530001 (iT4/S3B)	Zaxis180LC-5N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDBGH0_C230001	Zaxis160LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1FFDBHH0_C530001	Zaxis180LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1FFDBP70_F240001	Zaxis160LC-6N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDBQ70_F540001	Zaxis180LC-6N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDC270_FXXXXXX	Zaxis250LC-6N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDC571_F340001	Zaxis210LC-6N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDCDH1_C330106 (T2/S2)	Zaxis210LC-5G	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
HITACHI	Excavators	1FFDCEH1_C430001 (T2/S2)	Zaxis250LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1FFDCJ70_E330001 (iT4/S3B)	Zaxis210LC-5N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDDC71_E630001 (iT4/S3B)	Zaxis380LC-5N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDDEH1_C930001 (T2/S2)	Zaxis350LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1FFDDFH1_C830001 (T2/S2)	Zaxis290LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	1FFDDP70_FXXXXXX	Zaxis300LC-6N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDDR70_FXXXXXX	Zaxis350LC-6N	✓	✓	✓	✓	
HITACHI	Excavators	1FFDDR71_FXXXXXX	Zaxis380LC-6N	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX1200-5	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX1200-6	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX1900-5	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX1900-6	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX2500-5	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX2500-6	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX2500E-5	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX2600E-6BH	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX3600-5	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX3600-6	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX5500-5	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX5500-6	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX5600-6BH	✓	✓	✓	✓	
HITACHI	Excavators	Backhoe	EX5600E-6BH	✓	✓	✓	✓	
HITACHI	Excavators	Engine 4HK1XZSA-01	Zaxis250LC-5N	✓	✓	✓	✓	
HITACHI	Excavators	Engine 4HK1XZSA-01	Zaxis290LC-5N	✓	✓	✓	✓	
HITACHI	Excavators	Engine 6HK1XZSA-01	Zaxis350LC-5N	✓	✓	✓	✓	
HITACHI	Excavators	Engine 6WG1XZSA-01	Zaxis870LC-5B	✓	✓	✓	✓	
HITACHI	Excavators	Engine 6WG1XZSA-02	Zaxis670LC-5B	✓	✓	✓	✓	
HITACHI	Excavators	Gray	UH073	✓	✓	✓	✓	
HITACHI	Excavators	HCMDAF60_0100001-	Zaxis135US-5N	✓	✓	✓	✓	
HITACHI	Excavators	HCMDCP60_0400001-	Zaxis245USLC-5N	✓	✓	✓	✓	
HITACHI	Excavators	HCMDEC60V00015001- (FT4)	Zaxis75US-5N	✓	✓	✓	✓	
HITACHI	Excavators	HCMDEF60V00017001- (FT4)	Zaxis85USB-5N	✓	✓	✓	✓	
HITACHI	Excavators	HCMJAA70_0003001- (iT4/S3B)	Zaxis470LC-5B	✓	✓	✓	✓	
HITACHI	Excavators	HCMJACK0_00050001 (T2/S2)	Zaxis470LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	HCMJAG60_0060001-	Zaxis470LC-6	✓	✓	✓	✓	
HITACHI	Excavators	HCMJBEO0_00050001 (T2/S2)	Zaxis870LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	HCMJBFO0_00050001 (T2/S2)	Zaxis670LC-5G	✓	✓	✓	✓	
HITACHI	Excavators	HCMJBK60_0060001-	Zaxis670LC-6	✓	✓	✓	✓	
HITACHI	Excavators	HCMJBL60_0060001-	Zaxis870LC-6	✓	✓	✓	✓	
HITACHI	Excavators	HCLBD60_0004001	Zaxis190W-5N	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
HITACHI	Excavators	HCMLCC60__0004001	Zaxis230W-5N	✓	✓	✓	✓	
HITACHI	Excavators	None	EX110-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX120-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX160LC-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX200LC-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX230LC-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX270LC-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX330LC-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX370-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX450LC-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX550LC-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX750-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX80-5	✓	✓	✓	✓	
HITACHI	Excavators	None	EX8000	✓	✓	✓	✓	
HITACHI	Excavators	None	EX8000-6	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis120	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis120-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis160LC	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis160LC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis200-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis200LC	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis200LC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis225USLC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis230LC	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis240LC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis270LC	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis270LC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis330LC	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis350LC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis370	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis450LC	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis450LC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis600LC	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis650LC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis75US-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis800	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis850LC-3	✓	✓	✓	✓	
HITACHI	Excavators	None	Zaxis85USB-3	✓	✓	✓	✓	
HITACHI	Excavators	RTS	Zaxis135US	✓	✓	✓	✓	
HITACHI	Excavators	RTS	Zaxis135US-3	✓	✓	✓	✓	
HITACHI	Excavators	RTS	Zaxis225USLC	✓	✓	✓	✓	
HITACHI	Excavators	RTS	Zaxis75US	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX1200-5	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX1200-5C	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX1200-6	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX1900-5	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX1900-6	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX2500-5	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX2500-6	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX2500E-5	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX2600-6LD	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX2600E-6LD	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX3600-5	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
HITACHI	Excavators	Shovel	EX3600-6	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX5500-5	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX5500-6	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX5600-6LD	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX5600E-6LD	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX8000	✓	✓	✓	✓	
HITACHI	Excavators	Shovel	EX8000-6	✓	✓	✓	✓	
HITACHI	Excavators	Wheeled	Zaxis180W	✓	✓	✓	✓	
HITACHI	Excavators	Wheeled	Zaxis190W-3	✓	✓	✓	✓	
HITACHI	Excavators	Wheeled	Zaxis210W	✓	✓	✓	✓	
HITACHI	Excavators	Wheeled	Zaxis220W-3	✓	✓	✓	✓	
HITACHI	Forester	Delimber	EX330LC-5	✓	✓	✓	✓	
HITACHI	Forester	Delimber	EX370-5	✓	✓	✓	✓	
HITACHI	Forester	Delimber	Zaxis200LC	✓	✓	✓	✓	
HITACHI	Forester	Delimber	Zaxis210-3	✓	✓	✓	✓	
HITACHI	Forester	Delimber	Zaxis250	✓	✓	✓	✓	
HITACHI	Forester	Delimber	Zaxis290-3	✓	✓	✓	✓	
HITACHI	Forester	Delimber	Zaxis350	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	EX330LC-5	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	EX370-5	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	Zaxis200LC	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	Zaxis210-3	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	Zaxis240-3	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	Zaxis250	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	Zaxis290-3	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	Zaxis350	✓	✓	✓	✓	
HITACHI	Forester	Log Loader	Zaxis370-3	✓	✓	✓	✓	
HITACHI	Forester	Processor	Zaxis210-3	✓	✓	✓	✓	
HITACHI	Forester	Processor	Zaxis290-3	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	EX330LC-5	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	EX370-5	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	Zaxis200LC	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	Zaxis210-3	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	Zaxis240-3	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	Zaxis250	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	Zaxis290-3	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	Zaxis350	✓	✓	✓	✓	
HITACHI	Forester	Road Builder	Zaxis370-3	✓	✓	✓	✓	
HITACHI	Forester	Wheeled	EX330LC-5	✓	✓	✓	✓	
HITACHI	Forester	Wheeled	EX370-5	✓	✓	✓	✓	
HITACHI	Forester	Wheeled	Zaxis200LC	✓	✓	✓	✓	
HITACHI	Forester	Wheeled	Zaxis250	✓	✓	✓	✓	
HITACHI	Forester	Wheeled	Zaxis350	✓	✓	✓	✓	
HITACHI	Other	Machine Information	ICF	✓	✓	✓	✓	
HITACHI	Other	Machine Information	ICX	✓	✓	✓	✓	
HITACHI	Truck	Articulated Dump	AH250	✓	✓	✓	✓	
HITACHI	Truck	Articulated Dump	AH300	✓	✓	✓	✓	
HITACHI	Truck	Articulated Dump	AH350	✓	✓	✓	✓	
HITACHI	Truck	Articulated Dump	AH350D	✓	✓	✓	✓	
HITACHI	Truck	Articulated Dump	AH400	✓	✓	✓	✓	
HITACHI	Truck	Articulated Dump	AH400D	✓	✓	✓	✓	
HITACHI	Truck	Rigid Frame	EH3500ACII	✓	✓	✓	✓	
HITACHI	Truck	Rigid Frame	EH4000ACII	✓	✓	✓	✓	
HITACHI	Truck	Rigid Frame	EH5000AC-3	✓	✓	✓	✓	
HITACHI	Truck	Rigid Frame	EH5000ACII	✓	✓	✓	✓	
John Deere	4WD Loader	(-632967) Engine 6090HDW06, 6090HDW08	744K	✓	✓	✓	✓	
John Deere	4WD Loader	(-641522) Engine 6090HDW03, 6090HDW09	724K	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	4WD Loader	(-641969) Engine 6135HDW01, 6135HDW03	824K	✓	✓	✓	✓	
John Deere	4WD Loader	(-642100) Engine 4045HDW54 (T3)	444K	✓	✓	✓	✓	
John Deere	4WD Loader	(-642245) Engine 6068HDW74 (T3)	524K	✓	✓	✓	✓	
John Deere	4WD Loader	(-642443) Engine 6068HDW80, 6068HDW83	644K	✓	✓	✓	✓	
John Deere	4WD Loader	(-642634) Engine 6068HDW79 (T3), 6068HDW83 (S2)	624K	✓	✓	✓	✓	
John Deere	4WD Loader	(-642664) Engine 6068HDW74 (T3)	544K	✓	✓	✓	✓	
John Deere	4WD Loader	(630720-) Engine 6090HDW12	744K	✓	✓	✓	✓	
John Deere	4WD Loader	(632968-) Engine 6090HDW06, 6090HDW08	744K	✓	✓	✓	✓	
John Deere	4WD Loader	(634315-) Engine 6090HDW13	644K	✓	✓	✓	✓	
John Deere	4WD Loader	(634315-) Engine 6090HDW13	724K	✓	✓	✓	✓	
John Deere	4WD Loader	(641523-658296) 6090HDW03, 6090HDW09	724K	✓	✓	✓	✓	
John Deere	4WD Loader	(641970-) Engine 6135HDW01, 6135HDW03	824K	✓	✓	✓	✓	
John Deere	4WD Loader	(641970-) Engine 6135HDW02	824K	✓	✓	✓	✓	
John Deere	4WD Loader	(642101-) Engine 4045HDW54 (T3)	444K	✓	✓	✓	✓	
John Deere	4WD Loader	(642101-) Engine 4045HDW56 (iT4)	444K	✓	✓	✓	✓	
John Deere	4WD Loader	(642246-) Engine 6068HDW74 (T3)	524K	✓	✓	✓	✓	
John Deere	4WD Loader	(642246-) Engine 6068HDW84 (iT4)	524K	✓	✓	✓	✓	
John Deere	4WD Loader	(642444-658217) 6068HDW80, 6068HDW83	644K	✓	✓	✓	✓	
John Deere	4WD Loader	(642635-) Engine 6068HDW78 (iT4)	624K	✓	✓	✓	✓	
John Deere	4WD Loader	(642635-658064) 6068HDW79 (T3), 6068HDW83 (S2)	624K	✓	✓	✓	✓	
John Deere	4WD Loader	(642665-) Engine 6068HDW74 (T3)	544K	✓	✓	✓	✓	
John Deere	4WD Loader	(642665-) Engine 6068HDW84 (iT4)	544K	✓	✓	✓	✓	
John Deere	4WD Loader	1BZ524K D000001	524K	✓	✓	✓	✓	
John Deere	4WD Loader	1BZ544K D000001	544K	✓	✓	✓	✓	
John Deere	4WD Loader	1BZ624K C000001	624K	✓	✓	✓	✓	
John Deere	4WD Loader	1BZ624K D000001	624K	✓	✓	✓	✓	
John Deere	4WD Loader	1BZ644K C000001	644K	✓	✓	✓	✓	
John Deere	4WD Loader	1BZ644K D000001	644K	✓	✓	✓	✓	
John Deere	4WD Loader	1BZ724K C000001	724K	✓	✓	✓	✓	
John Deere	4WD Loader	1BZ724K D000001	724K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW444K CXXXXXX	444K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW444K D670312	444K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW444K F670313	444K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW524K CXXXXXX	524K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW524K D670310	524K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW524K F670311	524K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW544K CXXXXXX	544K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW544K D670308	544K	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	4WD Loader	1DW544K F670309	544K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW624K C658065	624K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW624K D658065	624K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW624K__F658065	624K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW644K C658218	644K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW644K D658218	644K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW644K E651322 - (iT4/S3B)	644K Hybrid	✓	✓	✓	✓	
John Deere	4WD Loader	1DW644K__F658218	644K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW724K C658297	724K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW724K D658297	724K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW724K__F658297	724K	✓	✓	✓	✓	
John Deere	4WD Loader	1DW744K C664101	744K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW744K D664101	744K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW744K F664578	744K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW824K C664100	824K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW824K D664100	824K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW824K F664579	824K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW844K C664096	844K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW844K D664096	844K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW844K F664098	844K-II	✓	✓	✓	✓	
John Deere	4WD Loader	1DW944K E669456	944K	✓	✓	✓	✓	
John Deere	4WD Loader	1LU344K__BXXXXXX (iT4)	344K	✓	✓	✓	✓	
John Deere	4WD Loader	1YNWL53 D100008	WL53	✓	✓	✓	✓	
John Deere	4WD Loader	1YNWL56__ C000010 (T2/S2)	WL56	✓	✓	✓	✓	
John Deere	4WD Loader	1YNWL56 DXXXXXX	WL56	✓	✓	✓	✓	
John Deere	4WD Loader	Engine 6135HDW01 (T3), 6135HDW03 (S2)	844K-II	✓	✓	✓	✓	
John Deere	4WD Loader	Engine 6135HDW02 (iT4/S3b)	844K-II	✓	✓	✓	✓	
John Deere	4WD Loader	Log Loader	544ELL	✓	✓	✓	✓	
John Deere	4WD Loader	Log Loader	544GL	✓	✓	✓	✓	
John Deere	4WD Loader	Material Handler	644H MH	✓	✓	✓	✓	
John Deere	4WD Loader	Material Handler	744H MH	✓	✓	✓	✓	
John Deere	4WD Loader	None	344E	✓	✓	✓	✓	
John Deere	4WD Loader	None	344G	✓	✓	✓	✓	
John Deere	4WD Loader	None	344H	✓	✓	✓	✓	
John Deere	4WD Loader	None	344J	✓	✓	✓	✓	
John Deere	4WD Loader	None	444C	✓	✓	✓	✓	
John Deere	4WD Loader	None	444CH	✓	✓	✓	✓	
John Deere	4WD Loader	None	444D	✓	✓	✓	✓	
John Deere	4WD Loader	None	444E	✓	✓	✓	✓	
John Deere	4WD Loader	None	444G	✓	✓	✓	✓	
John Deere	4WD Loader	None	444H	✓	✓	✓	✓	
John Deere	4WD Loader	None	444J	✓	✓	✓	✓	
John Deere	4WD Loader	None	444JR	✓	✓	✓	✓	
John Deere	4WD Loader	None	524K	✓	✓	✓	✓	
John Deere	4WD Loader	None	544E	✓	✓	✓	✓	
John Deere	4WD Loader	None	544EH	✓	✓	✓	✓	
John Deere	4WD Loader	None	544G	✓	✓	✓	✓	
John Deere	4WD Loader	None	544GH	✓	✓	✓	✓	
John Deere	4WD Loader	None	544H	✓	✓	✓	✓	
John Deere	4WD Loader	None	544J	✓	✓	✓	✓	
John Deere	4WD Loader	None	544K	✓	✓	✓	✓	
John Deere	4WD Loader	None	624EH	✓	✓	✓	✓	
John Deere	4WD Loader	None	624G	✓	✓	✓	✓	
John Deere	4WD Loader	None	624H	✓	✓	✓	✓	
John Deere	4WD Loader	None	624J	✓	✓	✓	✓	
John Deere	4WD Loader	None	624KR	✓	✓	✓	✓	
John Deere	4WD Loader	None	644D	✓	✓	✓	✓	
John Deere	4WD Loader	None	644E	✓	✓	✓	✓	
John Deere	4WD Loader	None	644EH	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	4WD Loader	None	644ER	✓	✓	✓	✓	
John Deere	4WD Loader	None	644G	✓	✓	✓	✓	
John Deere	4WD Loader	None	644H	✓	✓	✓	✓	
John Deere	4WD Loader	None	644J	✓	✓	✓	✓	
John Deere	4WD Loader	None	724J	✓	✓	✓	✓	
John Deere	4WD Loader	None	744H	✓	✓	✓	✓	
John Deere	4WD Loader	None	744J	✓	✓	✓	✓	
John Deere	4WD Loader	None	824J	✓	✓	✓	✓	
John Deere	4WD Loader	None	844J	✓	✓	✓	✓	
John Deere	4WD Loader	None	844K	✓	✓	✓	✓	
John Deere	4WD Loader	Tool Carrier	544ETC	✓	✓	✓	✓	
John Deere	4WD Loader	Tool Carrier	544GT	✓	✓	✓	✓	
John Deere	ADT	(-642000) (T3/S3A)	250D Series II	✓	✓	✓	✓	
John Deere	ADT	(-642000) (T3/S3A)	300D Series II	✓	✓	✓	✓	
John Deere	ADT	1DW250D2_C642001 - (T2/S2)	250D Series II	✓	✓	✓	✓	
John Deere	ADT	1DW250D2_E642001 - (iT4/S3B)	250D Series II	✓	✓	✓	✓	
John Deere	ADT	1DW300D2_C642001 - (T2/S2)	300D Series II	✓	✓	✓	✓	
John Deere	ADT	1DW300D2_E642001 - (iT4/S3B)	300D Series II	✓	✓	✓	✓	
John Deere	ADT	1DW370E_C634583 -668586 (T2/S2)	370E	✓	✓	✓	✓	
John Deere	ADT	1DW370E_C668588	370E	✓	✓	✓	✓	
John Deere	ADT	1DW370E_D634583 -668586 (T3/S3A)	370E	✓	✓	✓	✓	
John Deere	ADT	1DW370E_D668588	370E	✓	✓	✓	✓	
John Deere	ADT	1DW370E_E634583 -668586 (iT4/S3B)	370E	✓	✓	✓	✓	
John Deere	ADT	1DW370E_F668588	370E	✓	✓	✓	✓	
John Deere	ADT	1DW410E_C634583 -668586 (T2/S2)	410E	✓	✓	✓	✓	
John Deere	ADT	1DW410E_C668589	410E	✓	✓	✓	✓	
John Deere	ADT	1DW410E_D634583 -668586 (T3/S3A)	410E	✓	✓	✓	✓	
John Deere	ADT	1DW410E_D668589	410E	✓	✓	✓	✓	
John Deere	ADT	1DW410E_E634583 -668586 (iT4/S3B)	410E	✓	✓	✓	✓	
John Deere	ADT	1DW410E_F668589	410E	✓	✓	✓	✓	
John Deere	ADT	1DW460E_C634583 -668586 (T2/S2)	460E	✓	✓	✓	✓	
John Deere	ADT	1DW460E_C668587	460E	✓	✓	✓	✓	
John Deere	ADT	1DW460E_D634583 -668586 (T3/S3A)	460E	✓	✓	✓	✓	
John Deere	ADT	1DW460E_D668587	460E	✓	✓	✓	✓	
John Deere	ADT	1DW460E_E634583 -668586 (iT4/S3B)	460E	✓	✓	✓	✓	
John Deere	ADT	1DW460E_F668587	460E	✓	✓	✓	✓	
John Deere	Apollo Series	None	Transaxle	✓	✓	✓	✓	
John Deere	Axles	None	AR15MTL	✓	✓	✓	✓	
John Deere	Axles	TM 3	1200	✓	✓	✓	✓	
John Deere	Axles	TM 3	1400	✓	✓	✓	✓	
John Deere	Axles	TM 4	1200	✓	✓	✓	✓	
John Deere	Axles	TM 4	1400	✓	✓	✓	✓	
John Deere	Axles	TM 5	1400	✓	✓	✓	✓	
John Deere	Axles	TM 5	1500	✓	✓	✓	✓	
John Deere	Axles	TM 5	1600	✓	✓	✓	✓	
John Deere	Axles	TM 5	1700	✓	✓	✓	✓	
John Deere	Backhoe	1BZ310K_CXXXXXX (T2/S2)	310K	✓	✓	✓	✓	
John Deere	Backhoe	1T0310EK_G219607 - (iT4/S3A)	310K EP	✓	✓	✓	✓	
John Deere	Backhoe	1T0310EL_G273920	310L EP	✓	✓	✓	✓	
John Deere	Backhoe	1T0310HL_F273920	310SL HL	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Backhoe	IT0310KX_C219607 - (T2/S2)	310K	✓	✓	✓	✓	
John Deere	Backhoe	IT0310KX_D219607 - (T3/S3A)	310K	✓	✓	✓	✓	
John Deere	Backhoe	IT0310KX_E219607 - (iT4/S3B)	310K	✓	✓	✓	✓	
John Deere	Backhoe	IT0310LX_C273920	310L	✓	✓	✓	✓	
John Deere	Backhoe	IT0310LX_D273920	310L	✓	✓	✓	✓	
John Deere	Backhoe	IT0310LX_F273920	310L	✓	✓	✓	✓	
John Deere	Backhoe	IT0310SK_C219607 - (T2/S2)	310SK	✓	✓	✓	✓	
John Deere	Backhoe	IT0310SK_D219607 - (T3/S3A)	310SK	✓	✓	✓	✓	
John Deere	Backhoe	IT0310SK_E219607 - (iT4/S3B)	310SK	✓	✓	✓	✓	
John Deere	Backhoe	IT0310SL_C273920	310SL	✓	✓	✓	✓	
John Deere	Backhoe	IT0310SL_D273920	310SL	✓	✓	✓	✓	
John Deere	Backhoe	IT0310SL_F273920	310SL	✓	✓	✓	✓	
John Deere	Backhoe	IT0310TK_E219607 - (iT4/S3B)	310SK TC	✓	✓	✓	✓	
John Deere	Backhoe	IT0315SK_C219607 - (T2/S2)	315SK	✓	✓	✓	✓	
John Deere	Backhoe	IT0315SK_D229820 - (T3/S3A)	315SK	✓	✓	✓	✓	
John Deere	Backhoe	IT0315SL_C273920	315SL	✓	✓	✓	✓	
John Deere	Backhoe	IT0315SL_D273920	315SL	✓	✓	✓	✓	
John Deere	Backhoe	IT0315SL_F273920	315SL	✓	✓	✓	✓	
John Deere	Backhoe	IT0325KX_C219607 -234969 (T2/S2)	325K	✓	✓	✓	✓	
John Deere	Backhoe	IT0325SK_C235589 (T2/S2)	325SK	✓	✓	✓	✓	
John Deere	Backhoe	IT0325SL_C273920	325SL	✓	✓	✓	✓	
John Deere	Backhoe	IT0410KX_C219607 - (T2/S2)	410K	✓	✓	✓	✓	
John Deere	Backhoe	IT0410KX_D219607 - (T3/S3A)	410K	✓	✓	✓	✓	
John Deere	Backhoe	IT0410KX_E219607 - (iT4/S3B)	410K	✓	✓	✓	✓	
John Deere	Backhoe	IT0410LX_C273920	410L	✓	✓	✓	✓	
John Deere	Backhoe	IT0410LX_D273920	410L	✓	✓	✓	✓	
John Deere	Backhoe	IT0410LX_F273920	410L	✓	✓	✓	✓	
John Deere	Backhoe	IT0410TK_E219607 - (iT4/S3B)	410K TC	✓	✓	✓	✓	
John Deere	Backhoe	IT0710KX_D219607 - (T3/S3A)	710K	✓	✓	✓	✓	
John Deere	Backhoe	IT0710KX_E219607 - (iT4/S3B)	710K	✓	✓	✓	✓	
John Deere	Backhoe	None	310	✓	✓	✓	✓	
John Deere	Backhoe	None	310A	✓	✓	✓	✓	
John Deere	Backhoe	None	310B	✓	✓	✓	✓	
John Deere	Backhoe	None	310C	✓	✓	✓	✓	
John Deere	Backhoe	None	310D	✓	✓	✓	✓	
John Deere	Backhoe	None	310E	✓	✓	✓	✓	
John Deere	Backhoe	None	310G	✓	✓	✓	✓	
John Deere	Backhoe	None	310J	✓	✓	✓	✓	
John Deere	Backhoe	None	310SE	✓	✓	✓	✓	
John Deere	Backhoe	None	310SG	✓	✓	✓	✓	
John Deere	Backhoe	None	310SJ	✓	✓	✓	✓	
John Deere	Backhoe	None	410D	✓	✓	✓	✓	
John Deere	Backhoe	None	410E	✓	✓	✓	✓	
John Deere	Backhoe	None	410G	✓	✓	✓	✓	
John Deere	Backhoe	None	410J	✓	✓	✓	✓	
John Deere	Backhoe	None	435E	✓	✓	✓	✓	
John Deere	Backhoe	None	510B	✓	✓	✓	✓	
John Deere	Backhoe	None	510C	✓	✓	✓	✓	
John Deere	Backhoe	None	510D	✓	✓	✓	✓	
John Deere	Backhoe	None	710G	✓	✓	✓	✓	
John Deere	Backhoe	None	710J	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Backhoe	Side Shift	315C	✓	✓	✓	✓	
John Deere	Backhoe	Side Shift	315CH	✓	✓	✓	✓	
John Deere	Backhoe	Side Shift	315D	✓	✓	✓	✓	
John Deere	Backhoe	Side Shift	315SE	✓	✓	✓	✓	
John Deere	Backhoe	Side Shift	315SG	✓	✓	✓	✓	
John Deere	Backhoe	Side Shift	315SJ	✓	✓	✓	✓	
John Deere	Backhoe	Side Shift	325J	✓	✓	✓	✓	
John Deere	Backhoe	TMC	310SJ	✓	✓	✓	✓	
John Deere	Backhoe	TMC	310SJ TC	✓	✓	✓	✓	
John Deere	Backhoe	TMC	410J	✓	✓	✓	✓	
John Deere	Backhoe	TMC	410J TC	✓	✓	✓	✓	
John Deere	CF Management Solutions	Full Tree	TimberNavi	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	1450	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	1550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2054	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2056	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2058	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2064	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2066	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2254	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2256	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2258	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2264	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2266	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	2266EXTRA	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	6620	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9410	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9500	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9500SH	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9510	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9560SH	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9600	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9610	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9660CTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9660WTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9780iCTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9880iSTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	9880STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	C670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	CTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	CTS II	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	CTS Region II	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	S560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	T550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	T560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	T660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	T670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	W540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	W550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	W650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines	W660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 072800 - XXXXXX	9780CTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 745100-764999	S550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 745100-764999	S650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 745100-764999	S685	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 745100-764999	S690 Hillmaster	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 765000 - 784999	S650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 785000 - XXXXXX	S650	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines 1H0 785000 - XXXXXX	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 785000 - XXXXXX	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 785000 - XXXXXX	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0 785000 - XXXXXX	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0S660 745100 -765171	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0S660 765172 - 784999	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0S670 745100 - 765252	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0S670 765253 - 784999	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0S680 745100 - 766006	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0S680 766007 - 784999	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0S690 745100 - 765249	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1H0S690 765250 - 784999	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1JZ 745100-XXXXXX	S550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1JZ 745100-XXXXXX	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1JZ 745100-XXXXXX	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1JZ 745100-XXXXXX	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1JZ 745100-XXXXXX	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1YC 785000 - XXXXXX	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1YH 745100-764999	S550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1YH 745100-764999	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1YH 745100-764999	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1YH 745100-764999	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1YH 745100-764999	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1YH 765000 - 784999	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 100000 - 104999	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 100000 - 104999	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 100000 - 104999	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 100000 - 104999	S685	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 100000 - 104999	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 102000 - XXXXXX	T550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 102000 - XXXXXX	T560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 102000 - XXXXXX	T660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 102000 - XXXXXX	T670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 102000 - XXXXXX	W540	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines 1Z0 102000 - XXXXXX	W550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 102000 - XXXXXX	W650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 1Z0 102000 - XXXXXX	W660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 695101 - XXXXXX	9450	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 695101 - XXXXXX	9550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 695101 - XXXXXX	9550SH	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 695101 - XXXXXX	9650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines 695101 - XXXXXX	9650CTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines H0 or 1H0 XXXXX-745099	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines H0 or 1H0 XXXXX-745099	S690 Hillmaster	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY12 and 13 Wide Cab PIN Prefix 1Z0	T550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY12 and 13 Wide Cab PIN Prefix 1Z0	T560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY12 and 13 Wide Cab PIN Prefix 1Z0	T660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY12 and 13 Wide Cab PIN Prefix 1Z0	T670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY12 and 13 Wide Cab PIN Prefix 1Z0	W540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY12 and 13 Wide Cab PIN Prefix 1Z0	W550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY12 and 13 Wide Cab PIN Prefix 1Z0	W650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY12 and 13 Wide Cab PIN Prefix 1Z0	W660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 PIN Prefix 1JZ	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 PIN Prefix 1JZ	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 PIN Prefix 1Z0	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 PIN Prefix 1Z0	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 PIN Prefix 1Z0	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 PIN Prefix 1Z0	S685	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 PIN Prefix 1Z0	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 Wide Cab PIN	T550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 Wide Cab PIN	T560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 Wide Cab PIN	T660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 Wide Cab PIN	T670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 Wide Cab PIN	W540	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines MY14 Wide Cab PIN	W550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 Wide Cab PIN	W650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines MY14 Wide Cab PIN	W660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	1175	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	9470STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	9570STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	9650STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	9670STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	9750STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	9770STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	S540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	S550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ - Brazil	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ 90000-XXXXXX	1470	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ 90000-XXXXXX	S540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ 90000-XXXXXX	S550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ 90000-XXXXXX	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ 90000-XXXXXX	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1CQ 90000-XXXXXX	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1J0	S540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1J0	S550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1J0	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1J0	S670	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines PIN Prefix 1J0	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1JZ	W330	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1JZ	W540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1MY	109	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1MY	112	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1MY	W50	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1XG	W330	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1XG	W440	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 000001 - 009999	3316	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 000001 - 009999	C110	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 000001 - 009999	C230	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 000001 - 009999	L70	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 000001 - 009999	W210	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 000001 - 009999	Y215	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	C100	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	C230	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	L60	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	W210	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	W80	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	Y110	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	Y115	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	Y210	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC - 010000 - XXXXXX	Y215	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC 015000 - XXXXXX	C240	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix 1YC 015000 - XXXXXX	R230	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines PIN Prefix 1YC 015000 - XXXXXX	W230	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	S685	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	T560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	T660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	T670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	W540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	W550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	W650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO	W660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO MY15	S660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO MY15	S670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO MY15	S680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO MY15	S685	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix 1ZO MY15	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - 000181 -	9650STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - 000181 -	9750STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 -	1450	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 -	1450CWS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 -	1450WTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 -	1550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 -	1550CWS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 -	1550WTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - XXXX -	9650STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ - Brasil - XXXX -	9750STS	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	1175	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	1470	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	1570	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	1650CTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	9470STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	9570STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	9670STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	9770STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	S540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ -	S690	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ - Brazil - 047354 -	1450	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ - Brazil - XXXXXX -	1450	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ - Brazil - XXXXXX -	1450CWS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ - Brazil - XXXXXX -	1550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix CQ - Brazil - XXXXXX -	1550CWS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B -	1450	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B -	1450CWS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B -	1450WTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B -	1550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B -	1550CWS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B -	1550WTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	1450CWS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	1450WTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	1550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	1550CWS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	1550WTS	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines PIN Prefix HO - 695101 - XXXXXX	9650STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - 695101 - XXXXXX	9750STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - North American	9560STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - North American	9570STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - North American	9660STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - North American	9670STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - North American	9760STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - North American	9770STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - North American	9860STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - North American	9870STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - XXXXXX - 695100	9650STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix HO - XXXXXX - 695100	9750STS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix MY - India	W70	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix N4	R40-STC	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9540i	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9560i	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9580	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9580i	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9640	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9640i	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9660	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9660i	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines PIN Prefix Z0 - European	9680	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-prefix 1JZ	W650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	T550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	T560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	T660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	T670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	W540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	W550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	W660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-Prefix Z0	T550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-Prefix Z0	T560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-Prefix Z0	T660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-Prefix Z0	T670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-Prefix Z0	W540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-Prefix Z0	W550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-Prefix Z0	W650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines w/Command Center Pin-Prefix Z0	W660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines With Command Center	C670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines With Command Center	T550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines With Command Center	T560	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines With Command Center	T660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines With Command Center	T670	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines With Command Center	W540	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines With Command Center	W550	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Combines With Command Center	W650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines With Command Center	W660	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines XXXXXX - 072799	9780CTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines XXXXXX - 695100	9450	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines XXXXXX - 695100	9550	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines XXXXXX - 695100	9550SH	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines XXXXXX - 695100	9650	✓	✓	✓	✓	
John Deere	Combines and Headers	Combines XXXXXX - 695100	9650CTS	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads	608C STALKMASTER	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads	612C STALKMASTER	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads	616C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix 1CQ - Brazil	613C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix 1CQ - Brazil	616C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1H0	616C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1H0	616C STALKMASTER	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1H0	618C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1H0	618C STALKMASTER	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1YC	203C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1YC	204C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1YC	205C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1YC	206C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1YC	207C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix 1YC	208C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	204	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	604C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	606C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	607C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	608C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	609C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	610C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	611C	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	612C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	613C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	614C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	615C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	616C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix CQ -	617C	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN Prefix HO or 1HO	606C STALKMASTER	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix KM	606C STALKMASTER	✓	✓	✓	✓	
John Deere	Combines and Headers	Corn Heads PIN prefix KM	608C STALKMASTER	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms	640D	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms	640FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms	645FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1CQ	630FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1CQ	635D	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1CQ	635FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1CQ	640D	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1CQ	640FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1CQ	645FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1HO	630FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1HO	645FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1JO	630FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1JO	635FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1JO	640FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1JZ or 1XG	930D	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix 1JZ or 1XG	936D	✓	✓	✓	✓	
John Deere	Combines and Headers	Draper Platforms PIN Prefix HO or 1HO	635FD	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platform	213F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platform	222F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platform Pin Prefix 1VH	635F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	618F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	620F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	622F	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	625F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	630F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	635F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix 1J0	625F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix CQ -	616F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix CQ -	618F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix CQ -	620F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix CQ -	622F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix CQ -	625F	✓	✓	✓	✓	
John Deere	Combines and Headers	Flex Platforms PIN Prefix CQ -	630F	✓	✓	✓	✓	
John Deere	Combines and Headers	None	GPCS	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	313R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	314R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	315R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	316R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	317R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	321R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	323R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	618PF	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	620PF	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	622PF	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	625PF	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	630PF	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	635PF	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	PF618	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	PF620	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	PF622	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	PF625	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	PF630	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms	PF635	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	208R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	209F	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	209R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	210F	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	210R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	212P	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	212R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	213F	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	215F	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	215R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	218F	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	218R	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	220F	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix 1YC	220R	✓	✓	✓	✓	
John Deere	Combines and Headers	Platforms PIN Prefix MY	314	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform	618R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform	620R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform	622R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform	625R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform 13 digit PIN	630R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform 17 Digit PIN	630R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform PIN prefix CQ -	616R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform PIN prefix CQ -	618R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platform PIN prefix CQ -	620R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms	222R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms Pin Prefix 1H0	630R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix 1Z0 - European	622X	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix 1Z0 - European	625X	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix 1Z0 - European	630X	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix 1Z0 - European	635R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix 1Z0 - European	635X	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix 1Z0 - European	640X	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix Z0 or 1Z0	616R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix Z0 or 1Z0	618R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix Z0 or 1Z0	620R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix Z0 or 1Z0	622R	✓	✓	✓	✓	
John Deere	Combines and Headers	Rigid Platforms PIN Prefix Z0 or 1Z0	625R	✓	✓	✓	✓	
John Deere	Commercial Mowing	Front Mowers and Equipment	F912	✓	✓	✓	✓	
John Deere	Communication	450 MHz Radio	AMS StarFire RTK	✓	✓	✓	✓	
John Deere	Communication	869 MHz Radio	AMS StarFire RTK	✓	✓	✓	✓	
John Deere	Communication	900 MHz Radio	AMS StarFire RTK	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Communication	Gateway and In-Field Hardware System	AMS Field Connect	✓	✓	✓	✓	
John Deere	Communication	MTG 2G/3G	JDLink	✓	✓	✓	✓	
John Deere	Communication	UTG LMU-3000 CalAmp	JDLink	✓	✓	✓	✓	
John Deere	Communication	UTG MC-3 Morey	JDLink	✓	✓	✓	✓	
John Deere	Communication	UTG TTU-720	JDLink	✓	✓	✓	✓	
John Deere	Compact Excavator	1FF017GX K225001	17G	✓	✓	✓	✓	
John Deere	Compact Excavator	1FF026GX K260001	26G	✓	✓	✓	✓	
John Deere	Compact Excavator	1FF035GX K270001 - (FT4)	35G	✓	✓	✓	✓	
John Deere	Compact Excavator	1FF050GX H280001 - (FT4)	50G	✓	✓	✓	✓	
John Deere	Compact Excavator	1FF060GX J285001 - (FT4)	60G	✓	✓	✓	✓	
John Deere	Compact Excavator	None	17D	✓	✓	✓	✓	
John Deere	Compact Excavator	None	60D	✓	✓	✓	✓	
John Deere	Compact Loader	1LU204K B030899 (iT4)	204K	✓	✓	✓	✓	
John Deere	Compact Loader	1LU244KX B034088-	244K	✓	✓	✓	✓	
John Deere	Compact Loader	1LU304K B030847 (iT4)	304K	✓	✓	✓	✓	
John Deere	Compact Loader	1LU324KX B034182-	324K	✓	✓	✓	✓	
John Deere	Compact Loader	None	244J	✓	✓	✓	✓	
John Deere	Compact Loader	None	304J	✓	✓	✓	✓	
John Deere	Compact Loader	None	324H	✓	✓	✓	✓	
John Deere	Compact Loader	None	324J	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Picker PIN Prefix YC	9970	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	7660	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	7760	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	9965	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	9970	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	9976	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	9986	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	9996	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	CP20	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Pickers PIN Prefix NO or	CP690	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Strippers	7460	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Cotton Strippers	CS690	✓	✓	✓	✓	
John Deere	Cotton Harvesting	Pull - Type Two Row	7260	✓	✓	✓	✓	
John Deere	Crawler	1T01050K C287054	1050K	✓	✓	✓	✓	
John Deere	Crawler	1T01050K F268234	1050K	✓	✓	✓	✓	
John Deere	Crawler	1T0550KX F275977 -	550K	✓	✓	✓	✓	
John Deere	Crawler	1T0650KX F275978 -	650K	✓	✓	✓	✓	
John Deere	Crawler	1T0700KX F275598 -	700K	✓	✓	✓	✓	
John Deere	Crawler	1T0750KX F271593	750K	✓	✓	✓	✓	
John Deere	Crawler	1T0850KX F271510	850K	✓	✓	✓	✓	
John Deere	Crawler	Dozer	1050J	✓	✓	✓	✓	
John Deere	Crawler	Dozer	350B	✓	✓	✓	✓	
John Deere	Crawler	Dozer	350C	✓	✓	✓	✓	
John Deere	Crawler	Dozer	350D	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Crawler	Dozer	450D	✓	✓	✓	✓	
John Deere	Crawler	Dozer	450E	✓	✓	✓	✓	
John Deere	Crawler	Dozer	450ELT	✓	✓	✓	✓	
John Deere	Crawler	Dozer	450G	✓	✓	✓	✓	
John Deere	Crawler	Dozer	450H	✓	✓	✓	✓	
John Deere	Crawler	Dozer	550G	✓	✓	✓	✓	
John Deere	Crawler	Dozer	550H	✓	✓	✓	✓	
John Deere	Crawler	Dozer	550K	✓	✓	✓	✓	
John Deere	Crawler	Dozer	650G	✓	✓	✓	✓	
John Deere	Crawler	Dozer	650H	✓	✓	✓	✓	
John Deere	Crawler	Dozer	650K	✓	✓	✓	✓	
John Deere	Crawler	Dozer	700H	✓	✓	✓	✓	
John Deere	Crawler	Dozer	700K	✓	✓	✓	✓	
John Deere	Crawler	Dozer	750C	✓	✓	✓	✓	
John Deere	Crawler	Dozer	750J	✓	✓	✓	✓	
John Deere	Crawler	Dozer	750K	✓	✓	✓	✓	
John Deere	Crawler	Dozer	850C	✓	✓	✓	✓	
John Deere	Crawler	Dozer	850JR	✓	✓	✓	✓	
John Deere	Crawler	Dozer	850K	✓	✓	✓	✓	
John Deere	Crawler	Dozer	950C	✓	✓	✓	✓	
John Deere	Crawler	Dozer	950J	✓	✓	✓	✓	
John Deere	Crawler	Dozer 139436-	700J	✓	✓	✓	✓	
John Deere	Crawler	Dozer 159987-XXXXXX	450J	✓	✓	✓	✓	
John Deere	Crawler	Dozer 159987-XXXXXX	550J	✓	✓	✓	✓	
John Deere	Crawler	Dozer 159987-XXXXXX	650J	✓	✓	✓	✓	
John Deere	Crawler	Dozer XXXXXX-139435	700J	✓	✓	✓	✓	
John Deere	Crawler	Dozer XXXXXX-159986	450J	✓	✓	✓	✓	
John Deere	Crawler	Dozer XXXXXX-159986	550J	✓	✓	✓	✓	
John Deere	Crawler	Dozer XXXXXX-159986	650J	✓	✓	✓	✓	
John Deere	Crawler	Engine 6068HT090	850J	✓	✓	✓	✓	
John Deere	Crawler	Engine 6081HT006	850J	✓	✓	✓	✓	
John Deere	Crawler	Engine 6090HT001	850J	✓	✓	✓	✓	
John Deere	Crawler	High Speed Dozer	764	✓	✓	✓	✓	
John Deere	Crawler	Loader	355D	✓	✓	✓	✓	
John Deere	Crawler	Loader	455D	✓	✓	✓	✓	
John Deere	Crawler	Loader	455E	✓	✓	✓	✓	
John Deere	Crawler	Loader	455G	✓	✓	✓	✓	
John Deere	Crawler	Loader	555G	✓	✓	✓	✓	
John Deere	Crawler	Loader	605C	✓	✓	✓	✓	
John Deere	Crawler	Loader	605K	✓	✓	✓	✓	
John Deere	Crawler	Loader	655K	✓	✓	✓	✓	
John Deere	Crawler	Loader	755D	✓	✓	✓	✓	
John Deere	Crawler	Loader	755K	✓	✓	✓	✓	
John Deere	Display	GreenStar	AMS Lightbar	✓	✓	✓	✓	
John Deere	Display	GreenStar 2	AMS 1800	✓	✓	✓	✓	
John Deere	Display	GreenStar 2	AMS 2100	✓	✓	✓	✓	
John Deere	Display	GreenStar 2	AMS 2600	✓	✓	✓	✓	
John Deere	Display	GreenStar 3	AMS 2630	✓	✓	✓	✓	
John Deere	Display	Original Display & Mobile	AMS Orig. Display	✓	✓	✓	✓	
John Deere	Engine	None	4045TFM85	✓	✓	✓	✓	
John Deere	Excavators	1F9160GX D055001	160GLC	✓	✓	✓	✓	
John Deere	Excavators	1F9180GX D020001	180GLC	✓	✓	✓	✓	
John Deere	Excavators	1F9210GX_C520001 (T2/S2)	210GLC	✓	✓	✓	✓	
John Deere	Excavators	1F9210GX_D520001 (T3/S3A)	210GLC	✓	✓	✓	✓	
John Deere	Excavators	1F9250GX_C608001 (T2/S2)	250GLC	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Excavators	1F9250GX_D608001 (T3/S3A)	250GLC	✓	✓	✓	✓	
John Deere	Excavators	1F9350GX_C808001	350GLC	✓	✓	✓	✓	
John Deere	Excavators	1F9350GX_D808001	350GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF075GX_J015001 - (FT4)	75G	✓	✓	✓	✓	
John Deere	Excavators	1FF085GX_J017001 - (FT4)	85G	✓	✓	✓	✓	
John Deere	Excavators	1FF130G_E040001 (iT4/S3B)/	130G	✓	✓	✓	✓	
John Deere	Excavators	1FF130GX_D040001 - (T3/S3a)	130G	✓	✓	✓	✓	
John Deere	Excavators	1FF130GX_F040608	130G	✓	✓	✓	✓	
John Deere	Excavators	1FF135GX_E400001 (iT4)	135G	✓	✓	✓	✓	
John Deere	Excavators	1FF160GX_D055001 (T3/S3A)	160GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF160GX_E055001 (iT4/S3B)	160GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF160GX_F055671	160GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF180GX_D020001 (T3/S3A)	180GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF180GX_E020001 (iT4/S3B)	180GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF180GX_F020331	180GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF190GW_E051001	190GW	✓	✓	✓	✓	
John Deere	Excavators	1FF210GX_C520001 (T2/S2)	210GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF210GX_D520001 (T3/S3a)	210GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF210GX_E520001 (iT4/S3B)	210GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF210GX_F521988	210GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF230GW_E061001	230GW	✓	✓	✓	✓	
John Deere	Excavators	1FF245G_E600001 (iT4)	245GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF250GX_F608713	250GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF300GX_F710002	300GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF350GX_F809192	350GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF380GX_D900001 (T3/S3A)	380GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF380GX_E900001 (iT4/S3B)	380GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF380GX_F900006	380GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF470GX_C047001	470GLC	✓	✓	✓	✓	
John Deere	Excavators	1FF470GX_E470001 - (iT4/S3B)	470GLC	✓	✓	✓	✓	
John Deere	Excavators	1YNE21AL_C400021 -400200 (T2/S2)	E210LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE21AL_C400201	E210LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE21AL_DXXXXXX	E210LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE23AL_C400201	E230LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE24AL_C500021 -500200 (T2/S2)	E240LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE24AL_C500201	E240LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE24AL_D500201	E240LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE24AL_D500201	E240LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE26AL_C500201	E260LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE30AL_C600002 (T2/S2)	E300LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE30AL_D600014	E300LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE33AL_C600002	E330LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE33AL_D600025	E330LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE36AL_C600002	E360LC	✓	✓	✓	✓	
John Deere	Excavators	1YNE36AL_D600069	E360LC	✓	✓	✓	✓	
John Deere	Excavators	Army	250GLCR	✓	✓	✓	✓	
John Deere	Excavators	Engine 6WG1XZSA-	870GLC	✓	✓	✓	✓	
John Deere	Excavators	Engine 6WG1XZSA-	670GLC	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Excavators	Marines	250GLCR	✓	✓	✓	✓	
John Deere	Excavators	Military	240DLCR	✓	✓	✓	✓	
John Deere	Excavators	Military	250GLCR	✓	✓	✓	✓	
John Deere	Excavators	None	110	✓	✓	✓	✓	
John Deere	Excavators	None	120	✓	✓	✓	✓	
John Deere	Excavators	None	120C	✓	✓	✓	✓	
John Deere	Excavators	None	120D	✓	✓	✓	✓	
John Deere	Excavators	None	160CLC	✓	✓	✓	✓	
John Deere	Excavators	None	160DLC	✓	✓	✓	✓	
John Deere	Excavators	None	160LC	✓	✓	✓	✓	
John Deere	Excavators	None	190E	✓	✓	✓	✓	
John Deere	Excavators	None	200CLC	✓	✓	✓	✓	
John Deere	Excavators	None	200D	✓	✓	✓	✓	
John Deere	Excavators	None	200DLC	✓	✓	✓	✓	
John Deere	Excavators	None	200LC	✓	✓	✓	✓	
John Deere	Excavators	None	225DLC	✓	✓	✓	✓	
John Deere	Excavators	None	230CLC	✓	✓	✓	✓	
John Deere	Excavators	None	230LC	✓	✓	✓	✓	
John Deere	Excavators	None	240DLC	✓	✓	✓	✓	
John Deere	Excavators	None	240DLCR	✓	✓	✓	✓	
John Deere	Excavators	None	250GLC	✓	✓	✓	✓	
John Deere	Excavators	None	270CLC	✓	✓	✓	✓	
John Deere	Excavators	None	270DLC	✓	✓	✓	✓	
John Deere	Excavators	None	270LC	✓	✓	✓	✓	
John Deere	Excavators	None	290GLC	✓	✓	✓	✓	
John Deere	Excavators	None	330CLC	✓	✓	✓	✓	
John Deere	Excavators	None	330LC	✓	✓	✓	✓	
John Deere	Excavators	None	350DLC	✓	✓	✓	✓	
John Deere	Excavators	None	350GLC	✓	✓	✓	✓	
John Deere	Excavators	None	370	✓	✓	✓	✓	
John Deere	Excavators	None	370C	✓	✓	✓	✓	
John Deere	Excavators	None	450CLC	✓	✓	✓	✓	
John Deere	Excavators	None	450DLC	✓	✓	✓	✓	
John Deere	Excavators	None	450LC	✓	✓	✓	✓	
John Deere	Excavators	None	490E	✓	✓	✓	✓	
John Deere	Excavators	None	550LC	✓	✓	✓	✓	
John Deere	Excavators	None	600CLC	✓	✓	✓	✓	
John Deere	Excavators	None	650DLC	✓	✓	✓	✓	
John Deere	Excavators	None	750	✓	✓	✓	✓	
John Deere	Excavators	None	75D	✓	✓	✓	✓	
John Deere	Excavators	None	790ELC	✓	✓	✓	✓	
John Deere	Excavators	None	80	✓	✓	✓	✓	
John Deere	Excavators	None	800C	✓	✓	✓	✓	
John Deere	Excavators	None	80C	✓	✓	✓	✓	
John Deere	Excavators	None	850DLC	✓	✓	✓	✓	
John Deere	Excavators	None	85D	✓	✓	✓	✓	
John Deere	Excavators	None	892ELC	✓	✓	✓	✓	
John Deere	Excavators	None	992ELC	✓	✓	✓	✓	
John Deere	Excavators	RTS	135C RTS	✓	✓	✓	✓	
John Deere	Excavators	RTS	135D	✓	✓	✓	✓	
John Deere	Excavators	RTS	225CLC RTS	✓	✓	✓	✓	
John Deere	Excavators	RTS	225DLC	✓	✓	✓	✓	
John Deere	Excavators	RTS	75C	✓	✓	✓	✓	
John Deere	Excavators	Wheeled	180CW	✓	✓	✓	✓	
John Deere	Excavators	Wheeled	190DW	✓	✓	✓	✓	
John Deere	Excavators	Wheeled	210CW	✓	✓	✓	✓	
John Deere	Excavators	Wheeled	220DW	✓	✓	✓	✓	
John Deere	Feller Buncher	1DW643L C666898	643L	✓	✓	✓	✓	
John Deere	Feller Buncher	1DW643L F666898	643L	✓	✓	✓	✓	
John Deere	Feller Buncher	1DW843LX F666898	843L	✓	✓	✓	✓	
John Deere	Feller Buncher	1T0803MX_C270423 (T2/S2)	803M	✓	✓	✓	✓	
John Deere	Feller Buncher	1T0803MX_D270423 (T3/S3a)	803M	✓	✓	✓	✓	
John Deere	Feller Buncher	1T0803MX_FXXXXXX	803M	✓	✓	✓	✓	
John Deere	Feller Buncher	1T0853MX_C270423 (T2/S2)	853M	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Feller Buncher	IT0853MX_D270423 (T3/S3a)	853M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0853MX_FXXXXXX	853M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0859MX_C270423 (T2/S2)	859M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0859MX_D270423 (T3/S3a)	859M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0859MX_FXXXXXX	859M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0903MX_C271505 (T2/S2)	903M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0903MX_D271505 (T3/S3a)	903M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0909MX_C271505 (T2/S2)	909M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0909MX_D271505 (T3/S3a)	909M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0953MX_C271505 (T2/S2)	953M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0953MX_D271505 (T3/S3a)	953M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0959MX_C271505 (T2/S2)	959M	✓	✓	✓	✓	
John Deere	Feller Buncher	IT0959MX_D271505 (T3/S3a)	959M	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	653E	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	653G	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	703G	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	753G	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	753GL	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	753J	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	759G	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	759J	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	853G	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	853J	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	903G	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	903J	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	903K	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	909J	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	909K	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	953G	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	953J	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	953K	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	959J	✓	✓	✓	✓	
John Deere	Feller Buncher	Track	959K	✓	✓	✓	✓	
John Deere	Feller Buncher	Wheeled	643J	✓	✓	✓	✓	
John Deere	Feller Buncher	Wheeled	643K	✓	✓	✓	✓	
John Deere	Feller Buncher	Wheeled	843J	✓	✓	✓	✓	
John Deere	Feller Buncher	Wheeled	843K	✓	✓	✓	✓	
John Deere	Felling Head	Disc Saw	FD45	✓	✓	✓	✓	
John Deere	Felling Head	Disc Saw	FD55	✓	✓	✓	✓	
John Deere	Felling Head	Disc Saw	FR21B	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	GreenStar	AMS Harv ID, Cotton	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	GreenStar	AMS iGrade	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	GreenStar	AMS Mobile Weather	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	Raven Accuflow	AMS Raven Accuflow	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	Raven AutoBoom	AMS Raven AutoBoom	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	Raven SCS 450	AMS Raven SCS 450	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	Raven SCS 660M	AMS Raven SCS 660M	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	Raven Sidekick	AMS Raven Sidekick	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Field and Crop Solutions	Raven SmartBoom	AMS RavenSmart Boom	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	Surface Water Pro & SWP Plus	AMS Surface Water	✓	✓	✓	✓	
John Deere	Field and Crop Solutions	Swath Control Pro, Sprayer Pro	AMS Swath Control	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Delimber	2154D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Delimber	2454D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Delimber	2954D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Log Loader	2154D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Log Loader	2454D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Log Loader	2954D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Log Loader	3754D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Processor	2154D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Processor	2454D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Processor	2954D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Road Builder	2154D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Road Builder	2454D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Road Builder	2954D	✓	✓	✓	✓	
John Deere	Forestry Swing Machine	Road Builder	3754D	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1010D	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1010E	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1110D	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1110E	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1210E	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1410D	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1510E	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1710D	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1710E	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1711D	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1758	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1910E	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	1910G	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	810D	✓	✓	✓	✓	
John Deere	Forwarder	Wheeled	810E	✓	✓	✓	✓	
John Deere	GPS Receiver	RTK	AMS StarFire RTK	✓	✓	✓	✓	
John Deere	GPS Receiver	StarFire	AMS StarFire 300	✓	✓	✓	✓	
John Deere	GPS Receiver	StarFire	AMS StarFire 3000	✓	✓	✓	✓	
John Deere	GPS Receiver	StarFire	AMS StarFire 6000	✓	✓	✓	✓	
John Deere	GPS Receiver	StarFire	AMS StarFire iTC	✓	✓	✓	✓	
John Deere	GPS Receiver	StarFire	AMS StarFire Orig.	✓	✓	✓	✓	
John Deere	GPS Receiver	StarFire Mobile RTK	AMS StarFire Mobil	✓	✓	✓	✓	
John Deere	Guidance	Active Implement Guidance	AMS ActImpGuidance	✓	✓	✓	✓	
John Deere	Guidance	Automation - MCR	AMS Machine Sync	✓	✓	✓	✓	
John Deere	Guidance	AutoTrac Controller	AMS AT Controller	✓	✓	✓	✓	
John Deere	Guidance	Integrated	AMS AT Integrated	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Guidance	iTEC Pro	AMS iTEC Pro	✓	✓	✓	✓	
John Deere	Guidance	Reichart	AMS AT Controller	✓	✓	✓	✓	
John Deere	Guidance	RowSense & RS Universal	AMS AT RowSense	✓	✓	✓	✓	
John Deere	Guidance	Shared Data - MCR	AMS Machine Sync	✓	✓	✓	✓	
John Deere	Guidance	Universal	AMS AT RowSense	✓	✓	✓	✓	
John Deere	Guidance	Universal	AMS ATU 100	✓	✓	✓	✓	
John Deere	Guidance	Universal	AMS ATU 200	✓	✓	✓	✓	
John Deere	Harvester	1T0803MH_C270423 (T2/S2)	803MH	✓	✓	✓	✓	
John Deere	Harvester	1T0803MH_D270423 (T3/S3a)	803MH	✓	✓	✓	✓	
John Deere	Harvester	1T0803MH_FXXXXXX	803MH	✓	✓	✓	✓	
John Deere	Harvester	1T0853MH_C270423 (T2/S2)	853MH	✓	✓	✓	✓	
John Deere	Harvester	1T0853MH_D270423 (T3/S3a)	853MH	✓	✓	✓	✓	
John Deere	Harvester	1T0853MH_FXXXXXX	853MH	✓	✓	✓	✓	
John Deere	Harvester	1T0859MH_C270423 (T2/S2)	859MH	✓	✓	✓	✓	
John Deere	Harvester	1T0859MH_D270423 (T3/S3a)	859MH	✓	✓	✓	✓	
John Deere	Harvester	1T0859MH_FXXXXXX	859MH	✓	✓	✓	✓	
John Deere	Harvester	1T0903MH_C271505 (T2/S2)	903MH	✓	✓	✓	✓	
John Deere	Harvester	1T0903MH_D271505 (T3/S3a)	903MH	✓	✓	✓	✓	
John Deere	Harvester	1T0909MH_C271505 (T2/S2)	909MH	✓	✓	✓	✓	
John Deere	Harvester	1T0909MH_D271505 (T3/S3a)	909MH	✓	✓	✓	✓	
John Deere	Harvester	Harvester	1270G	✓	✓	✓	✓	
John Deere	Harvester	Harvester	1470G	✓	✓	✓	✓	
John Deere	Harvester	Track	703GH	✓	✓	✓	✓	
John Deere	Harvester	Track	703JH	✓	✓	✓	✓	
John Deere	Harvester	Track	753G	✓	✓	✓	✓	
John Deere	Harvester	Track	753GL	✓	✓	✓	✓	
John Deere	Harvester	Track	753JH	✓	✓	✓	✓	
John Deere	Harvester	Track	759GH	✓	✓	✓	✓	
John Deere	Harvester	Track	759JH	✓	✓	✓	✓	
John Deere	Harvester	Track	853JH	✓	✓	✓	✓	
John Deere	Harvester	Track	903JH	✓	✓	✓	✓	
John Deere	Harvester	Track	903KH	✓	✓	✓	✓	
John Deere	Harvester	Track	909JH	✓	✓	✓	✓	
John Deere	Harvester	Track	909KH	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	1070D	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	1070E	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	1170E	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	1270D	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	1270E	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	1470D	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	1470E	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	770D	✓	✓	✓	✓	
John Deere	Harvester	Wheeled	970D	✓	✓	✓	✓	
John Deere	Harvester Head	Bar Saw	H215	✓	✓	✓	✓	
John Deere	Harvester Head	Bar Saw	H270E	✓	✓	✓	✓	
John Deere	Harvester Head	Bar Saw	H412	✓	✓	✓	✓	
John Deere	Harvester Head	Bar Saw	H413	✓	✓	✓	✓	
John Deere	Harvester Head	Bar Saw	H414	✓	✓	✓	✓	
John Deere	Harvester Head	Bar Saw	H415	✓	✓	✓	✓	
John Deere	Harvester Head	Bar Saw	H480C	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Harvester Head	Corn Heads PIN Prefix 1YH	606C	✓	✓	✓	✓	
John Deere	Harvester Head	Corn Heads PIN Prefix 1YH	608C	✓	✓	✓	✓	
John Deere	Harvester Head	Corn Heads PIN Prefix 1YH	612C	✓	✓	✓	✓	
John Deere	Harvester Head	Corn Heads PIN Prefix 1YH	618C	✓	✓	✓	✓	
John Deere	Harvester Head	Flex Platform Pin Prefix 1YH	625F	✓	✓	✓	✓	
John Deere	Harvester Head	Flex Platform Pin Prefix 1YH	630F	✓	✓	✓	✓	
John Deere	Harvester Head	Pickup Platforms PIN Prefix 1YH	615P	✓	✓	✓	✓	
John Deere	Harvester Head	Rigid Platforms PIN Prefix 1YH	622R	✓	✓	✓	✓	
John Deere	Harvester Head	Rigid Platforms PIN Prefix 1YH	625R	✓	✓	✓	✓	
John Deere	Harvester Head	Rigid Platforms PIN Prefix 1YH	630R	✓	✓	✓	✓	
John Deere	Hay and Forage	3 Meter Pickups	630C	✓	✓	✓	✓	
John Deere	Hay and Forage	3 Meter Pickups	639	✓	✓	✓	✓	
John Deere	Hay and Forage	4 Meter Pickups	640C	✓	✓	✓	✓	
John Deere	Hay and Forage	4 Meter Pickups	649	✓	✓	✓	✓	
John Deere	Hay and Forage	4.5 Meter Pickups	645C	✓	✓	✓	✓	
John Deere	Hay and Forage	4.5 Meter Pickups	659	✓	✓	✓	✓	
John Deere	Hay and Forage	Auger Platforms	140A	✓	✓	✓	✓	
John Deere	Hay and Forage	Auger Platforms	160A	✓	✓	✓	✓	
John Deere	Hay and Forage	Auger Platforms	180A	✓	✓	✓	✓	
John Deere	Hay and Forage	Draper Platforms	415D	✓	✓	✓	✓	
John Deere	Hay and Forage	Draper Platforms	420D	✓	✓	✓	✓	
John Deere	Hay and Forage	Draper Platforms	425D	✓	✓	✓	✓	
John Deere	Hay and Forage	Draper Platforms	430D	✓	✓	✓	✓	
John Deere	Hay and Forage	Draper Platforms	435D	✓	✓	✓	✓	
John Deere	Hay and Forage	Draper Platforms	440D	✓	✓	✓	✓	
John Deere	Hay and Forage	Draper Platforms	525D	✓	✓	✓	✓	
John Deere	Hay and Forage	Large Square Balers	L1533	✓	✓	✓	✓	
John Deere	Hay and Forage	Large Square Balers	L1534	✓	✓	✓	✓	
John Deere	Hay and Forage	Large Square Balers	L330	✓	✓	✓	✓	
John Deere	Hay and Forage	Large Square Balers	L330C	✓	✓	✓	✓	
John Deere	Hay and Forage	Large Square Balers	L340	✓	✓	✓	✓	
John Deere	Hay and Forage	Large Square Balers	L340C	✓	✓	✓	✓	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix CC or ICC	530	✓	✓	✓	✓	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix CC or ICC	535	✓	✓	✓	✓	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix CC or ICC	630	✓	✓	✓	✓	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix CC or ICC	635	✓	✓	✓	✓	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix CC or ICC	730	✓	✓	✓	✓	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix CC or ICC	735	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix CC or ICC	830	✓	✓	✓	✓	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix CC or ICC	835	✓	✓	✓	✓	
John Deere	Hay and Forage	Mower Conditioners PIN Prefix EO or 1EO	535	✓	✓	✓	✓	
John Deere	Hay and Forage	None	F350R	✓	✓	✓	✓	
John Deere	Hay and Forage	None	R950R	✓	✓	✓	✓	
John Deere	Hay and Forage	None	R990R	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	300F	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	345plus	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	360plus	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	375plus	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	390plus	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	400F	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	460plus	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	475	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	475plus	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	690	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	692	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	696	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	698	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	770	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	778	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Harvesting Units	M4500 or 445	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Mower	R160	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Mower	R200	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Mower	R240	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Mower	R280	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Mower	R310	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Platforms	500R	✓	✓	✓	✓	
John Deere	Hay and Forage	Rotary Platforms	994	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix ICC	C440R	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix ICC	F440M	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix ICC	F440R	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix CC	623	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix CC	842	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix CC	852	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix CC	862	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix CC	F440E	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Hay and Forage	Round Balers PIN Prefix CC	F450E	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	449	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	458STD	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	459	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	459 Silage	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	459 Standard	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	459E	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	469	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	469 Premium	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	469 Silage	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	559	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	559 Silage	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	559S	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	569	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	569 Premium	✓	✓	✓	✓	
John Deere	Hay and Forage	Round Balers PIN Prefix EO or 1EO	569 Silage	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	7200	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	7300	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	7400	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	7500	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	7700	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	7800	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	6650	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	6750	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	6810	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	6850	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	6950	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	7200	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	7300	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	7400	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	7500	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	7700	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters	7800	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN 1Z0 or 1Z0	7250	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN 1Z0 or 1Z0	7350	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN 1Z0 or 1Z0	7450	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN 1Z0 or 1Z0	7550	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN 1Z0 or 1Z0	7750	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN 1Z0 or 1Z0	7850	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN 1Z0 or 1Z0	7950	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	7180	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	7280	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	7380	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	7480	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	7580	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	7780	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	7980	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	8100	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	8200	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	8300	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	8400	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	8500	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	8600	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	8700	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	8800	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	ZX15SPFH	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	4890	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	4990	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	4995	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	A400	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	D400	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	D450	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	R450	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	W110	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	W150	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers 320001 - XXXXXX	4895	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers PIN Prefix EO or 1EO	W155	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers PIN Prefix EO or 1EO	W235 Draper	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers PIN Prefix EO or 1EO	W235 Rotary	✓	✓	✓	✓	
John Deere	Hay and Forage	Self-Propelled Windrowers PIN Prefix EO or 1EO	W260	✓	✓	✓	✓	
John Deere	Hay and Forage	Square Balers	1424	✓	✓	✓	✓	
John Deere	Hay and Forage	Square Balers	1424C	✓	✓	✓	✓	
John Deere	Hay and Forage	Square Balers	1433	✓	✓	✓	✓	
John Deere	Hay and Forage	Square Balers	1433C	✓	✓	✓	✓	
John Deere	Hay and Forage	Square Balers	1434	✓	✓	✓	✓	
John Deere	Hay and Forage	Square Balers	1434C	✓	✓	✓	✓	
John Deere	Information Management	Agriculture - Website	AMS AgLogic	✓	✓	✓	✓	
John Deere	Information Management	Documentation Printer	AMS Printer	✓	✓	✓	✓	
John Deere	Landscape Loader	None	210LE	✓	✓	✓	✓	
John Deere	Landscape Loader	None	210LJ	✓	✓	✓	✓	
John Deere	LG Attachments	Sprayer	15	✓	✓	✓	✓	
John Deere	Log Loader	1T0437E_ - F291461-	437E	✓	✓	✓	✓	
John Deere	Log Loader	Trailer Mount	335C	✓	✓	✓	✓	
John Deere	Log Loader	Trailer Mount	335D	✓	✓	✓	✓	
John Deere	Log Loader	Trailer Mount	437D	✓	✓	✓	✓	
John Deere	Logger	Delimber	2054	✓	✓	✓	✓	
John Deere	Logger	Delimber	2554	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Logger	Delimber	3554	✓	✓	✓	✓	
John Deere	Logger	Log Loader	2054	✓	✓	✓	✓	
John Deere	Logger	Log Loader	2554	✓	✓	✓	✓	
John Deere	Logger	Log Loader	3554	✓	✓	✓	✓	
John Deere	Logger	None	200LC	✓	✓	✓	✓	
John Deere	Logger	None	330LC	✓	✓	✓	✓	
John Deere	Logger	None	370	✓	✓	✓	✓	
John Deere	Logger	Road Builder	2054	✓	✓	✓	✓	
John Deere	Logger	Road Builder	2554	✓	✓	✓	✓	
John Deere	Logger	Road Builder	3554	✓	✓	✓	✓	
John Deere	Logger	Wheeled	2054	✓	✓	✓	✓	
John Deere	Logger	Wheeled	2554	✓	✓	✓	✓	
John Deere	Logger	Wheeled	3554	✓	✓	✓	✓	
John Deere	Machine and Implement Control	GreenStar	AMS RateControlDrv	✓	✓	✓	✓	
John Deere	Machine and Implement Control	GreenStar	AMS RateController	✓	✓	✓	✓	
John Deere	Machine and Implement Control	GreenStar 3	AMS ActiveFillCont	✓	✓	✓	✓	
John Deere	Machine and Implement Control	John Deere Implement Detection	AMS Impl Detection	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	ATRB BROOM	60HD	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Flail Shredders	520	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loader	D120	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loader	H120	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loader	H480	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders	110	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders	400X	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders	H420	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	603R	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	623R	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	643R	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	663R	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	683R	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	H240	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	H260	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	H310	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	H340	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	H360	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	H380	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	562	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	640R	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	D160	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	D170	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H130	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H160	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H165	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H180	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H240	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H260	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H310	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H340	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H360	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	H380	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Rotary Cutters	HX6	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Rotary Cutters	HX7	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	1510D C	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	1612D E	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	1810D C	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	1812D C	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	1814D C	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	2010D E	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	2014D E	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	2112D C	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Scrapers	2412D E	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Sugar Cane	1800	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Sugar Cane	1850	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Sugar Cane	2254	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Telehandlers	3200	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Telehandlers	3215	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Telehandlers	3220	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Telehandlers	3400	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Telehandlers	3415	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Telehandlers	3420	✓	✓	✓	✓	
John Deere	Mate. Hand Cut. and Shredders	Telehandlers	3800	✓	✓	✓	✓	
John Deere	Measuring System	Automatic Control	TimberMatic F	✓	✓	✓	✓	
John Deere	Measuring System	Automatic Control	TimberMatic H	✓	✓	✓	✓	
John Deere	Mobile Application	Connected	AMS Harvest Mobile	✓	✓	✓	✓	
John Deere	Mobile Application	Connected	AMS SeedStar Mobil	✓	✓	✓	✓	
John Deere	Mobile Application	Non-Connected	AMS Mobile Data Tr	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6068HDW75	670G	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6068HDW75	670GP	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6068HDW75	672G	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6068HDW75	672GP	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	770G	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	770GP	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	772G	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	772GP	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	870G	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	870GP	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	872G	✓	✓	✓	✓	
John Deere	Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	872GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634380 - 656507) Engine 6090HDW11 (iT4/S3b)	772G	✓	✓	✓	✓	
John Deere	Motor Grader	(634380 - 656507) Engine 6090HDW11 (iT4/S3b)	772GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634380 - 656507) Engine 6090HDW11 (iT4/S3b)	870G	✓	✓	✓	✓	
John Deere	Motor Grader	(634380 - 656507) Engine 6090HDW11 (iT4/S3b)	870GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634380 - 656507) Engine 6090HDW11 (iT4/S3b)	872G	✓	✓	✓	✓	
John Deere	Motor Grader	(634380 - 656507) Engine 6090HDW11 (iT4/S3b)	872GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634380-656507) Engine 6090HDW16 (iT4/S3b)	670G	✓	✓	✓	✓	
John Deere	Motor Grader	(634380-656507) Engine 6090HDW16 (iT4/S3b)	670GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634380-656507) Engine 6090HDW16 (iT4/S3b)	672G	✓	✓	✓	✓	
John Deere	Motor Grader	(634380-656507) Engine 6090HDW16 (iT4/S3b)	672GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634380-656507) Engine 6090HDW16 (iT4/S3b)	770G	✓	✓	✓	✓	
John Deere	Motor Grader	(634380-656507) Engine 6090HDW16 (iT4/S3b)	770GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6068HDW75 (S2)	670G	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6068HDW75 (S2)	670GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6068HDW75 (S2)	672G	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6068HDW75 (S2)	672GP	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6090HDW04 (S2)	770G	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6090HDW04 (S2)	770GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6090HDW04 (S2)	772G	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6090HDW04 (S2)	772GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6090HDW04 (S2)	870G	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6090HDW04 (S2)	870GP	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6090HDW04 (S2)	872G	✓	✓	✓	✓	
John Deere	Motor Grader	(634754-656508) 6090HDW01 (S3a) 6090HDW04 (S2)	872GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW670G_C656729 - (T2/S2)	670G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW670G_C656729 - (T2/S2)	670GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW670G_D656729 - (T3/S3a)	670G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW670G_D656729 - (T3/S3a)	670GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW670GP_F656526 -	670GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW670GX_F656526 -	670G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW672G_C656729 - (T2/S2)	672G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW672G_C656729 - (T2/S2)	672GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW672G_D656729 - (T3/S3a)	672G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW672G_D656729 - (T3/S3a)	672GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW672GP_F656526 -	672GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW672GX_F656526 -	672G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW770G_C656729 - (T2/S2)	770G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW770G_C656729 - (T2/S2)	770GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW770G_D656729 - (T3/S3a)	770G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW770G_D656729 - (T3/S3a)	770GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW770GP_F656526 -	770GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW770GX_F656526 -	770G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW772G_C656729 - (T2/S2)	772G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW772G_C656729 - (T2/S2)	772GP	✓	✓	✓	✓	
John Deere	Motor Grader	1DW772G_D656729 - (T3/S3a)	772G	✓	✓	✓	✓	
John Deere	Motor Grader	1DW772G_D656729 - (T3/S3a)	772GP	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Motor Grader	IDW772GP_F656526	772GP	✓	✓	✓	✓	
John Deere	Motor Grader	IDW772GX_F656526	772G	✓	✓	✓	✓	
John Deere	Motor Grader	IDW870G_C656729	870G	✓	✓	✓	✓	
John Deere	Motor Grader	IDW870G_C656729	870GP	✓	✓	✓	✓	
John Deere	Motor Grader	IDW870G_D656729	870G	✓	✓	✓	✓	
John Deere	Motor Grader	IDW870G_D656729	870GP	✓	✓	✓	✓	
John Deere	Motor Grader	IDW870GP_F656526	870GP	✓	✓	✓	✓	
John Deere	Motor Grader	IDW870GX_F656526	870G	✓	✓	✓	✓	
John Deere	Motor Grader	IDW872G_C656729	872G	✓	✓	✓	✓	
John Deere	Motor Grader	IDW872G_C656729	872GP	✓	✓	✓	✓	
John Deere	Motor Grader	IDW872G_D656729	872G	✓	✓	✓	✓	
John Deere	Motor Grader	IDW872G_D656729	872GP	✓	✓	✓	✓	
John Deere	Motor Grader	IDW872GP_F656526	872GP	✓	✓	✓	✓	
John Deere	Motor Grader	IDW872GX_F656526	872G	✓	✓	✓	✓	
John Deere	Motor Grader	HFWD	672CH	✓	✓	✓	✓	
John Deere	Motor Grader	HFWD	672CH Series II	✓	✓	✓	✓	
John Deere	Motor Grader	HFWD	672D	✓	✓	✓	✓	
John Deere	Motor Grader	HFWD	772CH	✓	✓	✓	✓	
John Deere	Motor Grader	HFWD	772CH Series II	✓	✓	✓	✓	
John Deere	Motor Grader	HFWD	772D	✓	✓	✓	✓	
John Deere	Motor Grader	HFWD	872D	✓	✓	✓	✓	
John Deere	Motor Grader	None	670C Series II	✓	✓	✓	✓	
John Deere	Motor Grader	None	670CH	✓	✓	✓	✓	
John Deere	Motor Grader	None	670CH Series II	✓	✓	✓	✓	
John Deere	Motor Grader	None	670D	✓	✓	✓	✓	
John Deere	Motor Grader	None	770C	✓	✓	✓	✓	
John Deere	Motor Grader	None	770C Series II	✓	✓	✓	✓	
John Deere	Motor Grader	None	770CH	✓	✓	✓	✓	
John Deere	Motor Grader	None	770CH Series II	✓	✓	✓	✓	
John Deere	Motor Grader	None	770D	✓	✓	✓	✓	
John Deere	Motor Grader	None	870D	✓	✓	✓	✓	
John Deere	Motor Inverter	None	300s	✓	✓	✓	✓	
John Deere	Motor Inverter	None	550d	✓	✓	✓	✓	
John Deere	Motor Inverter	None	550s	✓	✓	✓	✓	
John Deere	OEM Engines	CNG LNG	6068	✓	✓	✓	✓	
John Deere	OEM Engines	CNG LNG	6081	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3009	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3011	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3029	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3029 FT4	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3152	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3164	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3179	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3TNV86	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	3TNV88	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	4024	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	4045	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	4219	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	OEM Engines	Diesel	4TNV86	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	4TNV88	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	4TNV94	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	4TNV98	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	5030	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	6068	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	6081	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	6090	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	6105	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	6125	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	6135	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	6329	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	6531	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	8955	✓	✓	✓	✓	
John Deere	OEM Engines	Diesel	QSX15	✓	✓	✓	✓	
John Deere	OEM Engines	Marine PowerTech	4045	✓	✓	✓	✓	
John Deere	OEM Engines	Marine PowerTech	6068	✓	✓	✓	✓	
John Deere	OEM Engines	Marine PowerTech	6090	✓	✓	✓	✓	
John Deere	OEM Engines	Marine PowerTech	6125	✓	✓	✓	✓	
John Deere	OEM Engines	Marine PowerTech	6135	✓	✓	✓	✓	
John Deere	OEM Engines	Marine PowerTech	Sea Trial	✓	✓	✓	✓	
John Deere	Other	Machine Information	ICF	✓	✓	✓	✓	
John Deere	Other	Machine Information	ICX	✓	✓	✓	✓	
John Deere	Other	Other	oCONN1	✓	✓	✓	✓	
John Deere	Planetary Drive	Planetary Wheel Drive	WD098	✓	✓	✓	✓	
John Deere	Planting and Seeding	Air Seeders	1690CCS	✓	✓	✓	✓	
John Deere	Planting and Seeding	Air Seeders	1890CCS	✓	✓	✓	✓	
John Deere	Planting and Seeding	Air Seeders	740A	✓	✓	✓	✓	
John Deere	Planting and Seeding	Air Seeders	750A	✓	✓	✓	✓	
John Deere	Planting and Seeding	Air Seeders PIN Prefix 1EK	1830	✓	✓	✓	✓	
John Deere	Planting and Seeding	Air Seeders PIN Prefix 1EK	1890	✓	✓	✓	✓	
John Deere	Planting and Seeding	Air Seeders PIN Prefix 1EK	730	✓	✓	✓	✓	
John Deere	Planting and Seeding	Drills	BD1108	✓	✓	✓	✓	
John Deere	Planting and Seeding	Drills	BD1110	✓	✓	✓	✓	
John Deere	Planting and Seeding	Drills	BD1113	✓	✓	✓	✓	
John Deere	Planting and Seeding	Drills PIN Prefix 1EK	455	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	1725	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	1775NT 12ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	1775NT 16ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	1775NT 24ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	1795	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	DB60 24 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	DB60 36 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	DB60 47 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	DB60 48 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	DB80 32 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	DB80 48 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	ExactEmerge	DB90	✓	✓	✓	✓	
John Deere	Planting and Seeding	Ground Drive PIN Prefix 1EK	1910	✓	✓	✓	✓	
John Deere	Planting and Seeding	Hydraulic Drive PIN Prefix 1EK	1910	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Planting and Seeding	Hydraulic Drive PIN Prefix AO and 1A8	1910	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1705	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1715	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1725	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1735	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1755	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1765	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1765NT	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1775	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1775NT 12ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1775NT 16ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1775NT 24ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1785	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	1795	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB120	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB44	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB60 24 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB60 36 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB60 47 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB66	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB80 32 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB80 48 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB88	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB90	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5	DB90 54 row	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5 Twin Row	1705	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5 Twin Row	1725	✓	✓	✓	✓	
John Deere	Planting and Seeding	MaxEmerge 5 Twin Row	DB60T	✓	✓	✓	✓	
John Deere	Planting and Seeding	None	2115	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters	1740	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters	DR16	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters	DR18	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters	DR24	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters	DR8T	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1010	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1015	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1025	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1030	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1035	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1745	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1745 12ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1745 14ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1745 16ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix PO	1745 18ROW	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Planting and Seeding	Planters - Pin Prefix P0	1745 20ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix P0	1745 24ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix P0	1755	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix P0	D06R	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters - Pin Prefix P0	D08R	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	1770NT 12ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	1770NT 16ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	1770NT 24ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	1790	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB120	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB37	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB44	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB50	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB55	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB58	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB60 36ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB60 47ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB66	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB74	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB80 48 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB83 36 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB88	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 740101-745000	DB90	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	1770NT 12ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	1770NT 16ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	1770NT 24ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	1790	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB120	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB37	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB44	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB50	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB55	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB58	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB60 24 Row	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB60 36 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB60 47 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB66	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB74	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB80 32 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB80 48 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB83 36 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB88	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters 745101-XXXXXX	DB90	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ	2109	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ	2111	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 000248 - 099999	2130	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 090087 - 099999	1107	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 090225 - 099999	2122	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 090394 - 099999	2126	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 090431 - 099999	2113	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 090455 - XXXXXX	1109	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 090569 - 099999	1113	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 090605 - 099999	1111	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 090740 - 099999	2117	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	1107	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	1109	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	1111	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	1113	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2109	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2111	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2113	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2115	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2117	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2122	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2126	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2130	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	2134	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	DB40	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	DB50	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	DB74	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ 100000 - XXXXXX	DB90	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 000247	2130	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090086	1107	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090086	1113	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090224	2122	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090243	2115	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090393	2126	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090430	2113	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090454	1109	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090604	1111	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 090739	2117	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 099999	2134	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 099999	DB50	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 099999	DB74	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix 1CQ XXXXXX - 099999	DB90	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix CQ	2117	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix CQ	2126	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters PIN Prefix CQ	2130	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB120	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB37	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB50	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB55	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB60 36 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB60 47 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB60 47ROW	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB74	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB80 32 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB80 48 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB83 36 Row	✓	✓	✓	✓	
John Deere	Planting and Seeding	Planters XXXXX - 740100	DB88	✓	✓	✓	✓	
John Deere	Planting and Seeding	seeders	1512FX	✓	✓	✓	✓	
John Deere	Planting and Seeding	seeders	1516FX	✓	✓	✓	✓	
John Deere	Planting and Seeding	seeders	1524FX	✓	✓	✓	✓	
John Deere	Planting and Seeding	Twin Row Planter	1700	✓	✓	✓	✓	
John Deere	PTO	Series	F30	✓	✓	✓	✓	
John Deere	Pump Drive	GPD	GPD1511	✓	✓	✓	✓	
John Deere	Pump Drive	GPD	GPD2224	✓	✓	✓	✓	
John Deere	Pump Drive	Series	28000	✓	✓	✓	✓	
John Deere	Pump Drive	Series	56000	✓	✓	✓	✓	
John Deere	Pump Drive	Series	57000	✓	✓	✓	✓	
John Deere	Pump Drive	Series	59000	✓	✓	✓	✓	
John Deere	Pump Drive	Series	61000	✓	✓	✓	✓	
John Deere	Riding Lawn Equipment	JD Lawn and Garden Tractors	GX255	✓	✓	✓	✓	
John Deere	Scraper	Scrapers	1810c	✓	✓	✓	✓	
John Deere	Skid Steer	1T0312G J288093	312GR	✓	✓	✓	✓	
John Deere	Skid Steer	1T0314G J288093	314G	✓	✓	✓	✓	
John Deere	Skid Steer	1T0316G J288093	316GR	✓	✓	✓	✓	
John Deere	Skid Steer	1T0317E J999999 (FT4/S4)	317E	✓	✓	✓	✓	
John Deere	Skid Steer	1T0317G J288093	317G	✓	✓	✓	✓	
John Deere	Skid Steer	1T0318E G253889 (IT4/S3A)	318E	✓	✓	✓	✓	
John Deere	Skid Steer	1T0318E J249323 (FT4/S4)	318E	✓	✓	✓	✓	
John Deere	Skid Steer	1T0318G J288093	318G	✓	✓	✓	✓	
John Deere	Skid Steer	1T0319E G254929 (IT4/S3A)	319E	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Skid Steer	IT0319E__J249321 (FT4/S4)	319E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0320E__G254913 (IT4/S3A)	320E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0320E__J249291 (FT4/S4)	320E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0323E__G254917 (IT4/S3A)	323E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0323E__J249322 (FT4/S4)	323E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0326E__G254998 (IT4/S3A)	326E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0326E__J247388 - (FT4/S4)	326E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0328E__E236673 (IT4/S3B)	328E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0329E__E236704 (IT4/S3B)	329E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0332E__E236670 (IT4/S3B)	332E	✓	✓	✓	✓	
John Deere	Skid Steer	IT0333E__E236690 (IT4/S3B)	333E	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	318D	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	319D	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	320D	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	323D	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	326D	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	328D	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	329D	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	332D	✓	✓	✓	✓	
John Deere	Skid Steer	Electrohydraulic Controls - EH	333D	✓	✓	✓	✓	
John Deere	Skid Steer	Loader	125	✓	✓	✓	✓	
John Deere	Skid Steer	Loader	325	✓	✓	✓	✓	
John Deere	Skid Steer	Loader	328	✓	✓	✓	✓	
John Deere	Skid Steer	Loader	332	✓	✓	✓	✓	
John Deere	Skid Steer	Loader	CT315	✓	✓	✓	✓	
John Deere	Skid Steer	Loader	CT332	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	318D	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	319D	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	320D	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	323D	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	326D	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	328D	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	329D	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	332D	✓	✓	✓	✓	
John Deere	Skid Steer	Manual Controls	333D	✓	✓	✓	✓	
John Deere	Skidder	1DW640L C666893	640L	✓	✓	✓	✓	
John Deere	Skidder	1DW640L F666893	640L	✓	✓	✓	✓	
John Deere	Skidder	1DW648L C666893	648L	✓	✓	✓	✓	
John Deere	Skidder	1DW648L F666893	648L	✓	✓	✓	✓	
John Deere	Skidder	1DW748L C666893	748L	✓	✓	✓	✓	
John Deere	Skidder	1DW748L F666893	748L	✓	✓	✓	✓	
John Deere	Skidder	1DW848L C666893	848L	✓	✓	✓	✓	
John Deere	Skidder	1DW848L F666893	848L	✓	✓	✓	✓	
John Deere	Skidder	1DW948L C666893	948L	✓	✓	✓	✓	
John Deere	Skidder	1DW948L F666893	948L	✓	✓	✓	✓	
John Deere	Skidder	Cable	540G	✓	✓	✓	✓	
John Deere	Skidder	Cable	540G-II	✓	✓	✓	✓	
John Deere	Skidder	Cable	540H	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Skidder	Cable	640E	✓	✓	✓	✓	
John Deere	Skidder	Cable	640G	✓	✓	✓	✓	
John Deere	Skidder	Cable	640G-II	✓	✓	✓	✓	
John Deere	Skidder	Cable	640G-III	✓	✓	✓	✓	
John Deere	Skidder	Cable	640H	✓	✓	✓	✓	
John Deere	Skidder	Cable 613179-XXXXX	540G-III	✓	✓	✓	✓	
John Deere	Skidder	Cable XXXXX-613178	540G-III	✓	✓	✓	✓	
John Deere	Skidder	Grapple	548G	✓	✓	✓	✓	
John Deere	Skidder	Grapple	548G-II	✓	✓	✓	✓	
John Deere	Skidder	Grapple	548H	✓	✓	✓	✓	
John Deere	Skidder	Grapple	640GS	✓	✓	✓	✓	
John Deere	Skidder	Grapple	648E	✓	✓	✓	✓	
John Deere	Skidder	Grapple	648G	✓	✓	✓	✓	
John Deere	Skidder	Grapple	648G-II	✓	✓	✓	✓	
John Deere	Skidder	Grapple	648G-III	✓	✓	✓	✓	
John Deere	Skidder	Grapple	648H	✓	✓	✓	✓	
John Deere	Skidder	Grapple	740GS	✓	✓	✓	✓	
John Deere	Skidder	Grapple	748G-II	✓	✓	✓	✓	
John Deere	Skidder	Grapple	748G-III	✓	✓	✓	✓	
John Deere	Skidder	Grapple	748H	✓	✓	✓	✓	
John Deere	Skidder	Grapple	848G	✓	✓	✓	✓	
John Deere	Skidder	Grapple	848H	✓	✓	✓	✓	
John Deere	Skidder	Grapple 613179-XXXXX	548G-III	✓	✓	✓	✓	
John Deere	Skidder	Grapple XXXXX-613178	548G-III	✓	✓	✓	✓	
John Deere	Software	Automatic Control	TimberLink	✓	✓	✓	✓	
John Deere	Sprayers	Fertilizer Spreader	DN200	✓	✓	✓	✓	
John Deere	Sprayers	Fertilizer Spreader	DN218	✓	✓	✓	✓	
John Deere	Sprayers	Fertilizer Spreader	DN224	✓	✓	✓	✓	
John Deere	Sprayers	Fertilizer Spreader	DN236	✓	✓	✓	✓	
John Deere	Sprayers	Fertilizer Spreader	DN300	✓	✓	✓	✓	
John Deere	Sprayers	Fertilizer Spreader	DN350	✓	✓	✓	✓	
John Deere	Sprayers	Fertilizer Spreader	DN456	✓	✓	✓	✓	
John Deere	Sprayers	Fertilizer Spreader	DN485	✓	✓	✓	✓	
John Deere	Sprayers	Mounted Sprayers	408A	✓	✓	✓	✓	
John Deere	Sprayers	Mounted Sprayers	410A	✓	✓	✓	✓	
John Deere	Sprayers	Mounted Sprayers	412A	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix 1NW	4630	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix 1NW	4730	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix 1YH	4630	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	4630	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	4720	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	4730	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	4830	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	4920	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	4930	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	4940	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	DN345	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	R4023	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	R4030	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	R4038	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	R4045	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix WZ or 1WZ	5430i	✓	✓	✓	✓	
John Deere	Sprayers	Self-Propelled Sprayers PIN Prefix WZ or 1WZ	R4040i	✓	✓	✓	✓	
John Deere	Sprayers	Sprayers	M944	✓	✓	✓	✓	
John Deere	Sprayers	Sprayers	M944i	✓	✓	✓	✓	
John Deere	Sprayers	Sprayers	R944i	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers	824TF	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers	832TF	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers	840TF	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers	R942i	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers	R942iTF	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers	R952i	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers	R952iTF	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M724	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M732	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M732i	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M740	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M740i	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M952	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M952i	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M962	✓	✓	✓	✓	
John Deere	Sprayers	Trailed Sprayers PIN Prefix 1WZ	M962i	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix 1N4 200000 - 200012	CH330	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix 1N4 201001 - XXXXXX	CH330	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix 1NW 090021 - 090324	3522	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Sugar Cane Harvesters	PIN Prefix 1NW 120201 - XXXXX	3522	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix 1NW 150001 - XXXXX	CH570	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix 1NW 150001-XXXXX	CH670	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix 1T8 121901 - 121960	CH330	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix 1T8 150001 - XXXXX	CH570	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix 1T8 161001 - XXXXX	CH330	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix NW 080002 - 090439	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	PIN Prefix T8 090504 - 090755	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix T8 - Thibodaux	2500	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix T8 - Thibodaux	3500	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix T8 - Thibodaux	3510	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix T8 - Thibodaux	CHSM	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Track PIN Prefix 1NW 090564 - 092286	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Track PIN Prefix 1NW 120701 - XXXXXX	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Track PIN Prefix 1T8 100601 - 101190	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Track PIN Prefix 1T8 120701 - XXXXXX	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Wheel PIN Prefix 1NW 090564 - 092286	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Wheel PIN Prefix 1NW 120701 - XXXXXX	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Wheel PIN Prefix 1T8 100601 - 101190	3520	✓	✓	✓	✓	
John Deere	Sugar Cane Harvesters	Wheel PIN Prefix 1T8 120701 - XXXXXX	3520	✓	✓	✓	✓	
John Deere	Tillage	Disk PIN Prefix 1EK	2623	✓	✓	✓	✓	
John Deere	Tillage	Disk PIN Prefix 1NO	2623	✓	✓	✓	✓	
John Deere	Tillage	Disk Plows	624	✓	✓	✓	✓	
John Deere	Tillage	Disk Ripper PIN Prefix 1A8/1JL	2720	✓	✓	✓	✓	
John Deere	Tillage	Disk Ripper PIN Prefix 1EK	2720	✓	✓	✓	✓	
John Deere	Tillage	Disk Rippers	2730	✓	✓	✓	✓	
John Deere	Tillage	Disks	2620	✓	✓	✓	✓	
John Deere	Tillage	Disks	2625	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tillage	Disks	635	✓	✓	✓	✓	
John Deere	Tillage	Disks - PIN prefix P0 -	655	✓	✓	✓	✓	
John Deere	Tillage	Disks - PIN prefix P0 -	660	✓	✓	✓	✓	
John Deere	Tillage	Field Cultivators - Level Lift PIN Prefix 1EK	2210	✓	✓	✓	✓	
John Deere	Tillage	Field Cultivators PIN Prefix 1EK	2210	✓	✓	✓	✓	
John Deere	Tillage	Nutrient Applicator	2410C	✓	✓	✓	✓	
John Deere	Tillage	Nutrient Applicator	2510H Dry Attachme	✓	✓	✓	✓	
John Deere	Tillage	Nutrient Applicator	2510L	✓	✓	✓	✓	
John Deere	Tillage	Nutrient Applicator	PitStop Pro	✓	✓	✓	✓	
John Deere	Tillage	Plows	3810	✓	✓	✓	✓	
John Deere	Tillage	Plows	3910	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	1317RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	1319RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	1321RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	1525RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	1630RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	2315RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	2317RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	2415RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	2417RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	2419RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	2421RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	2525RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	3416RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	3417RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	3419RT	✓	✓	✓	✓	
John Deere	Tillage	Rotary Tiller	3421rt	✓	✓	✓	✓	
John Deere	Tillage	Toolbars	MX10	✓	✓	✓	✓	
John Deere	Tractor Attachments	ATBL BLADE	54	✓	✓	✓	✓	
John Deere	Tractor Attachments	Backhoe	375A	✓	✓	✓	✓	
John Deere	Tractor Attachments	Backhoe	385A	✓	✓	✓	✓	
John Deere	Tractor Attachments	Backhoe	485A	✓	✓	✓	✓	
John Deere	Tractor Attachments	Backhoe	595	✓	✓	✓	✓	
John Deere	Tractor Attachments	Blade Front	366	✓	✓	✓	✓	
John Deere	Tractor Loader	1T8210EK_G891000	210K EP	✓	✓	✓	✓	
John Deere	Tractor Loader	1T8210EL_G892600	210L EP	✓	✓	✓	✓	
John Deere	Tractor Loader	1T8210KX_E891000 - (iT4/S3B)	210K	✓	✓	✓	✓	
John Deere	Tractor Loader	1T8210LX_F892600	210L	✓	✓	✓	✓	
John Deere	Tractors	***6RC L0 (Engine 4045RXXXXXX) (Interim Tier 4)	6090RC	✓	✓	✓	✓	
John Deere	Tractors	***6RC L0 (Engine 4045RXXXXXX) (Interim Tier 4)	6100RC	✓	✓	✓	✓	
John Deere	Tractors	***6RC L0 (Engine 4045RXXXXXX) (Interim Tier 4)	6110RC	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	4760	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	5620	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	5720	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	5820	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6010	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6010L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6010SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6020	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6020SE	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD	6100	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6100SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6110L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6110SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6120L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6120SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6200L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6200SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6210L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6210SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6215	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6220L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6220SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6300L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6300SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6310L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6310S	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6310SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6320L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6320SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6400L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6400SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6410L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6410S	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6410SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6415	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6420L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6420S	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6420SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6500L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6505	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6510	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6510L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6510S	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6510SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6520	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6520L	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6520SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6603	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6610	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6610SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6615	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6620	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6620SE	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6715	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6800	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6810	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6820	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6900	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6910	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6910S	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6920	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	6920S	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7200	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7210	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7400	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7405	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7410	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7510	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7600	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7610	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7630	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7700	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7710	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7715	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7730	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7800	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7815	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD	7830	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	7930	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8100	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8110	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8120	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8130	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8200	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8210	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8220	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8230	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8300	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8310	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8320	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8330	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8400	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8410	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8420	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8430	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8520	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD	8530	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	6300	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	6405	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	6500	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	6600	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	6605	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	7500	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	7505	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	7715	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - Brazilian	7815	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	5-1050	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	6603	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	B350	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	B550	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	JD550-1	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	JD554-1	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	JD600-1	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	JD604-1	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	JD650-1	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	JD654-1	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	JD700-1	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China	JD704-1	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000- XXXXXX	2C-280	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000- XXXXXX	2C-284	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	2C-320	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	2C-324	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	3B-450	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	3B-480	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	3B-484	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	4B-504	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	4B-554	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	5B-550	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	5B-650	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	5B-700	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	5B-750	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - China 300000-XXXXXX	5B-754	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5070M	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5080M	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5080R	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5080RN	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5090M	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5090R	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5090RN	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5100M	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5100R	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	5100RN	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6110	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6120	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6130	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6200	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6205	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6210	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD - European	6215	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6220	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6225	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6230	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6230 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6300	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6310	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6320	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6325	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6330	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6330 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6400	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6410	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6420	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6425	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6430	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6430 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6506	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6515	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6525	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6530	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6530 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6534	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6534 PREMIUM	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6600	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6630	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6630 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6830	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6830 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6930	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	6930 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	7130	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	7230	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	7430 E Premium	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD - European	7430 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	7530 E Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - European	7530 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6110	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6120	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6200	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6210	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6220	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6230	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6230 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6300	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6310	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6320	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6330	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6330 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6400	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6405	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6410	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6420	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6430	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6430 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6500	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6603	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	6605	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	7130	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - North American	7230	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5055E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5055EF	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5055EL	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5065E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5075E	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5075EF	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5075EL	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5078E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5085E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	5090E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6110E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6110J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6125E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6125J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6130J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6145J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6155J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6165J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6180J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	6205J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	7185J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	7195J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	7205J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	7210J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	7225J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	7715	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	7815	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix CQ -	6415	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD - PIN prefix CQ -	6615	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix CQ -	7515	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix CQ -	7810	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix JZ	6130D	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix JZ	7830	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN Prefix JZ	7930	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5076E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5076EF	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5076EL	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5082E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5083E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5090E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5090EH	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5090EL	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5093E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5415	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5415N	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5425	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5425N	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5615	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5625	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5625HC	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5715	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5725	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	5725N	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6100D	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6105J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6110D	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6115D	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6125D	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6130D	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6140D	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6140J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6140JH	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6155J	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6155JH	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6403	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6415	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6425	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	6603	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	7220	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	7320	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	7420	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	7425	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	7500	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	7520	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix PO	7525	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7130 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7220	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7230 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7320	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7330 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7420	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7430 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7520	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7530 Premium	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7720	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7810	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7820	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix RW - USA	7920	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix TK -	5615	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix TK -	5715	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix YH	2204	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix YH	2854	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix YH	4104	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix YR	2204	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix YR	2904	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD - PIN prefix YR	3204	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5045D	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5045E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5065E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5075E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5076EF	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5082E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5090E	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5090EH	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5425N	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5725	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD PIN Prefix JO	5725HC	✓	✓	✓	✓	
John Deere	Tractors	2WD or MFWD Pin Prefix RW or LO	7330	✓	✓	✓	✓	
John Deere	Tractors	3E LV (090001 - 599999)	3032E	✓	✓	✓	✓	
John Deere	Tractors	3E LV (090001 - 599999)	3036E	✓	✓	✓	✓	
John Deere	Tractors	3E LV (090001 - 599999)	3038E	✓	✓	✓	✓	
John Deere	Tractors	3E LV (600000 -)	3032E	✓	✓	✓	✓	
John Deere	Tractors	3E LV (600000 -)	3036E	✓	✓	✓	✓	
John Deere	Tractors	3E LV (600000 -)	3038E	✓	✓	✓	✓	
John Deere	Tractors	3R LV (090001 -)	3033R	✓	✓	✓	✓	
John Deere	Tractors	3R LV (090001 -)	3038R	✓	✓	✓	✓	
John Deere	Tractors	3R LV (090001 -)	3039R	✓	✓	✓	✓	
John Deere	Tractors	3R LV (090001 -)	3045R	✓	✓	✓	✓	
John Deere	Tractors	3R LV (090001 -)	3046R	✓	✓	✓	✓	
John Deere	Tractors	4M LV (090001 -)	4044M	✓	✓	✓	✓	
John Deere	Tractors	4M LV (090001 -)	4049M	✓	✓	✓	✓	
John Deere	Tractors	4M LV (090001 -)	4052M	✓	✓	✓	✓	
John Deere	Tractors	4M LV (090001 -)	4066M	✓	✓	✓	✓	
John Deere	Tractors	4R LV (090001 -)	4044R	✓	✓	✓	✓	
John Deere	Tractors	4R LV (090001 -)	4049R	✓	✓	✓	✓	
John Deere	Tractors	4R LV (090001 -)	4052R	✓	✓	✓	✓	
John Deere	Tractors	4R LV (090001 -)	4066R	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	18RR	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9100	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9120	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9200	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9220	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9230	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9300	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9320	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9330	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9400	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9420	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9430	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9520	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9530	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9620	✓	✓	✓	✓	
John Deere	Tractors	4WD Articulated	9630	✓	✓	✓	✓	
John Deere	Tractors	4WD PIN Prefix JZ	9430	✓	✓	✓	✓	
John Deere	Tractors	5E LV (D_000001 -) iT4	5085E	✓	✓	✓	✓	
John Deere	Tractors	5E LV (D_000001 -) iT4	5100E	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	5E LV (F_400001 -) FT4	5085E	✓	✓	✓	✓	
John Deere	Tractors	5E LV (F_400001 -) FT4	5100E	✓	✓	✓	✓	
John Deere	Tractors	5G 1AT (Engine PIN: F5D) FT4 North America	5075GN	✓	✓	✓	✓	
John Deere	Tractors	5G 1AT (Engine PIN: F5D) FT4 North America	5075GV	✓	✓	✓	✓	
John Deere	Tractors	5G 1AT (Engine PIN: F5G) FT4 North America	5090GV	✓	✓	✓	✓	
John Deere	Tractors	5G 1AT (Engine PIN: F5G) FT4 North America	5100GN	✓	✓	✓	✓	
John Deere	Tractors	5M LV (000001 -) T3/S3A	5085M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (000001 -) T3/S3A	5095M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (000001 -) T3/S3A	5105M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (000001 - B 399999) T3	5095MH	✓	✓	✓	✓	
John Deere	Tractors	5M LV (000001 - B 399999) T3	5105ML	✓	✓	✓	✓	
John Deere	Tractors	5M LV (000001 - E 699999) iT4	5065M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (000001 - E 699999) iT4	5075M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (C_400001 -) iT4/S3B	5085M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (C_400001 -) iT4/S3B	5100M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (C_400001 -) iT4/S3B	5115M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (C_400001 - E 699999) iT4	5100MH	✓	✓	✓	✓	
John Deere	Tractors	5M LV (C_400001 - E 699999) iT4	5115ML	✓	✓	✓	✓	
John Deere	Tractors	5M LV (D_000001 - E 199999) iT4	5100ML	✓	✓	✓	✓	
John Deere	Tractors	5M LV (F_200001 -) FT4	5100ML	✓	✓	✓	✓	
John Deere	Tractors	5M LV (F_700001 -) FT4	5085M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (F_700001 -) FT4	5100M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (F_700001 -) FT4	5100MH	✓	✓	✓	✓	
John Deere	Tractors	5M LV (F_700001 -) FT4	5115M	✓	✓	✓	✓	
John Deere	Tractors	5M LV (F_700001 -) FT4/S3B	5075M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045GXXXXXX) (Tier 2) (SN -	6105M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045GXXXXXX) (Tier 2) (SN -	6125M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045GXXXXXX) (Tier 2) (SN	6105M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045GXXXXXX) (Tier 2) (SN	6110M	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	6M LO (Engine 4045GXXXXXX) (Tier 2) (SN	6125M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045RXXXXXX) (Interim Tier 4)	6105M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045RXXXXXX) (Interim Tier 4)	6115M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045RXXXXXX) (Interim Tier 4)	6125M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045RXXXXXX) (Interim Tier 4)	6130M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045RXXXXXX) (Interim Tier 4)	6140M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045UXXXXXX) (Final Tier 4)	6110M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045UXXXXXX) (Final Tier 4)	6120M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045UXXXXXX) (Final Tier 4)	6130M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045UXXXXXX) (Final Tier 4)	6135M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 4045UXXXXXX) (Final Tier 4)	6145M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068GXXXXXX) (Tier 2) (SN -	6140M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068GXXXXXX) (Tier 2) (SN -	6150M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068GXXXXXX) (Tier 2) (SN -	6170M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068GXXXXXX) (Tier 2) (SN	6140M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068GXXXXXX) (Tier 2) (SN	6155M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068GXXXXXX) (Tier 2) (SN	6175M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068GXXXXXX) (Tier 2) (SN	6195M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068RXXXXXX) (Interim Tier 4)	6150M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068RXXXXXX) (Interim Tier 4)	6170M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068UXXXXXX) (Final Tier 4)	6155M	✓	✓	✓	✓	
John Deere	Tractors	6M LO (Engine 6068UXXXXXX) (Final Tier 4)	6175M	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	6M LO (Engine 6068UXXXXXX) (Final Tier 4)	6195M	✓	✓	✓	✓	
John Deere	Tractors	6MC RC LO (Engine 4045RXXXXXX) (Interim Tier 4)	6090MC	✓	✓	✓	✓	
John Deere	Tractors	6MC RC LO (Engine 4045RXXXXXX) (Interim Tier 4)	6100MC	✓	✓	✓	✓	
John Deere	Tractors	6MC RC LO (Engine 4045RXXXXXX) (Interim Tier 4)	6110MC	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 4045RXXXXXX) (Interim Tier 4)	6105R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 4045RXXXXXX) (Interim Tier 4)	6115R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 4045RXXXXXX) (Interim Tier 4)	6125R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 4045RXXXXXX) (Interim Tier 4)	6130R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 4045UXXXXXX) (Final Tier 4)	6110R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 4045UXXXXXX) (Final Tier 4)	6120R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 4045UXXXXXX) (Final Tier 4)	6130R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 4045UXXXXXX) (Final Tier 4)	6135R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068RXXXXXX) (Interim Tier 4)	6140R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068RXXXXXX) (Interim Tier 4)	6150R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068RXXXXXX) (Interim Tier 4)	6170R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068RXXXXXX) (Interim Tier 4)	6190R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068RXXXXXX) (Interim Tier 4)	6210R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068RXXXXXX) (Interim Tier 4)	6210RE	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068UXXXXXX) (Final Tier 4)	6145R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068UXXXXXX) (Final Tier 4)	6155R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068UXXXXXX) (Final Tier 4)	6175R	✓	✓	✓	✓	
John Deere	Tractors	6R LO (Engine 6068UXXXXXX) (Final Tier 4)	6195R	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	6R LO (Engine 6068UXXXXX) (Final Tier 4)	6215R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (20,001-) (Final Tier 4)	6145R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (20,001-) (Final Tier 4)	6155R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (20,001-) (Final Tier 4)	6155RH	✓	✓	✓	✓	
John Deere	Tractors	6R RW (20,001-) (Final Tier 4)	6175R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (20,001-) (Final Tier 4)	6195R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (20,001-) (Final Tier 4)	6215R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (Engine 6068RXXXXX) (Interim Tier 4)	6140R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (Engine 6068RXXXXX) (Interim Tier 4)	6150R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (Engine 6068RXXXXX) (Interim Tier 4)	6150RH	✓	✓	✓	✓	
John Deere	Tractors	6R RW (Engine 6068RXXXXX) (Interim Tier 4)	6170R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (Engine 6068RXXXXX) (Interim Tier 4)	6190R	✓	✓	✓	✓	
John Deere	Tractors	6R RW (Engine 6068RXXXXX) (Interim Tier 4)	6210R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (000101-80000)	7200R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (000101-80000)	7215R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (000101-80000)	7230R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (000101-80000)	7260R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (000101-80000)	7280R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (080001-)	7210R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (080001-)	7230R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (080001-)	7250R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (080001-)	7270R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (080001-)	7290R	✓	✓	✓	✓	
John Deere	Tractors	7R RW (080001-)	7310R	✓	✓	✓	✓	
John Deere	Tractors	8R BM (000100 -)	8270R	✓	✓	✓	✓	
John Deere	Tractors	8R BM (000100 -)	8295R	✓	✓	✓	✓	
John Deere	Tractors	8R BM (000100 -)	8320R	✓	✓	✓	✓	
John Deere	Tractors	8R BM (000100 -)	8345R	✓	✓	✓	✓	
John Deere	Tractors	8R BM (000100 -)	8370R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (001001-052200)	8245R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (001001-052200)	8270R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (001001-052200)	8295R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (001001-052200)	8320R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (001001-052200)	8345R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (052201-055000)	8285R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (052201-055000)	8310R	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	8R JZ (052201-055000)	8335R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (055001 -)	8295R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (055001 -)	8320R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (055001 -)	8335R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (055001 -)	8345R	✓	✓	✓	✓	
John Deere	Tractors	8R JZ (055001 -)	8370R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (000101-053099)	8225R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (000101-053099)	8245R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (000101-053099)	8270R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (000101-053099)	8295R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (000101-053099)	8320R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (000101-053099)	8345R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (016001-090000)	8235R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (016001-090000)	8260R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (016001-090000)	8285R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (016001-090000)	8310R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (016001-090000)	8335R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (016001-090000)	8360R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (090001 -)	8245R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (090001 -)	8270R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (090001 -)	8295R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (090001 -)	8320R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (090001 -)	8335R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (090001 -)	8345R	✓	✓	✓	✓	
John Deere	Tractors	8R RW (090001 -)	8370R	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (900101-907100)	8295RT	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (900101-907100)	8320RT	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (900101-907100)	8345RT	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (902501-912000)	8310RT	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (902501-912000)	8335RT	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (902501-912000)	8360RT	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (912001 -)	8320RT	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (912001 -)	8345RT	✓	✓	✓	✓	
John Deere	Tractors	8RT RW (912001 -)	8370RT	✓	✓	✓	✓	
John Deere	Tractors	9R JZ (000101 - 001999)	9410R	✓	✓	✓	✓	
John Deere	Tractors	9R JZ (000101 - 001999)	9460R	✓	✓	✓	✓	
John Deere	Tractors	9R JZ (002000 -)	9370R	✓	✓	✓	✓	
John Deere	Tractors	9R JZ (002000 -)	9420R	✓	✓	✓	✓	
John Deere	Tractors	9R JZ (002000 -)	9470R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (000101 - 014999)	9360R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (000101 - 014999)	9410R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (000101 - 014999)	9460R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (000101 - 014999)	9510R	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	9R RW (000101 - 014999)	9560R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (015000 -)	9370R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (015000 -)	9420R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (015000 -)	9470R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (015000 -)	9520R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (015000 -)	9570R	✓	✓	✓	✓	
John Deere	Tractors	9R RW (015000 -)	9620R	✓	✓	✓	✓	
John Deere	Tractors	9RT RW (900101 - 905999)	9460RT	✓	✓	✓	✓	
John Deere	Tractors	9RT RW (900101 - 905999)	9510RT	✓	✓	✓	✓	
John Deere	Tractors	9RT RW (900101 - 905999)	9560RT	✓	✓	✓	✓	
John Deere	Tractors	9RT RW (906000 -)	9470RT	✓	✓	✓	✓	
John Deere	Tractors	9RT RW (906000 -)	9520RT	✓	✓	✓	✓	
John Deere	Tractors	9RT RW (906000 -)	9570RT	✓	✓	✓	✓	
John Deere	Tractors	9RX RW (800000 -)	9470RX	✓	✓	✓	✓	
John Deere	Tractors	9RX RW (800000 -)	9520RX	✓	✓	✓	✓	
John Deere	Tractors	9RX RW (800000 -)	9570RX	✓	✓	✓	✓	
John Deere	Tractors	9RX RW (800000 -)	9620RX	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	1025R	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	2025R	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	2032R	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	3025E	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	3120	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	3320	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	3520	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	3720	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	4062R	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	4120	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	4210	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	4310	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	4320	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	4410	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	4520	✓	✓	✓	✓	
John Deere	Tractors	Compact Utility	4720	✓	✓	✓	✓	
John Deere	Tractors	FT4 2WD or MFWD - PIN prefix 1P0 001001 - XXXXXX	6105E	✓	✓	✓	✓	
John Deere	Tractors	FT4 2WD or MFWD - PIN prefix 1P0 001001 - XXXXXX	6120E	✓	✓	✓	✓	
John Deere	Tractors	FT4 2WD or MFWD - PIN prefix 1P0 001001 - XXXXXX	6135E	✓	✓	✓	✓	
John Deere	Tractors	General Purpose Construction	2350	✓	✓	✓	✓	
John Deere	Tractors	General Purpose Construction	2355	✓	✓	✓	✓	
John Deere	Tractors	General Purpose Construction	2755	✓	✓	✓	✓	
John Deere	Tractors	iT4 2WD or MFWD - PIN prefix PO 60000-100000	6105D	✓	✓	✓	✓	
John Deere	Tractors	iT4 2WD or MFWD - PIN prefix PO 60000-100000	6115D	✓	✓	✓	✓	
John Deere	Tractors	iT4 2WD or MFWD - PIN prefix PO 60000-100000	6130D	✓	✓	✓	✓	
John Deere	Tractors	iT4 2WD or MFWD - PIN prefix PO 60000-100000	6140D	✓	✓	✓	✓	
John Deere	Tractors	iT4 2WD or MFWD - PIN Prefix PO - 050001 - 59999	6105D	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	iT4 2WD or MFWD PIN Prefix PO - 050001 - 59999	6115D	✓	✓	✓	✓	
John Deere	Tractors	iT4 2WD or MFWD PIN Prefix PO - 050001 - 59999	6130D	✓	✓	✓	✓	
John Deere	Tractors	iT4 2WD or MFWD PIN Prefix PO - 050001 - 59999	6140D	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	280	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	284	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	300	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	304	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	320	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	324	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	350	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	350-3	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	354	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	400	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	404	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	450	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	454	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	480	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	484	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	500	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	504	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	550	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	554	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	5E-704	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	5E-754	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	5E-804	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	5E-854	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	600	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	604	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	650	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	654	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	700	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	704	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	B350	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	B550	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	X550	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 China	X554	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 JDA	4035B	✓	✓	✓	✓	
John Deere	Tractors	N4 S2 JDA	5055B	✓	✓	✓	✓	
John Deere	Tractors	N4 S2&S3 China	2C-354	✓	✓	✓	✓	
John Deere	Tractors	N4 S2&S3 China	3B-504	✓	✓	✓	✓	
John Deere	Tractors	N4 S2&S3 China	3B-554	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	2C-300	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	2C-304	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	2C-350	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	3B-400	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	3B-404	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	3B-454	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	5B-554	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	5B-654	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	5B-704	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	5E-704	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	5E-754	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	5E-804	✓	✓	✓	✓	
John Deere	Tractors	N4 S3 China	5E-854	✓	✓	✓	✓	
John Deere	Tractors	None	5075GN	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1AT - Italy	5075GF	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1AT - Italy	5075GL	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1AT - Italy	5075GN	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	PIN prefix IAT - Italy	5075GV	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5080G	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5085GF	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5085GL	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5085GN	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5085GV	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5090G	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5090GH	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5100GF	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix IAT - Italy	5100GN	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix 1BM - Brazil	5303	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix 1BM - Brazil	5403	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix 1BM - Brazil	5603	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix 1BM - Brazil	5605	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix 1BM - Brazil	5705	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix 1BM - Brazil	6415	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix 1BM - Brazil	6615	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix 1BM - Brazil	7515	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1LV	5055E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1LV	5065E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1LV	5075E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	3036D	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	3036E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	4049M	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	4060M	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	5050E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	5055E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	5060E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	5065E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1PY - India	5075E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1VY - India	5036C	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1VY - India	5039C	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1VY - India	5041C	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1VY - India	5042C	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix 1VY - India	5045D	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	PIN prefix 1VY - India	5050D	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5080G	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5080GF	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5080GH	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5080GN	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5080GV	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5090G	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5090GF	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5090GH	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5090GN	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5090GV	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5100G	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5100GF	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5100GH	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5100GV	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5215	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5215F	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5215V	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5315	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5315F	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5315V	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5415	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5515	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5515F	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5515HC	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5515V	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5615	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5615F	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix AT - Italy	5615V	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix BM - Brazil	5303	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix BM - Brazil	5403	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix BM - Brazil	5603	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix BM - Brazil	5605	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix BM - Brazil	6415	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	PIN Prefix BM - Brazil	6615	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix BM - Brazil	7515	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5083E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5083EN	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5093E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5093EN	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5101E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5101EN	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5225	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5325	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5325N	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5425	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5425N	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5525	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5525N	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5603	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix LV - USA	5625	✓	✓	✓	✓	
John Deere	Tractors	Pin Prefix PX - Monterrey	5425HC	✓	✓	✓	✓	
John Deere	Tractors	Pin Prefix PX - Monterrey	54250R	✓	✓	✓	✓	
John Deere	Tractors	Pin Prefix PX - Monterrey	5725HC	✓	✓	✓	✓	
John Deere	Tractors	Pin Prefix PX - Monterrey	57250R	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix PY - India	5042D	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix PY - India	5047D	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix PY - India	5050D	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix PY - India	5103E	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix PY - India	5103S	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix PY - India	5104	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix PY - India	5203S	✓	✓	✓	✓	
John Deere	Tractors	PIN prefix PY - India	5410	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix PY or 1PY	5036C	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix PY or 1PY	5038D	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix PY or 1PY	5039D	✓	✓	✓	✓	
John Deere	Tractors	PIN Prefix PY or 1PY	5041C	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	Tier 0 2WD or MFWD - PIN prefix PO 60000-100000	6100D	✓	✓	✓	✓	
John Deere	Tractors	Tier 0 2WD or MFWD - PIN prefix PO 60000-100000	6110D	✓	✓	✓	✓	
John Deere	Tractors	Tier 0 2WD or MFWD - PIN prefix PO 60000-100000	6125D	✓	✓	✓	✓	
John Deere	Tractors	Tier 3 2WD or MFWD-PIN prefix PO 60000-100000	6100D	✓	✓	✓	✓	
John Deere	Tractors	Tier 3 2WD or MFWD-PIN prefix PO 60000-100000	6115D	✓	✓	✓	✓	
John Deere	Tractors	Tier 3 2WD or MFWD-PIN prefix PO 60000-100000	6130D	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8100T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8110T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8120T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8200T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8210T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8220T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8230T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8300T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8310T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8320T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8330T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8400T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8410T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8420T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8430T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	8520T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9300T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9320T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9400T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9420T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9430T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9520T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9530T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9620T	✓	✓	✓	✓	
John Deere	Tractors	Tracks	9630T	✓	✓	✓	✓	
John Deere	Tractors	Tractor Loader Backhoe	110	✓	✓	✓	✓	
John Deere	Tractors	YH S2 China	1654	✓	✓	✓	✓	
John Deere	Tractors	YH S2 China	1854	✓	✓	✓	✓	
John Deere	Tractors	YH S2 China	2054	✓	✓	✓	✓	
John Deere	Tractors	YH S2 China	2104	✓	✓	✓	✓	
John Deere	Tractors	YH S2&S3 JDA&Mongolia	6165J	✓	✓	✓	✓	
John Deere	Tractors	YH S2&S3 JDA&Mongolia	6185J	✓	✓	✓	✓	
John Deere	Tractors	YH S2&S3 JDA&Mongolia	6205J	✓	✓	✓	✓	
John Deere	Tractors	YH S2&S3 JDA&Mongolia	6210J	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	1204	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	1354	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-750	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-754	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-800	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-804	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-850	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-854	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-900	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-904	✓	✓	✓	✓	
John Deere	Tractors	YR S2 China	5-950	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Tractors	YR S2 China	904	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	5E-1000	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	5E-850	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	5E-850H	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	5E-854	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	5E-950	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	5E-954	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	6B-1104	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	6B-1204	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	6B-1354	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	6B-1404	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	6B-954	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	6J-1654	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	6J-1854	✓	✓	✓	✓	
John Deere	Tractors	YR S3 China	6J-2054	✓	✓	✓	✓	
John Deere	Tractors	YR S3 CIS	6095B	✓	✓	✓	✓	
John Deere	Tractors	YR S3 CIS	6110B	✓	✓	✓	✓	
John Deere	Tractors	YR S3 CIS	6135B	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6095B	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6110B	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6120B	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6135B	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6140B	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6165J	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6185J	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6205J	✓	✓	✓	✓	
John Deere	Tractors	YR S3	6210J	✓	✓	✓	✓	
John Deere	Transmission	EMD Series	EMD0630	✓	✓	✓	✓	
John Deere	Transmission	Series	AG150	✓	✓	✓	✓	
John Deere	Transmission	Series	AG250	✓	✓	✓	✓	
John Deere	Transmission	Series	AG8000	✓	✓	✓	✓	
John Deere	Transmission	Series	AG9000	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	250C	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	350C	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	350D Series II	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	400C	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	400D Series II	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	250D	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	200366-609165	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	200366-609165	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	608490 - XXXXXX	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	608490 - XXXXXX	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	609166-XXXXXX	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	609166-XXXXXX	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	XXXXXX-609165	✓	✓	✓	✓	
John Deere	Truck	Articulated Dump	XXXXXX-609165	✓	✓	✓	✓	
John Deere	Utility Vehicle Attachment	Front Blade	66	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator H Series	HPX4X2	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator H Series	HPX4X4	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator H Series Diesel	HPX4X2D	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator H Series Diesel	HPX4X4D	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator H Series Trail	HPX4X4 Trail	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator Military	M-Gator A2	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator R Series	RSX 850i	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator R Series	RSX 860i	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator Robotic	R-Gator	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
John Deere	Utility Vehicles	Gator T Series	TH6X4	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator T Series	TS4X2	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator T Series Diesel	TH6X4D	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator Turf	TXTurf	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator X Series	625i	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator X Series	825i	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator X Series	XUV 550	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator X Series	XUV 550 S4	✓	✓	✓	✓	
John Deere	Utility Vehicles	Gator X Series Diesel	855D	✓	✓	✓	✓	
John Deere	Utility Vehicles	ProGator Attachment	HD300 Sprayer	✓	✓	✓	✓	
John Deere	Vertical Tillage	Disk PIN Prefix 1EK	2623VT	✓	✓	✓	✓	
John Deere	Vertical Tillage	Disk PIN Prefix 1NO	2623VT	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	3 Point Hitch	3 Point Hitch	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Angle Broom	BA96	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Auger Planetary	PA40	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Backhoe	800	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Backhoe	850	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Backhoe	900	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Backhoe	911	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Breaker	HH40	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Breaker	HH60	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Breaker	HH80	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Cold Planer	CP12D	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Cold Planer	CP18D	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Cold Planer	CP24D	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Cold Planer	CP30D	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Mulching Head	MH60C	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Multi-Purpose Bucket	MP66B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Multi-Purpose Bucket	MP72B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Multi-Purpose Bucket	MP78B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Multi-Purpose Bucket	MP84B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Nursery Fork	NF44	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Rotary Cutters	RC60B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Rotary Cutters	RC72	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Rotary Cutters	RC72B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Rotary Cutters	RC78	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Rotary Cutters	RC78B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Rotary Cutters	RS72	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Scrap Grapple	GS88	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Blower	SB60	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Blower	SB60B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Blower	SB72B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Blower	SB78B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Blower	SB84B	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Push	SP10C	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Push	SP8C	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Utility	BV6	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Utility	BV8	✓	✓	✓	✓	
John Deere	Worksite Pro Attachment	Snow Utility	BV9	✓	✓	✓	✓	
TIMBERJACK	Alternate	Track	850	✓	✓	✓	✓	
TIMBERJACK	Bundler	Wheeled	1490D	✓	✓	✓	✓	
TIMBERJACK	Feller Buncher	Track	608	✓	✓	✓	✓	
TIMBERJACK	Feller Buncher	Track	608B	✓	✓	✓	✓	
TIMBERJACK	Feller Buncher	Track	608L	✓	✓	✓	✓	
TIMBERJACK	Feller Buncher	Track	608S	✓	✓	✓	✓	
TIMBERJACK	Feller Buncher	Track	759G	✓	✓	✓	✓	
TIMBERJACK	Feller Buncher	Track	850	✓	✓	✓	✓	
TIMBERJACK	Feller Buncher	Track	900	✓	✓	✓	✓	

Diagnostic List John Deere_v7.42

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Make	Category	Subcategory	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
TIMBERJACK	Feller Buncher	Track	950	✓	✓	✓	✓	
TIMBERJACK	Forwarder	Wheeled	1010	✓	✓	✓	✓	
TIMBERJACK	Forwarder	Wheeled	1010B	✓	✓	✓	✓	
TIMBERJACK	Forwarder	Wheeled	1010D	✓	✓	✓	✓	
TIMBERJACK	Forwarder	Wheeled	1110D	✓	✓	✓	✓	
TIMBERJACK	Forwarder	Wheeled	1410D	✓	✓	✓	✓	
TIMBERJACK	Forwarder	Wheeled	1710D	✓	✓	✓	✓	
TIMBERJACK	Forwarder	Wheeled	1711D	✓	✓	✓	✓	
TIMBERJACK	Forwarder	Wheeled	810D	✓	✓	✓	✓	
TIMBERJACK	Harvester	Track	608B	✓	✓	✓	✓	
TIMBERJACK	Harvester	Track	608L	✓	✓	✓	✓	
TIMBERJACK	Harvester	Track	608S	✓	✓	✓	✓	
TIMBERJACK	Harvester	Track	759GH	✓	✓	✓	✓	
TIMBERJACK	Harvester	Track	900	✓	✓	✓	✓	
TIMBERJACK	Harvester	Track	950	✓	✓	✓	✓	
TIMBERJACK	Harvester	Wheeled	1070D	✓	✓	✓	✓	
TIMBERJACK	Harvester	Wheeled	1270D	✓	✓	✓	✓	
TIMBERJACK	Harvester	Wheeled	1470D	✓	✓	✓	✓	
TIMBERJACK	Harvester	Wheeled	770D	✓	✓	✓	✓	
TIMBERJACK	Measuring System	Automatic Control	Timbermatic 10	✓	✓	✓	✓	
TIMBERJACK	Skidder	Cable	240	✓	✓	✓	✓	
TIMBERJACK	Skidder	Cable	240C	✓	✓	✓	✓	
TIMBERJACK	Skidder	Cable	360D	✓	✓	✓	✓	
TIMBERJACK	Skidder	Cable	460D	✓	✓	✓	✓	
TIMBERJACK	Skidder	Grapple	460D	✓	✓	✓	✓	
TIMBERJACK	Skidder	Grapple	560D	✓	✓	✓	✓	
TIMBERJACK	Skidder	Grapple	660D	✓	✓	✓	✓	
TIMBERJACK	Skidder	Single Arch Grapple	360C	✓	✓	✓	✓	
TIMBERJACK	Skidder	Single Arch Grapple	360D	✓	✓	✓	✓	
TIMBERJACK	Skidder	Single Arch Grapple	460D	✓	✓	✓	✓	
Waratah	Felling Head	Bar Saw	FL85	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	H215	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	H480C	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTD316C	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH616	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH616C	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH618C	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH620	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH622	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH622B	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH622C 4X4	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH623C	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH623C 4X4	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH624	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH625C	✓	✓	✓	✓	
Waratah	Harvester Head	Bar Saw	HTH626	✓	✓	✓	✓	
Waratah	Measuring System	Automatic Control	TimberRite H-16	✓	✓	✓	✓	
XCG	Excavators	None	210LC-8B	✓	✓	✓	✓	
XCG	Excavators	None	240LC-8B	✓	✓	✓	✓	
XCG	Excavators	None	330LC-8B	✓	✓	✓	✓	