

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System			Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H3	Delphi MT20U2_EOBD electronic control system			√	√	√	√	√	√	Read historical fault code; Oxygen sensor feedback rationality diagnosis; idle catalytic converter diagnosis; CKP learning; fault code diagnosis test
General type	Haval H3	Bosch V50 engine system			√	√	√	√	√	√	Engine test,read freeze frame
General type	Haval H3	Great Wall bosch-edc16 Diesel engine			-	√	√	√	√	-	Engine test,matching function
General type	Haval H3	Delphi MT20U engine			-	√	√	√	√	-	System state
General type	Haval H3	Liaoning Xinfeng electronic control system			√	√	√	√	-	√	Read freeze frame
General type	Haval H3	Bosch ABS system			√	√	√	√	√	-	Exhaust mode
General type	Haval H3	Jinzhou Jinheng Airbag			√	√	√	√	-	-	-
General type	Haval H3	BOSCH Airbag			√	√	√	√	-	-	-
General type	Haval H3	Continental Airbag			√	√	√	-	-	-	-
General type	Haval H3	TungThih Body control system			√	√	√	√	√	-	Network configuration; function configuration; system configuration
General type	Haval H3	Delphi Body control system			√	√	√	√	√	-	Network configuration; function configuration; system configuration
General type	Haval H3	Airbag(ABM)	TRW Airbag system		√	√	√	√	-	-	Read network configuration information; write network configuration information(manual); offline start
General type	Haval H3	Immobilizer(IMMO)	Delphi gasoline Immobilizer		-	√	√	√	-	-	User authorization code setting; anti-theft matching function
General type	Haval H3	Immobilizer(IMMO)	Delphi diesel (Bosch 2.8TC) Immobilizer		-	√	√	√	-	-	User authorization code setting; anti-theft matching function; read safty level; read engine VIN code
General type	Haval H5	Delphi gasoline(4G63 MT20) Immobilizer			√	√	√	√	-	-	Authorization code settings; Enter user authorization code
General type	Haval H5	Delphi gasoline(4G63T MT80) Immobilizer			√	√	√	√	-	-	Authorization code settings; Enter user authorization code
General type	FLORID, Haval M4	UAES ME797eobd engine system			√	√	√	√	√	√	System state
General type	FLORID, Haval M4	Siemens engine system			√	√	√	√	√	√	System state; Activate anti-theft
General type	FLORID, Haval M4	Bosch ABS			√	√	√	√	√	-	Exhaust mode
General type	FLORID, Haval M4	TIANHE ABS system			√	√	√	√	√	-	-
General type	FLORID, Haval M4	Airbag system	AUTOLIV airbag		√	√	√	√	-	-	ECU module lock
General type	FLORID, Haval M4	Airbag system	AUTOLIV airbag-CH041		√	√	√	√	-	-	-
General type	FLORID, Haval M4	Bunge_VT2_CVT system			√	√	√	√	-	-	-
General type	FLORID, Haval M4	Immobilizer			√	√	√	√	√	-	Special function
General type	COOLBEAR, Haval M2	UAES ME797eobd engine system			√	√	√	√	√	√	System state
General type	COOLBEAR, Haval M2	Bosch ABS			√	√	√	√	√	-	Exhaust mode
General type	COOLBEAR, Haval M2	TIANHE ABS system			√	√	√	√	√	-	-
General type	COOLBEAR, Haval M2	Airbag system	AUTOLIV airbag		√	√	√	√	-	-	ECU module lock
General type	COOLBEAR, Haval M2	Airbag system	AUTOLIV airbag-CH041		√	√	√	√	-	-	-
General type	COOLBEAR, Haval M2	Bunge_VT2_CVT system			√	√	√	√	-	-	-
General type	Haval H5	4D20 Delphi electronic control system			√	√	√	√	√	-	Injector code; Network configuration information

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H5	Delphi MT20U2_EOBD electronic control system			√	√	√	√	√	√	Read historical fault code; Oxygen sensor feedback rationality diagnosis; idle catalytic converter diagnosis; CKP learning; fault code diagnosis test	
General type	Haval H5	Bosch V50 engine system			√	√	√	√	√	√	Engine test	
General type	Haval H5	4D20 Bosch diesel engine system			√	√	√	√	√	-	Injector code; Network configuration information	
General type	Haval H5	4G63T engine system			√	√	√	√	√	-	Routine control	
General type	Haval H5	Bosch ABS (CAN network)			√	√	√	√	√	-	Steering sensor calibration,Network configuration information	
General type	Haval H5	Bosch ABS			√	√	√	√	√	-	Exhaust mode	
General type	Haval H5	Bosch ABS9 ESP system			√	√	√	√	√	-	Steering sensor calibration,Network configuration information, longitudinal acceleration calibration	
General type	Haval H5	Bosch Airbag (CAN network)			√	√	√	-	-	-	Network configuration information	
General type	Haval H5	BOSCH Airbag			√	√	√	√	-	-	-	
General type	Haval H5	Continental Airbag			√	√	√	-	-	-	-	
General type	Haval H5	TRW Airbag system			√	√	√	√	-	-	Read network configuration information; write network configuration information	
General type	Haval H5	Delphi Body control system			√	√	√	√	√	-	Network configuration; function configuration; system configuration	
General type	Haval H5	Delphi Body control system (CAN network)			√	√	√	√	√	-	Network configuration information; system configuration	
General type	Haval H5	TungThih Body control system			√	√	√	√	√	-	Network configuration; function configuration; system configuration	
General type	Haval H5	Continental Instrument system (CAN network)			√	√	√	√	√	-	Network configuration information	
General type	Haval H5	Hyundai Mobis_P4MFI_AT			√	√	√	√	√	-	-	
General type	Haval H5	BorgWarner TOD system(Intelligent 4-wheel drive)			√	√	√	√	√	-	-	
General type	Haval H5	Delphi gasoline Immobilizer			-	√	√	√	-	-	User authorization code setting	
General type	Haval H5	Delphi diesel(Bosch 2.8TC) Immobilizer			-	√	√	√	-	-	User authorization code setting	
General type	Haval H5	Delphi diesel(Delphi 4D20) Immobilizer			√	√	√	√	-	-	Authorization code settings; Enter user authorization code	
General type	Haval H5	Delphi diesel(Bosch 4D20) Immobilizer			√	√	√	√	-	-	Authorization code settings; Enter user authorization code	
General ty	Haval H6	4D20 Delphi electronic control system			√	√	√	√	√	-	Injector code; Read network configuration information; write network configuration information	
General ty	Haval H6	Delphi MT20U2_EOBD electronic control system			√	√	√	√	√	√	Read historical fault code; Oxygen sensor feedback rationality diagnosis; idle catalytic converter diagnosis; CKP learning; fault code diagnosis test	
General ty	Haval H6	Delphi MT80 engine			√	√	√	√	√	√	Write VIN; CKP learning	
General ty	Haval H6	4D20 Bosch diesel engine system			√	√	√	√	√	-	Network configuration information; Injector code; OBD function module	
General ty	Haval H6	4D20 Delphi Euro V engine system			√	√	√	√	√	-	Network configuration information; Injector code; OBD function module; Routine control; EGR clear self-learning; IUPR function	
General ty	Haval H6	4G15T engine electronic control system			√	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	UAES Body control system			√	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Bosch ABS (CAN network)			√	√	√	√	√	-	Steering sensor calibration,Network configuration information	
General ty	Haval H6	Bosch ABS9 ESP system			√	√	√	√	√	-	Steering sensor calibration,Network configuration information, longitudinal acceleration calibration	

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System	Function							Remarks(Other functions)	
			Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame			
General ty	Haval H6	Airbag		√	√	√	√	-	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Delphi Body control system		-	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	UAES Body control system		√	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Instrument system		-	√	√	-	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	BorgWarner TOD system		√	√	√	√	-	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Hyundai Mobis_P4MFI_AT		√	√	√	√	√	-		
General ty	Haval H6	Headlamp Leveling System		√	√	√	√	√	-		
General ty	Haval H6	A/C control system(CHB021)		√	√	√	-	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	A/C control system(CHB022)		√	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Parking Services system		√	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Keyless start system		√	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Gateway system		√	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Xiamen TungThih Immobilizer		√	√	√	√	-	-	-	
General ty	Haval H6	SICC traffic Immobilizer		√	√	√	√	√	-	-	
General ty	Haval H6	Instrument system	Delco	-	√	√	-	√	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Instrument system	YAZAKI	√	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Entertainment system	ADAYO CD system	√	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H6	Entertainment system	HSAE CD system	√	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H6	2013 MY	engine system(ECM)	UAES engine (ME788)	√	√	√	√	-	Read network configuration information; write network configuration information(manual); Read and write VIN code; IUPR	
General ty	Haval H6	2013 MY		4G15E engine electronic control system	√	√	√	√	√	√	Read network configuration information; write network configuration information(manual); Read and write VIN code; IUPR
General ty	Haval H6	2013 MY		4D20D Delphi Euro IV engine system	√	√	√	√	√	-	Routine control; Read injector code; Write injector code; Read network configuration information; write network configuration information(manual); OBD diagnosis function; IUPR function; DPF(Diesel Particulate Filter); EGR clear self-learning; Read and write VIN code
General ty	Haval H6	2013 MY	KSTAR press key type PEPS system		√	√	√	√	√	-	After-sale function; Read network configuration information; write network configuration information(manual)
General ty	Haval H6	2013 MY	KSTAR knob type PEPS system		√	√	√	√	√	-	After-sale function; Read network configuration information; write network configuration information(manual)
General ty	Haval H6	2013 MY	Transmission electronic control system (TCU)		√	√	√	√	√	-	write network configuration information
General ty	Haval H6	New H6	Engine system(ECM)	engine system(4C13)	√	√	√	√	√	-	Write VIN; write network configuration information; Read freeze frame; OBD function; VVT self-learning
General ty	Haval H6	New H6	Engine system(ECM)	engine system(4C20)	√	√	√	√	√	√	Write VIN; write network configuration information; CKP learning; IUPR function
General ty	Haval H6	New H6	Body control system(BCM)		√	√	√	√	√	-	Write VIN; write network configuration information; Special function
General ty	Haval H6	New H6	Airbag module(ABM)		√	√	√	√	-	-	Write VIN; write network configuration information; write circuit configuration word; Yaw angle calibration
General ty	Haval H6	New H6	Instrument system(IP)	Full color instrument sys	√	√	√	√	√	-	Write VIN; write network configuration information; Maintenance mileage setting
General ty	Haval H6	New H6	Instrument system(IP)	Non-full color instrument	√	√	√	√	√	-	Write VIN; write network configuration information; Special function
General ty	Haval H6	New H6	Adaptive cruise control system(ACC)		√	√	√	√	-	-	Write VIN; write network configuration information; After-sales calibration

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System	Function							Remarks(Other functions)	
			Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame			
General ty	Haval H6	New H6	Electric power steering system(EPS)		√	√	√	√	√	-	Write VIN; write network configuration information; PDC initial torque reset
General ty	Haval H6	New H6	Electronic stabilization program(ESP)		√	√	√	√	√	-	Write VIN; write network configuration information; Artificial exhaust; Yaw rate sensor calibration
General ty	Haval H6	New H6	Intelligent front view camera(IFC)		√	√	√	√	-	-	Write VIN; write network configuration information; IFVAfter-sales calibration; Write calibration date
General ty	Haval H6	New H6	Keyless start system(PEPS)		√	√	√	√	-	-	Write VIN; write network configuration information; After-sales learning
General ty	Haval H6	New H6	Parallel line assisted reverse side	left radar detection syst	√	√	√	√	-	-	Write VIN; write network configuration information; After-sales calibration
General ty	Haval H6	New H6	Parallel line assisted reverse side	Right radar detection sys	√	√	√	√	-	-	Write VIN; write network configuration information; After-sales calibration
General ty	Haval H6	New H6	Transmission control unit(T		√	√	√	√	-	-	Write function; write network configuration information
General ty	Haval H6	New H6	Transmission control unit(T		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Electronic shifter(SBWM)		√	√	√	√	-	-	Write VIN; Write classification code
General ty	Haval H6	New H6	Tire pressure monitoring system(TPMS)		√	√	√	√	-	-	Write VIN; write network configuration information; Tire pressure sensor ID learning; ABS delayed write
General ty	Haval H6	New H6	A/C control system(AC)		√	√	√	√	√	-	Write VIN; write network configuration information; Stepper motor self-learning
General ty	Haval H6	New H6	Driver seat memory system(DSM)		√	√	√	√	√	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Driver side door module(DDCM)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Front passenger side door module(PDCM)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Rear-view camera system(RVC)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Seat heating module(SHM)		√	√	√	√	-	-	Write VIN
General ty	Haval H6	New H6	Automatic parking assist system(APA)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Around view module(AVM)		√	√	√	√	-	-	Write VIN; write network configuration information; After-sales calibration
General ty	Haval H6	New H6	Electronic steering column lock(ESCL)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Independent gateway(GW)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Parking assist system(PAS)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Internet of Vehicles host system(TBOX)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Navigation host system(HUT)		√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	New H6	Steering angle sensor(SAS)		√	√	√	√	-	-	Write VIN; write network configuration information; SAS steering angle calibration
General ty	Haval H6	New H6	GLO-NASS emergency call system(GLO-NASS)		√	√	√	-	-	-	-
General ty	Haval H6	New H6	engine system (ECM)	engine system (4B13)	√	√	√	√	√	-	Write VIN; write network configuration information; VVT self-learning
General ty	Haval H6	New H6	engine system (ECM)	engine system (4B15)	√	√	√	√	√	-	Write VIN; write network configuration information; VVT self-learning
General ty	Haval H6	New H6	Continuously variable valve lift (CVVL)		√	-	-	√	-	-	Write VIN; write network configuration information
General ty	Haval H6	18 MY H6	engine system (ECM)	4G15B	√	√	√	√	√	-	Read network configuration information; write network configuration information(manual); Read and write VIN code; IUPR; VVT self-learning
General ty	Haval H6	18 MY H6	Body control system (BCM)		√	√	√	√	√	-	Write function; Tire pressure sensor learning; Tire pressure learning
General ty	Haval H6	18 MY H6	Instrument system (IP)		√	√	√	√	√	-	Write function
General ty	Haval H6	18 MY H6	Electronic stability system (ESP)		√	√	√	√	√	-	Steering sensor calibration (only for ESP); Read network configuration information; write network configuration information(automatic); write network configuration information(manual); Exhaust function; Calibration of yaw angle sensor(models with steep slope descent function)
General ty	Haval H6	18 MY H6	Independent gateway(GW)		√	√	√	√	-	-	Write function
General ty	Haval H6	18 MY H6	Electronic parking controller (EPB)		√	√	√	√	√	-	Write function;Gradient sensor calibration
General ty	Haval H6	18 MY H6	Parking assist system(PAS)		√	√	√	√	-	-	Write function
General ty	Haval H6	18 MY H6	Passive entry passive start system (PEPS)		√	√	√	√	√	-	Write function;After-sales learning
General ty	Haval H6	18 MY H6	Airbag system (ABM)		-	√	√	√	-	-	write network configuration information(automatic);write network configuration information(manual)
General ty	Haval H6	18 MY H6	A/C control system (AC)	A/C control system (AC)	√	√	√	√	√	-	write network configuration information

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function									
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)			
General ty	Haval H6	18 MY H6	A/C control system (AC)	A/C control system (AC)	√	√	√	√	√	-	write network configuration information(manual)
General ty	Haval H6	18 MY H6	Transmission control unit (1	Transmission control unit (7DCT300)	√	√	√	√	-	-	write network configuration information; Write VIN; Shift drum self-learning; Clutch self-learning; Clutch reset
General ty	Haval H6	18 MY H6	Transmission control unit (1	Transmission control system DCT	√	√	√	√	-	-	write network configuration information; Write VIN; Transmission self-learning; Clutch self-learning
General ty	Haval H6	18 MY H6	Electronic shifter (SBWM)		√	√	√	√	-	-	Write function,Write classification code
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ECM (Engine system)	4G15T engine electronic control system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ECM (Engine system)	4D20Bosch diesel engine system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ECM (Engine system)	4G15E engine electronic control system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ECM (Engine system)	4G15B engine electronic control system(ME1788)	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ECM (Engine system)	4D20 Delphi Euro V engine system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ECM (Engine system)	4D20Delphi Euro IV engine system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ECM (Engine system)	Delphi MT80 engine system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ECM (Engine system)	Delphi MT20U2_EOBD engine system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	AT(Automatic transmission system)		√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ABS(Anti-lock brake system)		√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	SRS( Airbag system)		√	√	√	√	-	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ICM/IP(Instrument panel system)	Delco Instrument control system	√	√	√	√	-	Maintenance interval setting
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ICM/IP(Instrument panel system)	YAZAKIInstrument control system	√	√	√	√	-	Maintenance interval setting
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	BCM(Body control system)	UAES Body controller	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	BCM(Body control system)	Delphi Body controller	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	AC(Auto A/C system)	A/C control system(CHB022)	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	AC(Auto A/C system)	A/C control system(CHB021)	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	PEPS(Passive entry passive start system)	KSTAR knob type PEPS system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	PEPS(Passive entry passive start system)	KSTAR press key type PEPS system	√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	TOD(4WD system)		√	√	√	√	-	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	CD(Entertainment system)	ADAYO CD system	√	√	√	√	-	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	CD(Entertainment system)	HSAE CD system	√	√	√	√	-	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	ALS(Headlamp Leveling System)		√	√	√	√	√	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	PAS(Parking Services system )		√	√	√	√	-	-
General ty	Haval H6	2013-2014 MY	CC6460RM/CC6461RM	GW(Gateway system)		√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4G15T engine electronic control system	√	√	√	√	√	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4D20Bosch diesel engine system	√	√	√	√	√	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4G15E engine electronic control system	√	√	√	√	√	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4G15B engine electronic control system(ME1788)	√	√	√	√	√	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4D20 Delphi Euro V engine system	√	√	√	√	√	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function										
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)				
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4D20 DDelphi Euro IV engine system	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	Delphi MT80 engine system	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	Delphi MT20U2_EOBD engine system	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	AT (Automatic transmission system)		√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ABS (Anti-lock brake system)		√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	SRS (Airbag system)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ICM/IP (Instrument panel system)	DelcoInstrument control system	√	√	√	-	√	-	Maintenance interval setting
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ICM/IP (Instrument panel system)	YAZAKIInstrument control system	√	√	√	-	-	-	Maintenance interval setting
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	BCM (Body control system)	UAES Body controller	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	BCM (Body control system)	Delphi Body controller	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	AC (Auto A/C system)	A/C control system (CHB022)	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	AC (Auto A/C system)	A/C control system (CHB021)	√	√	√	-	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	PEPS (Passive entry passive start system)	KSTAR knob type PEPS system	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	PEPS (Passive entry passive start system)	KSTAR press key type PEPS system	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	TOD (4WD system)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	CD (Entertainment system)	ADAYO CD system	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	CD (Entertainment system)	HSAE CD system	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	ALS (Headlamp Leveling System)		√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	PAS (Parking Services system)		√	√	√	-	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460RM/CC6461RM/CC6472RM	GW (Gateway system)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	4C20-MT92 engine system	√	√	√	√	√	√	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	4D20Bosch diesel engine system	√	√	√	√	√	√	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	engine system (4G15B)	√	√	√	√	√	√	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	engine system (4B15)	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	4D20 Delphi Euro V engine system	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT (Automatic transmission system)	Transmission control system (6DCT)	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT (Automatic transmission system)	Transmission control unit (7DCT300)	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT (Automatic transmission system)	Transmission control unit (7DCT450)	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT (Automatic transmission system)	Transmission control system 6AT	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SRS (Airbag system)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	TCP/IP (Instrument panel system)		√	√	√	-	√	-	Read and write maintenance mileage default value, Read and write maintenance mileage default value (China VI), Total mileage reset
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	EPB (Electronic parking controller)		√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ESP (Electronic stability system)		√	√	√	√	√	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function										
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)				
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	BCM(Body control system)		√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AC(A/C control system)		√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PEPS(Keyless start system)		√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	EPS(Electric steering system)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CVVL(Continuously variable valve lift)		√	-	-	√	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SBWM(Electronic shifter)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AFS(Adaptive Headlight System)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AVM(Around view module)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	RVC(Rear-view camera)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PAS(Parking Services system )	APA(Auto parking assist system)	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PAS(Parking Services system )	PAS(Parking assist system)	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	NEXTRAC(Intelligent FWD)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD(Entertainment system)	CD(Delphi CD)	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD(Entertainment system)	ADAYO CD(CD host_19 MY)	√	√	√	√	√	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD(Entertainment system)	CD(Desay SV CD)	√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ESCL(Electronic steering column lock)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	GW(Gateway system)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SAS(Steering wheel steering angle sensor)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SCM(Seat heating massage system)		√	√	√	√	-	-	-
General ty	Haval H6	2015-2016 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CMS(CAN signal conversion system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4G15T engine electronic control system	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4D20Bosch diesel engine system	√	√	√	√	√	√	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4G15E engine electronic control system	√	√	√	√	√	√	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4G15B engine electronic control system(ME1788)	√	√	√	√	√	√	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4D20 Delphi Euro V engine system	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	4D20D Delphi Euro IV engine system	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	Delphi MT80 engine system	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ECM (Engine system)	Delphi MT20U2_EOBD engine system	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	AT(Automatic transmission system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ABS(Anti-lock brake system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	SRS( Airbag system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ICM/IP(Instrument panel system)	DelcoInstrument control system	√	√	√	-	√	-	Maintenance interval setting
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ICM/IP(Instrument panel system)	YAZAKIInstrument control system	√	√	√	-	-	-	Maintenance interval setting

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System	System	ECU	Function							
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)	
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	BCM(Body control system)	UAES Body controller	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	BCM(Body control system)	Delphi Body controller	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	AC(Auto A/C system)	A/C control system(CHB022)	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	AC(Auto A/C system)	A/C control system(CHB021)	√	√	√	-	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	PEPS(Passive entry passive start system)	KSTAR knob type PEPS system	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	PEPS(Passive entry passive start system)	KSTAR press key type PEPS system	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	TOD(4WD system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	CD(Entertainment system)	ADAYO CD system	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	CD(Entertainment system)	HSAE CD system	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	ALS(Headlamp Leveling System)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	PAS(Parking Services system )		√	√	√	-	-	-	-
General ty	Haval H6	2017 MY	CC6460RM/CC6461RM/CC6472RM	GW(Gateway system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ECM (Engine system)	engine system(4B15)	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ECM (Engine system)	engine system(4B13)	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ECM (Engine system)	engine system(4C20)	√	√	√	√	√	√	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ECM (Engine system)	UAES GDChina VI (4B15A+4C20B)	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	AT(Automatic transmission system)	Transmission control unit(7DCT300)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	AT(Automatic transmission system)	Transmission control unit(7DCT450)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	SRS( Airbag system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ICM/IP(Instrument panel system)	IP(Full color instrument system)	√	√	√	√	√	-	Maintenance settings
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ICM/IP(Instrument panel system)	IP(Non-full color instrument system)	√	√	√	√	√	-	Maintenance settings
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	TPMS(Tire pressure monitoring system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ESP(Electronic stability system)		√	√	√	√	√	-	Write VIN code, Network configuration(manual), Yaw rate sensor calibration, Artificial exhaust function
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	BCM(Body control system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	AC(Auto A/C system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	PEPS(Passive entry passive start system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ESCL(Electronic steering column lock)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	SBWM(Electronic shifter)	SBWM(Electronic shifter)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	SBWM(Electronic shifter)	SBWM(Electronic shifter) (MAX)	√	√	√	-	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	EPS(Electric steering system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	SAS(Steering wheel steering angle sensor)		√	√	√	√	-	-	Write VIN code, Calibration
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	CVVL(Continuously variable valve lift)		√	-	-	√	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	GW(Gateway system)	GW(Independent gateway)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	GW(Gateway system)	GW(Independent gateway) (with EBS LIN)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	AVM(Around view module)		√	√	√	√	-	-	Write VIN code, Network configuration(manual), Electronic control unit serial number
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	RVC(Rear-view camera)		√	√	√	√	-	-	-



## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System	Function									
			Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)			
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	PAS(Parking Services system )	PAS(Parking assist system)	√	√	√	√	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	PAS(Parking Services system )	APA(Automatic parking assist system)	√	√	√	√	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	IFC(Intelligent front view camera)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	SHM(Seat heating module)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	RSDS_L(left radar detection system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	RSDS_R(Right radar detection system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	T-BOX(Internet of Vehicles host system)	TBOX(Internet of Vehicles host system)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	T-BOX(Internet of Vehicles host system)	T-BOX(Internet of Vehicles host system) (4G)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	HUT(Navigation System)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	ACC(Automatic cruise system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	DSM(Driver side seat memory module)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	DDCM(Driver side door system)		√	√	√	√	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	PDCM(Front passenger side door system)		√	√	√	√	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2017 MY	CC6461UM/CC6463UM/CC6464RM	GLO-NASS(GLO-NASS emergency call system)		√	√	√	-	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	ECM (Engine system)	4C20-MT92 engine system	√	√	√	√	√	√	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	ECM (Engine system)	4D20Bosch diesel engine system	√	√	√	√	√	√	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	ECM (Engine system)	Engine system(4G15B)	√	√	√	√	√	√	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	ECM (Engine system)	Engine system(4B15)	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	ECM (Engine system)	4D20 Delphi Euro V engine system	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	AT (Automatic transmission system)	Transmission control system(6DCT)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	AT (Automatic transmission system)	Transmission control unit(7DCT300)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	AT (Automatic transmission system)	Transmission control unit(7DCT450)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	AT (Automatic transmission system)	Transmission control system6AT	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	SRS( Airbag system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	TCP/IP (Instrument panel system)		√	√	√	-	√	-	Read and write maintenance mileage default value, Read and write maintenance mileage default value(China VI), Total mileage reset
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	EPB(Electronic parking controller)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	ESP(Electronic stability system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	BCM(Body control system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	AC(A/C control system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	PEPS(Keyless start system)		√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	EPS(Electric steering system)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	CVVL(Continuously variable valve lift)		√	-	-	√	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	SBWM(Electronic shifter)		√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	AFS(Adaptive Headlight System)		√	√	√	√	-	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System	System	System	Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	AVM(Around view module)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	RVC(Rear-view camera)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	PAS(Parking Services system )	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	PAS(Parking Services system )	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	NEXTRAC(Intelligent FWD)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	CD(Entertainment system)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	CD(Entertainment system)	√	√	√	√	√	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	CD(Entertainment system)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	ESCL(Electronic steering column lock)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	GW(Gateway system)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	SAS(Steering wheel steering angle sensor)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	SCM(Seat heating massage system)	√	√	√	√	-	-	-
General ty	Haval H6	2017 MY	CC6460UM/CC6450UM/CC6463UM/CC6465UM	CMS(CAN signal conversion system)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	ECM (Engine system)	√	√	√	√	√	√	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	AT(Automatic transmission system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	AT(Automatic transmission system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	SRS( Airbag system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	ICM/IP(Instrument panel system)	√	√	√	√	√	-	Reset maintenance mileage, Total mileage reset
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	EPB(Electronic parking controller)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	ESP(Electronic stability system)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	BCM(Body control system)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	AC(Auto A/C system)	√	√	√	-	√	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	AC(Auto A/C system)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	PEPS(Passive entry passive start system)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	SBWM(Electronic shifter)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	PAS(Parking service system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	GW(Gateway system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	CD(Entertainment system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	ACC(Automatic cruise system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	IFC(Intelligent front view camera)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	RSDS_L(left radar detection system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6461RM/CC6472RM	RSDS_R(Right radar detection system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	ECM (Engine system)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6464RM	ECM (Engine system)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6464RM	ECM (Engine system)	√	√	√	√	√	√	-
General ty	Haval H6	2019 MY	CC6464RM	ECM (Engine system)	√	√	√	√	√	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function										
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)				
General ty	Haval H6	2019 MY	CC6464RM	AT(Automatic transmission system)	Transmission control unit(7DCT300)	✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	AT(Automatic transmission system)	Transmission control unit(7DCT450)	✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	SRS( Airbag system)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	ICM/IP(Instrument panel system)	IP(Full color instrument system)	✓	✓	✓	✓	✓	-	Maintenance settings
General ty	Haval H6	2019 MY	CC6464RM	ICM/IP(Instrument panel system)	IP(Non-full color instrument system)	✓	✓	✓	✓	✓	-	Maintenance settings
General ty	Haval H6	2019 MY	CC6464RM	TPMS(Tire pressure monitoring system)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	ESP(Electronic stability system)		✓	✓	✓	✓	✓	-	Write VIN code, Network configuration(manual), Yaw rate sensor calibration, Artificial exhaust function
General ty	Haval H6	2019 MY	CC6464RM	BCM(Body control system)		✓	✓	✓	✓	✓	-	-
General ty	Haval H6	2019 MY	CC6464RM	AC(Auto A/C system)		✓	✓	✓	✓	✓	-	-
General ty	Haval H6	2019 MY	CC6464RM	PEPS(Passive entry passive start system)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	ESCL(Electronic steering column lock)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	SBWM(Electronic shifter)	SBWM(Electronic shifter)	✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	SBWM(Electronic shifter)	SBWM(Electronic shifter) (MAX)	✓	✓	✓	-	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	EPS(Electric steering system)		✓	✓	✓	✓	✓	-	-
General ty	Haval H6	2019 MY	CC6464RM	SAS(Steering wheel steering angle sensor)		✓	✓	✓	✓	-	-	Write VIN code, Calibration
General ty	Haval H6	2019 MY	CC6464RM	CWV(Continuously variable valve lift)		✓	-	-	✓	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2019 MY	CC6464RM	GW(Gateway system)	GW(Independent gateway)	✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	GW(Gateway system)	GW(Independent gateway) (with EBS LIN)	✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	AVM(Around view module)		✓	✓	✓	✓	-	-	Write VIN code, Network configuration(manual), Electronic control unit serial number
General ty	Haval H6	2019 MY	CC6464RM	RVC(Rear-view camera)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	PAS(Parking Services system )	PAS(Parking assist system)	✓	✓	✓	✓	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2019 MY	CC6464RM	PAS(Parking Services system )	APA(Automatic parking assist system)	✓	✓	✓	✓	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2019 MY	CC6464RM	IFC(Intelligent front view camera)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	SHM(Seat heating module)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	RSDS_L(left radar detection system)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	RSDS_R(Right radar detection system)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	T-BOX(Internet of Vehicles host system)	TBOX(Internet of Vehicles host system)	✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	T-BOX(Internet of Vehicles host system)	T-BOX(Internet of Vehicles host system) (4G)	✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	HUT(Navigation System)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	ACC(Automatic cruise system)		✓	✓	✓	✓	-	-	-
General ty	Haval H6	2019 MY	CC6464RM	DSM(Driver side seat memory module)		✓	✓	✓	✓	✓	-	-
General ty	Haval H6	2019 MY	CC6464RM	DDCM(Driver side door system)		✓	✓	✓	✓	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2019 MY	CC6464RM	PDCM(Front passenger side door system)		✓	✓	✓	✓	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2019 MY	CC6464RM	GLO-NASS(GLO-NASS emergency call system)		✓	✓	✓	-	-	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function										
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)				
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	4C20-MT92 engine system	√	√	√	√	√	√	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	4D20Bosch diesel engine system	√	√	√	√	√	√	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	Engine system(4G15B)	√	√	√	√	√	√	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	Engine system(4B15)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM (Engine system)	4D20 Delphi Euro V engine system	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT (Automatic transmission system)	Transmission control system(6DCT)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT (Automatic transmission system)	Transmission control unit(7DCT300)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT (Automatic transmission system)	Transmission control unit(7DCT450)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT (Automatic transmission system)	Transmission control system6AT	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SRS( Airbag system)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	TCP/IP(Instrument panel system)		√	√	√	-	√	-	Read and write maintenance mileage default value, Read and write maintenance mileage default value(China VI), Total mileage reset
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	EPB(Electronic parking controller)		√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ESP(Electronic stability system)		√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	BCM(Body control system)		√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AC(A/C control system)		√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PEPS(Keyless start system)		√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	EPS(Electric steering system)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CVVL(Continuously variable valve lift)		√	-	-	√	-	-	Write VIN code, Network configuration(manual)
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SBWM(Electronic shifter)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AFS(Adaptive Headlight System)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AVM(Around view module)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	RVC(Rear-view camera)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PAS(Parking Services system )	APA(Auto parking assist system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PAS(Parking Services system )	PAS(Parking assist system)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	NEXTRAC(Intelligent FWD)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD(Entertainment system)	CD(Delphi CD)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD(Entertainment system)	ADAYO CD(CD host_19 MY)	√	√	√	√	√	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD(Entertainment system)	CD(Desay SV CD)	√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ESCL(Electronic steering column lock)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	GW(Gateway system)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SAS(Steering wheel steering angle sensor)		√	√	√	√	-	-	-
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SCM(Seat heating massage system)		√	√	√	√	-	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System			Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General ty	Haval H6	2019 MY	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CMS (CAN signal conversion system)	√	√	√	√	√	-	-
General ty	Haval H6	COUPE		Transmission control system	√	√	√	√	-	-	write network configuration information; Write VIN; Shift drum self-learning; Clutch self-learning
General ty	Haval H6	COUPE		Transmission control system	√	√	√	√	√	-	write network configuration information
General ty	Haval H6	COUPE		Transmission control system	√	√	√	√	-	-	write network configuration information; Write VIN; Shift drum self-learning; Clutch self-learning; Clutch reset
General ty	Haval H7	Body control system(BCM)			√	√	√	√	√	-	Write VIN; write network configuration information; Special function
General ty	Haval H7	Electronic stabilization program(ESP)			√	√	√	√	√	-	Write VIN; write network configuration information; Artificial exhaust; Yaw rate sensor calibration
General ty	Haval H7	Airbag module(ABM)			√	√	√	√	-	-	Write VIN; write network configuration information; IMU static calibration; EOL function
General ty	Haval H7	A/C system(AC)			√	√	√	√	√	-	Write VIN; write network configuration information
General ty	Haval H7	Automatic Headlamp Leveling System(ALS)			√	√	√	√	√	-	Write VIN; write network configuration information; Horizontal zero calibration
General ty	Haval H7	Auto parking assist system(APA)			√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H7	Instrument system(IP)	Delphi Instrument system		√	√	√	√	√	-	Write VIN; write network configuration information; Maintenance settings
General ty	Haval H7		Bosch Instrument system		√	√	√	√	√	-	Write VIN; write network configuration information; Maintenance function
General ty	Haval H7	Lane Departure Warning System(LDW)			√	√	√	√	-	-	Write VIN; write network configuration information; IFVAfter-sales calibration; Write calibration date
General ty	Haval H7	Adaptive cruise control system(ACC)			√	√	√	√	-	-	Write VIN; write network configuration information; After-sales calibration
General ty	Haval H7	Parking assist system(PAS)			√	√	√	√	-	-	Write VIN; Write vehicle configuration information
General ty	Haval H7	Front passenger side door module(PDCM)			√	√	√	-	-	-	Write VIN; Write vehicle configuration information; Read vehicle configuration information
General ty	Haval H7	Steering angle sensor(SAS)			√	√	√	√	-	-	Write VIN; SAS Calibration; SAS Decalibration
General ty	Haval H7	KSTAR press key type PEPS system			√	√	√	√	√	-	After-sale function; Read network configuration information; write network configuration information(manual)
General ty	Haval H7	Independent gateway(GW)			√	√	√	-	-	-	Read network configuration information; Write VIN; write network configuration information
General ty	Haval H7	Internet of Vehicles host system(T-Box)			√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H7	Around view module(AVM)			√	√	√	-	-	-	Read network configuration information; Write VIN; write network configuration information; EOL calibration
General ty	Haval H7	Navigation host system(HUT)			√	√	√	-	-	-	Read network configuration information; Write VIN; write network configuration information
General ty	Haval H7	CAN signal conversion system(CMS)			√	√	√	√	√	-	CMS model learning;write network configuration information
General ty	Haval H7	Driver side door control system(DDCM)			√	√	√	-	-	-	Read network configuration information; Write VIN; write network configuration information
General ty	Haval H7	Seat memory system(DSM)			√	√	√	-	√	-	Read network configuration information; Write VIN; write network configuration information
General ty	Haval H7	Seat heating massage system(SCM)			√	√	√	-	-	-	Read network configuration information; Write VIN; write network configuration information
General ty	Haval H7	Rear-view camera system(RVC)			√	-	-	-	-	-	Read network configuration information; Write VIN; write network configuration information
General ty	Haval H7	Parallel line auxiliary side warning(RSDS)	left radar detection system(RSDS-L)		√	√	√	√	-	-	write network configuration information; After-sales calibration; After-sales calibration result reading
General ty	Haval H7		Right radar detection system(RSDS-R)		√	√	√	√	-	-	write network configuration information; After-sales calibration; After-sales calibration result reading
General ty	Haval H7	Electric power steering system(EPS)			√	√	√	√	-	-	Write VIN; write network configuration information
General ty	Haval H7	Transmission control system DCT			√	√	√	√	-	-	write network configuration information; Write VIN; Gearbox self-learning; Clutch self-learning
General ty	Haval H7	EBS data monitoring			-	-	-	√	-	-	-
General ty	Haval H8	engine system(ECM)	MT92		√	√	√	√	√	√	Read system configuration; Read network configuration information; write network configuration information (manual); CKP learning; Write VIN; IUPR; Read VIN code
General ty	Haval H8		MT92 (6AT+ACC+T-Box)		√	√	√	√	-	-	Read network configuration information; write network configuration information(manual); Write VIN
General ty	Haval H8	Rain light sensor(RLS)			-	-	-	-	-	-	Rain sensor initialization routine

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System	Function							Remarks(Other functions)
			Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame		
General ty	Haval H8	Entertainment system(CD) Old CD system	√	√	√	-	-	-	Read network configuration information; write network configuration information(manual)	
General ty	Haval H8	2016 CD system	√	√	√	-	-	-	Vehicle configuration information; write network configuration information	
General ty	Haval H8	Adaptive cruise control system(ACC)	√	√	√	√	-	-	write network configuration information; Write VIN; After-sales calibration	
General ty	Haval H8	Internet of Vehicles host system(T-box) Old T-BOX system	√	√	√	√	-	-	write network configuration information	
General ty	Haval H8	2016 T-BOX system	√	√	√	√	-	-	write network configuration information	
General ty	Haval H8	Around view module(AVM)	√	√	√	-	-	-	Vehicle configuration information; After-sales calibration; write network configuration information	
General ty	Haval H8	Seat heating massage system(SCM)	√	√	√	-	-	-	Read network configuration information	
General ty	Haval H1	engine electronic control system(ECM)	√	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H1	Anti-lock brake system(ABS)	√	√	√	√	√	-	Read network configuration information; write network configuration information; Steering sensor calibration; longitudinal acceleration calibration	
General ty	Haval H1	Body control system(BCM)	√	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H1	Instrument system(IP)	-	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H1	Electric power steering system	√	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H1	SICC traffic Immobilizer	√	√	√	√	√	-	EOL function, change engine EMS, Replace transponder, Replace the anti-theft device	
General ty	Haval H1	GETRAG AMT transmission(UAES )	√	√	√	√	√	-	Write VIN, Write TSN code, TCU reset	
General ty	Haval H1	CHO41 AUTOLIV Airbag system	√	√	√	√	-	-	Write configuration information	
General ty	Haval H2	engine electronic control system(ECM)	√	√	√	√	√	√	Read network configuration information; write network configuration information;Read and write VIN code;IUPR;VVT self-learning	
General ty	Haval H2	Anti-lock brake system(ABS)	√	√	√	√	√	-	Read network configuration information; write network configuration information;Exhaust function	
General ty	Haval H2	Airbag system(SRS)	√	√	√	√	√	-	Read network configuration information; write network configuration information,Circuit configuration	
General ty	Haval H2	Body controller system(BCM)	√	√	√	√	√	-	Read network configuration information; write network configuration information;Tire pressure sensor learning;Tire pressure sensor learning(new);Clear tire pressure ID with one key	
General ty	Haval H2	Electric power steering system(EPS)	√	√	√	√	-	-	Read network configuration information; write network configuration information;Steering sensor calibration	
General ty	Haval H2	Electronic steering column lock(ESCL)	√	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H2	Gateway(GW)	√	√	√	-	-	-	Read network configuration information; write network configuration information	
General ty	Haval H2	Gateway(GW) Gateway(Continental )	√	√	√	√	-	-	Write function	
General ty	Haval H2	BorgWarner TOD system	√	√	√	√	-	-	Read network configuration information; write network configuration information	
General ty	Haval H2	Keyless start system(PEPS)	√	√	√	√	√	-	Read network configuration information; write network configuration information;After-sale function	
General ty	Haval H2	Rear-view camera(RVC)	√	√	√	-	-	-	Read network configuration information; write network configuration information;EOL calibration	
General ty	Haval H2	Instrument system(IP)	√	√	√	√	√	-	Read network configuration information; write network configuration information; Reset the odometer;Mileage reset	
General ty	Haval H2	A/C control system(AC)	√	√	√	√	√	-	Read network configuration information; write network configuration information	
General ty	Haval H2	A/C control system(AC) Red tab	√	√	√	√	√	-	Read network configuration information;write network configuration information(manual)	
General ty	Haval H2	A/C control system(AC) Blue tab	√	√	√	√	√	-	Write function	
General ty	Haval H2	Headlamp Leveling System(ALS)	√	√	√	√	√	-	Read network configuration information; write network configuration information; Horizontal zero calibration	
General ty	Haval H2	Steering wheel steering angle sensor(SAS)	√	√	√	√	-	-	Read network configuration information; write network configuration information; Calibration; Decalibration	
General ty	Haval H2	Intelligent 4-wheel drive(TOD)	√	√	√	√	√	-	Read network configuration; write network configuration information(manual)	
General ty	Haval H2	Transmission electronic control system(TCU)	√	√	√	√	√	-	write network configuration information	

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System	Function							Remarks(Other functions)
			Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame		
General ty	Haval H2	Electronic stabilization program(ESP)		√	√	√	√	√	-	write network configuration information; Artificial exhaust; Yaw rate sensor calibration; APBMI initial setup
General ty	Haval H2	CAN signal conversion system(CMS)		√	√	√	√	-	-	CMS model learning; write network configuration information
General ty	Haval H2	CD host(CD/MP5)		√	-	-	√	-	-	Write function
General ty	Haval H2	Transmission control unit (TCU)	Transmission electronic control system (6AT)	√	√	√	√	√	-	write network configuration information
General ty	Haval H2	Transmission control unit (TCU)	Transmission control unit(7DCT300)	√	√	√	√	-	-	Write VIN;write network configuration information;Shift drum self-learning;Clutch self-learning;Clutch reset
General ty	Haval H2	Electronic shifter (SBWM)		√	√	√	√	-	-	Write function;Write classification code
General ty	Haval H2s	Engine control unit(ECM)		√	√	√	√	√	√	Write function; write network configuration information; EBS battery ID flashing;OBD function;VVT self-learning
General ty	Haval H2s	Body control system(BCM)		√	√	√	√	√	-	Write function; Remote control key matching(low configuration); write network configuration information;System configuration word modification
General ty	Haval H2s	Airbag module(ABM)		√	√	√	√	-	-	Write function; write network configuration information; write circuit configuration word
General ty	Haval H2s	Instrument system(IP)		√	√	√	√	√	-	Write VIN; Maintenance mileage reset; Total mileage reset; write network configuration information
General ty	Haval H2s	Keyless start system(PEPS)		√	√	√	√	-	-	Write function; After-sales learning; write network configuration information
General ty	Haval H2s	Electronic power system(EPS)		√	√	√	√	-	-	Write function; EPS replacement calibration; write network configuration information
General ty	Haval H2s	A/C system(AC)		√	√	√	√	√	-	Write function; write network configuration information
General ty	Haval H2s	Rear-view camera(RVC)		√	√	√	√	-	-	Write function; write network configuration information
General ty	Haval H2s	Navigation host system(HUT)		√	√	√	√	-	-	Write function; write network configuration information
General ty	Haval H2s	Independent gateway(GW)		√	√	√	√	-	-	Write function; write network configuration information
General ty	Haval H2s	Electronic steering column lock(ESCL)		√	√	√	√	-	-	Write function; write network configuration information
General ty	Haval H2s	Steering angle sensor(SAS)		√	√	√	√	-	-	Write VIN; Write vehicle configuration information; SAS steering angle calibration;
General ty	Haval H2s	Tire pressure monitoring system(TPMS)		√	√	√	√	-	-	Write function; ABS delayed write; write network configuration information;Tire pressure sensor ID learning
General ty	Haval H2s	Electronic stabilization program(ESP)		√	√	√	√	√	-	Write function; Special operation; Artificial exhaust; write network configuration information
General ty	Haval H2s	Transmission control unit(TCU)		√	√	√	√	-	-	Write function; write network configuration information
General ty	Haval H2s	Parking Services system(PAS)		-	-	-	-	-	-	Radar parameter configuration
General ty	Haval H2s	Electronic shifter(SBWM)		√	√	√	√	-	-	Write function; Write classification code
General ty	Haval H2s	SICC traffic Immobilizer		√	√	√	√	√	-	EOL function; change engine EMS; Replace transponder; Replace the anti-theft device
General ty	Haval H2s	Transmission control unit (TCU)	Transmission control unit (7DCT300)	√	√	√	√	√	-	Write VIN;write network configuration information;Shift drum self-learning;Clutch self-learning;Clutch reset
General ty	Haval H2s	Transmission control unit (TCU)	Transmission control unit (7DCT450)	√	√	√	√	-	-	write network configuration information;Transmission self-learning;Read and write function;Close DEV CAN function
General ty	Haval H2s	Parking Services system(PAS)	4/8 probe model	-	-	-	-	-	-	Front Radar parameter configuration;Rear radar parameter configuration
General ty	Haval H2s	Parking Services system(PAS)	3/5 probe model	-	-	-	-	-	-	Front Radar parameter configuration;Rear radar parameter configuration
General type	Haval H4	ECM (Engine system)	engine system (4B13)	√	√	√	√	√	√	Write VIN, write network configuration information, OBD function, VVT self-learning
General type	Haval H4	ECM (Engine system)	engine system (4C20)	-	√	√	√	√	-	Write VIN, CKP learning
General type	Haval H4	ECM (Engine system)	engine system (4B15)	√	√	√	√	√	√	Write VIN, write network configuration information, OBD function, VVT self-learning
General type	Haval H4	ABM ( Airbag system)		√	√	√	√	-	-	Write VIN, write network configuration information
General type	Haval H4	BCM(Body control system)		√	√	√	√	√	-	Write VIN, write network configuration information, Read the final calibration parameters of the DDD fatigue driving algorithm, Write DDD fatigue driving algorithm final Calibration parameter adjustment, Read system configuration, Write system configuration, Electric tailgate self-learning (PLG)
General type	Haval H4	HUT (Navigation host system)		√	√	√	√	-	-	Write VIN, Write network configuration
General type	Haval H4	GW (Gateway)		√	√	√	√	-	-	Write VIN, write network configuration information

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function							Remarks(Other functions)			
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame					
General type	Haval H4	AC (A/C control system)						√	√	√	-	Write function, write network configuration information
General type	Haval H4	AVM (Around view module)						-	√	√	-	Write VIN, write network configuration information
General type	Haval H4	EPS (Electric power steering system)						√	√	√	-	Write function, EPS replacement calibration, write network configuration information
General type	Haval H4	ESCL (Electronic steering column lock)						√	√	√	-	Write function, write network configuration information
General type	Haval H4	ESP (Electronic stabilization program)						√	√	√	-	Write VIN, write network configuration information, Artificial exhaust, Yaw rate sensor calibration
General type	Haval H4	IFC (Intelligent Front View Control Module)						√	√	√	-	Write VIN, write network configuration information, IFVAfter-sales calibration, Write calibration date
General type	Haval H4	IP(Instrument system)		IP (Full color instrument system)				√	√	√	-	Write VIN, write network configuration information, Maintenance settings
General type	Haval H4	IP(Instrument system)		Non-full color instrument system (IP)				√	√	√	-	Write VIN, write network configuration information, Maintenance settings
General type	Haval H4	PAS (Parking Services system )						√	√	√	-	Write VIN, write network configuration information
General type	Haval H4	PEPS (Passive entry passive start system)						√	√	√	-	Write VIN, write network configuration information
General type	Haval H4	RSDS (Parallel line assisted reverse side warning)		left radar detection system (RSDS_L)				√	√	√	-	Write VIN, write network configuration information, After-sales calibration
General type	Haval H4	RSDS (Parallel line assisted reverse side warning)		Right radar detection system (RSDS_R)				√	√	√	-	Write VIN, write network configuration information, After-sales calibration
General type	Haval H4	RVC (Rear-view camera)						√	√	√	-	Write VIN, write network configuration information
General type	Haval H4	SAS (Steering angle sensor)						√	√	√	-	Write function, SAS (Steering angle calibration)
General type	Haval H4	SBWM (Electronic shifter)						√	√	√	-	Write VIN
General type	Haval H4	SHM (Seat heating module)						√	√	√	-	Write VIN
General type	Haval H4	T-BOX (Internet of Vehicles host system)						√	√	√	-	Write VIN, write network configuration information
General type	Haval H4	Trailer Module (Trailer Module)						√	√	√	-	Write VIN
General ty	Haval H8	engine electronic control system(ECM)						√	√	√	√	Read network configuration information; write network configuration information
General ty	Haval H8	Airbag(ABM)						√	√	√	-	Read network configuration information; write network configuration information
General ty	Haval H8	Body controller system(BCM)						√	√	√	√	Read network configuration information; write network configuration information
General ty	Haval H8	Transmission electronic control system(TCU)						√	√	√	-	Read network configuration information; write network configuration information
General ty	Haval H8	Electronic stability system(ESP)						√	√	√	-	Read network configuration information; write network configuration information
General ty	Haval H8	Driver side door system(DDCM)						√	√	√	-	Read network configuration information; write network configuration information
General ty	Haval H8	Front passenger side door system(PDCM)						√	√	√	-	Read network configuration information; write network configuration information
General ty	Haval H8	Driver side seat memory system(DSM)						√	√	√	-	Read network configuration information; write network configuration information
General ty	Haval H8	Passive entry passive start system(PEPS)						√	√	√	√	Read network configuration information; write network configuration information
General ty	Haval H8	Gateway(GW)						√	√	√	-	Read network configuration information; write network configuration information
General ty	Haval H8	Instrument system(IP)						√	√	√	-	Read network configuration information; write network configuration information; Reset the odometer; Total mileage reset
General ty	Haval H8	Parking Services system(PAS)		Front				√	-	-	-	-



## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System			Function							
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)	
General ty	Haval H8	Parking Services system(PAS)		Rear	√	-	-	-	-	-	-	-
General ty	Haval H8	Rear-view camera(RVC)			√	-	-	-	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H8	Adaptive Headlight System(AFS)			√	√	√	√	√	-	-	Read network configuration information; write network configuration information; Horizontal zero calibration
General ty	Haval H8	A/C control system(AC)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H8	Entertainment system(CD)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H8	Steering wheel steering angle sensor(SAS)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information; Calibration; Decalibration
General ty	Haval H8	Intelligent 4-wheel drive(TOD)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	engine electronic control system(ECM)			√	√	√	√	√	-	-	Read network configuration information; write network configuration information;Read system configuration;CKP learning;IUPR;Write VIN
General ty	Haval H9	Airbag(ABM)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information;IMU static calibration
General ty	Haval H9	Body controller system(BCM)			√	√	√	√	√	-	-	Read network configuration information; write network configuration information;Write four tire pressure sensor ID;Tire pressure sensor learning
General ty	Haval H9	Electronic stability system(ESP)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	KSTAR press key type PEPS system			√	√	√	√	√	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	Gateway(GW)			√	√	√	-	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	Instrument system(IP)			√	√	√	-	√	-	-	Read network configuration information; write network configuration information; Reset the odometer; Total mileage reset
General ty	Haval H9	Adaptive Headlight System(AFS)			√	√	√	√	√	-	-	Read network configuration information; write network configuration information;Horizontal zero calibration
General ty	Haval H9	Entertainment system(CD)			√	√	√	-	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	Intelligent 4-wheel drive(TOD)			√	√	√	√	√	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	Parking Services system(PAS)		Front	√	-	-	-	-	-	-	-
General ty	Haval H9	Parking Services system(PAS)		Rear	√	-	-	-	-	-	-	-
General ty	Haval H9	A/C control system(HCM)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	Electronic parking brake(EPB)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information; Gradient sensor calibration
General ty	Haval H9	Transmission electronic control system(TCU)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information; Reset adaptive value
General ty	Haval H9	Transmission electronic control system			√	√	√	√	-	-	-	Current power transmission system diagnostic data; Power transmission system freeze frame data; Power transmission system fault codes related to emissions; Clear/reset and discharge related diagnostic information; Emission-related failures in the current or last posture cycle; Vehicle Information
General ty	Haval H9	Transmission electronic control system			√	√	√	√	-	-	-	Current power transmission system diagnostic data; Power transmission system freeze frame data; Power transmission system fault codes related to emissions; Clear/reset and discharge related diagnostic information; Emission-related failures in the current or last posture cycle; Vehicle Information
General ty	Haval H9	Driver side door system(DDCM)			√	√	√	-	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	Front passenger side door system(PDCM)			√	√	√	-	-	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	Driver side seat memory system(DSM)			√	√	√	-	√	-	-	Read network configuration information; write network configuration information
General ty	Haval H9	Rear-view camera(RVC)			√	-	-	-	-	-	-	Read network configuration information; write network configuration information; EOL calibration
General ty	Haval H9	Steering wheel steering angle sensor(SAS)			√	√	√	√	-	-	-	Read network configuration information; write network configuration information; Calibration
General ty	Haval H9	Rain light sensor(RLS)			-	-	-	-	-	-	-	Rain sensor initialization routine
General ty	Haval H9	Electronic differential lock(EGD)			√	√	√	√	-	-	-	write network configuration information

## Diagnostic List HAVAL\_v10.52

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System			Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General ty	Haval H9	Entertainment system(CD)		Old CD system	✓	✓	✓	-	-	-	Read network configuration information; write network configuration information(manual)
General ty	Haval H9			2016 CD system	✓	✓	✓	-	-	-	Vehicle configuration information; write network configuration information
General ty	Haval H9	Internet of Vehicles host system(T-box)		Old T-BOX system	✓	✓	✓	✓	-	-	Write VIN; write network configuration information
General ty	Haval H9			2016 T-BOX system	✓	✓	✓	✓	-	-	write network configuration information
General ty	Haval H9	Intelligent Front View Control Module(IFV)			✓	✓	✓	✓	-	-	IFVAfter-sales calibration; Write calibration date; write network configuration information
General ty	Haval H9	Around view module(AVM)			✓	✓	✓	-	-	-	Vehicle configuration information; After-sales calibration; write network configuration information
General ty	Haval H9	Adaptive cruise control system(ACC)			✓	✓	✓	✓	-	-	write network configuration information; Write VIN; After-sales calibration
General ty	Haval H9	Seat heating massage system(SCM)			✓	✓	✓	-	-	-	Read network configuration information
General ty	Haval H6COUPE	4G15BUAES ME1788 engine system			✓	✓	✓	✓	✓	-	Read network configuration information; write network configuration information(manual); Read and write VIN code; IUPR
General ty	Haval H6COUPE	Delphi CD(CD)			✓	✓	✓	✓	-	-	write network configuration information
General ty	Haval H6COUPE	Desay SV CD(CD)			✓	✓	✓	✓	-	-	Write VIN; write network configuration information
General ty	Haval H6COUPE	Transmission control system(6DCT)			✓	✓	✓	✓	-	-	write network configuration information; Write VIN; Transmission self-learning; Clutch self-learning
General ty	Haval H6COUPE	Transmission control system6AT			✓	✓	✓	✓	✓	-	write network configuration information
General ty	Haval H6COUPE	Transmission control unit(7DTC300)			✓	✓	✓	✓	-	-	Write function; write network configuration information
General ty	Haval H6COUPE	Parking assist system(PAS)			✓	✓	✓	✓	-	-	write network configuration information
General ty	Haval H6COUPE	Seat ventilation heating module(SCM)			✓	✓	✓	✓	-	-	Write function
General ty	Haval H6COUPE	Electronic shifter(SBWM)			✓	✓	✓	✓	-	-	Write function; Write classification code
General ty	Haval H6COUPE	Around view module(AVM)			✓	✓	✓	✓	-	-	Write VIN; write network configuration information
General ty	Haval H6COUPE	Rear-view camera(RVC)			✓	✓	✓	✓	-	-	Write VIN; write network configuration information
General ty	Haval H6COUPE	4C20-MT92 engine system			✓	✓	✓	✓	✓	-	Read network configuration information; write network configuration information(manual); Read system configuration; CKP learning; IUPR; Write VIN
General ty	Haval H6COUPE	4D20 Bosch diesel engine system			✓	✓	✓	✓	✓	-	Read network configuration information; write network configuration information(manual); Injector code
General ty	Haval H6COUPE	4D20 Bosch diesel engine system OBD function			-	-	-	-	-	-	Current power transmission system diagnostic data; Power transmission system freeze frame data; Power transmission system fault codes related to emissions; Clear/reset and discharge related diagnostic information; Vehicle Information
General ty	Haval H6COUPE	4D20 Delphi Euro V engine system			✓	✓	✓	✓	✓	-	Read network configuration information; write network configuration information(manual); Injector code; Routine control; EGR clear self-learning; Read and write VIN code
General ty	Haval H6COUPE	4D20 Delphi Euro V engine system OBD function			-	-	-	-	-	-	OBD diagnosis function; IUPR function
General ty	Haval H6COUPE	Keyless start system(PEPS)			✓	✓	✓	✓	✓	-	Read network configuration information; write network configuration information(manual)
General ty	Haval H6COUPE	Instrument(IP)			✓	✓	✓	-	✓	-	Read network configuration information; write network configuration information(manual); Reset maintenance mileage表; Total mileage reset
General ty	Haval H6COUPE	Body control(BCM)			✓	✓	✓	✓	✓	-	write network configuration information(manual); Tire pressure sensor learning; Read system configuration; Write system configuration; Write VIN
General ty	Haval H6COUPE	Airbag(ABM)			✓	✓	✓	✓	-	-	write network configuration information(manual); Write VIN
General ty	Haval H6COUPE	A/C control system(AC)			✓	✓	✓	✓	✓	-	write network configuration information(manual)
General ty	Haval H6COUPE	Electronic parking controller(EPB)			✓	✓	✓	✓	✓	-	write network configuration information(manual); Gradient sensor calibration

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function							Remarks(Other functions)	
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame			
General ty	Haval H6COUPE	Electric power steering system(EPS)	√	√	√	√	-	-	write network configuration information(manual); Steering sensor calibration; Write VIN	
General ty	Haval H6COUPE	Electronic stability system(ESP)	√	√	√	√	√	-	write network configuration information(manual); Yaw rate sensor calibration	
General ty	Haval H6COUPE	Automatic Headlamp Leveling System(AFS)	√	√	√	√	-	-	write network configuration information(manual); Horizontal zero calibration	
General ty	Haval H6COUPE	Auto parking assist system(APA)	√	√	√	√	-	-	write network configuration information(manual)	
General ty	Haval H6COUPE	Entertainment system(CD)	√	√	√	√	-	-	write network configuration information(manual)	
General ty	Haval H6COUPE	Electronic steering column lock(ESCL)	√	√	√	√	-	-	write network configuration information(manual)	
General ty	Haval H6COUPE	Gateway(GW)	√	√	√	√	-	-	write network configuration information(manual)	
General ty	Haval H6COUPE	Intelligent FWD(NEXTRAC)	√	√	√	√	-	-	write network configuration information(manual)	
General ty	Haval H6COUPE	Steering angle sensor(SRS)	√	√	√	√	-	-	write network configuration information(manual); Write VIN; SASCalibration; SAS Decalibration	
General ty	Haval H6COUPE	Transmission control system(DTC)	√	√	√	√	-	-	write network configuration information(manual); Write VIN	
General ty	Haval H6COUPE	CAN signal conversion system(CMS)	√	√	√	√	√	-	CMS model learning	
General ty	Haval M6	ECM (Engine system)	Delphi MT80 engine system	√	√	√	√	√	√	Write VIN, CKP learning, Write VIN(new), Read VIN code
General ty	Haval M6	ECM (Engine system)	4D20 Delphi Euro V engine system	√	√	√	√	√	-	Routine control, Read injector code, Write injector code, Read network configuration information, write network configuration information(automatic), write network configuration information(manual), IUPR, DPF (Diesel Particulate Filter), EGR clear self-learning, Read and write VIN code
General ty	Haval M6	ECM (Engine system)	4D20Bosch diesel engine system (2013 MY)	√	√	√	√	√	√	Read network configuration information, write network configuration information(automatic), Engine test, write network configuration information(manual), Read injector code, Write injector code(Write all), Write injector code(single), OBD function, EGR self-learning function
General ty	Haval M6	ECM (Engine system)	4G15T engine electronic control system (ME788)	√	√	√	√	√	√	Read network configuration information, write network configuration information(manual), Read and write VIN code, IUPR, VVT self-learning
General ty	Haval M6	ECM (Engine system)	4G15B engine electronic control system (ME1788)	√	√	√	√	√	√	Read network configuration information, write network configuration information(manual), Read and write VIN code, IUPR, VVT self-learning
General ty	Haval M6	ECM (Engine system)	4G15E engine electronic control system	√	√	√	√	√	√	Read network configuration information, write network configuration information(manual), Read and write VIN code, IUPR, VVT self-learning
General ty	Haval M6	ECM (Engine system)	4G20DDelphi Euro IV engine system	√	√	√	√	√	-	Routine control, Read injector code, Write injector code, Read network configuration information, write network configuration information(manual), OBD diagnosis function, IUPR function, DPF (Diesel Particulate Filter), EGR clear self-learning, Read and write VIN code
General ty	Haval M6	ESP (Electronic stabilization program)		√	√	√	√	√	-	Steering sensor calibration (only for ESP), Read network configuration information, write network configuration information(manual), write network configuration information(automatic), Exhaust function, Calibration of yaw angle sensor(models with steep slope descent function)
General ty	Haval M6	TCU (Transmission system)		√	√	√	√	√	-	write network configuration information, Shift drum self-learning, Clutch self-learning, Clutch reset
General ty	Haval M6	BCM(Body control system)		√	√	√	√	√	-	Write function, Tire pressure learning, system configuration
General ty	Haval M6	PAS (Parking Services system )		√	√	√	-	-	-	Vehicle configuration information, Write function
General ty	Haval M6	EPB (Electronic parking controller)		√	√	√	√	√	-	Write function, Gradient sensor calibration, Read deep fault code
General ty	Haval M6	T-BOX (Internet of Vehicles host system)		√	√	√	√	-	-	Write function
General ty	Haval M6	ABM ( Airbag system)		√	√	√	-	-	-	Vehicle configuration information, Write function

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model	Menu	System	Function						
			Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General ty	Haval M6	AC (A/C control system)	√	√	√	√	√	-	Write function
General ty	Haval M6	CD/MP5 (CD host)	-	√	√	-	-	-	Vehicle configuration information, Write function
General ty	Haval M6	GW (Gateway)	√	√	√	√	-	√	Write function, Data mapping function configuration
General ty	Haval M6	IP(Instrument system)	√	√	√	√	√	-	Write function
General ty	Haval M6	PEPS (Passive entry passive start system)	√	√	√	-	√	-	Vehicle configuration information, Write function, After-sales learning
General ty	Haval M6	RVC(Rear-view camera)	√	√	√	-	-	-	Vehicle configuration information, Write function
General ty	Haval M6	TOD (Intelligent 4-wheel drive system)	-	-	-	-	-	-	write network configuration information(manual)
General ty	Haval M6	SBWM (Electronic shifter)	√	√	√	√	-	-	Write function
General ty	Haval M6	ESCL (Electronic steering column lock)	√	√	√	√	-	-	Write VIN, write network configuration information
General ty	Haval F5	ECM (Engine system)	√	√	√	√	√	-	-
General ty	Haval F5	ECM (Engine system)	√	√	√	√	√	√	-
General ty	Haval F5	ECM (Engine system)	√	√	√	√	√	-	Write VIN code, write network configuration information(31 characters), Change GPF(Diesel Particulate Filter), Replace the differential pressure sensor, Replace ECU(Electronic control unit), VVT(continuously variable timing) self-learning
General ty	Haval F5	TCU (Automatic transmission system)	√	√	√	√	-	-	Write VIN code, write network configuration information(17 characters), After-sales learning function, Read and write function, Close DEV CAN function
General ty	Haval F5	SRS( Airbag system)	√	√	√	√	-	-	-
General ty	Haval F5	ICM/IP(Instrument panel system)	√	√	√	√	√	-	-
General ty	Haval F5	ICM/IP(Instrument panel system)	√	√	√	√	√	-	-
General ty	Haval F5	TPMS(Tire pressure monitoring system)	√	√	√	√	-	-	-
General ty	Haval F5	ESP(Electronic stability system)	√	√	√	√	√	-	-
General ty	Haval F5	BCM(Body control system)	√	√	√	√	√	-	-
General ty	Haval F5	AC(Auto A/C system)	√	√	√	√	√	-	-
General ty	Haval F5	PEPS(Passive entry passive start system)	√	√	√	√	-	-	-
General ty	Haval F5	GW(Gateway system)	√	√	√	√	-	-	-
General ty	Haval F5	EPS(Electric steering system)	√	√	√	√	√	-	-
General ty	Haval F5	PAS(Parking Services system )	√	√	√	√	-	-	-
General ty	Haval F5	PAS(Parking Services system )	√	√	√	√	-	-	-
General ty	Haval F5	RVC(Rear-view camera)	√	√	√	√	-	-	-
General ty	Haval F5	AVM(Around view module)	√	√	√	√	-	-	-
General ty	Haval F5	IFC(Intelligent front view camera)	√	√	√	√	-	-	-
General ty	Haval F5	HUT(Navigation host system)	√	√	√	√	-	-	-
General ty	Haval F5	HUT(Navigation host system)	√	√	√	√	-	-	-
General ty	Haval F5	ESCL(Electronic steering column lock)	√	√	√	√	-	-	-
General ty	Haval F5	SAS(Steering wheel steering angle sensor)	√	√	√	√	-	-	-
General ty	Haval F5	Trailer(Trailer Module)	√	√	√	√	√	-	-
General ty	Haval F5	SHM(Seat heating module)	√	√	√	√	-	-	-
General ty	Haval F5	SBWM(Electronic shifter)	√	√	√	√	-	-	-
General ty	Haval F7	ECM (Engine system)	√	√	√	√	√	√	-
General ty	Haval F7	ECM (Engine system)	√	√	√	√	√	-	-
General ty	Haval F7	ECM (Engine system)	√	√	√	√	√	-	Write VIN code, write network configuration information(31 characters), Change GPF(Diesel Particulate Filter), Replace the differential pressure sensor, Replace ECU(Electronic control unit), VVT(continuously variable timing) self-learning
General ty	Haval F7	TCU(Automatic transmission system)	√	√	√	√	-	-	-
General ty	Haval F7	ABM( Airbag system)	√	√	√	√	-	-	-
General ty	Haval F7	ICM/IP(Instrument panel system)	√	√	√	√	√	-	-
General ty	Haval F7	ICM/IP(Instrument panel system)	√	√	√	√	√	-	-
General ty	Haval F7	TPMS(Tire pressure monitoring system)	√	√	√	√	-	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function							Remarks(Other functions)		
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame				
General ty	Haval F7	ESP(Electronic stabilization program)				√	√	√	√	-	-
General ty	Haval F7	BCM(Body control system)				√	√	√	√	-	-
General ty	Haval F7	AC(Auto A/C system)				√	√	√	√	-	-
General ty	Haval F7	PEPS(Passive entry passive start system)				√	√	√	√	-	-
General ty	Haval F7	GW(Gateway system)				√	√	√	√	-	-
General ty	Haval F7	EPS(Electric steering system)				√	√	√	√	-	-
General ty	Haval F7	PAS(Parking Services system )				√	√	√	√	-	-
General ty	Haval F7	RVC(Rear-view camera)				√	√	√	√	-	-
General ty	Haval F7	AVM(Around view module)				√	√	√	√	-	-
General ty	Haval F7	IFC(Intelligent Front View Control Module)				√	√	√	√	-	-
General ty	Haval F7	HUT(Navigation System)				√	√	√	√	-	-
General ty	Haval F7	ESCL(Electronic steering column lock)				√	√	√	√	-	-
General ty	Haval F7	SAS(Steering wheel steering angle sensor)				√	√	√	√	-	-
General ty	Haval F7	CVVL(Continuously variable valve lift)				√	-	-	√	-	-
General ty	Haval F7	SBWM(Electronic shifter)				√	√	√	√	-	-
General ty	Haval F7	Nextrac(Intelligent FWD)				√	√	√	√	-	-
General ty	Haval F7	ACC(Automatic cruise system)				√	√	√	√	-	-
General ty	Haval F7	RSDS-L(left radar detection system)				√	√	√	√	-	-
General ty	Haval F7	RSDS-R(Right radar detection system)				√	√	√	√	-	-
General ty	Haval F7	SCM(Seat heating massage system)				√	√	√	√	-	-
General ty	Haval F7	T-BOX(Internet of Vehicles host system)				√	√	√	√	-	-
General ty	Haval F7	GLO-NASS(GLO-NASS emergency call system)				√	√	√	√	-	-
General type	Haval H2	2019 MY(China VI)	ECM(Engine system)			√	√	√	√	-	Write VIN, Variable valve timing(VVT) self-learning, Replace the gasoline particulate filter(GPF), Replace the oxidation catalyst(DOC) (Differential pressure sensor), Gasoline Particulate Filter(GPF) regeneration, Fuel tank leak test
General type	Haval H2	2019 MY(China VI)	AT(Automatic transmission system)	Transmission control system6AT		√	√	√	√	-	-
General type	Haval H2	2019 MY(China VI)	AT(Automatic transmission system)	Transmission control unit(7DCT300)		√	√	√	√	-	Write VIN, Transmission self-learning, Clutch reset
General type	Haval H2	2019 MY(China VI)	AT(Automatic transmission system)	Transmission control unit(7DCT450)		√	√	√	√	-	Write VIN code, Close DEV CAN function, Change TCU, but do not replace the hydraulic module(HCM), Change TCU, but do not replace the clutch(PT), Change TCU, but do not replace the register module(NB), After-sales learning function, Turn off the Auto P function, After-sales data reading
General type	Haval H2	2019 MY(China VI)	ESP(Electronic stability system)			√	√	√	√	-	Yaw rate sensor calibration, APBMI initial setup, Artificial exhaust
General type	Haval H2	2019 MY(China VI)	SRS( Airbag system)			√	√	√	√	-	-
General type	Haval H2	2019 MY(China VI)	BCM(Body controller system)			√	√	√	√	-	-
General type	Haval H2	2019 MY(China VI)	ICM/IP(Instrument panel system)			√	√	√	√	-	Reset maintenance mileage, Mileage reset(ODO)
General type	Haval H2	2019 MY(China VI)	AC(Auto A/C system)	AC(A/C control system-Red tab)		√	√	√	√	-	-
General type	Haval H2	2019 MY(China VI)	AC(Auto A/C system)	AC(A/C control system-Blue tab)		√	√	√	√	-	Write VIN
General type	Haval H2	2019 MY(China VI)	PEPS(Passive entry passive start system)			√	√	√	√	-	After-sale function
General type	Haval H2	2019 MY(China VI)	GW(Gateway system)	Gateway(Micron)		√	√	√	-	-	Write VIN
General type	Haval H2	2019 MY(China VI)	GW(Gateway system)	Gateway(Continental )		√	√	√	√	-	Write VIN
General type	Haval H2	2019 MY(China VI)	ESCL(Electronic steering column lock)			√	√	√	-	-	-
General type	Haval H2	2019 MY(China VI)	EPS(Power steering system)			√	√	√	√	-	Sensor calibration
General type	Haval H2	2019 MY(China VI)	SAS(Steering wheel steering angle sensor)			√	√	√	√	-	Calibration

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function							Remarks(Other functions)		
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame				
General type	Haval H2	2019 MY (China VI)	SBWM(Electronic shifter)	SBWM(Electronic shifter) (ZF)	√	√	√	√	-	-	Write VIN
General type	Haval H2	2019 MY (China VI)	SBWM(Electronic shifter)	SBWM(Electronic shifter) (Chongqing Regal)	√	√	√	√	√	-	Write VIN
General type	Haval H2	2019 MY (China VI)	CMS (CAN signal conversion system)		√	√	√	√	-	-	Write VIN code
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	ECM(Engine system)	√	√	√	√	√	-	Write VIN, Variable valve timing(VVT) self-learning, Replace the gasoline particulate filter(GPF), Replace the oxidation catalyst(DOC) (Differential pressure sensor), Gasoline Particulate Filter(GPF) regeneration, Fuel tank leak test
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	AT(Automatic transmission system)	√	√	√	√	-	-	Write VIN code, Close DEV CAN function, Change TCU, but do not replace the hydraulic module(HCM), Change TCU, but do not replace the clutch(PT), Change TCU, but do not replace the register module(NB), After-sales learning function, Turn off the Auto P function, After-sales data reading
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	ESP(Electronic stability system)	√	√	√	√	√	-	Write VIN, Steering angle sensorCalibration, Artificial exhaust, Caliper test
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	SRS( Airbag system)	√	√	√	√	-	-	Write VIN code, Calibration
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	BCM(Body control system)	√	√	√	√	√	-	Write VIN
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	ICM/IP (Instrument panel system)	√	√	√	√	√	-	Write VIN, Maintenance mileage reset, Manually reset
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	SBWM(Electronic shifter)	√	√	√	√	-	-	Write VIN code
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	SBWM(Electronic shifter)	√	√	√	√	√	-	Write VIN
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	GW(Gateway system)	√	√	√	√	-	-	Write VIN code, Electronic brake system(EBS) battery ID flashing
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	AC(Auto A/C system)	√	√	√	√	√	-	Write VIN
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	CD(Entertainment system)	√	√	√	√	-	-	Write VIN code
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	PAS(Parking assist system)	√	√	√	-	-	-	Write VIN
General type	Haval H6	2019 MY (China VI)	CC6461RM system/CC6472RM system	PEPS(Passive entry passive start system)	√	√	√	√	√	-	Write VIN, After-sales learning
General type	Haval H7	2019 MY (China VI)	ECM(Engine system)		√	√	√	√	√	-	Write VIN code, write network configuration information(31 characters), Replace the gasoline particulate filter(GPF), Replace the differential pressure sensor, Replace ECU(Electronic control unit), Variable valve timing(VVT) self-learning, Write configuration, Read configuration, Gasoline Particulate Filter(GPF) regeneration, Fuel tank leak test, OBD function
General type	Haval H7	2019 MY (China VI)	AT(Automatic transmission system)	Transmission control system(GDCT)	√	√	√	√	-	-	Write VIN code, self-learning
General type	Haval H7	2019 MY (China VI)	AT(Automatic transmission system)	Transmission control unit(7DCT450)	√	√	√	√	-	-	Write VIN code, Close DEV CAN function, Change TCU, but do not replace the hydraulic module(HCM), Change TCU, but do not replace the clutch(PT), Change TCU, but do not replace the register module(NB), After-sales learning function, Turn off the Auto P function, After-sales data reading
General type	Haval H7	2019 MY (China VI)	ESP(Electronic stability system)		√	√	√	√	√	-	Write VIN, Calibration, Artificial exhaust function
General type	Haval H7	2019 MY (China VI)	SRS( Airbag system)		√	√	√	√	-	-	Write VIN code, IMU static calibration
General type	Haval H7	2019 MY (China VI)	BCM(Body control system)		√	√	√	√	√	-	Write VIN
General type	Haval H7	2019 MY (China VI)	ICM/IP(Instrument panel system)	Delphi Instrument system	√	√	√	√	√	-	Write VIN code, Maintenance settings
General type	Haval H7	2019 MY (China VI)	ICM/IP(Instrument panel system)	Bosch Instrument system	√	√	√	√	√	-	Write VIN code, Maintenance settings

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System				Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H7	2019 MY (China VI)	AC(Auto A/C system)		√	√	√	√	√	-	Write VIN
General type	Haval H7	2019 MY (China VI)	PAS(Parking assist system)	PAS(Parking assist system)	√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	PAS(Parking assist system)	APA(Semi-automatic parking assist system)	√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	RVC(Rear-view camera)		√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	AVM(Around view module)	AVM(Around view module) (Standard Definition)	√	√	√	√	-	-	Write VIN code, Network configuration(manual), Electronic control unit serial number
General type	Haval H7	2019 MY (China VI)	AVM(Around view module)	AVM(Around view module) (High Definition)	√	√	√	√	-	-	Write VIN code, After-sales configuration camera, After-sales calibration
General type	Haval H7	2019 MY (China VI)	DSM(Driver side seat memory system)		√	√	√	√	√	-	Write VIN
General type	Haval H7	2019 MY (China VI)	SCM(Seat heating massage system)		√	√	√	√	√	-	Write VIN
General type	Haval H7	2019 MY (China VI)	IFC(Intelligent front view camera)		√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	ACC(Adaptive cruise control system)		√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	LRSDS(Left rear radar detection system)		√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	RRSDS(Right rear radar detection system)		√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	PEPS(Passive entry passive start system)		√	√	√	√	√	-	After-sales learning
General type	Haval H7	2019 MY (China VI)	GW(Gateway system)		√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	EPS(Electric steering system)		√	√	√	√	√	-	Write VIN, PDC initial torque reset
General type	Haval H7	2019 MY (China VI)	SAS(Steering wheel steering angle sensor)		√	√	√	√	-	-	Write VIN, Calibration
General type	Haval H7	2019 MY (China VI)	T-BOX(Internet of Vehicles host system)		√	√	√	√	-	-	Write VIN
General type	Haval H7	2019 MY (China VI)	HUT(Navigation System)		√	√	√	√	√	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	ECM(Engine system)	engine system(UAES GDICChina VI (4B15A+4C20B))	√	√	√	√	√	-	Write VIN code, write network configuration information(31 characters), Replace the gasoline particulate filter(GPF), Replace the differential pressure sensor, Replace ECU(Electronic control unit), Variable valve timing(VVT) self-learning, Write configuration, Read configuration, Gasoline Particulate Filter(GPF) regeneration, Fuel tank leak test, OBD function
General type	Haval H9	2020 MY (8AT China VI)	ECM(Engine system)	engine system(4D20M)	√	√	√	√	-	-	Write VIN, Read and write injector code, Reset NVV(learning value), Diesel particulate filter(DPF) regeneration and routine test
General type	Haval H9	2020 MY (8AT China VI)	AT(Automatic transmission system)		√	√	√	√	-	-	Write VIN, Reset self-learning data, Reset message learning data, Activate permanent fault codes
General type	Haval H9	2020 MY (8AT China VI)	ESP(Electronic stability system)		√	√	√	√	√	-	Write VIN, Yaw rate sensor calibration, Artificial exhaust, Caliper test
General type	Haval H9	2020 MY (8AT China VI)	SRS( Airbag system)		√	√	√	√	-	-	Write VIN, Yaw angle calibration
General type	Haval H9	2020 MY (8AT China VI)	BCM(Body control system)		√	√	√	√	√	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	ICM/IP(Instrument panel system)		√	√	√	√	-	-	Write VIN, Maintenance mileage reset
General type	Haval H9	2020 MY (8AT China VI)	TPMS(Tire pressure monitoring system)		√	√	√	√	-	-	Write data, Network configuration(manual), Tire pressure sensor learning
General type	Haval H9	2020 MY (8AT China VI)	ALS(Headlamp Leveling System)		√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	EPS(Electric steering system)		√	√	√	√	-	-	Write VIN

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function										
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)				
General type	Haval H9	2020 MY (8AT China VI)	GW(Gateway system)			√	√	√	√	-	-	Write VIN, Electronic brake system(EBS) battery ID flashing
General type	Haval H9	2020 MY (8AT China VI)	HUT(Navigation System)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	PAS(Parking assist system)	APS(Automatic parking assist system)		√	√	√	√	-	-	-
General type	Haval H9	2020 MY (8AT China VI)	PAS(Parking assist system)	PAS(Parking assist system)		√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	DSM(Driver side seat memory system)			√	√	√	√	√	-	Write VIN code
General type	Haval H9	2020 MY (8AT China VI)	AVM(Around view module)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	T-BOX(Internet of Vehicles host system)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	SAS(Steering wheel steering angle sensor)			√	√	√	√	-	-	Write VIN code, Calibration
General type	Haval H9	2020 MY (8AT China VI)	SBWM(Electronic shifter)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	ESCL(Electronic steering column lock)			√	√	√	√	-	-	Write VIN code
General type	Haval H9	2020 MY (8AT China VI)	Trailer(Trailer Module)			√	√	√	√	√	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	SCM(Seat heating massage system)			√	√	√	√	-	-	-
General type	Haval H9	2020 MY (8AT China VI)	TOD(4WD system)			√	√	√	√	√	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	RHDS(Rear armrest display assembly)			√	√	√	√	√	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	IFC(Intelligent front view camera)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	LRSDS(Left rear radar detection system)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	RRSDS(Right rear radar detection system)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	ACC(Adaptive cruise control system)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	ELD(Electronically controlled differential lock)			√	√	√	√	√	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	AC(Auto A/C system)			√	√	√	√	√	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	DDCM(Driver side door system)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	PDCM(Front passenger side door system)			√	√	√	√	-	-	Write VIN
General type	Haval H9	2020 MY (8AT China VI)	GLO-NASS(GLO-NASS emergency call system)			√	√	√	√	-	-	Write VIN
General type	Haval M6	2019 MY (China VI)	ECM(Engine system)			√	√	√	√	√	-	Write VIN, Variable valve timing(VVT) self-learning, Replace the gasoline particulate filter(GPF), Replace the oxidation catalyst(DOC) (Differential pressure sensor), Gasoline Particulate Filter(GPF) regeneration, Fuel tank leak test
General type	Haval M6	2019 MY (China VI)	AT(Automatic transmission system)			√	√	√	√	-	-	Write VIN code, Close DEV CAN function, Change TCU, but do not replace the hydraulic module(HCM), Change TCU, but do not replace the clutch(PT), Change TCU, but do not replace the register module(NB), After-sales learning function, Turn off the Auto P function, After-sales data reading
General type	Haval M6	2019 MY (China VI)	ESP(Electronic stability system)			√	√	√	√	√	-	Write VIN, Steering angle sensor Calibration, Artificial exhaust, Caliper test
General type	Haval M6	2019 MY (China VI)	SRS( Airbag system)			√	√	√	√	-	-	Write VIN code, Calibration
General type	Haval M6	2019 MY (China VI)	BCM(Body control system)			√	√	√	√	√	-	Write VIN
General type	Haval M6	2019 MY (China VI)	ICM/IP(Instrument panel system)			√	√	√	√	-	-	Write VIN, Total mileage reset, Manually reset



## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function							Remarks(Other functions)			
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame					
General type	Haval M6	2019 MY (China VI)	AC(Auto A/C system)			√	√	√	√	√	-	Write VIN
General type	Haval M6	2019 MY (China VI)	GW(Independent gateway)			√	√	√	√	-	-	Write VIN
General type	Haval M6	2019 MY (China VI)	PEPS(Passive entry passive start system)			√	√	√	√	√	-	Write VIN, After-sales learning
General type	Haval M6	2019 MY (China VI)	PAS(Parking assist system)			√	√	√	√	-	-	Write VIN
General type	Haval M6	2019 MY (China VI)	CD(Entertainment system)			√	√	√	√	-	-	Write VIN code
General type	Haval F7	2020 MY	ECM(Engine system)			√	√	√	√	√	-	Write VIN code, write network configuration information(31 characters), Replace the gasoline particulate filter(GPF), Replace the differential pressure sensor, Replace ECU(Electronic control unit), Variable valve timing(VVT) self-learning, Write configuration, Read configuration, Gasoline Particulate Filter(GPF) regeneration, Fuel tank leak test, OBD function
General type	Haval F7	2020 MY	AT(Automatic transmission system)			√	√	√	√	-	-	Write VIN code, Close DEV CAN function, Change TCU, but do not replace the hydraulic module(HCM), Change TCU, but do not replace the clutch(PT), Change TCU, but do not replace the register module(NB), After-sales learning function, Turn off the Auto P function, After-sales data reading
General type	Haval F7	2020 MY	ESP(Electronic stability system)			√	√	√	√	√	-	Write VIN code, Artificial exhaust
General type	Haval F7	2020 MY	SRS( Airbag system)			√	√	√	√	-	-	Write VIN code, Yaw angle calibration
General type	Haval F7	2020 MY	BCM(Body control system)			√	√	√	√	√	-	Write VIN code
General type	Haval F7	2020 MY	ICM/IP(Instrument panel system)	IP(Instrument system) (Bosch )		√	√	√	√	√	-	Write VIN code, write network configuration information, Maintenance settings, Manually reset
General type	Haval F7	2020 MY	ICM/IP(Instrument panel system)	IP(Instrument system) (Continental )		√	√	√	√	√	-	Write VIN code, write network configuration information, Maintenance mileage reset, Total mileage reset, Manually reset
General type	Haval F7	2020 MY	ICM/IP(Instrument panel system)	IP(Instrument system) (Marelli)		√	√	√	√	√	-	Write VIN code, Maintenance mileage reset
General type	Haval F7	2020 MY	TPMS(Tire pressure monitoring system)			√	√	√	√	-	-	Write VIN code, Tire pressure sensor learning, ABS delayed write
General type	Haval F7	2020 MY	SAS(Steering wheel steering angle sensor)			√	√	√	√	-	-	Write VIN code, SAS steering angle calibration
General type	Haval F7	2020 MY	EPS(Electric steering system)			√	√	√	√	-	-	Write VIN code, Steering calibration
General type	Haval F7	2020 MY	SBWM(Electronic shifter)	SBWM(Electronic shifter) (ZF)		√	√	√	√	-	-	Write VIN code
General type	Haval F7	2020 MY	SBWM(Electronic shifter)	SBWM(Electronic shifter) (Ningbo Gaofa)		√	√	√	√	√	-	Write VIN
General type	Haval F7	2020 MY	GW(Gateway system)			√	√	√	√	-	-	Write VIN code, Electronic brake system(EBS) battery ID flashing
General type	Haval F7	2020 MY	AC(Auto A/C system)	AC(A/C control system) (BHTC)		√	√	√	√	√	-	Write VIN code
General type	Haval F7	2020 MY	AC(Auto A/C system)	AC(A/C control system) (Fengtian)		√	√	√	√	√	-	Write VIN
General type	Haval F7	2020 MY	HUT(Navigation System)			√	√	√	√	√	-	Write VIN
General type	Haval F7	2020 MY	RVC(Rear-view camera)			√	√	√	√	-	-	Write VIN
General type	Haval F7	2020 MY	AVM(Around view module)	AVM(Around view module) (Standard Definition)		√	√	√	√	-	-	Write VIN code
General type	Haval F7	2020 MY	AVM(Around view module)	AVM(Around view module) (High Definition)		√	√	√	√	-	-	Write VIN code, After-sales configuration camera, After-sales calibration
General type	Haval F7	2020 MY	ACC(Adaptive cruise control system)			√	√	√	√	-	-	Write VIN code
General type	Haval F7	2020 MY	RSDS-L(left radar detection system)			√	√	√	√	-	-	Write VIN code

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu	System	Function							Remarks(Other functions)			
		Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame					
General type	Haval F7	2020 MY	RSDS-R(Right radar detection system)			√	√	√	√	-	-	Write VIN code
General type	Haval F7	2020 MY	IFC(Intelligent front view camera)			√	√	√	√	-	-	Write VIN code
General type	Haval F7	2020 MY	PAS(Parking assist system)	PAS(Parking assist system)(TungThih )		√	√	√	√	-	-	Write VIN code, Network configuration(manual)
General type	Haval F7	2020 MY	PAS(Parking assist system)	APS(Automatic parking assist system)		√	√	√	√	-	-	-
General type	Haval F7	2020 MY	SCM(Seat heating massage system)			√	√	√	√	-	-	Write VIN code
General type	Haval F7	2020 MY	NEXTRAC(Intelligent FWD)			√	√	√	√	√	-	-
General type	Haval F7	2020 MY	PEPS(Passive entry passive start system)			√	√	√	√	-	-	Write VIN, After-sales learning
General type	Haval F7	2020 MY	T-BOX(Internet of Vehicles host system)	T-BOX(Internet of Vehicles host system)(Bosch )		√	√	√	√	-	-	Write VIN code
General type	Haval F7	2020 MY	T-BOX(Internet of Vehicles host system)	T-BOX(Internet of Vehicles host system)(Valeo)		√	√	√	√	-	-	Write VIN
General type	Haval F7	2020 MY	GLO-NASS(GLO-NASS emergency call system)			√	√	√	√	-	-	Write VIN
General type	Haval F7	2020 MY	CVVL(Continuously variable valve lift)			√	√	√	-	-	-	Write VIN code
General type	Haval F7X		ECM(Engine system)	ECM(Engine system4C20NT)		√	√	√	√	√	-	Write VIN code, IUPR function
General type	Haval F7X		ECM(Engine system)	ECM(Engine system4B15)		√	√	√	√	√	-	Write VIN code, Variable valve timing(VVT) self-learning
General type	Haval F7X		ECM(Engine system)	engine system(UAES GDICChina VI(4B15A+4C20B))		√	√	√	√	√	-	Write VIN code, write network configuration information(31 characters), Replace the gasoline particulate filter(GPF), Replace the differential pressure sensor, Replace ECU(Electronic control unit), Variable valve timing(VVT) self-learning, Write configuration, Read configuration, Gasoline Particulate Filter(GPF) regeneration, Fuel tank leak test, OBD function
General type	Haval F7X		AT(Automatic transmission system)			√	√	√	√	-	-	Write VIN code, Close DEV CAN function, After-sales learning function, Read and write function, After-sales data reading, Turn off the Auto P function
General type	Haval F7X		ESP(Electronic stability system)			√	√	√	√	√	-	Write VIN code, Artificial exhaust
General type	Haval F7X		SRS( Airbag system)			√	√	√	√	-	-	Write VIN code, Yaw angle calibration
General type	Haval F7X		BCM(Body control system)			√	√	√	√	√	-	Write VIN
General type	Haval F7X		ICM/IP(Instrument panel system)			√	√	√	√	-	-	Write VIN code, write network configuration information, Maintenance settings, Manually reset
General type	Haval F7X		TPMS(Tire pressure monitoring system)			√	√	√	√	-	-	Write VIN code, Tire pressure sensor learning, ABS delayed write
General type	Haval F7X		PEPS(Passive entry passive start system)			√	√	√	√	-	-	Write VIN, After-sales learning
General type	Haval F7X		AC(Auto A/C system)	AC(A/C control system)(BHTC)		√	√	√	√	√	-	Write VIN code
General type	Haval F7X		AC(Auto A/C system)	AC(A/C control system)(Fengtian)		√	√	√	√	√	-	Write VIN
General type	Haval F7X		GW(Gateway system)			√	√	√	√	-	-	Write VIN, EBS(Electronic Braking System) battery ID flashing
General type	Haval F7X		SAS(Steering wheel steering angle sensor)			√	√	√	√	-	-	Write VIN code, SAS steering angle calibration
General type	Haval F7X		CVVL(Continuously variable valve lift)			√	-	-	√	-	-	Write VIN code
General type	Haval F7X		SBWM(Electronic shifter)	SBWM(Electronic shifter)(ZF)		√	√	√	√	-	-	Write VIN code
General type	Haval F7X		SBWM(Electronic shifter)	SBWM(Electronic shifter)(Ningbo Gaofa)		√	√	√	√	√	-	Write VIN

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval F7X		NEXTRAC(Intelligent FWD)			√	√	√	√	√	-	-
General type	Haval F7X		EPS(Electric steering system)			√	√	√	√	-	-	Write VIN, Steering calibration
General type	Haval F7X		RVC(Rear-view camera)			√	√	√	√	-	-	Write VIN
General type	Haval F7X		AVM(Around view module)			√	√	√	√	-	-	Write VIN code, After-sales configuration camera, After-sales calibration
General type	Haval F7X		PAS(Parking assist system)	PAS(Parking assist system)		√	√	√	√	-	-	Write VIN code
General type	Haval F7X		PAS(Parking assist system)	APS(Automatic parking assist system)		√	√	√	√	-	-	-
General type	Haval F7X		ACC(Adaptive cruise control system)			√	√	√	√	-	-	Write VIN
General type	Haval F7X		RSDS_L(left radar detection system)			√	√	√	√	-	-	Write VIN
General type	Haval F7X		RSDS_R(Right radar detection system)			√	√	√	√	-	-	Write VIN
General type	Haval F7X		IFC(Intelligent front view camera)			√	√	√	√	-	-	Write VIN code, write network configuration information, After-sales configuration camera, After-sales calibration
General type	Haval F7X		HUT(Navigation System)			√	√	√	√	-	-	Write VIN
General type	Haval F7X		SCM(Seat heating massage system)			√	√	√	√	-	-	Write VIN code
General type	Haval F7X		ESCL(Electronic steering column lock)			√	√	√	√	-	-	Write VIN code
General type	Haval F7X		T-BOX(Internet of Vehicles host system)			√	√	√	√	-	-	Write VIN code, write network configuration information(17 characters), write network configuration information(31 characters), Single ECU configuration word, LED brightness, Passive entry passive start system(PEPS) learning achievement, LED brightness multiple
General type	Haval F7X		GLO-NASS(GLO-NASS emergency call system)	GLO-NASS(GLO-NASS emergency call system1)		√	√	√	√	-	-	-
General type	Haval F7X		GLO-NASS(GLO-NASS emergency call system)	GLO-NASS(GLO-NASS emergency call system2)		√	√	√	√	-	-	Write VIN
General type	Haval H6	2020 model	ECM(engine control module)	Engine system(4B15)		√	√	√	√	√	-	Write VIN code, VVT self-learning, network configuration (manual), OBD diagnostic function, write configuration
General type	Haval H6	2020 model	ECM(engine control module)	Engine system(4B13)		√	√	√	√	√	-	Write VIN code, VVT self-learning, network configuration (manual), OBD diagnosis function
General type	Haval H6	2020 model	ECM(engine control module)	Engine system(4C20)		√	√	√	√	√	√	Write VIN code, learn information, network configuration (manual), iupr function
General type	Haval H6	2020 model	ECM(engine control module)	Engine system(UAES GDI CHINA VI(4B15A+4C20B))		√	√	√	√	√	-	Write VIN code, write network configuration information (31 characters), replace vehicle particulate filter (GPF), replace differential pressure sensor, replace ECU (electronic control unit), variable valve timing (VVT) self-learning, write configuration, read configuration, gasoline particulate filter (GPF) regeneration, fuel tank leakage test, OBD function, read relevant data of old ECM gasoline particulate filter (GPF)
General type	Haval H6	2020 model	AT(automatic transmission)	Transmission control unit(7DCT300)		√	√	√	√	-	-	Write VIN code, transmission self-learning, clutch reset, write configuration, read configuration
General type	Haval H6	2020 model	AT(automatic transmission)	Transmission control unit(7DCT450)		√	√	√	√	-	-	Write VIN code, read network configuration information, turn off dev can function, replace TCU, but do not replace hydraulic module (HCM), replace TCU, but do not replace clutch (PT), replace TCU, but do not replace register module (NB), after-sales learning function, turn off auto P function and after-sales data reading
General type	Haval H6	2020 model	ESP(Electronic Stability Program)			√	√	√	√	√	-	Write VIN code, network configuration (manual), yaw rate sensor calibration, manual exhaust function, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), read configuration (62-digit)

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System			Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H6	2020 model	SRS(Supplemental Restrgint System)		√	√	√	√	-	-	Write VIN code, calibration, network configuration (manual), write circuit configuration word
General type	Haval H6	2020 model	BCM(Body Control Module)		√	√	√	√	√	-	Write VIN code, network configuration (manual), read-write DDD fatigue driving algorithm, final calibration parameter adjustment, read-write system configuration, electric tailgate self-learning (PLG)
General type	Haval H6	2020 model	ICM/IP(instrument panel system)	IP(full color instrument system)	√	√	√	√	√	-	Write VIN code, write network configuration information (17 characters), write network configuration information (31 characters), repair and maintenance settings and manual zeroing
General type	Haval H6	2020 model	ICM/IP(instrument panel system)	IP(non full color instrument system)	√	√	√	√	√	-	Write VIN code, write network configuration information (17 characters), write network configuration information (31 characters), repair and maintenance settings and manual zeroing
General type	Haval H6	2020 model	TPMS(Tire Pressure Monitoring System)		√	√	√	√	-	-	Vin code writing, ABS delay writing, network configuration (manual), tire pressure sensor learning
General type	Haval H6	2020 model	AC(automatic air conditioning system)		√	√	√	√	√	-	Write VIN code, network configuration (manual), self-learning
General type	Haval H6	2020 model	PEPS(Passive entry passive start system)		√	√	√	√	-	-	Write VIN code, after-sales function, network configuration (manual), write configuration (34 digits), read configuration (34 digits), write configuration (62 digits)
General type	Haval H6	2020 model	ESCL(Electronic Steering Column Lock)		√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2020 model	SBWM(Electronic shifter)	SBWM(Electronic shifter)(ZF)	√	√	√	√	-	-	Write VIN code and category distinguishing code
General type	Haval H6	2020 model	SBWM(Electronic shifter)	SBWM(Electronic shifter)Chongqing Ruige)	√	√	√	√	√	-	Write VIN code, write category distinguishing code, write configuration (34 digits), write configuration (62 digits)
General type	Haval H6	2020 model	EPS(Electric Power Steering)		√	√	√	√	√	-	Write VIN code, PDC initial torque reset, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit)
General type	Haval H6	2020 model	SAS(Steering Angle Sensor)		√	√	√	√	-	-	Write VIN code and calibrate
General type	Haval H6	2020 model	CVVL(continuously variable valve lift)		√	-	-	√	-	-	Write VIN code, network configuration (manual), cvvl (continuously variable valve lift) self-learning
General type	Haval H6	2020 model	GW(Gateway)	GW(independent gateway system)	√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2020 model	GW(Gateway)	GW(independent gateway) (including EBS LIN)	√	√	√	√	-	-	Write VIN code, fingerprint information, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), read configuration (62-digit)
General type	Haval H6	2020 model	AVM(Around View Monitor)		√	√	√	√	-	-	Write VIN code, write network configuration information, ECU serial number, offline automatic calibration, write configuration (34 digits), read configuration (34 digits), write configuration (62 digits)
General type	Haval H6	2020 model	RVC(Rear View Camera)		√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (34-digit), read configuration (34-digit), write configuration (62-digit)
General type	Haval H6	2020 model	PAS(Park Assist System)	PAS(Park Assist System)(TONGZHI)	√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2020 model	PAS(Park Assist System)	APA(semi automatic parking aid)	√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (34-digit), read configuration (34-digit), write configuration (62-digit)
General type	Haval H6	2020 model	PAS(Park Assist System)	PAS(Park Assist System)(Valeo)	√	√	√	√	-	-	Write VIN code, write configuration and read configuration
General type	Haval H6	2020 model	IFC(Intelligent front view camera)		√	√	√	√	-	-	Write data, network configuration (manual)
General type	Haval H6	2020 model	SHM(Seat Heating Module)		√	√	√	√	-	-	Write VIN code
General type	Haval H6	2020 model	RSDS_L(Left side radar detection system)		√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2020 model	RSDS_R(Right side radar detection system)		√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2020 model	T-BOX(Internet of vehicles host system)	TBOX(Internet of vehicles host)	√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), read configuration (62-digit)

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H6	2020 model	T-BOX(Internet of vehicles host system)	T-BOX(Internet of vehicles host system)(4G)	√	√	√	√	-	-	Write VIN code, write network configuration information, LED brightness, T-box test	
General type	Haval H6	2020 model	HUT(navigation system)		√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (34 digits), read configuration (34 digits), write configuration (62 digits)	
General type	Haval H6	2020 model	ACC(adaptive cruise control)		√	√	√	√	-	-	Write VIN code, write network configuration information, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), active calibration	
General type	Haval H6	2020 model	DSM(driver seat memory system)		√	√	√	√	√	-	Write VIN code and network configuration (manual)	
General type	Haval H6	2020 model	DDCM(Driver side door system)		√	√	√	√	-	-	Write VIN code and network configuration (manual)	
General type	Haval H6	2020 model	PDCM(Passenger side door system)		√	√	√	√	-	-	Write VIN code and network configuration (manual)	
General type	Haval H6	2020 model	GLO-NASS(GLONASS emergency call system)		√	√	√	-	-	-		
General type	Haval H4			ECM(Engine system)	Engine system(UAES GDI CHINA VI(4B15A+4C20B))	√	√	√	√	√	-	Write VIN code, write network configuration information (31 characters), replace vehicle particulate filter (GPF), replace differential pressure sensor, replace ECU (electronic control unit), variable valve timing (VVT) self-learning, OBD diagnostic function, write configuration, read configuration, gasoline particulate filter (GPF) regeneration, fuel tank leakage test, and read relevant data of old ECM gasoline particulate filter (GPF)
General type	Haval H4			ECM(Engine system)	Engine system(UAES CHINA VI(4G15F))	√	√	√	√	√	-	Write VIN code, variable valve timing (VVT) self-learning, replace vehicle particulate filter (GPF), replace oxidation catalyst (DOC) (differential pressure sensor), gasoline particulate filter (GPF) regeneration, fuel tank leakage test, write configuration, read configuration and OBD diagnosis function
General type	Haval H4			ESP(Electronic Stability Program)	ESP(Electronic Stability Program)CHINA VI	√	√	√	√	√	-	Write VIN code, network configuration (manual), yaw rate sensor calibration, manual exhaust function, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), read configuration (62-digit)
General type	Haval H4			SBWM(Electronic shifter)	SBWM(Electronic shifter)(NINGBO GAOFA)	√	√	√	√	√	-	Write VIN code and configuration
General type	Haval H4			EPS(Electric Power Steering)	SMRAT(by reading the version information system, the supplier identification number is gaglc)	√	√	√	√	-	-	Write VIN code, write configuration, write end protection angle (left end and right end), PDC initial value
General type	Haval H4			GW(Gateway)	GW(independent gateway)(including EBS LIN)	√	√	√	√	-	-	Write VIN code, fingerprint information, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), read configuration (62-digit)
General type	Haval H4			PAS(Park Assist System)	PAS(Park Assist System)(Valeo)	√	√	√	√	-	-	Write VIN code, write configuration and read configuration
General type	Haval H4			T-BOX(Internet of vehicles host system)	T-BOX(Internet of vehicles host system)(4G)	√	√	√	√	-	-	Write VIN code, write network configuration information, LED brightness, T-box test
General type	Haval H4			CCVL(continuously variable valve lift)		√	-	-	√	-	-	Write network configuration information, write VIN code, cvvl (continuously variable valve lift) self-learning
General type	Haval H5 Classic version			IMMO		√	√	-	√	-	-	Anti theft device matching
General type	Haval H6	2018 model	CC6472RM	ECM(Engine system)	Delphi diesel(Delphi 4D20)IMMO	√	√	√	√	√	√	Write VIN code, iupr function, VVT self-learning, write configuration, read configuration
General type	Haval H6	2018 model	CC6472RM	AT(automatic transmission)	Transmission control unit(7DCT300)	√	√	√	√	-	-	Write VIN code, transmission self-learning, clutch reset, write configuration, read configuration
			CC6472RM	AT(automatic transmission)	Transmission control system TCU	√	√	√	√	-	-	Write data, network configuration (manual), self-learning
General type	Haval H6	2018 model	CC6472RM	ESP(Electronic Stability Program)		√	√	√	√	√	-	Steering sensor calibration (ESP only), network configuration (automatic), network configuration (manual), exhaust function, yaw angle sensor calibration (steep slope descent function vehicles)
General type	Haval H6	2018 model	CC6472RM	SRS(Supplemental Restrgint System)		√	√	√	√	-	-	Write network configuration information (automatic) and network configuration (manual)

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H6	2018 model	CC6472RM	BCM(Body Control Module)	√	√	√	√	√	-	Key learning, VIN code writing, system configuration writing, tire pressure learning (standby)	
General type	Haval H6	2018 model	CC6472RM	ICM/IP(instrument panel system)	√	√	√	√	√	-	Write vehicle configuration information, reset maintenance mileage, clear the total mileage, and manually reset to zero	
General type	Haval H6	2018 model	CC6472RM	EPB(Electronic Parking Brake)	√	√	√	√	√	-	Replace brake pads, network configuration (manual), write VIN code, calibrate slope sensor and read deep fault code	
General type	Haval H6	2018 model	CC6472RM	AC(automatic air conditioning system)	√	√	√		√	-	Network configuration (manual)	
General type	Haval H6	2018 model	CC6472RM	AC(automatic air conditioning system)	√	√	√	√	√	-	Network configuration (manual)	
General type	Haval H6	2018 model	CC6472RM	PEPS(Passive entry passive start system)	√	√	√	√	√	-	After sales learning (New), writing VIN code, network configuration (manual)	
General type	Haval H6	2018 model	CC6472RM	SBWM(Electronic shifter)	√	√	√	√	-	-	Write VIN code and category distinguishing code	
General type	Haval H6	2018 model	CC6472RM	PAS(Park Assist System)	√	√	√	√	-	-	Network configuration (manual)	
General type	Haval H6	2018 model	CC6472RM	GW(independent gateway system)	√	√	√	√	-	-	Network configuration (manual), write VIN code	
General type	Haval H6	2018 model	CC6472RM	CD(CD host)	√	√	√	√	-	-	Network configuration (manual), write VIN code	
General type	Haval H6	2018 model	CC6472RM	ACC(adaptive cruise control)	√	√	√	√	-	-	Write VIN code and network configuration information (17 characters)	
General type	Haval H6	2018 model	CC6472RM	IPC(Intelligent front view camera)	√	√	√	√	-	-	Write data, network configuration (manual)	
General type	Haval H6	2018 model	CC6472RM	RSDS_L(Left side radar detection system)	√	√	√	√	-	-	Write VIN code and network configuration (manual)	
General type	Haval H6	2018 model	CC6472RM	RSDS_R(Right side radar detection system)	√	√	√	√	-	-	Write VIN code and network configuration (manual)	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ECM(Engine system)	√	√	√	√	√	-	Write VIN code, VVT self-learning, network configuration (manual), OBD diagnostic function, write configuration	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ECM(Engine system)	√	√	√	√	√	-	Write VIN code, VVT self-learning, network configuration (manual), OBD diagnosis function	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ECM(Engine system)	√	√	√	√	√	√	Write VIN code, learn information, network configuration (manual), iupr function	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ECM(Engine system)	√	√	√	√	√	-	Write VIN code, write network configuration information (31 characters), replace vehicle particulate filter (GPF), replace differential pressure sensor, replace ECU (electronic control unit), variable valve timing (VVT) self-learning, OBD diagnostic function, write configuration, read configuration, gasoline particulate filter (GPF) regeneration, fuel tank leakage test, and read relevant data of old ECM gasoline particulate filter (GPF)	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	AT(automatic transmission)	√	√	√	√	-	-	Write VIN code, transmission self-learning, clutch reset, write configuration, read configuration	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	AT(automatic transmission)	√	√	√	√	-	-	Write VIN code, write network configuration information, turn off dev can function, replace TCU, but do not replace hydraulic module (HCM), replace TCU, but do not replace clutch (PT), replace TCU, but do not replace register module (NB), after-sales learning function, turn off auto P function and after-sales data reading	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ESP(Electronic Stability Program)	√	√	√	√	√	-	Write VIN code, network configuration (manual), yaw rate sensor calibration, manual exhaust function, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), read configuration (62-digit)	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	SRS(Supplemental Restrgint System)	√	√	√	√	-	-	Write VIN code, calibration, network configuration (manual), write circuit configuration word	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	BCM(Body Control Module)	√	√	√	√	√	-	Write VIN code, network configuration (manual), read-write DDD fatigue driving algorithm, final calibration parameter adjustment, read-write system configuration, electric tailgate self-learning (PLG)	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ICM/IP(instrument panel system)	√	√	√	√	√	-	Write VIN code, write network configuration information (17 characters), write network configuration information (31 characters), repair and maintenance settings and manual zeroing	

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ICM/IP(instrument panel system)	IP(non full color instrument system)	√	√	√	√	√	-	Write VIN code, write network configuration information (17 characters), write network configuration information (31 characters), repair and maintenance settings and manual zeroing
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	TPMS(tire pressure monitoring system)		√	√	√	√	-	-	Vin code writing, ABS delay writing, network configuration (manual), tire pressure sensor learning
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	AC(air conditioning control module)		√	√	√	√	√	-	Write VIN code, network configuration (manual), self-learning
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	PEPS(Passive entry passive start system)		√	√	√	√	-	-	Write VIN code, after-sales function, network configuration (manual), write configuration (34 digits), read configuration (34 digits), write configuration (62 digits)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ESCL(Electronic Steering Column Lock)		√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	SBWM(Electronic shifter)	SBWM(Electronic shifter)(ZF)	√	√	√	√	-	-	Write VIN code and category distinguishing code
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	SBWM(Electronic shifter)	SBWM(Electronic shifter)Chongqing Ruige)	√	√	√	√	√	-	Write VIN code, write category distinguishing code, write configuration (34 digits), write configuration (62 digits)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	EPS(Electric Power Steering)		√	√	√	√	√	-	Write VIN code, PDC initial torque reset, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	SAS(Steering Angle Sensor)		√	√	√	√	-	-	Write VIN code and calibrate
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	CVVL(continuously variable valve lift)		√	-	-	√	-	-	Write VIN code, network configuration (manual), cvvl (continuously variable valve lift) self-learning
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	GW(independent gateway system)	GW(independent gateway system)	√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	GW(independent gateway system)	GW(independent gateway)(including EBS LIN)	√	√	√	√	-	-	Write VIN code, fingerprint information, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), read configuration (62-digit)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	AVM(Around View Monitor)		√	√	√	√	-	-	Write VIN code, write network configuration information, ECU serial number, offline automatic calibration, write configuration (34 digits), read configuration (34 digits), write configuration (62 digits)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	RVC(Rear View Camera)		√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (34-digit), read configuration (34-digit), write configuration (62-digit)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	PAS(Park Assist System)	PAS(Park Assist System)(TONGZHI)	√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	PAS(Park Assist System)	APA(semi automatic parking aid)	√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (34-digit), read configuration (34-digit), write configuration (62-digit)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	PAS(Park Assist System)	PAS(Park Assist System)(Valeo)	√	√	√	√	-	-	Write VIN code, write configuration and read configuration
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	IFC(Intelligent front view camera)		√	√	√	√	-	-	Write data, network configuration (manual)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	SHM(Seat Heating Module)		√	√	√	√	-	-	Write VIN code
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	RSDS_L(Left side radar detection system)		√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	RSDS_R(Right side radar detection system)		√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	T-BOX(Internet of vehicles host system)	TBOX(Internet of vehicles host)	√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), read configuration (62-digit)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	T-BOX(Internet of vehicles host system)	T-BOX(Internet of vehicles host system)(4G)	√	√	√	√	-	-	Write VIN code, write network configuration information, LED brightness, T-box test
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	HUT(navigation host system)		√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (34 digits), read configuration (34 digits), write configuration (62 digits)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	ACC(adaptive cruise control)		√	√	√	√	-	-	Write VIN code, write network configuration information, write configuration (34-digit), read configuration (34-digit), write configuration (62-digit), active calibration
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	DSM (seat memory module)		√	√	√	√	√	-	Write VIN code and network configuration (manual)

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	DDCM (driver side door module)	√	√	√	√	-	-	Write VIN code and network configuration (manual)	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	PDCM(front passenger side door module)	√	√	√	√	-	-	Write VIN code and network configuration (manual)	
General type	Haval H6	2018 model	CC6461UM/CC6463UM/CC6464RM	GLO-NASS (GLONASS emergency call system)	√	√	√	-	-	-	-	
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM(Engine system)	4C20-MT92 Engine system	√	√	√	√	√	√	Tooth information learning, reading and writing VIN code, iupr function, network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM(Engine system)	4D20 Bosch diesel Engine system	√	√	√	√	√	√	Write network configuration information (manual), write network configuration information (automatic), EGR self-learning function, read injector code, write injector code (full write), write injector code (separate), compression test, start fault information, injection shutdown test, empty and add air drift compensation value, OBD diagnosis function
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM(Engine system)	Engine system(4G15B)	√	√	√	√	√	√	Write VIN code, iupr function, VVT self-learning, write configuration, read configuration
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM(Engine system)	Engine system(4B15)	√	√	√	√	√	-	Write VIN code, OBD diagnosis function, VVT self-learning, network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM(Engine system)	4D20 德尔福欧5Engine system	√	√	√	√	√	-	Routine control, injector matching, writing VIN code, DPF (particle trap), iupr function, writing network configuration information (manual), writing network configuration information (automatic), EGR emptying self-learning, OBD diagnosis function, emptying and adding air drift compensation value, tooth information learning
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM(Engine system)	Engine system(UAES GDI CHINA VI (4B15A+4C20B))	√	√	√	√	√	-	Write VIN code, write network configuration information (31 characters), replace vehicle particulate filter (GPF), replace differential pressure sensor, replace ECU (electronic control unit), variable valve timing (VVT) self-learning, OBD diagnostic function, write configuration, read configuration, gasoline particulate filter (GPF) regeneration, fuel tank leakage test, and read relevant data of old ECM gasoline particulate filter (GPF)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ECM(Engine system)	Engine system(UAES CHINA VI (4G15P))	√	√	√	√	√	-	Write VIN code, variable valve timing (VVT) self-learning, replace vehicle particulate filter (GPF), replace oxidation catalyst (DOC) (differential pressure sensor), gasoline particulate filter (GPF) regeneration, fuel tank leakage test, write configuration, read configuration and OBD diagnosis function
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT(automatic transmission)	Transmission control system(6DCT)	√	√	√	√	-	-	Write VIN code, self-learning and network configuration information
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT(automatic transmission)	Transmission control unit(7DCT300)	√	√	√	√	-	-	Write VIN code, transmission self-learning, clutch reset, write configuration, read configuration
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT(automatic transmission)	Transmission control unit(7DCT450)	√	√	√	√	-	-	Write VIN code, write network configuration information, turn off dev can function, replace TCU, but do not replace hydraulic module (HCM), replace TCU, but do not replace clutch (PT), replace TCU, but do not replace register module (NB), after-sales learning function, turn off auto P function and after-sales data reading
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AT(automatic transmission)	Transmission control system6AT	√	√	√	√	√	-	Write configuration, read configuration
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ESP(Electronic Stability Program)	ESP(Electronic Stability Program)CHINA V	√	√	√	√	√	-	Yaw rate sensor calibration, network configuration (manual), manual exhaust function
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ESP(Electronic Stability Program)	ESP(Electronic Stability Program)CHINA VI	√	√	√	√	√	-	Write network configuration information, VIN code and manual exhaust
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SRS(Supplemental Restrgint System)	Airbag module (ABM)(Ottoliv CHINA V)	√	√	√	√	√	-	Write VIN code and network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SRS(Supplemental Restrgint System)	Airbag module (ABM)(Ottoliv CHINA VI)	√	√	√	√	√	-	Write VIN code, calibration, network configuration (manual), write circuit configuration word
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	BCM(Body Control Module)		√	√	√	√	√	-	Write system configuration, tire pressure sensor learning, read and write VIN code, network configuration (manual), write configuration (62-digit), read configuration (20-digit), write configuration (20-digit)



## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ICM/IP(instrument panel system)	IP(instrument system)CHINA V	√	√	√	-	√	-	Default value of reading and writing maintenance mileage, default value of reading and writing maintenance mileage (China VI), total mileage clearing, manual zeroing, date reset, network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ICM/IP(instrument panel system)	IP(instrument system)CHINA VI	√	√	√	√	√	-	Write VIN code, write network configuration information, reset maintenance mileage, reset total mileage, and reset manually
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	EPB(Electronic Parking Brake)		√	√	√	√	√	-	Replace the brake pad, calibrate the slope sensor, configure the network (manually), and read the deep fault code
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	Air conditioning control system(AC)		√	√	√	-	√	-	Network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PEPS(Passive entry passive start system)	PEPS(Haila)	√	√	√	√	√	-	Network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PEPS(Passive entry passive start system)	PEPS(KSTAR BUTTON)	√	√	√	√	-	-	Write network configuration information, write VIN code, write configuration (62-digit), read configuration (62-digit)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	EPS(Electric Power Steering)	EPS(Electric Power Steering)(ZF)	√	√	√	√	-	-	Steering sensor calibration, VIN code writing, network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	EPS(Electric Power Steering)	EPS(Electric Power Steering)(BOSCH)	√	√	√	√	-	-	Write VIN code, corner calibration, limit learning, data elimination, write configuration, read configuration
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CVWL(continuously variable valve lift)		√	-	-	√	-	-	Write VIN code, network configuration (manual), cvwl (continuously variable valve lift) self-learning
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SBWM(Electronic shifter)	SBWM(Electronic shifter)(ZF)	√	√	√	√	-	-	Write VIN code and category distinguishing code
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SBWM(Electronic shifter)	SBWM(Electronic shifter)Chongqing Ruige)	√	√	√	√	√	-	Write VIN code, write category distinguishing code, write configuration (34 digits), write configuration (62 digits)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AFS(automatic headlamp leveling system)		√	√	√	√	-	-	Horizontal zero calibration, network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	AVM(Around View Monitor)		√	√	√	√	-	-	Write VIN code, ECU serial number, network configuration (manual), write configuration
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	RVC(rear view camera system)		√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PAS(Park Assist System)	APA(semi automatic parking aid)	√	√	√	√	-	-	Network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	PAS(Park Assist System)	PAS(Park Assist System)	√	√	√	√	-	-	Network configuration (manual), write configuration (62-digit), write configuration (20-digit), read configuration (20-digit)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	NEXTRAC(smarter precursor)		√	√	√	√	-	-	Network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD (entertainment system)	CD(Delphi CD)	√	√	√	√	-	-	Network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD (entertainment system)	HUAYANG CD(CD host system)	√	√	√	√	√	-	Write VIN code, write configuration (20 digits), read configuration (20 digits), write configuration (62 digits)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CD (entertainment system)	CD/MP5(CD host)	√	√	√	√	-	-	Write VIN code and network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ESCL(electronic steering column lock)	ESCL(electronic steering column lock)(Haila)	√	√	√	√	-	-	Network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	ESCL(electronic steering column lock)	ESCL(electronic steering column lock)(KSTAR)	√	√	√	√	-	-	Write network configuration information and VIN code
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	GW(Gateway)		√	√	√	√	-	-	Write VIN code, network configuration (manual), write configuration (62-digit), read configuration (20-digit), write configuration (20-digit)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SAS(Steering Angle Sensor)		√	√	√	√	-	-	Calibration, VIN code writing, network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	SCM(seat ventilation and heating module)		√	√	√	√	-	-	Write VIN code
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	CMS (CAN signal conversion system)		√	√	√	√	√	-	CMS model learning and network configuration (manual)
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	HUT(navigation host system)		√	√	√	√	√	-	Write VIN code, write configuration and read configuration
General type	Haval H6	2018 model	CC6460UM/CC6450UM/CC6463UM/CC6461UM/CC6465UM	T-BOX(Internet of vehicles host system)		√	√	√	√	-	-	Write network configuration information and VIN code

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H7	2017-2019(basic model China V)	ECM(Engine system)	Engine system(UAES GDI CHINA VI(4B15A+4C20B))	√	√	√	√	√	-	Write VIN code, write network configuration information (31 characters), replace vehicle particulate filter (GPF), replace differential pressure sensor, replace ECU (electronic control unit), variable valve timing (VVT) self-learning, OBD diagnostic function, write configuration, read configuration, gasoline particulate filter (GPF) regeneration, fuel tank leakage test, and read relevant data of old ECM gasoline particulate filter (GPF)	
General type	Haval H7	2017-2019(basic model China V)	AT(automatic transmission)	Transmission control unit(7DCT450)	√	√	√	√	-	-	Write VIN code, write network configuration information, turn off dev can function, replace TCU, but do not replace hydraulic module (HCM), replace TCU, but do not replace clutch (PT), replace TCU, but do not replace register module (NB), after-sales learning function, turn off auto P function and after-sales data reading	
General type	Haval H8	2015-2016(6AT)	IFV (Intelligent front view control module)		√	√	√	√	-	-	Write calibration date	
General type	Haval M6	2017-2019(basic model China V)	ECM(engine control module)	Engine system(4G15B)	√	√	√	√	√	√	Write VIN code, iupr function, VVT self-learning, write configuration, read configuration	
General type	Haval F5		ECM(Engine system)	Engine system(UAES CHINA VI(4G15F))	√	√	√	√	√	-	Write VIN code, variable valve timing (VVT) self-learning, replace vehicle particulate filter (GPF), replace oxidation catalyst (DOC) (differential pressure sensor), gasoline particulate filter (GPF) regeneration, fuel tank leakage test, write configuration, read configuration and OBD diagnosis function	
General type	Haval F5		HUT(navigation host system)	HUT(navigation host system)(YUANFENG)	√	√	√	√	-	-	Write VIN code and configuration	
General type	Haval F5		PAS(Parking assist system)	PAS(Park Assist System)(Valeo)	√	√	√	√	-	-	Write VIN code, write configuration and read configuration	
General type	Haval H2	2019 model(CHINA VI)	EPS(Electric Power Steering)	EPS(YUBNEI Electric Power Steering)	√	√	√	√	-	-	-	
General type	Haval H4		ICM/IP(instrument panel system)	Instrument system(xintongda)	√	√	√	√	√	-	-	
General type	Haval H4		HUT-TBOX(integrated machine)		√	√	√	-	-	-	-	
General type	Haval H5	2021 model(Russian version)	ECM(engine control module)		√	√	√	√	√	-	-	
General type	Haval H5	2021 model(Russian version)	ESP(Electronic Stability Program)		√	√	√	√	√	-	-	
General type	Haval H5	2021 model(Russian version)	SRS(Supplemental Restrgint System)		√	√	√	√	-	-	-	
General type	Haval H5	2021 model(Russian version)	BCM(Body Control Module)		√	√	√	√	√	-	-	
General type	Haval H5	2021 model(Russian version)	ICM/IP(instrument panel system)		√	√	√	√	√	-	-	
General type	Haval H5	2021 model(Russian version)	TPMS(Tire Pressure Monitoring System)		√	√	√	√	-	-	-	
General type	Haval H5	2021 model(Russian version)	IMMO		-	√	√	√	-	-	-	
General type	Haval H5	2021 model(Russian version)	TOD(4WD system)	TOD(Intelligent 4WD)	√	√	√	√	√	-	-	
General type	Haval H5	2021 model(Russian version)	TOD(4WD system)	Esof(BorgWarner 4WD system)	√	√	√	√	√	-	-	
General type	Haval H5	2021 model(Russian version)	RVC(Rear View Camera)		√	√	√	√	-	-	-	
General type	Haval H6	Third generation Haval H6	ECM(engine control module)		√	√	√	√	√	-	-	
General type	Haval H6	Third generation Haval H6	TCU(Transmission control unit)		√	√	√	√	-	-	-	
General type	Haval H6	Third generation Haval H6	ESP(Electronic Stability Program)		√	√	√	√	√	-	-	
General type	Haval H6	Third generation Haval H6	ABM(airbag module)		√	√	√	√	√	-	-	
General type	Haval H6	Third generation Haval H6	KBCM(body electronic domain control unit)	KBCM(UAES vehicle body electronic domain control unit)	√	√	√	√	√	-	-	
General type	Haval H6	Third generation Haval H6	KBCM(body electronic domain control unit)	KBCM(kstar body electronic domain control unit)	√	√	√	√	√	-	-	

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System			Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval H6	Third generation Haval H6	AC(air conditioning control module)		√	√	√	√	√	-	-
General type	Haval H6	Third generation Haval H6	AMP(power amplifier)		√	√	√	-	-	-	-
General type	Haval H6	Third generation Haval H6	AWD(full-time 4WD)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	Ble(Bluetooth module)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	CP(electric sidestep module)		√	√	√	-	-	-	-
General type	Haval H6	Third generation Haval H6	CSA(combination switch assembly)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	CVVL(continuously variable valve lift)		√	-	-	-	-	-	-
General type	Haval H6	Third generation Haval H6	DDCM(driver side door module)		√	√	√	-	-	-	-
General type	Haval H6	Third generation Haval H6	DVR(DASH CAM)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	F-PBOX(front fuse box module)		√	√	√	√	√	-	-
General type	Haval H6	Third generation Haval H6	GW(independent gateway)	GW(Amber gateway)	√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	GW(independent gateway)	GW(UAES GATEWAY)	√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	HAP(advanced automatic parking)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	IFC(Intelligent front view module)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	TPMS(tire pressure monitoring system)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	HUD(head up display)		√	√	√	-	-	-	-
General type	Haval H6	Third generation Haval H6	HUT(multimedia player assembly)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	HVSM(seat heating ventilation module)	Hvsm(Anwen seat heating and ventilation module)	√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	HVSM(seat heating ventilation module)	Hvsm(warm seat heating and ventilation module)	√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	IPAS(Integrated Parking Aid System)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	PDCM(passenger side door module)		√	√	√	-	-	-	-
General type	Haval H6	Third generation Haval H6	PLG(Power Lift Gate)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	RPAS(Rear Radar Parking Aid)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	R-PBOX(rear fuse box module)		√	√	√	√	√	-	-
General type	Haval H6	Third generation Haval H6	RSDS_L(left radar detection system)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	RSDS_R(right radar detection system)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	SBWM(Electronic shifter)	SBWM(Mander electronic shifter assembly)	√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	SBWM(Electronic shifter)	SBWM(Searle electronic shifter assembly)	√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	T-BOX(Internet of vehicles host system)	T-BOX(Lear on-board wireless terminal)	√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	T-BOX(Internet of vehicles host system)	T-BOX(Neusoft on-board wireless terminal)	√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	WPC(wireless charging assembly)		√	√	√	√	-	-	-
General type	Haval H6	Third generation Haval H6	EPS(Electronic Power Steering)		√	√	√	√	-	-	-
General type	Haval H6 COUPE		HUT-TBOX(integrated machine)		√	√	√	-	-	-	-
General type	Haval H7	2019 model(CHINA VI)	SBWM(Electronic shifter)		√	√	√	-	-	-	-
General type	Haval H9	2020 model(SAT CHINA VI)	VBC(reversing image system)		√	√	√	√	-	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval M6	2021 model (M6 PLUS)	ECM(engine control module)			√	√	√	√	√	-	Write VIN code, variable valve timing (VVT) self-learning, replace vehicle particulate filter (GPF), replace oxidation catalyst (DOC) (differential pressure sensor), gasoline particulate filter (GPF) regeneration, fuel tank leakage test, write configuration, read configuration and OBD diagnosis function
General type	Haval M6	2021 model (M6 PLUS)	AT(automatic transmission)	Transmission control unit(7DCT450)		√	√	√	√	-	-	Write VIN code, write network configuration information, turn off dev can function, replace TCU, but do not replace hydraulic module (HCM), replace TCU, but do not replace clutch (PT), replace TCU, but do not replace register module (NB), after-sales learning function, turn off auto P function and after-sales data reading
General type	Haval M6	2021 model (M6 PLUS)	AT(automatic transmission)	TCU(Transmission control unit 7DCT-300S)		√	√	√	√	-	-	-
General type	Haval M6	2021 model (M6 PLUS)	ESP(Electronic Stability Program)			√	√	√	√	√	-	Vin code writing, angle sensor calibration, manual exhaust and caliper test
General type	Haval M6	2021 model (M6 PLUS)	SRS(Supplemental Restrgint System)			√	√	√	√	-	-	Write VIN code, calibration, network configuration (manual), write circuit configuration word
General type	Haval M6	2021 model (M6 PLUS)	BCM(Body Control Module)			√	√	√	√	√	-	Write VIN code
General type	Haval M6	2021 model (M6 PLUS)	ICM/IP(instrument panel system)			√	√	√	√	-	-	Write VIN code, clear the total mileage and reset it manually
General type	Haval M6	2021 model (M6 PLUS)	PEPS(Passive entry passive start system)			√	√	√	√	√	-	-
General type	Haval M6	2021 model (M6 PLUS)	AC(automatic air conditioning system)	AC(Air conditioning control system)(Belhella)		√	√	√	√	√	-	Write VIN code
General type	Haval M6	2021 model (M6 PLUS)	AC(automatic air conditioning system)	AC(Air conditioning control system)(PENGJIAN)		√	√	√	√	√	-	Write VIN code
General type	Haval M6	2021 model (M6 PLUS)	GW(independent gateway)			√	√	√	√	-	-	Write VIN code
General type	Haval M6	2021 model (M6 PLUS)	PAS(Park Assist System)			√	√	√	-	-	-	-
General type	Haval M6	2021 model (M6 PLUS)	HUT(navigation system)			√	√	√	-	√	-	-
General type	Haval M6	2021 model (M6 PLUS)	SBWM(Electronic shifter)	SBWM(Electronic shifter)(ZF)		√	√	√	√	-	-	Write VIN code and category distinguishing code
General type	Haval M6	2021 model (M6 PLUS)	SBWM(Electronic shifter)	SBWM(Electronic shifter)(NINGBO GAOFA)		√	√	√	√	√	-	Write VIN code and configuration
General type	Haval M6	2021 model (M6 PLUS)	AVM(Around View Monitor)			√	√	√	√	-	-	-
General type	Haval M6	2021 model (M6 PLUS)	DVR(Digital Video Recorder)			√	√	√	√	-	-	-
General type	Haval F5		Instrument system (xintongda)			√	√	√	√	√	-	-
General type	Haval F5		Continental instrument (IP 3.5 inch)			√	√	√	√	√	-	-
General type	Haval F5		IP (7-inch DSV instrument)			√	√	√	√	√	-	-
General type	Haval F5		APS (fully automatic parking system)			√	√	√	√	-	-	-
General type	Haval F5		RPAS (anti collision radar system (rear four configurations))			√	√	√	√	-	-	-
General type	Haval F5		AVM (panoramic view controller - HD)			√	√	√	√	-	-	-
General type	Haval F5		Tbox (Valeo on-board wireless terminal)			√	√	√	√	-	-	-
General type	Haval F7	2021 model	ECM(engine control module)	Engine system(UAES GDI CHINA VI (4B15A & 4C20B & 4N20))		√	√	√	√	√	-	-
General type	Haval F7	2021 model	TCU(Transmission Control Unit)			√	√	√	√	-	-	-
General type	Haval F7	2021 model	ESP(Electronic Stability Program)			√	√	√	√	√	-	-
General type	Haval F7	2021 model	ABM(airbag module)			√	√	√	√	-	-	-
General type	Haval F7	2021 model	BCM(Body Control Module)			√	√	√	√	√	-	-
General type	Haval F7	2021 model	PEPS(Passive entry passive start system)			√	√	√	√	-	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval F7	2021 model	AC(Air conditioning control system)	AC(Air conditioning control system)(Belhella)	√	√	√	√	√	-	-	
General type	Haval F7	2021 model	AC(Air conditioning control system)	AC(Air conditioning control system)(FENGHIAN)	√	√	√	√	√	-	-	
General type	Haval F7	2021 model	GW(independent gateway)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	SAS(Steering Angle Sensor)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	CVVL(continuously variable valve lift)		√	-	-	√	-	-	-	
General type	Haval F7	2021 model	SBWM(Electronic shifter)	SBWM(Electronic shifter)(ZF)	√	√	√	√	-	-	-	
General type	Haval F7	2021 model	SBWM(Electronic shifter)	SBWM(Electronic shifter)(NINGBO GAOFU)	√	√	√	√	-	-	-	
General type	Haval F7	2021 model	NEXTRAC(smooth precursor)		√	√	√	√	√	-	-	
General type	Haval F7	2021 model	EPS(Electric Power Steering)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	IP(instrument system)	3.5 inches_ Continental instrument	√	√	√	√	√	-	-	
General type	Haval F7	2021 model	IP(instrument system)	7 inches_ Bertek instrument	√	√	√	√	√	-	-	
General type	Haval F7	2021 model	IP(instrument system)	12.3 inches_ Marelli instrument	√	√	√	√	√	-	-	
General type	Haval F7	2021 model	TPMS(tire pressure monitoring system)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	PAS(Park Assist System)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	ACC(adaptive cruise control)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	RSDS(reversing radar)	RSDS-L(left radar detection system)	√	√	√	√	-	-	-	
General type	Haval F7	2021 model	RSDS(reversing radar)	RSDS-R(right side radar detection system)	√	√	√	√	-	-	-	
General type	Haval F7	2021 model	IFC(Intelligent front view control module)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	HUT(navigation host system)	HUT(Huayang navigation host system)	√	√	√	√	√	-	-	
General type	Haval F7	2021 model	HUT(navigation host system)	HUT(Desai navigation host system)	√	√	√	√	-	-	-	
General type	Haval F7	2021 model	SCM(seat ventilation and heating module)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	T-BOX(Internet of vehicles host system)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	DSM (seat memory module)		√	√	√	√	√	-	-	
General type	Haval F7	2021 model	DMS(intelligent identification system)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	DDCM(driver side door module)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	PDCM(passenger side door module)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	ALCM(atmosphere lamp control module)		√	√	√	√	√	-	-	
General type	Haval F7	2021 model	HAP(advanced automatic parking)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	IPAS(Integrated Parking Aid System)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	RPAS(Rear Radar Parking Aid)		√	√	√	√	-	-	-	
General type	Haval F7	2021 model	DVR(Digital Video Recorder)		√	√	√	√	-	-	-	
General type	Haval F7X	F7X-2021 model	ECM(engine control module)		√	√	√	√	-	-	-	
General type	Haval F7X	F7X-2021 model	TCU(Transmission Control Unit)		√	√	√	√	-	-	-	
General type	Haval F7X	F7X-2021 model	ESP(Electronic Stability Program)		√	√	√	√	√	-	-	
General type	Haval F7X	F7X-2021 model	ABM(airbag module)		√	√	√	√	-	-	-	

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System			Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval F7X	F7X-2021 model	BCM(Body Control Module)		√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	PEPS(Passive entry passive start system)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	AC(Air conditioning control system)	AC(Air conditioning control system)(Belhella)	√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	AC(Air conditioning control system)	AC(Air conditioning control system)(FENGtian)	√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	GW(independent gateway)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	SAS(Steering Angle Sensor)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	CVVL(continuously variable valve lift)		√	-	-	√	-	-	-
General type	Haval F7X	F7X-2021 model	SBWM(Electronic shifter)	SBWM(Electronic shifter)(ZF)	√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	SBWM(Electronic shifter)	SBWM(Electronic shifter)(NINGBO GAOFA)	√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	NEXTRAC(smart precursor)		√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	EPS(Electric Power Steering)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	7 inches + 12.3 inches_ Bertek instrument		√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	TPMS(tire pressure monitoring system)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	ACC(adaptive cruise control)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	RSDS(reversing radar)	RSDS-L(left radar detection system)	√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	RSDS(reversing radar)	RSDS-R(right side radar detection system)	√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	IFC(Intelligent front view control module)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	HUT(navigation host system)	HUT(Huayang navigation host system)	√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	HUT(navigation host system)	HUT(Desai navigation host system)	√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	SCM(seat ventilation and heating module)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	T-BOX(Internet of vehicles host system)	TBOX(low configuration of vehicle networking controller)	√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	T-BOX(Internet of vehicles host system)	TBOX(high configuration of vehicle networking controller)	√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	DSM (seat memory module)		√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	DMS(intelligent identification system)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	DDCM(driver side door module)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	PDCM(passenger side door module)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	ALCM(atmosphere lamp control module)		√	√	√	√	√	-	-
General type	Haval F7X	F7X-2021 model	HAP(advanced automatic parking)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	IPAS(Integrated Parking Aid System)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	RPAS(Rear Radar Parking Aid)		√	√	√	√	-	-	-
General type	Haval F7X	F7X-2021 model	DVR(Digital Video Recorder)		√	√	√	√	-	-	-
General type	Haval DARGO		ECM(Engine control module)		√	√	√	√	√	-	-
General type	Haval DARGO		TCU(Transmission control unit)		√	√	√	√	-	-	-
General type	Haval DARGO		ESP(Electronic Stability Program)		√	√	√	√	√	-	-

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval DARGO		ABM(Airbag module)		√	√	√	√	√	-	-	
General type	Haval DARGO		KBCM(body electronic domain control unit)	KBCM(UAES Body electronic domain control unit)	√	√	√	√	√	-	-	
General type	Haval DARGO		KBCM(body electronic domain control unit)	KBCM(KSTAR Body electronic domain control unit)	√	√	√	√	√	-	-	
General type	Haval DARGO		AC(air conditioning control module)		√	√	√	√	√	-	-	
General type	Haval DARGO		AMP (amplifier)		√	√	√	-	-	-	-	
General type	Haval DARGO		AWD(all wheel drive)		√	√	√	√	-	-	-	
General type	Haval DARGO		BLE(Bluetooth module)		√	√	√	√	-	-	-	
General type	Haval DARGO		CP(electric sidestep module)		√	√	√	-	-	-	-	
General type	Haval DARGO		CSA(combination switch assembly)		√	√	√	√	-	-	-	
General type	Haval DARGO		CVVL(continuously variable valve lift)		√	-	-	-	-	-	-	
General type	Haval DARGO		DDCM(driver side door module)		√	√	√	-	-	-	-	
General type	Haval DARGO		DVR(Digital Video Recorder)		√	√	√	√	-	-	-	
General type	Haval DARGO		ELD(electronic differential lock control unit)		√	√	√	-	√	-	-	
General type	Haval DARGO		F-PBOX(front fuse box module)		√	√	√	√	√	-	-	
General type	Haval DARGO		GW(independent gateway)	GW(Aptiv GATEWAY)	√	√	√	√	-	-	-	
General type	Haval DARGO		GW(independent gateway)	GW(UAES GATEWAY)	√	√	√	√	-	-	-	
General type	Haval DARGO		HAP(advanced automatic parking)		√	√	√	√	-	-	-	
General type	Haval DARGO		IFC(Intelligent front view module)		√	√	√	√	-	-	-	
General type	Haval DARGO		TPMS(tire pressure monitoring system)		√	√	√	√	-	-	-	
General type	Haval DARGO		HUD(head up display)		√	√	√	-	-	-	-	
General type	Haval DARGO		HUT(multimedia player assembly)		√	√	√	√	-	-	Maintenance mileage setting	
General type	Haval DARGO		HVSM(seat heating ventilation module)	HVSM(Anwen seat heating and ventilation module)	√	√	√	√	-	-	-	
General type	Haval DARGO		HVSM(seat heating ventilation module)	HVSM(warm seat heating and ventilation module)	√	√	√	√	-	-	-	
General type	Haval DARGO		IPAS(Integrated Parking Aid System)		√	√	√	√	-	-	-	
General type	Haval DARGO		PDCM(passenger side door module)		√	√	√	-	-	-	-	
General type	Haval DARGO		PLG(Power Lift Gate)		√	√	√	√	-	-	-	
General type	Haval DARGO		RPAS(Rear Radar Parking Aid)		√	√	√	√	-	-	-	
General type	Haval DARGO		R-PBOX(rear fuse box module)		√	√	√	√	√	-	-	
General type	Haval DARGO		RSDS_L(left radar detection system)		√	√	√	√	-	-	-	
General type	Haval DARGO		RSDS_R(right radar detection system)		√	√	√	√	-	-	-	
General type	Haval DARGO		SBWM(Electronic shifter)	Sbwm (Mander electronic shifter assembly)	√	√	√	√	-	-	-	
General type	Haval DARGO		SBWM(Electronic shifter)	Sbwm (Searle electronic shifter assembly)	√	√	√	√	-	-	-	
General type	Haval DARGO		STBS(screen touch key switch controller)		√	√	√	√	-	-	-	
General type	Haval DARGO		T-BOX(Internet of vehicles host system)	T-box (Lear on-board wireless terminal)	√	√	√	√	-	-	-	
General type	Haval DARGO		T-BOX(Internet of vehicles host system)	T-box (Neusoft on-board wireless terminal)	√	√	√	√	-	-	-	

## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System			Function						
					Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval DARGO		WPC(wireless charging assembly)		√	√	√	√	-	-	-
General type	Haval DARGO		EPS(Electronic Power Steering)		√	√	√	√	-	-	-
General type	Haval JOLION		ECM(engine control module)	Engine system(UAES CHINA VI(4G15F))	√	√	√	√	√	-	-
General type	Haval JOLION		TCU(Transmission control unit)		√	√	√	√	-	-	-
General type	Haval JOLION		ESP(Electronic Stability Program)		√	√	√	√	√	-	-
General type	Haval JOLION		ABM(airbag module)		√	√	√	√	-	-	-
General type	Haval JOLION		KBCM(body electronic domain control unit)	KBCM(UAES Body electronic domain control unit)	√	√	√	√	√	-	-
General type	Haval JOLION		KBCM(body electronic domain control unit)	KBCM(KSTAR Body electronic domain control unit)	√	√	√	√	√	-	-
General type	Haval JOLION		IP(instrument system)	IP (instrument system 3.5 inches)	√	√	√	√	√	-	-
General type	Haval JOLION		IP(instrument system)	IP (instrument system 7-inch Yazaki)	√	√	√	√	-	-	-
General type	Haval JOLION		IP(instrument system)	IP (instrument system 7-inch xintongda)	√	√	√	√	-	-	-
General type	Haval JOLION		GW(UAES GATEWAY)		√	√	√	-	-	-	-
General type	Haval JOLION		AC(air conditioning control module)		√	√	√	√	√	-	-
General type	Haval JOLION		ALCM(atmosphere lamp control module)		√	√	√	√	-	-	-
General type	Haval JOLION		APS(automatic parking system)		√	√	√	√	-	-	-
General type	Haval JOLION		AWD(all wheel drive)		√	√	√	√	-	-	-
General type	Haval JOLION		CSA(combination switch assembly)		√	√	√	√	-	-	-
General type	Haval JOLION		DMS(intelligent identification system)		√	√	√	√	-	-	-
General type	Haval JOLION		DVR(Digital Video Recorder)		√	√	√	√	-	-	-
General type	Haval JOLION		ECALL(emergency call system)		√	√	√	-	-	-	-
General type	Haval JOLION		EPS(Electric Power Steering)	EPS(Bosch Power Steering System)	√	√	√	√	-	-	-
General type	Haval JOLION		EPS(Electric Power Steering)	EPS(Henglong power steering system)	√	√	√	√	-	-	-
General type	Haval JOLION		ESCL(Electronic Steering Column Lock)		√	√	√	-	-	-	-
General type	Haval JOLION		F-PBOX(front fuse box module)		√	√	√	√	√	-	-
General type	Haval JOLION		R-PBOX(rear fuse box module)		√	√	√	√	√	-	-
General type	Haval JOLION		GLO-NASS(GLONASS emergency call system)		√	√	√	√	-	-	-
General type	Haval JOLION		HUD(head up display)		√	√	√	-	-	-	-
General type	Haval JOLION		HUT(multimedia player assembly)		√	√	√	√	-	-	-
General type	Haval JOLION		HVSM(seat heating ventilation module)	HVSM(Anwen seat heating and ventilation module)	√	√	√	√	-	-	-
General type	Haval JOLION		HVSM(seat heating ventilation module)	HVSM(warm seat heating and ventilation module)	√	√	√	√	-	-	-
General type	Haval JOLION		IFC(Intelligent front view module)		√	√	√	√	-	-	-
General type	Haval JOLION		RPAS(Rear Radar Parking Aid)		√	√	√	√	-	-	-
General type	Haval JOLION		RSDS_L(left radar detection system)		√	√	√	√	-	-	-
General type	Haval JOLION		RSDS_R(right radar detection system)		√	√	√	√	-	-	-
General type	Haval JOLION		SBWM(Electronic shifter)	SBWM(Mander electronic shifter assembly)	√	√	√	√	-	-	-



## Diagnostic List HAVAL\_v10.52

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color

Model Menu		System				Function						
						Read ECU information	Read DTC	Erase DTC	Live Data	Actuation Test	Read freeze frame	Remarks(Other functions)
General type	Haval JOLION		SBWM(Electronic shifter)	SBWM(Searle electronic shifter assembly)	√	√	√	√	-	-	-	
General type	Haval JOLION		TPMS(tire pressure monitoring system)		√	√	√	√	-	-	-	
General type	Haval JOLION		VMDR(Interior occupant detection radar)		√	√	√	-	-	-	-	
General type	Haval JOLION		WPC(wireless charging assembly)		√	√	√	√	-	-	-	
General type	Haval JOLION		T-BOX(Internet of vehicles host system)		√	√	√	√	-	-	-	