- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

		System	Function							
Vehicle	Area		Read Info.	Read DTC	Clear DTC	Data Stream	Actuation Test	Special Function	Remark	
ACURA	Canada	Engine System	-	√	√	√	√	√		
ACURA	Canada	Automatic Transmission System	_	√	√	<b>√</b>	√	√		
ACURA	Canada	Supplemental Inflatable Restraint System	√	√	√	√	√	√		
ACURA	Canada	Anti-lock Braking System	_	√	√	<b>√</b>	√	√		
ACURA	Canada	Brake System	-	√	√	√	√	√		
ACURA	Canada	Driving Support	_	√	√	<b>√</b>	√	√		
ACURA	Canada	Body Electric System	_	√	√	<b>√</b>	√	√		
ACURA	Canada	Electric Power Steering	_	√	√	√	√	-		
ACURA	Canada	Tire Pressure Monitor System	-	√	√	√	√	_		
ACURA	Canada	SH-AWD	-	<b>√</b>	√	<b>√</b>	√	-		
ACURA	Canada	SMART-H	-	√	√	√	√	√		
ACURA	Canada	Immobilizer System	_	_	_	<b>√</b>	_	-		
ACURA	Canada	Integrated Motor Assist System	_	√	√	√	√	√		
ACURA	Canada	VTM 4	_	√	√	<b>√</b>	_	-		
ACURA	Canada	Adaptive Cruise Control	_	√	√	√	√	-		
ACURA	Canada	Hydraulic Booster	-	√	√	√	√	-		
ACURA	Canada	Electric Vacuum Pump System	_	√	√	<b>√</b>	_	-		
ACURA	Canada	Pop-up Engine Cover	-	√	√	√	_	-		
ACURA	Canada	Active Shock Absorber System	_	√	√	<b>√</b>	_	ı		
ACURA	Canada	Active Engine Control Mount	-	√	√	√	√	_		
ACURA	Canada	Active Damper System	_	√	√	√	_	_		
ACURA	Canada	Real Time AWD	-	√	√	√	-	<b>√</b>		
ACURA	Canada	Acoustic Vehicle Alerting System	-	√	√	√	_	_		

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

	Area	System	Function							
Vehicle			Read Info.	Read DTC	Clear DTC	Data Stream	Actuation Test	Special Function	Remark	
ACURA	Canada	CAN Gateway	_	√	√	-	_	-		
ACURA	Canada	Precision All Wheel Steer	_	√	√	√	√	√		
ACURA	Canada	EDLC	_	√	√	√	√	-		
ACURA	Canada	R/C ENG Starter	_	-	_	√	_	_		
ACURA	Canada	SVT	_	√	√	√	√	√		
ACURA	Europ	Engine System	-	√	√	√	√	√		
ACURA	Europ	Automatic Transmission System	_	√	√	√	√	√		
ACURA	Europ	Supplemental Inflatable Restraint System	√	√	√	√	√	√		
ACURA	Europ	Anti-lock Braking System	_	√	√	√	√	√		
ACURA	Europ	Body Electric System	_	√	√	√	√	√		
ACURA	Europ	Electric Power Steering	_	√	√	√	√	-		
ACURA	Europ	Tire Pressure Monitor System	_	√	√	√	√	-		
ACURA	Europ	SH-AWD	_	√	√	√	√	-		
ACURA	Europ	SMART-H	_	√	√	√	√	-		
ACURA	Europ	Immobilizer System	-	-	_	√	_	-		
ACURA	Europ	Integrated Motor Assist System	_	√	√	√	√	√		
ACURA	Europ	VTM 4	_	√	√	√	_	-		
ACURA	Europ	Adaptive Cruise Control	_	√	√	√	√	-		
ACURA	Europ	Hydraulic Booster	_	√	√	√	√	_		
ACURA	Europ	Electric Vacuum Pump System	_	√	√	√	-	-		
ACURA	Europ	Pop-up Engine Cover	-	√	√	√	_	1		
ACURA	Europ	Active Shock Absorber System	_	√	√	√	-	_		
ACURA	Europ	Brake System	_	√	√	<b>√</b>	√	<b>√</b>		

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

		System	Function							
Vehicle	Area		Read Info.	Read DTC	Clear DTC	Data Stream	Actuation Test	Special Function	Remark	
ACURA	Europ	Driving Support	_	√	√	√	√	√		
ACURA	Europ	Active Damper System	_	√	√	<b>√</b>	_	-		
ACURA	Europ	Real Time AWD	_	√	√	√	_	√		
ACURA	Europ	Acoustic Vehicle Alerting System	_	√	√	<b>√</b>	_	ı		
ACURA	Europ	CAN Gateway	_	√	√	-	_	-		
ACURA	Europ	Precision All Wheel Steer	_	√	√	<b>√</b>	√	√		
ACURA	Europ	EDLC	_	√	√	<b>√</b>	√	-		
ACURA	Europ	Active Engine Control Mount	_	√	√	<b>√</b>	√	-		
ACURA	Europ	4ws	_	<b>√</b>	√	√	√	√		
ACURA	Europ	i-Shift	_	√	√	<b>√</b>	_	_		
ACURA	Europ	SVT	_	√	√	√	_	_		
ACURA	General	Engine System	_	√	√	<b>√</b>	√	√		
ACURA	General	Automatic Transmission System	_	√	√	√	√	√		
ACURA	General	Supplemental Inflatable Restraint System	√	√	√	<b>√</b>	√	√		
ACURA	General	Anti-lock Braking System	_	√	√	<b>√</b>	√	√		
ACURA	General	Body Electric System	_	√	√	√	√	√		
ACURA	General	Electric Power Steering	_	√	√	<b>√</b>	√	-		
ACURA	General	Tire Pressure Monitor System	_	√	√	<b>√</b>	√	-		
ACURA	General	SH-AWD	_	√	√	√	√	-		
ACURA	General	SMART-H	_	√	√	√	√	√		
ACURA	General	Immobilizer System	_	-	_	√	-	_		
ACURA	General	Integrated Motor Assist System	_	√	√	√	√	<b>√</b>		
ACURA	General	VTM 4	_	√	√	√	_	_		

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

			Function							
Vehicle	Area	System	Read Info.	Read DTC	Clear DTC	Data Stream	Actuation Test	Special Function	Remark	
ACURA	General	Adaptive Cruise Control	-	√	√	√	√	-		
ACURA	General	Hydraulic Booster	_	√	√	√	√			
ACURA	General	Electric Vacuum Pump System	-	√	√	√	_	-		
ACURA	General	Pop-up Engine Cover	-	√	√	√	_	ı		
ACURA	General	Active Shock Absorber System	-	√	√	√	_	ı		
ACURA	General	Active Engine Control Mount	-	√	√	√	√	-		
ACURA	General	Brake System	-	√	√	√	√	√		
ACURA	General	Driving Support	-	√	√	√	√	√		
ACURA	General	Active Damper System	-	√	√	√	_	_		
ACURA	General	Real Time AWD	-	√	√	√	_	√		
ACURA	General	Acoustic Vehicle Alerting System	-	√	√	√	_	_		
ACURA	General	CAN Gateway	-	√	√	_	_	ı		
ACURA	General	Precision All Wheel Steer	_	√	√	√	√	√		
ACURA	General	EDLC	-	√	√	√	√	-		
ACURA	General	Active Engine Control Mount	_	√	√	√	√			
ACURA	General	4ws	-	√	√	√	√	√		
ACURA	General	R/C ENG Starter	-	-	_	√	_	-		
ACURA	General	SVT	-	√	√	√	_	ı		
ACURA	Japan	Engine System	-	√	√	√	√	√		
ACURA	Japan	Automatic Transmission System	-	√	√	√	$\checkmark$	√		
ACURA	Japan	Supplemental Inflatable Restraint System	√	√	√	√	√	√		
ACURA	Japan	Anti-lock Braking System	-	√	√	√	$\checkmark$	√		
ACURA	Japan	Body Electric System	-	√	√	√	√	√		

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

		System	Function							
Vehicle	Area		Read Info.	Read DTC	Clear DTC	Data Stream	Actuation Test	Special Function	Remark	
ACURA	Japan	Electric Power Steering	_	√	√	√	√	-		
ACURA	Japan	Tire Pressure Monitor System	_	√	√	<b>√</b>	√	-		
ACURA	Japan	SH-AWD	_	√	√	√	√	-		
ACURA	Japan	SMART-H	_	√	√	<b>√</b>	√	ı		
ACURA	Japan	Immobilizer System	_	-	_	√	_	-		
ACURA	Japan	Integrated Motor Assist System	_	√	√	<b>√</b>	√	√		
ACURA	Japan	VTM 4	_	√	√	<b>√</b>	_	-		
ACURA	Japan	Adaptive Cruise Control	_	√	√	√	√	-		
ACURA	Japan	Hydraulic Booster	-	√	√	√	√	_		
ACURA	Japan	Electric Vacuum Pump System	_	√	√	<b>√</b>	_	_		
ACURA	Japan	Pop-up Engine Cover	_	√	√	√	_	-		
ACURA	Japan	Active Shock Absorber System	_	√	√	<b>√</b>	_	-		
ACURA	Japan	Active Engine Control Mount	_	√	√	<b>√</b>	√	-		
ACURA	Japan	Brake System	_	√	√	<b>√</b>	√	√		
ACURA	Japan	Driving Support	_	√	√	<b>√</b>	√	√		
ACURA	Japan	Active Damper System	_	√	√	√	_	-		
ACURA	Japan	Real Time AWD	_	√	√	<b>√</b>	_	√		
ACURA	Japan	Acoustic Vehicle Alerting System	_	√	√	<b>√</b>	_	-		
ACURA	Japan	CAN Gateway	-	√	√	-	-	-		
ACURA	Japan	Precision All Wheel Steer	-	√	√	√	√	√		
ACURA	Japan	EDLC	_	√	√	√	√	_		
ACURA	Japan	Active Engine Control Mount	-	√	√	√	√	-		
ACURA	Japan	4ws	_	√	√	√	√	√		

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

	Area	System	Function							
Vehicle			Read Info.	Read DTC	Clear DTC	Data Stream	Actuation Test	Special Function	Remark	
ACURA	Japan	R/C ENG Starter	_	-	_	√	_	-		
ACURA	Japan	SVT	_	√	√	<b>√</b>	_	-		
ACURA	Latin America	Engine System	_	√	√	√	√	√		
ACURA	Latin America	Automatic Transmission System	_	√	√	<b>√</b>	√	√		
ACURA	Latin America	Supplemental Inflatable Restraint System	√	√	√	√	√	√		
ACURA	Latin America	Anti-lock Braking System	_	√	√	<b>√</b>	√	√		
ACURA	Latin America	Body Electric System	_	√	√	√	√	√		
ACURA	Latin America	Electric Power Steering	_	√	√	<b>√</b>	√	-		
ACURA	Latin America	Tire Pressure Monitor System	_	√	√	√	√	-		
ACURA	Latin America	SH-AWD	_	<b>√</b>	√	<b>√</b>	√	-		
ACURA	Latin America	SMART-H	_	√	√	√	√	√		
ACURA	Latin America	Immobilizer System	_	_	_	<b>√</b>	_	-		
ACURA	Latin America	Integrated Motor Assist System	_	√	√	<b>√</b>	√	√		
ACURA	Latin America	VTM 4	_	√	√	<b>√</b>	_	-		
ACURA	Latin America	Adaptive Cruise Control	_	√	√	<b>√</b>	√	-		
ACURA	Latin America	Hydraulic Booster	_	√	√	√	√	-		
ACURA	Latin America	Electric Vacuum Pump System	_	√	√	<b>√</b>	_	-		
ACURA	Latin America	Pop-up Engine Cover	_	√	√	√	_	-		
ACURA	Latin America	Active Shock Absorber System	_	√	√	√	_	-		
ACURA	Latin America	Active Engine Control Mount	_	√	√	√	√	_		
ACURA	Latin America	Brake System	_	√	√	√	√	√		
ACURA	Latin America	Driving Support	-	√	√	√	$\checkmark$	<b>√</b>		
ACURA	Latin America	Active Damper System	_	√	√	√	_	-		

- 1.  $\checkmark$  : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

	Area	System	Function							
Vehicle			Read Info.	Read DTC	Clear DTC	Data Stream	Actuation Test	Special Function	Remark	
ACURA	Latin America	Real Time AWD	-	√	√	√	_	√		
ACURA	Latin America	Acoustic Vehicle Alerting System	_	√	√	<b>√</b>	_	-		
ACURA	Latin America	CAN Gateway	-	√	√	-	_	-		
ACURA	Latin America	Precision All Wheel Steer	-	√	√	<b>√</b>	√	√		
ACURA	Latin America	EDLC	-	√	√	√	√	-		
ACURA	Latin America	Active Engine Control Mount	_	√	√	<b>√</b>	√	-		
ACURA	Latin America	R/C ENG Starter	-	-	_	√	_	-		
ACURA	Latin America	SVT	-	√	√	<b>√</b>	_	-		
ACURA	United States	Engine System	-	√	√	<b>√</b>	√	√		
ACURA	United States	Automatic Transmission System	-	<b>√</b>	√	<b>√</b>	√	√		
ACURA	United States	Supplemental Inflatable Restraint System	√	√	√	<b>√</b>	√	√		
ACURA	United States	Anti-lock Braking System	-	√	√	<b>√</b>	√	√		
ACURA	United States	Body Electric System	-	√	√	<b>√</b>	√	√		
ACURA	United States	Electric Power Steering	-	√	√	<b>√</b>	√	-		
ACURA	United States	Tire Pressure Monitor System	-	√	√	<b>√</b>	√	-		
ACURA	United States	SH-AWD	-	√	√	√	√	-		
ACURA	United States	SMART-H	_	√	√	√	√	√		
ACURA	United States	Immobilizer System	-	_	_	<b>√</b>	_	-		
ACURA	United States	Integrated Motor Assist System	-	√	√	√	$\checkmark$	<b>√</b>		
ACURA	United States	VTM 4	-	√	√	√	-	_		
ACURA	United States	Adaptive Cruise Control	_	√	√	√	$\checkmark$	_		
ACURA	United States	Hydraulic Booster	-	√	√	√	$\checkmark$	-		
ACURA	United States	Electric Vacuum Pump System	-	√	√	<b>√</b>	_	_		

- 1.  $\sqrt{\ }$ : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

			Function								
Vehicle	Area	System	Read Info.	Read DTC	Clear DTC	Data Stream	Actuation Test	Special Function	Remark		
ACURA	United States	Pop-up Engine Cover	_	√	√	√	_	ı			
ACURA	United States	Active Shock Absorber System	-	√	√	√	_	_			
ACURA	United States	Active Engine Control Mount	_	√	√	√	√	ı			
ACURA	United States	Brake System	_	√	√	√	√	√			
ACURA	United States	Driving Support	-	√	√	√	√	√			
ACURA	United States	Active Damper System	-	√	√	√	_	_			
ACURA	United States	Real Time AWD	-	√	√	√	_	√			
ACURA	United States	Acoustic Vehicle Alerting System	-	√	√	√	_	_			
ACURA	United States	CAN Gateway	-	√	√	-	_	_			
ACURA	United States	Precision All Wheel Steer	-	√	√	√	√	√			
ACURA	United States	EDLC	-	√	√	√	√	_			
ACURA	United States	Active Engine Control Mount	-	√	√	√	√	-			
ACURA	United States	R/C ENG Starter	-	=	-	√	_	-			
ACURA	United States	SVT	-	<b>√</b>	√	√	_				