

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
1 Series	E81/E82/E87/E88	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
1 Series	E81/E82/E87/E88	Body	AHM Trailer module	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	AMP Amplifier	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CA Comfort access system	●	●	●	●	○	●
1 Series	E81/E82/E87/E88	Body	CAN communication analysis	●	●	○	○	○	○
1 Series	E81/E82/E87/E88	Body	CCC-A Applications	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●
1 Series	E81/E82/E87/E88		CCC-ASK Audio system controller	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CCC-BO User interface	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CCC-GW Gateway	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CDC CD Changer	●	●	●	○	●	●
1 Series	E81/E82/E87/E88	Body	CIC Car Information Computer	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CIC-GW Gateway	●	●	●	○	●	●
1 Series	E81/E82/E87/E88	Body	CID Central information display	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CON Controller	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CVM/CVM2 Convertible top module	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	DWA anti-theft alarm system	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	FRM footwell module	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	FRM2 footwell module 2	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	FZD Function centre,roof	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	IHKR Heater and A/C control	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	IHR Integrated heater control	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	INSTR Instrument cluster	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	JBE Junction-box electronics	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	JBE2 Junction Box electronics	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	JNAV Navigation system,Japan	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	M-ASK-BO User interface	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	M-ASK-GW Gateway	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	M-ASK-NAV Navigation system	●	●	●	●	●	○
1 Series	E81/E82/E87/E88	Body	MOST system analysis	●	○	○	●	●	○
1 Series	E81/E82/E87/E88	Body	PDC Park distance control	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	RAD Radio	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	RAD2-BO User interface	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	RAD2-GW Gateway	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	○	○
1 Series	E81/E82/E87/E88	Body	SDARS Satellite tuner	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	SINE Siren and tilt sensor	●	●	●	●	○	○
1 Series	E81/E82/E87/E88	Body	SMBF Seat memory,front passenger	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	SMFA Seat module,driver	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	TCU Telematic control unit	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	ULF-SBX Interface box	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Chassis	AL active front steering(AFS70)	●	●	●	●	○	●
1 Series	E81/E82/E87/E88	Chassis	AL active steering	●	●	●	●	○	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
1 Series	E81/E82/E87/E88	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Drive	CAS Car Access System	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Drive	EKPS fuel-pump control	●	●	●	●	●	●
3 Series	E30	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	
3 Series	E30	Drive	EML(Engine-Power Control)	●	●	●	●	○	
3 Series	E30	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	
3 Series	E30	Body	KOM(Instrument cluster)	●	●	●	●	●	
3 Series	E30	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	
3 Series	E30	Drive	GSR(Cruise control)	●	●	●	●	○	
3 Series	E30	Body	AB(airbag)	●	●	●	●	○	
3 Series	E30	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	
3 Series	E30	Body	IHK(Heater-A/C system)	●	●	●	●	○	
3 Series	E30	Chassis	ABS(Anti-lock braking system) ASC(Automatic stabilitycontrol) ABD(Automatic brake differential(All-wheeldrive))	●	●	●	●	●	
3 Series	E30	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	
3 Series	E30	Body	ADS(Throttle-valve control)	●	●	●	●	○	
3 Series	E30	Chassis	ABS/ASC tester	●	●	●	●	○	
3 Series	E36[<9803]	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	
3 Series	E36[<9803]	Drive	EML(Engine-Power Control)	●	●	●	●	○	
3 Series	E36[<9803]	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	
3 Series	E36[<9803]	Body	KOM(Instrument cluster)	●	●	●	●	●	
3 Series	E36[<9803]	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	
3 Series	E36[<9803]	Drive	GSR(Cruise control)	●	●	●	●	○	
3 Series	E36[<9803]	Body	AB(airbag)	●	●	●	●	○	
3 Series	E36[<9803]	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	
3 Series	E36[<9803]	Body	IHK(Heater-A/C system)	●	●	●	●	○	
3 Series	E36[<9803]	Chassis	ABS(Anti-lock braking system) ASC(Automatic stabilitycontrol) ABD(Automatic brake differential(All-wheeldrive)) DSC(Dynamic stability control('94->))	●	●	●	●	●	
3 Series	E36[<9803]	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	
3 Series	E36[<9803]	Body	ADS(Throttle-valve control)	●	●	●	●	○	
3 Series	E36[<9803]	Chassis	ABS/ASC tester	●	●	●	●	○	
3 Series	E36[>9803]	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
3 Series	E36[>9803]	Body	BCO/MID On-board computer/MID	●	●	●	●	●	●
3 Series	E36[>9803]	Body	CVM/CVM2 Convertible top module	●	●	●	●	●	●
3 Series	E36[>9803]	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	E36[>9803]	Body	IR Radio/infrared locking system	●	●	●	●	●	●
3 Series	E36[>9803]	Body	KOM Instrument cluster	●	●	●	●	●	○
3 Series	E36[>9803]	Body	PDC Park distance control	●	●	●	●	●	●
3 Series	E36[>9803]	Body	URS Rollover sensor	●	●	●	●	○	○
3 Series	E36[>9803]	Body	ZKE Central body electronics	●	●	●	●	●	○
3 Series	E36[>9803]	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
3 Series	E36[>9803]	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
3 Series	E36[>9803]	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
3 Series	E36[>9803]	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
3 Series	E36[>9803]	Drive	GR Cruise control	●	●	●	●	●	○
3 Series	E36[>9803]	Drive	TOENS Thermal oil-level sensor	●	●	●	●	●	○
3 Series	E46	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
3 Series	E46	Body	AHL Adaptive directional headlights	●	●	●	●	●	●
3 Series	E46	Body	AIC Automatic Interval control	●	●	●	●	○	○
3 Series	E46	Body	BIT Basis Interface Telephone	●	●	●	●	○	○
3 Series	E46	Body	BM On-board monitor	●	●	●	●	●	○
3 Series	E46	Body	CVM/CVM2 Convertible top module	●	●	●	●	●	●
3 Series	E46	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
3 Series	E46	Body	IHKR Heater and A/C control	●	●	●	●	●	●
3 Series	E46	Body	JBIT Japan Basis Interface Telephone	●	○	○	●	○	○
3 Series	E46	Body	KOM Instrument cluster	●	●	●	●	●	○
3 Series	E46	Body	LSZ Light switching centre	●	●	●	●	●	○
3 Series	E46	Body	MIR Multi-Information Radio	●	●	●	●	○	○
3 Series	E46	Body	NAJ Navigation computer,Japan	●	●	●	●	●	○
3 Series	E46	Body	NAR Navigation radio	●	●	●	○	●	○
3 Series	E46	Body	NAV Navigation computer	●	●	●	●	●	○
3 Series	E46	Body	NAV Navigation computer MKII	●	●	●	●	○	○
3 Series	E46	Body	PDC Park distance control	●	●	●	●	●	●
3 Series	E46	Body	RAD Radio	●	●	●	●	●	●
3 Series	E46	Body	RLS Rain/Light Sensor	●	●	●	●	○	●
3 Series	E46	Body	SES Language-input system	●	●	●	○	●	○
3 Series	E46	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●
3 Series	E46	Body	SMB Entrance aid,passenger	●	●	●	●	○	○
3 Series	E46	Body	SMF Entrance aid,driver	●	●	●	●	●	○
3 Series	E46	Body	SMF Seat memory,driver	●	●	●	●	●	○
3 Series	E46	Body	SPMBT Mirror memory,passenger	●	●	●	●	●	○
3 Series	E46	Body	SPMFT Mirror memory,driver	●	●	●	●	●	○
3 Series	E46	Body	SZM Switching centre,centre console	●	●	●	●	●	●
3 Series	E46	Body	TCU Telematic control unit	●	●	●	●	●	●
3 Series	E46	Body	TEL Telephone interface	○	○	○	●	●	○
3 Series	E46	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
3 Series	E46	Body	URS Rollover sensor	●	●	●	●	○	○
3 Series	E46	Body	VID Video module	●	●	●	○	○	○
3 Series	E46	Body	VID Video module III	●	●	●	○	○	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	E46	Body	ZKE Central body electronics	●	●	●	●	●	○
3 Series	E46	Body	ZUH Auxiliary heater	●	●	●	●	●	○
3 Series	E46	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
3 Series	E46	Chassis	DDS Deflation Detection System	●	●	●	●	○	○
3 Series	E46	Chassis	LWS Steering angle sensor	●	●	●	●	○	○
3 Series	E46	Chassis	MFL Multi-function steering wheel	●	●	●	●	○	○
3 Series	E46	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
3 Series	E46	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
3 Series	E46	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
3 Series	E46	Drive	EKP Fuel pump	●	●	●	●	●	○
3 Series	E46	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
3 Series	E46	Drive	GR Cruise control	●	●	●	●	●	○
3 Series	E90/E91/E92/E93	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Body	AHM Trailer module	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	AMP Amplifier	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CA Comfort access system	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Body	CAN communication analysis	●	●	○	○	○	○
3 Series	E90/E91/E92/E93	Body	CCC-A Applications	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CCC-ASK Audio system controller	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CCC-BO User interface	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CCC-GW Gateway	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CDC CD Changer	●	●	●	○	●	●
3 Series	E90/E91/E92/E93	Body	CIC Car Information Computer	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CIC-GW Gateway	●	●	●	○	●	●
3 Series	E90/E91/E92/E93	Body	CID Central information display	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CNAV Navigation system,China	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CON Controller	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CTM Convertible-top module	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	DAB Digital tuner	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	DWA anti-theft alarm system	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	FLA High Beam Assist	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	FRM footwell module	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	FRM2 footwell module 2	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	FZD Function centre,roof	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	IBOC Digital tuner US	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	IHKR Heater and A/C control	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	IHR Integrated heater control	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	INSTR Instrument cluster	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	JBE Junction-box electronics	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	JBE2 Junction Box electronics	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	JNAV Navigation system,Japan	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	KNAV Navigation system,Korea	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	E90/E91/E92/E93	Body	M-ASK-BO User interface	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	M-ASK-GW Gateway	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	M-ASK-NAV Navigation system	●	●	●	●	●	○
3 Series	E90/E91/E92/E93	Body	MOST system analysis	●	●	●	○	○	○
3 Series	E90/E91/E92/E93	Body	PDC Park distance control	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	RAD Radio	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	RAD2-BO User interface	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	RAD2-GW Gateway	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	○	○
3 Series	E90/E91/E92/E93	Body	SDARS Satellite tuner	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	SHD Panorama glass sunroof	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	SINE Siren and tilt sensor	●	●	●	●	○	○
3 Series	E90/E91/E92/E93	Body	SMBF Seat module,passenger	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	SMFA Seat module,driver	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	TCU Telematic control unit	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	ULF-SBX Interface box	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	VM Video Module	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	ACC Active Cruise Control	●	●	●	○	○	●
3 Series	E90/E91/E92/E93	Chassis	AL active front steering(AFS70)	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Chassis	AL active steering	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Chassis	EDC Damper Control	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	LDM Longitudinal Dynamics	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	CAS Car Access System	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	DKG Twin-clutch gearbox	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	EKPS fuel-pump control	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	GWS Gear selector switch	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	VTG Transfer case	●	●	●	●	●	●
5 Series	E28	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
5 Series	E28	Drive	EML(Engine-Power Control)	●	●	●	●	○	●
5 Series	E28	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
5 Series	E28	Body	KOM(Instrument cluster)	●	●	●	●	●	●
5 Series	E28	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	●
5 Series	E28	Drive	GSR(Cruise control)	●	●	●	●	○	●
5 Series	E28	Body	AB(airbag)	●	●	●	●	○	●
5 Series	E28	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	●
5 Series	E28	Body	IHK(Heater-A/C system)	●	●	●	●	○	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
			ABS(Anti-lock braking system)						
5 Series	E28	Chassis		●	●	●	●	●	
5 Series	E28	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	
5 Series	E28	Body	ADS(Throttle-valve control)	●	●	●	●	○	
5 Series	E28	Chassis	ABS/ASC tester	●	●	●	●	○	
5 Series	E34	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	
5 Series	E34	Drive	EML(Engine-Power Control)	●	●	●	●	○	
5 Series	E34	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	
5 Series	E34	Body	KOM(Instrument cluster)	●	●	●			
5 Series	E34	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	
5 Series	E34	Drive	GSR(Cruise control)	●	●	●	●	○	
5 Series	E34	Body	AB(airbag)	●	●	●	●	○	
5 Series	E34	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	
5 Series	E34	Body	IHK(Heater-A/C system)	●	●	●	●	○	
5 Series	E34	Chassis	ABS(Anti-lock braking system) ASC(Automatic stabilitycontrol) ABD(Automatic brake differential(All-wheeldrive))	●	●	●	●	●	
5 Series	E34	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	
5 Series	E34	Body	ADS(Throttle-valve control)	●	●	●	●	○	
5 Series	E34	Chassis	ABS/ASC tester	●	●	●	●	○	
5 Series	E39	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
5 Series	E39	Body	AIC Automatic Interval control	●	●	●	●	○	○
5 Series	E39	Body	BIT Basis Interface Telephone	●	●	●	●	○	○
5 Series	E39	Body	BM On-board monitor	●	●	●	●	●	○
5 Series	E39	Body	DSP Digital Sound Processor	●	●	●	●	○	○
5 Series	E39	Body	GM base module	●	●	●	●	●	○
5 Series	E39	Body	GSR Cruise control	●	●	●	●	○	○
5 Series	E39	Body	HKM Boot-lid module	●	●	●	○	○	○
5 Series	E39	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
5 Series	E39	Body	IHKR Heater and A/C control	●	●	●	●	●	●
5 Series	E39	Body	IHR Integrated heater control	●	●	●	●	●	●
5 Series	E39	Body	IKE Instrument-cluster electronics	●	●	●	○	○	○
5 Series	E39	Body	IRIS Integrated Radio-Information	●	○	○	○	○	○
5 Series	E39	Body	JBIT Japan Basis Interface Telephone	●	○	○	●	○	○
5 Series	E39	Body	KOM Instrument cluster	●	●	●	●	●	○
5 Series	E39	Body	LCM Light Check Module	●	●	●	●	●	○
5 Series	E39	Body	LCM Light Check Module IV	●	●	●	●	●	○
5 Series	E39	Body	LRA Automatic headlight vertical aim control	●	●	●	●	●	○
5 Series	E39	Body	MID Multi Information Display	●	●	●	○	○	○
5 Series	E39	Body	NAJ Navigation computer,Japan	●	●	●	●	●	○
5 Series	E39	Body	NAV Navigation computer	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	E39	Body	PDC Park distance control	●	●	●	●	●	●
5 Series	E39	Body	RAD Radio	●	●	●	●	●	●
5 Series	E39	Body	RLS Rain/Light Sensor	●	●	●	●	○	●
5 Series	E39	Body	SES Language-input system	●	●	●	○	●	○
5 Series	E39	Body	SM/LSM Seat/steering-column memory	○	○	○	●	●	○
5 Series	E39	Body	STH park heating	●	●	●	●	●	○
5 Series	E39	Body	SZM Switching centre,centre console	●	●	●	●	●	●
5 Series	E39	Body	TCU Telematic control unit	●	●	●	●	●	●
5 Series	E39	Body	TEL Telephone interface	○	○	○	●	●	○
5 Series	E39	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
5 Series	E39	Body	VID Video module	●	●	●	○	○	○
5 Series	E39	Body	ZKE Central body electronics	●	●	●	●	●	○
5 Series	E39	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
5 Series	E39	Chassis	DDS Deflation Detection System	●	●	●	●	○	○
5 Series	E39	Chassis	EDC Damper Control	●	●	●	●	●	●
5 Series	E39	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●
5 Series	E39	Chassis	LEW Steering-angle sensor	●	●	●	●	○	○
5 Series	E39	Chassis	MFL Multi-function steering wheel	●	●	●	●	○	○
5 Series	E39	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
5 Series	E39	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
5 Series	E39	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
5 Series	E39	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
5 Series	E39	Drive	GR Cruise control	●	●	●	●	●	○
5 Series	E60/E61	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
5 Series	E60/E61	Body	AHL Adaptive directional headlights	●	●	●	●	●	●
5 Series	E60/E61	Body	AHM Trailer module	●	●	●	●	●	●
5 Series	E60/E61	Body	ALBBF active backrest width,front passenger	●	●	●	●	○	●
5 Series	E60/E61	Body	ALBFA active backrest width,driver	●	●	●	●	○	●
5 Series	E60/E61	Body	AMP Amplifier	●	●	●	●	●	●
5 Series	E60/E61	Body	CA Comfort access system	●	●	●	●	○	●
5 Series	E60/E61	Body	CAN communication analysis	●	●	○	○	○	○
5 Series	E60/E61	Body	CCC-A Applications	●	●	●	●	●	●
5 Series	E60/E61	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●
5 Series	E60/E61	Body	CCC-ASK Audio system controller	●	●	●	●	●	●
5 Series	E60/E61	Body	CCC-BO User interface	●	●	●	●	●	●
5 Series	E60/E61	Body	CCC-GW Gateway	●	●	●	●	●	●
5 Series	E60/E61	Body	CDC CD Changer	●	●	●	○	●	●
5 Series	E60/E61	Body	CHAMP-BO User interface	●	●	●	●	●	●
5 Series	E60/E61	Body	CHAMP-GW Gateway	●	●	●	●	●	●
5 Series	E60/E61	Body	CIC Car Information Computer	●	●	●	●	●	●
5 Series	E60/E61	Body	CIC-GW Gateway	●	●	●	○	●	●
5 Series	E60/E61	Body	CID Central information display	●	●	●	●	●	●
5 Series	E60/E61	Body	CNAV Navigation system,China	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	E60/E61	Body	CON Controller	●	●	●	●	●	●
5 Series	E60/E61	Body	DAB Digital tuner	●	●	●	●	●	●
5 Series	E60/E61	Body	DVDC DVD Changer	●	●	●	○	●	●
5 Series	E60/E61	Body	DWA anti-theft alarm system	●	●	●	●	●	●
5 Series	E60/E61	Body	FBI Flexible Bus Interface	●	●	●	●	○	●
5 Series	E60/E61	Body	FD Rear-compartment display	●	●	●	●	●	●
5 Series	E60/E61	Body	FD2 Rear-compartment display 2	●	●	●	●	●	●
5 Series	E60/E61	Body	FLA High Beam Assist	●	●	●	●	●	●
5 Series	E60/E61	Body	HKL Rear-lid lift	●	●	●	●	●	●
5 Series	E60/E61	Body	HUD Head-Up Display	●	●	●	●	●	●
5 Series	E60/E61	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
5 Series	E60/E61	Body	INSTR Instrument cluster	●	●	●	●	●	●
5 Series	E60/E61	Body	JNAV Navigation system,Japan	●	●	●	●	●	●
5 Series	E60/E61	Body	KBM Body basic module	●	●	●	●	●	●
5 Series	E60/E61	Body	KGM Body Gateway Module	●	●	●	●	●	●
5 Series	E60/E61	Body	KHI Headset interface	●	●	●	●	●	●
5 Series	E60/E61	Body	KNAV Navigation system,Korea	●	●	●	●	●	●
5 Series	E60/E61	Body	LM2 Light module 2	●	●	●	●	●	●
5 Series	E60/E61	Body	LM2 Light module 2 with adaptive headlight	●	●	●	●	●	●
5 Series	E60/E61	Body	LM2 AHL2 Light module 2 with adaptive headlight 2	●	●	●	●	●	●
5 Series	E60/E61	Body	M-ASK-BO User interface	●	●	●	●	●	●
5 Series	E60/E61	Body	M-ASK-GW Gateway	●	●	●	●	●	●
5 Series	E60/E61	Body	M-ASK-NAV Navigation system	●	●	●	●	●	○
5 Series	E60/E61	Body	MOST system analysis	●	●	●	○	○	○
5 Series	E60/E61	Body	MPM Micro-power module	●	●	●	●	●	●
5 Series	E60/E61	Body	NVE Night Vision Electronics	●	●	●	●	●	●
5 Series	E60/E61	Body	NVK Night Vision camera	●	●	●	●	●	●
5 Series	E60/E61	Body	PDC Park distance control	●	●	●	●	●	●
5 Series	E60/E61	Body	RLS Rain/Light Sensor	●	●	●	●	○	●
5 Series	E60/E61	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	○	○
5 Series	E60/E61	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●
5 Series	E60/E61	Body	SBSL Satellite,B-pillar,left	●	●	●	●	○	●
5 Series	E60/E61	Body	SBSR Satellite,B-pillar,right	●	●	●	●	●	●
5 Series	E60/E61	Body	SDARS Satellite tuner	●	●	●	●	●	●
5 Series	E60/E61	Body	SFZ Satellite vehicle centre	●	●	●	●	○	●
5 Series	E60/E61	Body	SGM-SIM Safety and Gateway	●	●	●	●	●	●
5 Series	E60/E61	Body	SGM-ZGM Safety and Gateway Module(ZGM)	●	●	●	○	○	●
5 Series	E60/E61	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●
5 Series	E60/E61	Body	SHZH Independent/auxiliary heater	●	●	●	●	●	●
5 Series	E60/E61	Body	SINE Siren and tilt sensor	●	●	●	●	○	○
5 Series	E60/E61	Body	SMBF Seat module,passenger	●	●	●	●	●	●
5 Series	E60/E61	Body	SMFA Seat module,driver	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	E60/E61	Body	SVS Language processing system	●	●	●	○	●	●
5 Series	E60/E61	Body	SZL Steering column switch centre 2	●	●	●	●	●	●
5 Series	E60/E61	Body	SZL Switch centre, steering column	●	●	●	●	●	●
5 Series	E60/E61	Body	SZM Switching centre,centre console	●	●	●	●	●	●
5 Series	E60/E61	Body	TCU Telematic control unit	●	●	●	●	●	●
5 Series	E60/E61	Body	TLC Lane Departure Warning	●	●	●	●	●	○
5 Series	E60/E61	Body	TMBF Door module,front passenger	●	●	●	●	●	●
5 Series	E60/E61	Body	TMFA Door module,driver	●	●	●	●	○	●
5 Series	E60/E61	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
5 Series	E60/E61	Body	ULF-SBX Interface box	●	●	●	●	●	●
5 Series	E60/E61	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●
5 Series	E60/E61	Body	VM Video Module	●	●	●	●	●	●
5 Series	E60/E61	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
5 Series	E60/E61	Chassis	ACC Active Cruise Control	●	●	●	○	○	●
5 Series	E60/E61	Chassis	ACC2 Active Cruise Control 2	●	●	●	○	○	●
5 Series	E60/E61	Chassis	AL active front steering(AFS70)	●	●	●	●	○	●
5 Series	E60/E61	Chassis	AL active steering	●	●	●	●	○	●
5 Series	E60/E61	Chassis	ARS Dynamic Drive 2	●	●	●	●	●	●
5 Series	E60/E61	Chassis	EDC Damper Control	●	●	●	●	●	●
5 Series	E60/E61	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●
5 Series	E60/E61	Chassis	LDM Longitudinal Dynamics	●	●	●	●	○	●
5 Series	E60/E61	Chassis	LRR Long-range sensor	●	●	●	○	○	●
5 Series	E60/E61	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
5 Series	E60/E61	Drive	CAS Car Access System	●	●	●	●	●	●
5 Series	E60/E61	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
5 Series	E60/E61	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
5 Series	E60/E61	Drive	EKPS fuel-pump control	●	●	●	●	●	●
5 Series	E60/E61	Drive	GWS Gear selector switch	●	●	●	●	●	●
5 Series	E60/E61	Drive	VTC Valvetronic	●	○	○	○	○	●
5 Series	E60/E61	Drive	VTC2 Valvetronic 2	●	○	○	○	○	●
5 Series	E60/E61	Drive	VTG Transfer case	●	●	●	●	●	●
6 Series	E24	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
6 Series	E24	Drive	EML(Engine-Power Control)	●	●	●	●	○	●
6 Series	E24	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
6 Series	E24	Body	KOM(Instrument cluster)	●	●	●	●	●	●
6 Series	E24	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	●
6 Series	E24	Drive	GSR(Cruise control)	●	●	●	●	○	●
6 Series	E24	Body	AB(airbag)	●	●	●	●	○	●
6 Series	E24	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	●
6 Series	E24	Body	IHK(Heater-A/C system)	●	●	●	●	○	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
6 Series	E24	Chassis	ABS(Anti-lock braking system) ASC(Automatic stability control) ABD(Automatic brake differential(All-wheeldrive))	●	●	●	●	●	
6 Series	E24	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	
6 Series	E24	Body	ADS(Throttle-valve control)	●	●	●	●	○	
6 Series	E24	Chassis	ABS/ASC tester	●	●	●	●	○	
6 Series	E63/E64	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
6 Series	E63/E64	Body	AHL Adaptive directional headlights	●	●	●	●	●	●
6 Series	E63/E64	Body	AMP Amplifier	●	●	●	●	●	●
6 Series	E63/E64	Body	CA Comfort access system	●	●	●	●	○	●
6 Series	E63/E64	Body	CAN communication analysis	●	●	○	○	○	○
6 Series	E63/E64	Body	CCC-A Applications	●	●	●	●	●	●
6 Series	E63/E64	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●
6 Series	E63/E64	Body	CCC-ASK Audio system controller	●	●	●	●	●	●
6 Series	E63/E64	Body	CCC-BO User interface	●	●	●	●	●	●
6 Series	E63/E64	Body	CCC-GW Gateway	●	●	●	●	●	●
6 Series	E63/E64	Body	CDC CD Changer	●	●	●	○	●	●
6 Series	E63/E64	Body	CHAMP-BO User interface	●	●	●	●	●	●
6 Series	E63/E64	Body	CHAMP-GW Gateway	●	●	●	●	●	●
6 Series	E63/E64	Body	CIC Car Information Computer	●	●	●	●	●	●
6 Series	E63/E64	Body	CIC-GW Gateway	●	●	●	○	●	●
6 Series	E63/E64	Body	CID Central information display	●	●	●	●	●	●
6 Series	E63/E64	Body	CNAV Navigation system,China	●	●	●	●	●	●
6 Series	E63/E64	Body	CON Controller	●	●	●	●	●	●
6 Series	E63/E64	Body	CVM/CVM2 Convertible top module	●	●	●	●	●	●
6 Series	E63/E64	Body	DAB Digital tuner	●	●	●	●	●	●
6 Series	E63/E64	Body	DVDC DVD Changer	●	●	●	○	●	●
6 Series	E63/E64	Body	DWA anti-theft alarm system	●	●	●	●	●	●
6 Series	E63/E64	Body	FLA High Beam Assist	●	●	●	●	●	●
6 Series	E63/E64	Body	HUD Head-Up Display	●	●	●	●	●	●
6 Series	E63/E64	Body	IBOC Digital tuner US	●	●	●	●	○	●
6 Series	E63/E64	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
6 Series	E63/E64	Body	INSTR Instrument cluster	●	●	●	●	●	●
6 Series	E63/E64	Body	JNAV Navigation system,Japan	●	●	●	●	●	●
6 Series	E63/E64	Body	KBM Body basic module	●	●	●	●	●	●
6 Series	E63/E64	Body	KGM Body Gateway Module	●	●	●	●	●	●
6 Series	E63/E64	Body	KNAV Navigation system,Korea	●	●	●	●	●	●
6 Series	E63/E64	Body	LM2 Light module 2	●	●	●	●	●	●
6 Series	E63/E64	Body	LM2 AHL light module 2 with adaptive headlight	●	●	●	●	●	●
6 Series	E63/E64	Body	LM2 AHL2 Light module 2 with adaptive headlight 2	●	●	●	●	●	●
6 Series	E63/E64	Body	M-ASK-BO User interface	●	●	●	●	●	●
6 Series	E63/E64	Body	M-ASK-GW Gateway	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
6 Series	E63/E64	Body	MOST system analysis	●	●	●	○	○	○
6 Series	E63/E64	Body	MPM Micro-power module	●	●	●	●	●	●
6 Series	E63/E64	Body	NVE Night Vision Electronics	●	●	●	●	●	●
6 Series	E63/E64	Body	NVK Night Vision camera	●	●	●	●	●	●
6 Series	E63/E64	Body	PDC Park distance control	●	●	●	●	●	●
6 Series	E63/E64	Body	RLS Rain/Light Sensor	●	●	●	●	○	●
6 Series	E63/E64	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	○	○
6 Series	E63/E64	Body	SBSL Satellite,B-pillar,left	●	●	●	●	○	●
6 Series	E63/E64	Body	SBSR Satellite,B-pillar,right	●	●	●	●	●	●
6 Series	E63/E64	Body	SDARS Satellite tuner	●	●	●	●	●	●
6 Series	E63/E64	Body	SFZ Satellite vehicle centre	●	●	●	●	○	●
6 Series	E63/E64	Body	SGM-SIM Safety and Gateway	●	●	●	●	●	●
6 Series	E63/E64	Body	SGM-ZGM Safety and Gateway Module(ZGM)	●	●	●	○	○	●
6 Series	E63/E64	Body	SHD Slide/tilt sunroof 2	●	●	●	●	●	●
6 Series	E63/E64	Body	SHZH Independent/auxiliary heater	●	●	●	●	●	●
6 Series	E63/E64	Body	SMBF Seat memory,front passenger	●	●	●	●	●	●
6 Series	E63/E64	Body	SMF Seat memory,driver	●	●	●	●	●	○
6 Series	E63/E64	Body	SVS Language processing system	●	●	●	○	●	●
6 Series	E63/E64	Body	SZL Steering column switch centre 2	●	●	●	●	●	●
6 Series	E63/E64	Body	SZL Switch centre, steering column	●	●	●	●	●	●
6 Series	E63/E64	Body	SZM Switching centre,centre console	●	●	●	●	●	●
6 Series	E63/E64	Body	TCU Telematic control unit	●	●	●	●	●	●
6 Series	E63/E64	Body	TLC Lane Departure Warning	●	●	●	●	●	○
6 Series	E63/E64	Body	TMBF Door module,front passenger	●	●	●	●	●	●
6 Series	E63/E64	Body	TMFA Door module,driver	●	●	●	●	○	●
6 Series	E63/E64	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
6 Series	E63/E64	Body	ULF-SBX Interface box	●	●	●	●	●	●
6 Series	E63/E64	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●
6 Series	E63/E64	Body	VM Video Module	●	●	●	●	●	●
6 Series	E63/E64	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
6 Series	E63/E64	Chassis	ACC2 Active Cruise Control 2	●	●	●	○	○	●
6 Series	E63/E64	Chassis	AL active front steering(AFS70)	●	●	●	●	○	●
6 Series	E63/E64	Chassis	AL active steering	●	●	●	●	○	●
6 Series	E63/E64	Chassis	ARS Dynamic Drive	●	●	●	●	●	●
6 Series	E63/E64	Chassis	ARS Dynamic Drive 2	●	●	●	●	●	●
6 Series	E63/E64	Chassis	EDC Damper Control	●	●	●	●	●	●
6 Series	E63/E64	Chassis	LDM Longitudinal Dynamics	●	●	●	●	○	●
6 Series	E63/E64	Chassis	LRR Long-range sensor	●	●	●	○	○	●
6 Series	E63/E64	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
6 Series	E63/E64	Drive	CAS Car Access System	●	●	●	●	●	●
6 Series	E63/E64	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
6 Series	E63/E64	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
6 Series	E63/E64	Drive	EKPS fuel-pump control	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
6 Series	E63/E64	Drive	GWS Gear selector switch	●	●	●	●	●	●
6 Series	E63/E64	Drive	VTC Valvetronic	●	○	○	○	○	●
6 Series	E63/E64	Drive	VTC2 Valvetronic 2	●	○	○	○	○	●
7 Series	E23	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	
7 Series	E23	Drive	EML(Engine-Power Control)	●	●	●	●	○	
7 Series	E23	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	
7 Series	E23	Body	KOM(Instrument cluster)	●	●	●			
7 Series	E23	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	
7 Series	E23	Drive	GSR(Cruise control)	●	●	●	●	○	
7 Series	E23	Body	AB(airbag)	●	●	●	●	○	
7 Series	E23	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	
7 Series	E23	Body	IHK(Heater-A/C system)	●	●	●	●	○	
7 Series	E23	Chassis	ABS(Anti-lock braking system)ASC(Automatic stability control)ABD(Automatic brake differential(All-wheeldrive))	●	●	●	●	●	
7 Series	E23	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	
7 Series	E23	Body	ADS(Throttle-valve control)	●	●	●	●	○	
7 Series	E23	Chassis	ABS/ASC tester	●	●	●	●	○	
7 Series	E32	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	
7 Series	E32	Drive	EML(Engine-Power Control)	●	●	●	●	○	
7 Series	E32	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	
7 Series	E32	Body	KOM(Instrument cluster)	●	●	●			
7 Series	E32	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	
7 Series	E32	Drive	GSR(Cruise control)	●	●	●	●	○	
7 Series	E32	Body	AB(airbag)	●	●	●	●	○	
7 Series	E32	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	
7 Series	E32	Body	IHK(Heater-A/C system)	●	●	●	●	○	
7 Series	E32	Chassis	ABS(Anti-lock braking system)ASC(Automatic stability control)ABD(Automatic brake differential(All-wheeldrive))	●	●	●	●	●	
7 Series	E32	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	
7 Series	E32	Body	ADS(Throttle-valve control)	●	●	●	●	○	
7 Series	E32	Chassis	ABS/ASC tester	●	●	●	●	○	
7 Series	E38	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
7 Series	E38	Body	AIC Automatic Interval control	●	●	●	●	○	○
7 Series	E38	Body	BIT Basis Interface Telephone	●	●	●	●	○	○
7 Series	E38	Body	BM On-board monitor	●	●	●	●	●	○
7 Series	E38	Body	BMBT On-board monitor,control panel	●	●	●	●	○	○
7 Series	E38	Body	CCM Check Control Module	●	●	●	○	○	○
7 Series	E38	Body	DSP Digital Sound Processor	●	●	●	●	○	○
7 Series	E38	Body	FBZV Radio-control system	●	●	●	○	○	○
7 Series	E38	Body	FGB rear compartment blower	●	●	●	○	○	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	E38	Body	FHK rear-compartment heating/air conditioning	●	●	●	○	○	○
7 Series	E38	Body	FID Rear-compartment information display	●	●	●	○	○	○
7 Series	E38	Body	FMBT Rear-compartment monitor,control panel	○	○	○	○	○	○
7 Series	E38	Body	FMGT Rear-compartment monitor,graphics section	○	○	○	○	○	○
7 Series	E38	Body	GR2 Cruise control	●	●	●	●	○	○
7 Series	E38	Body	HKM Boot-lid module	●	●	●	○	○	○
7 Series	E38	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
7 Series	E38	Body	IHKR Heater and A/C control	●	●	●	●	●	●
7 Series	E38	Body	IKE Instrument-cluster electronics	●	●	●	○	○	○
7 Series	E38	Body	IR Infrared compact locking system	○	○	○	○	○	○
7 Series	E38	Body	IR Radio/infrared locking system	○	○	○	○	○	○
7 Series	E38	Body	JBIT Japan Basis Interface Telephone	●	○	○	●	○	○
7 Series	E38	Body	LCM Light Check Module	●	●	●	●	●	○
7 Series	E38	Body	LM Lights Module	●	●	●	●	●	●
7 Series	E38	Body	LRA Automatic headlight vertical aim control	●	●	●	●	●	○
7 Series	E38	Body	MID Multi Information Display	●	●	●	○	○	○
7 Series	E38	Body	NAJ Navigation computer,Japan	●	●	●	●	●	○
7 Series	E38	Body	NAV Navigation computer	●	●	●	●	●	○
7 Series	E38	Body	NAV Navigation computer MKIII	●	●	●	●	○	○
7 Series	E38	Body	PDC Park distance control	●	●	●	●	●	●
7 Series	E38	Body	RAD Radio	●	●	●	●	●	●
7 Series	E38	Body	RCC Radio-clock module	●	○	○	●	○	○
7 Series	E38	Body	SES Language-input system	●	●	●	○	●	○
7 Series	E38	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●
7 Series	E38	Body	SM/LSM Seat/steering-column memory	○	○	○	●	●	○
7 Series	E38	Body	SMB passenger seat memory	●	●	●	●	○	
7 Series	E38	Body	STH park heating	●	●	●	●	●	○
7 Series	E38	Body	SZM Switching centre,centre console	●	●	●	●	●	●
7 Series	E38	Body	TEL Telephone interface	○	○	○	●	●	○
7 Series	E38	Body	URS Rollover sensor	●	●	●	●	○	○
7 Series	E38	Body	VID Video module	●	●	●	○	○	○
7 Series	E38	Body	VID Video module III	●	●	●	○	○	○
7 Series	E38	Body	ZKE Central body electronics	●	●	●	●	●	○
7 Series	E38	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
7 Series	E38	Chassis	EDC Damper Control	●	●	●	●	●	●
7 Series	E38	Chassis	LEW Steering-angle sensor	●	●	●	●	○	○
7 Series	E38	Chassis	MFL Multi-function steering wheel	●	●	●	●	○	○
7 Series	E38	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
7 Series	E38	Chassis	RDW tyre-blowout warning	●	●	●	●	○	○
7 Series	E38	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	E38	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
7 Series	E38	Drive	EML Electronic engine-power control	●	●	●	○	○	○
7 Series	E38	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
7 Series	E38	Drive	TRS Electronic battery isolator switch	●	●	●	○	○	○
7 Series	E65	Body	AHL Adaptive directional headlights	●	●	●	●	●	●
7 Series	E65	Body	AHM Trailer module	●	●	●	●	●	●
7 Series	E65	Body	AMP Amplifier	●	●	●	●	●	●
7 Series	E65	Body	ANT Aerial/antenna tuner	●	●	●	●	●	●
7 Series	E65	Body	ASK Audio system controller	●	●	●	●	●	●
7 Series	E65	Body	BZM Control centre,centre console	●	●	●	●	●	●
7 Series	E65	Body	CA Comfort access system	●	●	●	●	○	●
7 Series	E65	Body	CAN communication analysis	●	●	○	○	○	○
7 Series	E65	Body	CD Control Display	●	●	●	○	●	●
7 Series	E65	Body	CDC CD Changer	●	●	●	○	●	●
7 Series	E65	Body	CD-GW Control Display(Gateway)	●	●	●	●	●	●
7 Series	E65	Body	CEM Clean Energy Module	●	●	●	●	○	○
7 Series	E65	Body	CNAV Navigation system,China	●	●	●	●	●	●
7 Series	E65	Body	CON Controller	●	●	●	●	●	●
7 Series	E65	Body	DAB Digital tuner	●	●	●	●	●	●
7 Series	E65	Body	DVDC DVD Changer	●	●	●	○	●	●
7 Series	E65	Body	DWA anti-theft alarm system	●	●	●	●	●	●
7 Series	E65	Body	FBI Flexible Bus Interface	●	●	●	●	○	●
7 Series	E65	Body	FBZM Rear compartment,control centre,centre console	●	●	●	●	●	●
7 Series	E65	Body	FCON Rear compartment controller	●	●	●	●	●	●
7 Series	E65	Body	FD Rear-compartment display	●	●	●	●	●	●
7 Series	E65	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●
7 Series	E65	Body	FLA High Beam Assist	●	●	●	●	●	●
7 Series	E65	Body	HKL Rear-lid lift	●	●	●	●	●	●
7 Series	E65	Body	IBOC Digital tuner US	●	●	●	●	○	●
7 Series	E65	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
7 Series	E65	Body	INSTR Instrument cluster	●	●	●	●	●	●
7 Series	E65	Body	JBIT Japan Basis Interface Telephone	●	○	○	●	○	○
7 Series	E65	Body	JNAV Navigation system,Japan	●	●	●	●	●	●
7 Series	E65	Body	KHI Headset interface	●	●	●	●	●	●
7 Series	E65	Body	KNAV Navigation system,Korea	●	●	●	●	●	●
7 Series	E65	Body	LM Lights Module	●	●	●	●	●	●
7 Series	E65	Body	LM2 Light module 2	●	●	●	●	●	●
7 Series	E65	Body	LM2 Light module 2 with adaptive headlight	●	●	●	●	●	●
7 Series	E65	Body	LM2 AHL2 Light module 2 with adaptive headlight 2	●	●	●	●	●	●
7 Series	E65	Body	MOST system analysis	●	●	●	○	○	○
7 Series	E65	Body	NAJ Navigation computer,Japan	●	●	●	●	●	○
7 Series	E65	Body	NAV Navigation computer	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	E65	Body	NVE Night Vision Electronics	●	●	●	●	●	●
7 Series	E65	Body	NVK Night Vision camera	●	●	●	●	●	●
7 Series	E65	Body	PDC Park distance control	●	●	●	●	●	●
7 Series	E65	Body	PM Power Module	●	●	●	●	●	●
7 Series	E65	Body	RLS Rain/Light Sensor	●	●	●	●	○	●
7 Series	E65	Body	SASL Satellite,A-pillar,left	●	●	●	●	○	●
7 Series	E65	Body	SASR Satellite,A-pillar,right	●	●	●	●	○	●
7 Series	E65	Body	SBSL Satellite,B-pillar,left	●	●	●	●	○	●
7 Series	E65	Body	SBSR Satellite,B-pillar,right	●	●	●	●	●	●
7 Series	E65	Body	SDARS Satellite tuner	●	●	●	●	●	●
7 Series	E65	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	●
7 Series	E65	Body	SFZ Satellite vehicle centre	●	●	●	●	○	●
7 Series	E65	Body	SG-FD Control unit,rear-compartment display	●	●	●	○	●	●
7 Series	E65	Body	SG-FD-GW Control unit,rear-compartment display(gateway)	●	●	●	●	●	●
7 Series	E65	Body	SGM-SIM Safety and Gateway	●	●	●	●	●	●
7 Series	E65	Body	SGM-ZGM Safety and Gateway Module(ZGM)	●	●	●	○	○	●
7 Series	E65	Body	SHD Slide/tilt sunroof 2	○	○	○	○	○	○
7 Series	E65	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●
7 Series	E65	Body	SHZH Independent/auxiliary heater	●	●	●	●	●	●
7 Series	E65	Body	SIM Safety and Information Module	●	●	●	●	●	○
7 Series	E65	Body	SINE Siren and tilt sensor	●	●	●	●	○	○
7 Series	E65	Body	SMBF Seat module,passenger	●	●	●	●	●	●
7 Series	E65	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	●
7 Series	E65	Body	SMFA Seat module,driver	●	●	●	●	●	●
7 Series	E65	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	●
7 Series	E65	Body	SSBF Satellite,seat,passenger	●	●	●	●	○	●
7 Series	E65	Body	SSFA Satellite,seat,driver	●	●	●	●	○	●
7 Series	E65	Body	SSH Satellite,seat,rear	●	●	●	●	●	●
7 Series	E65	Body	STVL Satellite,door,front left	●	●	●	●	○	●
7 Series	E65	Body	STVR Satellite,door,front right	●	●	●	●	○	●
7 Series	E65	Body	SVS Language processing system	●	●	●	○	●	●
7 Series	E65	Body	SZL Switch centre, steering column	●	●	●	●	●	●
7 Series	E65	Body	TCU Telematic control unit	●	●	●	●	●	●
7 Series	E65	Body	TEL Telephone interface	○	○	○	●	●	○
7 Series	E65	Body	TEL Telephone(USA)	●	●	●	○	●	●
7 Series	E65	Body	TMBFH Door module,passenger's side, rear	●	●	●	●	○	●
7 Series	E65	Body	TMBFT Door module,passenger door	●	●	●	●	○	●
7 Series	E65	Body	TMFAH Door module,driver's side, rear	●	●	●	●	○	●
7 Series	E65	Body	TMFAT Door module,driver's door	●	●	●	●	○	●
7 Series	E65	Body	VM Video Module	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	E65	Body	WIM Wiper module	●	●	●	●	●	●
7 Series	E65	Body	ZBM Two-battery management	●	●	●	●	●	●
7 Series	E65	Body	ZGM Central Gateway Module	●	●	●	○	○	●
7 Series	E65	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
7 Series	E65	Chassis	ACC Active Cruise Control	●	●	●	○	○	●
7 Series	E65	Chassis	ACC2 Active Cruise Control 2	●	●	●	○	○	●
7 Series	E65	Chassis	ARS Dynamic Drive	●	●	●	●	●	●
7 Series	E65	Chassis	ARS Dynamic Drive 2	●	●	●	●	●	●
7 Series	E65	Chassis	CIM Chassis Integration Module	●	●	●	●	●	●
7 Series	E65	Chassis	CIM2 Chassis Integration Module 2	●	●	●	●	●	●
7 Series	E65	Chassis	EDC Damper Control	●	●	●	●	●	●
7 Series	E65	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●
7 Series	E65	Chassis	EMF Parking brake	●	●	●	●	●	●
7 Series	E65	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
7 Series	E65	Drive	CAS Car Access System	●	●	●	●	●	●
7 Series	E65	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
7 Series	E65	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
7 Series	E65	Drive	EKPS fuel-pump control	●	●	●	●	●	●
7 Series	E65	Drive	HPFI control unit	○	○	○	○	○	○
7 Series	E65	Drive	VTC Valvetronic	●	○	○	○	○	●
7 Series	E65	Drive	VTC2 Valvetronic 2	●	○	○	○	○	●
8 Series	E31	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
8 Series	E31	Drive	EML(Engine-Power Control)	●	●	●	●	○	●
8 Series	E31	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
8 Series	E31	Body	KOM(Instrument cluster)	●	●	●	●	●	●
8 Series	E31	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	●
8 Series	E31	Drive	GSR(Cruise control)	●	●	●	●	○	●
8 Series	E31	Body	AB(airbag)	●	●	●	●	○	●
8 Series	E31	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	●
8 Series	E31	Body	IHK(Heater-A/C system)	●	●	●	●	○	●
8 Series	E31	Chassis	ABS(Anti-lock braking system) ASC(Automatic stabilitycontrol) ABD(Automatic brake differential(All-wheeldrive))	●	●	●	●	●	●
8 Series	E31	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	●
8 Series	E31	Body	ADS(Throttle-valve control)	●	●	●	●	○	●
8 Series	E31	Chassis	ABS/ASC tester	●	●	●	●	○	●
X3 Series	E83	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
X3 Series	E83	Body	AHL Adaptive directional headlights	●	●	●	●	●	●
X3 Series	E83	Body	CDC CD Changer	●	●	●	○	●	●
X3 Series	E83	Body	CID Central information display	●	●	●	●	●	●
X3 Series	E83	Body	DSP Digital Sound Processor	●	●	●	●	○	○
X3 Series	E83	Body	GM base module	●	●	●	●	●	○
X3 Series	E83	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X3 Series	E83	Body	IHKR Heater and A/C control	●	●	●	●	●	●
X3 Series	E83	Body	INSTR Instrument cluster	●	●	●	●	●	●
X3 Series	E83	Body	JBIT Japan Basis Interface Telephone	●	○	○	●	○	○
X3 Series	E83	Body	LM Lights Module	●	●	●	●	●	●
X3 Series	E83	Body	LSZ Light switch centre II	●	●	●	●	●	○
X3 Series	E83	Body	MIR Multi-Information Radio	●	●	●	●	○	○
X3 Series	E83	Body	NAJ Navigation computer,Japan	●	●	●	●	●	○
X3 Series	E83	Body	NAV Navigation computer	●	●	●	●	●	○
X3 Series	E83	Body	PDC Park distance control	●	●	●	●	●	●
X3 Series	E83	Body	RAD Radio	●	●	●	●	●	●
X3 Series	E83	Body	RLS Rain/Light Sensor	●	●	●	●	○	●
X3 Series	E83	Body	SBBF Seat occupancy,passenger	●	●	●	○		○
X3 Series	E83	Body	SES Language-input system	●	●	●	○	●	○
X3 Series	E83	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●
X3 Series	E83	Body	SMF Seat memory,driver	●	●	●	●	●	○
X3 Series	E83	Body	SZM Switching centre,centre console	●	●	●	●	●	●
X3 Series	E83	Body	TCU Telematic control unit	●	●	●	●	●	●
X3 Series	E83	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
X3 Series	E83	Body	VID Video module	●	●	●	○	○	○
X3 Series	E83	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
X3 Series	E83	Chassis	LWS Steering angle sensor	●	●	●	●	○	○
X3 Series	E83	Chassis	MFL Multi-function steering wheel	●	●	●	●	○	○
X3 Series	E83	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
X3 Series	E83	Chassis	SVT Servotronic	●	●	●	●	○	○
X3 Series	E83	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
X3 Series	E83	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
X3 Series	E83	Drive	EKPS fuel-pump control	●	●	●	●	●	●
X3 Series	E83	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
X3 Series	E83	Drive	VTG Transfer case	●	●	●	●	●	●
X5 Series	E53	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
X5 Series	E53	Body	AHL Adaptive directional headlights	●	●	●	●	●	●
X5 Series	E53	Body	AIC Automatic Interval control	●	●	●	●	○	○
X5 Series	E53	Body	BIT Basis Interface Telephone	●	●	●	●	○	○
X5 Series	E53	Body	BM On-board monitor	●	●	●	●	●	○
X5 Series	E53	Body	DSP Digital Sound Processor	●	●	●	●	○	○
X5 Series	E53	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
X5 Series	E53	Body	IHKR Heater and A/C control	●	●	●	●	●	●
X5 Series	E53	Body	IKE Instrument-cluster electronics	●	●	●	○	○	○
X5 Series	E53	Body	JBIT Japan Basis Interface Telephone	●	○	○	●	○	○
X5 Series	E53	Body	KOM Instrument cluster	●	●	●	●	●	○
X5 Series	E53	Body	LCM Light Check Module	●	●	●	●	●	○
X5 Series	E53	Body	LCM Light Check Module IV	●	●	●	●	●	○
X5 Series	E53	Body	LRA Automatic headlight vertical aim control	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X5 Series	E53	Body	MID Multi Information Display	●	●	●	○	○	○
X5 Series	E53	Body	NAJ Navigation computer,Japan	●	●	●	●	●	○
X5 Series	E53	Body	NAV Navigation computer	●	●	●	●	●	○
X5 Series	E53	Body	NAV Navigation computer MKII	●	●	●	●	○	○
X5 Series	E53	Body	PDC Park distance control	●	●	●	●	●	●
X5 Series	E53	Body	PDC2 Park Distance Control 2	●	●	●	●	●	○
X5 Series	E53	Body	RAD Radio	●	●	●	●	●	●
X5 Series	E53	Body	RLS Rain/Light Sensor	●	●	●	●	○	●
X5 Series	E53	Body	SBBF Seat occupancy,passenger	●	●	●	○		○
X5 Series	E53	Body	SES Language-input system	●	●	●	○	●	○
X5 Series	E53	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●
X5 Series	E53	Body	SM/SLM Seat/steering-column memory	●	●	●	●	●	○
X5 Series	E53	Body	STH park heating	●	●	●	●	●	○
X5 Series	E53	Body	SZM Switching centre,centre console	●	●	●	●	●	●
X5 Series	E53	Body	TCU Telematic control unit	●	●	●	●	●	●
X5 Series	E53	Body	TEL Telephone interface	○	○	○	●	●	○
X5 Series	E53	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
X5 Series	E53	Body	VID Video module	●	●	●	○	○	○
X5 Series	E53	Body	ZKE Central body electronics	●	●	●	●	●	○
X5 Series	E53	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
X5 Series	E53	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●
X5 Series	E53	Chassis	EHC2 Electronic ride-level control	○	○	○	○	○	○
X5 Series	E53	Chassis	LEW Steering-angle sensor	●	●	●	●	○	○
X5 Series	E53	Chassis	MFL Multi-function steering wheel	●	●	●	●	○	○
X5 Series	E53	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
X5 Series	E53	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
X5 Series	E53	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
X5 Series	E53	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
X5 Series	E53	Drive	VTG Transfer case	●	●	●	●	●	●
X5 Series	E70	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
X5 Series	E70	Body	AHM Trailer module	●	●	●	●	●	●
X5 Series	E70	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●
X5 Series	E70	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●
X5 Series	E70	Body	CA Comfort access system	●	●	●	●	○	●
X5 Series	E70	Body	CAN communication analysis	●	●	○	○	○	○
X5 Series	E70	Body	CCC-A Applications	●	●	●	●	●	●
X5 Series	E70	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●
X5 Series	E70	Body	CCC-ASK Audio system controller	●	●	●	●	●	●
X5 Series	E70	Body	CCC-BO User interface	●	●	●	●	●	●
X5 Series	E70	Body	CCC-GW Gateway	●	●	●	●	●	●
X5 Series	E70	Body	CDC CD Changer	●	●	●	○	●	●
X5 Series	E70	Body	CHAMP-BO User interface	●	●	●	●	●	●
X5 Series	E70	Body	CHAMP-GW Gateway	●	●	●	●	●	●
X5 Series	E70	Body	CID Central information display	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X5 Series	E70	Body	CNAV Navigation system,China	●	●	●	●	●	●
X5 Series	E70	Body	CON Controller	●	●	●	●	●	●
X5 Series	E70	Body	DAB Digital tuner	●	●	●	●	●	●
X5 Series	E70	Body	DVDC DVD Changer	●	●	●	○	●	●
X5 Series	E70	Body	FD Rear-compartment display	●	●	●	●	●	●
X5 Series	E70	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●
X5 Series	E70	Body	FLA High Beam Assist	●	●	●	●	●	●
X5 Series	E70	Body	FRM2 footwell module 2	●	●	●	●	●	●
X5 Series	E70	Body	FZD Function centre,roof	●	●	●	●	●	●
X5 Series	E70	Body	HKL Rear-lid lift	●	●	●	●	●	●
X5 Series	E70	Body	HUD Head-Up Display	●	●	●	●	●	●
X5 Series	E70	Body	IBOC Digital tuner US	●	●	●	●	○	●
X5 Series	E70	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
X5 Series	E70	Body	INSTR Instrument cluster	●	●	●	●	●	●
X5 Series	E70	Body	JBE2 Junction Box electronics	●	●	●	●	●	●
X5 Series	E70	Body	JNAV Navigation system,Japan	●	●	●	●	●	●
X5 Series	E70	Body	KHM Headphones module	○	○	○	○	○	○
X5 Series	E70	Body	KNAV Navigation system,Korea	●	●	●	●	●	●
X5 Series	E70	Body	M-ASK-BO User interface	●	●	●	●	●	●
X5 Series	E70	Body	M-ASK-GW Gateway	●	●	●	●	●	●
X5 Series	E70	Body	MOST system analysis	●	●	●	○	○	○
X5 Series	E70	Body	PDC Park distance control	●	●	●	●	●	●
X5 Series	E70	Body	RFK Reversing camera	●	●	●	●	●	●
X5 Series	E70	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	○	○
X5 Series	E70	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●
X5 Series	E70	Body	SDARS Satellite tuner	●	●	●	●	●	●
X5 Series	E70	Body	SINE Siren and tilt sensor	●	●	●	●	○	○
X5 Series	E70	Body	SMBF Seat module,passenger	●	●	●	●	●	●
X5 Series	E70	Body	SMFA Seat module,driver	●	●	●	●	●	●
X5 Series	E70	Body	TCU Telematic control unit	●	●	●	●	●	●
X5 Series	E70	Body	ULF-SBX Interface box	●	●	●	●	●	●
X5 Series	E70	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●
X5 Series	E70	Body	VM Video Module	●	●	●	●	●	●
X5 Series	E70	Body	VSW video switch	●	●	●	●	●	○
X5 Series	E70	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
X5 Series	E70	Chassis	AL active front steering(AFS70)	●	●	●	●	○	●
X5 Series	E70	Chassis	ARS Dynamic Drive	●	●	●	●	●	●
X5 Series	E70	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●
X5 Series	E70	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●
X5 Series	E70	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●
X5 Series	E70	Chassis	EDCSVV Damper satellite, front right	●	●	●	●	●	●
X5 Series	E70	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●
X5 Series	E70	Chassis	EMF Parking brake	●	●	●	●	●	●
X5 Series	E70	Chassis	RDC Tyre pressure control	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X5 Series	E70	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●
X5 Series	E70	Drive	CAS Car Access System	●	●	●	●	●	●
X5 Series	E70	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
X5 Series	E70	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
X5 Series	E70	Drive	EKPS fuel-pump control	●	●	●	●	●	●
X5 Series	E70	Drive	GWS Gear selector switch	●	●	●	●	●	●
X5 Series	E70	Drive	VTC Valvetronic	●	○	○	○	○	●
X5 Series	E70	Drive	VTC2 Valvetronic 2	●	○	○	○	○	●
X5 Series	E70	Drive	VTG Transfer case	●	●	●	●	●	●
X6 Series	E71	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
X6 Series	E71	Body	AHM Trailer module	●	●	●	●	●	●
X6 Series	E71	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●
X6 Series	E71	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●
X6 Series	E71	Body	CA Comfort access system	●	●	●	●	○	●
X6 Series	E71	Body	CAN communication analysis	●	●	○	○	○	○
X6 Series	E71	Body	CCC-A Applications	●	●	●	●	●	●
X6 Series	E71	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●
X6 Series	E71	Body	CCC-ASK Audio system controller	●	●	●	●	●	●
X6 Series	E71	Body	CCC-BO User interface	●	●	●	●	●	●
X6 Series	E71	Body	CCC-GW Gateway	●	●	●	●	●	●
X6 Series	E71	Body	CDC CD Changer	●	●	●	○	●	●
X6 Series	E71	Body	CHAMP-BO User interface	●	●	●	●	●	●
X6 Series	E71	Body	CHAMP-GW Gateway	●	●	●	●	●	●
X6 Series	E71	Body	CID Central information display	●	●	●	●	●	●
X6 Series	E71	Body	CNAV Navigation system,China	●	●	●	●	●	●
X6 Series	E71	Body	CON Controller	●	●	●	●	●	●
X6 Series	E71	Body	DAB Digital tuner	●	●	●	●	●	●
X6 Series	E71	Body	DVDC DVD Changer	●	●	●	○	●	●
X6 Series	E71	Body	FD Rear-compartment display	●	●	●	●	●	●
X6 Series	E71	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●
X6 Series	E71	Body	FLA High Beam Assist	●	●	●	●	●	●
X6 Series	E71	Body	FRM2 footwell module 2	●	●	●	●	●	●
X6 Series	E71	Body	FZD Function centre,roof	●	●	●	●	●	●
X6 Series	E71	Body	HKL Rear-lid lift	●	●	●	●	●	●
X6 Series	E71	Body	HUD Head-Up Display	●	●	●	●	●	●
X6 Series	E71	Body	IBOC Digital tuner US	●	●	●	●	○	●
X6 Series	E71	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
X6 Series	E71	Body	INSTR Instrument cluster	●	●	●	●	●	●
X6 Series	E71	Body	JBE2 Junction Box electronics	●	●	●	●	●	●
X6 Series	E71	Body	JNAV Navigation system,Japan	●	●	●	●	●	●
X6 Series	E71	Body	KHM Headphones module	●	●	●	●	●	●
X6 Series	E71	Body	KNAV Navigation system,Korea	●	●	●	●	●	●
X6 Series	E71	Body	M-ASK-BO User interface	●	●	●	●	●	●
X6 Series	E71	Body	M-ASK-GW Gateway	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X6 Series	E71	Body	MOST system analysis	●	●	●	○	○	○
X6 Series	E71	Body	PDC Park distance control	●	●	●	●	●	●
X6 Series	E71	Body	RFK Reversing camera	●	●	●	●	●	●
X6 Series	E71	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	○	○
X6 Series	E71	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●
X6 Series	E71	Body	SDARS Satellite tuner	●	●	●	●	●	●
X6 Series	E71	Body	SINE Siren and tilt sensor	●	●	●	●	○	○
X6 Series	E71	Body	SMBF Seat module,passenger	●	●	●	●	●	●
X6 Series	E71	Body	SMFA Seat module,driver	●	●	●	●	●	●
X6 Series	E71	Body	TCU Telematic control unit	●	●	●	●	●	●
X6 Series	E71	Body	ULF-SBX Interface box	●	●	●	●	●	●
X6 Series	E71	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●
X6 Series	E71	Body	VM Video Module	●	●	●	●	●	●
X6 Series	E71	Body	VSW video switch	●	●	●	●	●	○
X6 Series	E71	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
X6 Series	E71	Chassis	AL active steering	●	●	●	●	○	●
X6 Series	E71	Chassis	ARS Dynamic Drive 2	●	●	●	●	●	●
X6 Series	E71	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●
X6 Series	E71	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●
X6 Series	E71	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●
X6 Series	E71	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●
X6 Series	E71	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●
X6 Series	E71	Chassis	EMF Parking brake	●	●	●	●	●	●
X6 Series	E71	Chassis	ICM Integrated Chassis Management	●	●	●	●	○	○
X6 Series	E71	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
X6 Series	E71	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●
X6 Series	E71	Drive	CAS Car Access System	●	●	●	●	●	●
X6 Series	E71	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
X6 Series	E71	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
X6 Series	E71	Drive	EKPS fuel-pump control	●	●	●	●	●	●
X6 Series	E71	Drive	GWS Gear selector switch	●	●	●	●	●	●
X6 Series	E71	Drive	QMVH Lateral-moment distribution,rear axle	●	●	●	●	●	●
X6 Series	E71	Drive	VTG Transfer case	●	●	●	●	●	●
Z Series	E30	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
Z Series	E30	Drive	EML(Engine-Power Control)	●	●	●	●	○	●
Z Series	E30	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
Z Series	E30	Body	KOM(Instrument cluster)	●	●	●	●	●	●
Z Series	E30	Drive	EWS(Electronic car Immobilisation system)	●	●	●	●	○	●
Z Series	E30	Drive	GSR(Cruise control)	●	●	●	●	○	●
Z Series	E30	Body	AB(airbag)	●	●	●	●	○	●
Z Series	E30	Body	SPM/SM(Seat/mirror memory)	●	●	●	●	○	●
Z Series	E30	Body	IHK(Heater-A/C system)	●	●	●	●	○	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
Z Series	E30	Chassis	ABS(Anti-lock braking system) ASC(Automatic stabilitycontrol) ABD(Automatic brake differential(All-wheeldrive))	●	●	●	●	●	
Z Series	E30	Chassis	DSC(Dynamic stability control)	●	●	●	●	○	
Z Series	E30	Body	ADS(Throttle-valve control)	●	●	●	●	○	
Z Series	E30	Chassis	ABS/ASC tester	●	●	●	●	○	
Z3 Series	E36	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
Z3 Series	E36	Body	IR Radio/infrared locking system	●	●	●	●	●	●
Z3 Series	E36	Body	KOM Instrument cluster	●	●	●	●	●	○
Z3 Series	E36	Body	ZKE Central body electronics	●	●	●	●	●	○
Z3 Series	E36	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
Z3 Series	E36	Chassis	LEW Steering-angle sensor	●	●	●	●	○	○
Z3 Series	E36	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
Z3 Series	E36	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
Z3 Series	E36	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
Z3 Series	E36	Drive	GR Cruise control	●	●	●	●	●	○
Z3 Series	E36	Drive	TOENS Thermal oil-level sensor	●	●	●	●	●	○
Z4 Series	E85/E86	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
Z4 Series	E85/E86	Body	CDC CD Changer	●	●	●	○	●	●
Z4 Series	E85/E86	Body	CID Central information display	●	●	●	●	●	●
Z4 Series	E85/E86	Body	CVM/CVM2 Convertible top module	●	●	●	●	●	●
Z4 Series	E85/E86	Body	DSP Digital Sound Processor	●	●	●	●	○	○
Z4 Series	E85/E86	Body	GM5 General module 5	●	●	●	●	●	○
Z4 Series	E85/E86	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
Z4 Series	E85/E86	Body	IHKS Integrated heating/air-conditioning control	●	●	●	●	●	●
Z4 Series	E85/E86	Body	INSTR Instrument cluster	●	●	●	●	●	●
Z4 Series	E85/E86	Body	LSZ Light switch centre II	●	●	●	●	●	○
Z4 Series	E85/E86	Body	MIR Multi-Information Radio	●	●	●	●	○	○
Z4 Series	E85/E86	Body	NAJ Navigation computer,Japan	●	●	●	●	●	○
Z4 Series	E85/E86	Body	NAV Navigation computer	●	●	●	●	●	○
Z4 Series	E85/E86	Body	PDC Park distance control	●	●	●	●	●	●
Z4 Series	E85/E86	Body	RAD Radio	●	●	●	●	●	●
Z4 Series	E85/E86	Body	RLS Rain/Light Sensor	●	●	●	●	○	●
Z4 Series	E85/E86	Body	SBBF Seat occupancy,passenger	●	●	●	○		○
Z4 Series	E85/E86	Body	SBSL Satellite,B-pillar,left	●	●	●	●	○	●
Z4 Series	E85/E86	Body	SBSR Satellite,B-pillar,right	●	●	●	●	●	●
Z4 Series	E85/E86	Body	SES Language-input system	●	●	●	○	●	○
Z4 Series	E85/E86	Body	SIM Safety and Information Module	●	●	●	●	●	○
Z4 Series	E85/E86	Body	SMF Seat memory,driver	●	●	●	●	●	○
Z4 Series	E85/E86	Body	STVL Satellite,door,front left	●	●	●	●	○	●
Z4 Series	E85/E86	Body	STVR Satellite,door,front right	●	●	●	●	○	●
Z4 Series	E85/E86	Body	SZM Switching centre,centre console	●	●	●	●	●	●
Z4 Series	E85/E86	Body	TCU Telematic control unit	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
Z4 Series	E85/E86	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
Z4 Series	E85/E86	Body	VID Video module	●	●	●	○	○	○
Z4 Series	E85/E86	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
Z4 Series	E85/E86	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●
Z4 Series	E85/E86	Chassis	LWS Steering angle sensor	●	●	●	●	○	○
Z4 Series	E85/E86	Chassis	MFL Multi-function steering wheel	●	●	●	●	○	○
Z4 Series	E85/E86	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
Z4 Series	E85/E86	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
Z4 Series	E85/E86	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
Z4 Series	E85/E86	Drive	EKPS fuel-pump control	●	●	●	●	●	●
Z4 Series	E85/E86	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
Z8 Series	E52	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
Z8 Series	E52	Body	BIT Basis Interface Telephone	●	●	●	●	○	○
Z8 Series	E52	Body	CVM/CVM2 Convertible top module	●	●	●	●	●	●
Z8 Series	E52	Body	DSP Digital Sound Processor	●	●	●	●	○	○
Z8 Series	E52	Body	GM base module	●	●	●	●	●	○
Z8 Series	E52	Body	IHKS Integrated heating/air-conditioning control	●	●	●	●	●	●
Z8 Series	E52	Body	KOM Instrument cluster	●	●	●	●	●	○
Z8 Series	E52	Body	LCM Light Check Module	●	●	●	●	●	○
Z8 Series	E52	Body	LCM Light Check Module IV	●	●	●	●	●	○
Z8 Series	E52	Body	LRA Automatic headlight vertical aim control	●	●	●	●	●	○
Z8 Series	E52	Body	MIR Multi-Information Radio	●	●	●	●	○	○
Z8 Series	E52	Body	NAV Navigation computer MKII	●	●	●	●	○	○
Z8 Series	E52	Body	NAV Navigation computer MKIII	●	●	●	●	○	○
Z8 Series	E52	Body	RAD Radio	●	●	●	●	●	●
Z8 Series	E52	Body	TEL Telephone interface	○	○	○	●	●	○
Z8 Series	E52	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
Z8 Series	E52	Chassis	DDS Deflation Detection System	●	●	●	●	○	○
Z8 Series	E52	Chassis	ELV Electronic steering-column locking	●	●	●	●	○	○
Z8 Series	E52	Chassis	LEW Steering-angle sensor	●	●	●	●	○	○
Z8 Series	E52	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
Z8 Series	E52	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
Z8 Series	E52	Drive	EWS Vehicle immobilizer	●	●	●	●	●	○
Z Reihe	Z4_E89	Drive	CAS Car Access System	●	●	●	●	●	●
Z Reihe	Z4_E89	Drive	DKG Twin-clutch gearbox	●	●	●	●	●	●
Z Reihe	Z4_E89	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●
Z Reihe	Z4_E89	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●
Z Reihe	Z4_E89	Drive	EKPS Fuel-pump control	●	●	●	●	●	●
Z Reihe	Z4_E89	Drive	GWS Gear selector switch	●	●	●	●	●	●
Z Reihe	Z4_E89	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●
Z Reihe	Z4_E89	Chassis	EDC Damper Control	●	●	●	●	●	●
Z Reihe	Z4_E89	Chassis	EMF Parking brake	●	●	●	●	●	●

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
Z Reihe	Z4_E89	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●
Z Reihe	Z4_E89	Chassis	RDC Tyre pressure control	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	AMP Amplifier	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	CA Comfort access system	●	●	●	●	○	●
Z Reihe	Z4_E89	Body	CAN communication analysis	●	●	○	○	○	○
Z Reihe	Z4_E89	Body	CDC CD Changer	●	●	●	○	●	●
Z Reihe	Z4_E89	Body	CIC Car Information Computer	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	CIC-GW Gateway	●	●	●	○	●	●
Z Reihe	Z4_E89	Body	CID Central Information Display	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	CNAV Navigation system,China	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	CON Controller	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	CTM Convertible-top module	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	DAB Digital tuner	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	DVDC DVD Changer	●	●	●	○	●	●
Z Reihe	Z4_E89	Body	DWA anti-theft alarm system	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	FLA High Beam Assist	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	FRM2 Footwell module 2	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	FZD Function centre,roof	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	IHKR Heater and A/C control	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	IHR Integrated heater control	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	INSTR Instrument cluster	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	JBE2 Junction Box electronics	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	JNAV Navigation system,Japan	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	KNAV Navigation system,Korea	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	M-ASK-BO User interface	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	M-ASK-BO User interface	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	MOST system analysis	●	●	●	○	○	○
Z Reihe	Z4_E89	Body	MRS/AB Airbag/ACSM	●	●	●	●	○	●
Z Reihe	Z4_E89	Body	PDC Park Distance Control	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	RAD Radio	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	RAD2-BO User interface	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	RAD2-GW Gateway	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	RLSS Rain/light solar sensor	●	●	●	●	○	○
Z Reihe	Z4_E89	Body	SDARS Satellite tuner	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	SINE Siren and tilt sensor	●	●	●	●	○	○
Z Reihe	Z4_E89	Body	SMFA Seat module,driver	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	TCU Telematic Control Unit	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	ULF-SBX Interface box	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●
Z Reihe	Z4_E89	Body	VM Video Module	●	●	●	●	●	●
1 Series	F20	Drive	DDE Diesel Electronics	●	●	●	●	●	○
1 Series	F20	Drive	DME Digital Motor Electronics	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
1 Series	F20	Drive	EGS transmission management	●	●	●	●	●	○
1 Series	F20	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
1 Series	F20	Drive	GWS Gear selector switch	●	●	●	●	●	○
1 Series	F20	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
1 Series	F20	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
1 Series	F20	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
1 Series	F20	Body	ACC Active Cruise Control	●	●	●	●	●	○
1 Series	F20	Body	ACSM Crash Safety Module	●	●	●	●	●	○
1 Series	F20	Body	AHM Trailer module	●	●	●	●	●	○
1 Series	F20	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
1 Series	F20	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
1 Series	F20	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
1 Series	F20	Body	CIC Car Information Computer	●	●	●	●	●	○
1 Series	F20	Body	CID Central information display	●	●	●	●	●	○
1 Series	F20	Body	CON Controller	●	●	●	●	●	○
1 Series	F20	Body	DVDC DVD Changer	●	●	●	●	●	○
1 Series	F20	Body	FCON Rear compartment controller	●	●	●	●	●	○
1 Series	F20	Body	FEM Front electronic module	●	●	●	●	●	○
1 Series	F20	Body	FLA High Beam Assist	●	●	●	●	●	○
1 Series	F20	Body	FZD Function centre,roof	●	●	●	●	●	○
1 Series	F20	Body	ICM Integrated Chassis Management	●	●	●	●	●	○
1 Series	F20	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
1 Series	F20	Body	INSTR Instrument cluster	●	●	●	●	●	○
1 Series	F20	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
1 Series	F20	Body	PDC Park distance control	●	●	●	●	●	○
1 Series	F20	Body	PMA Parking assistant	●	●	●	●	●	○
1 Series	F20	Body	RAD Radio	●	●	●	●	●	○
1 Series	F20	Body	REM Rear electronic module	●	●	●	●	●	○
1 Series	F20	Body	SMBF Seat module,passenger	●	●	●	●	●	○
1 Series	F20	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
1 Series	F20	Body	SMFA Seat module,driver	●	●	●	●	●	○
1 Series	F20	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
1 Series	F20	Body	SWW Lane change warning	●	●	●	●	●	○
1 Series	F20	Body	TRVC allround-view camera	●	●	●	●	●	○
1 Series	F20	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
3 Series	F30	Drive	DDE Diesel Electronics	●	●	●	●	●	○
3 Series	F30	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
3 Series	F30	Drive	EGS transmission management	●	●	●	●	●	○
3 Series	F30	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
3 Series	F30	Drive	GWS Gear selector switch	●	●	●	●	●	○
3 Series	F30	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
3 Series	F30	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	F30	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
3 Series	F30	Body	ACC Active Cruise Control	●	●	●	●	●	○
3 Series	F30	Body	ACSM Crash Safety Module	●	●	●	●	●	○
3 Series	F30	Body	AHM Trailer module	●	●	●	●	●	○
3 Series	F30	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
3 Series	F30	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
3 Series	F30	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
3 Series	F30	Body	CID Central information display	●	●	●	●	●	○
3 Series	F30	Body	CON Controller	●	●	●	●	●	○
3 Series	F30	Body	DVDC DVD Changer	●	●	●	●	●	○
3 Series	F30	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
3 Series	F30	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
3 Series	F30	Body	EME Electric machine electronics	●	●	●	●	●	○
3 Series	F30	Body	FCON Rear compartment controller	●	●	●	●	●	○
3 Series	F30	Body	FEM Front electronic module	●	●	●	●	●	○
3 Series	F30	Body	FLA High Beam Assist	●	●	●	●	●	○
3 Series	F30	Body	FZD Function centre,roof	●	●	●	●	●	○
3 Series	F30	Body	ICM Integrated Chassis Management	●	●	●	●	●	○
3 Series	F30	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
3 Series	F30	Body	INSTR Instrument cluster	●	●	●	●	●	○
3 Series	F30	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
3 Series	F30	Body	PDC Park distance control	●	●	●	●	●	○
3 Series	F30	Body	PMA Parking assistant	●	●	●	●	●	○
3 Series	F30	Body	RAD Radio	●	●	●	●	●	○
3 Series	F30	Body	RDC Tyre pressure control	●	●	●	●	●	○
3 Series	F30	Body	REM Rear electronic module	●	●	●	●	●	○
3 Series	F30	Body	SMBF Seat module,passenger	●	●	●	●	●	○
3 Series	F30	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
3 Series	F30	Body	SME Accumulator-management electronics	●	●	●	●	●	○
3 Series	F30	Body	SMFA Seat module,driver	●	●	●	●	●	○
3 Series	F30	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
3 Series	F30	Body	SWW Lane change warning	●	●	●	●	●	○
3 Series	F30	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
3 Series	F30	Body	TR SVC allround-view camera	●	●	●	●	●	○
3 Series	F30	Body	VM Video Module	●	●	●	●	●	○
3 Series	F30	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
5 Series	F07	Drive	CAS Car Access System	●	●	●	●	●	○
5 Series	F07	Drive	DDE Diesel Electronics	●	●	●	●	●	○
5 Series	F07	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
5 Series	F07	Drive	EGS transmission management	●	●	●	●	●	○
5 Series	F07	Drive	EKPS Fuel-pump control	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	F07	Drive	GWS Gear selector switch	●	●	●	●	●	○
5 Series	F07	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
5 Series	F07	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
5 Series	F07	Chassis	EMF Parking brake	●	●	●	●	●	○
5 Series	F07	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
5 Series	F07	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
5 Series	F07	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	○
5 Series	F07	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	○
5 Series	F07	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	○
5 Series	F07	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	○
5 Series	F07	Body	ACC Active Cruise Control	●	●	●	●	●	○
5 Series	F07	Body	ACSM Crash Safety Module	●	●	●	●	●	○
5 Series	F07	Body	AHM Trailer module	●	●	●	●	●	○
5 Series	F07	Body	AL active steering	●	●	●	●	●	○
5 Series	F07	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
5 Series	F07	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
5 Series	F07	Body	CID Central information display	●	●	●	●	●	○
5 Series	F07	Body	CON Controller	●	●	●	●	●	○
5 Series	F07	Body	DVDC DVD Changer	●	●	●	●	●	○
5 Series	F07	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
5 Series	F07	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
5 Series	F07	Body	FD Rear-compartment display	●	●	●	●	●	○
5 Series	F07	Body	FD2 Rear-compartment display 2	●	●	●	●	●	○
5 Series	F07	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○
5 Series	F07	Body	FLA High Beam Assist	●	●	●	●	●	○
5 Series	F07	Body	FRM Footwell module	●	●	●	●	●	○
5 Series	F07	Body	FZD Function centre,roof	●	●	●	●	●	○
5 Series	F07	Body	HKL Rear-lid lift	●	●	●	●	●	○
5 Series	F07	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
5 Series	F07	Body	HUD Head-Up Display	●	●	●	●	●	○
5 Series	F07	Body	ICM Integrated Chassis Management	●	●	●	●	●	○
5 Series	F07	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
5 Series	F07	Body	JBE Junction-box electronics	●	●	●	●	●	○
5 Series	F07	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
5 Series	F07	Body	INSTR Instrument cluster	●	●	●	●	●	○
5 Series	F07	Body	NVE Night Vision Electronics	●	●	●	●	●	○
5 Series	F07	Body	PDC Park Distance Control	●	●	●	●	●	○
5 Series	F07	Body	RAD Radio	●	●	●	●	●	○
5 Series	F07	Body	RDC Tyre pressure control	●	●	●	●	●	○
5 Series	F07	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
5 Series	F07	Body	SMBF Seat module,passenger	●	●	●	●	●	○
5 Series	F07	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	F07	Body	SMFA Seat module,driver	●	●	●	●	●	○
5 Series	F07	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
5 Series	F07	Body	SVT Servotronic	●	●	●	●	●	○
5 Series	F07	Body	SWW Lane change warning	●	●	●	●	●	○
5 Series	F07	Body	SZL Switch centre, steering column	●	●	●	●	●	○
5 Series	F07	Body	TR SVC allround-view camera	●	●	●	●	●	○
5 Series	F07	Body	ULF-SBX Interface box	●	●	●	●	●	○
5 Series	F07	Body	ULF-SBX-H Interface box high	●	●	●	●	●	○
5 Series	F07	Body	VM Video Module	●	●	●	●	●	○
5 Series	F07	Body	VSW video switch	●	●	●	●	●	○
5 Series	F07	Body	VTG Transfer case	●	●	●	●	●	○
5 Series	F07	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
5 Series	F07	Body	SDARS Satellite tuner	●	●	●	●	●	○
5 Series	F10/F11	Drive	CAS Car Access System	●	●	●	●	●	○
5 Series	F10/F11	Drive	DDE Diesel Electronics	●	●	●	●	●	○
5 Series	F10/F11	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
5 Series	F10/F11	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
5 Series	F10/F11	Drive	EGS transmission management	●	●	●	●	●	○
5 Series	F10/F11	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
5 Series	F10/F11	Drive	GWS Gear selector switch	●	●	●	●	●	○
5 Series	F10/F11	Chassis	AL active steering	●	●	●	●	●	○
5 Series	F10/F11	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EMF Parking brake	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
5 Series	F10/F11	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
5 Series	F10/F11	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
5 Series	F10/F11	Body	ACC Active Cruise Control	●	●	●	●	●	○
5 Series	F10/F11	Body	ACSM Crash Safety Module	●	●	●	●	●	○
5 Series	F10/F11	Body	AHM Trailer module	●	●	●	●	●	○
5 Series	F10/F11	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
5 Series	F10/F11	Body	ASD Active Sound Design	●	●	●	●	●	○
5 Series	F10/F11	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
5 Series	F10/F11	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
5 Series	F10/F11	Body	CIC Car Information Computer	●	●	●	●	●	○
5 Series	F10/F11	Body	CID Central Information Display	●	●	●	●	●	○
5 Series	F10/F11	Body	CON Controller	●	●	●	●	●	○
5 Series	F10/F11	Body	DVDC DVD Changer	●	●	●	●	●	○
5 Series	F10/F11	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
5 Series	F10/F11	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	F10/F11	Body	EME Electric machine electronics	●	●	●	●	●	○
5 Series	F10/F11	Body	FCON Rear compartment controller	●	●	●	●	●	○
5 Series	F10/F11	Body	FD Rear-compartment display	●	●	●	●	●	○
5 Series	F10/F11	Body	FD2 Rear-compartment display 2	●	●	●	●	●	○
5 Series	F10/F11	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○
5 Series	F10/F11	Body	FLA High Beam Assist	●	●	●	●	●	○
5 Series	F10/F11	Body	FRM Footwell module	●	●	●	●	●	○
5 Series	F10/F11	Body	FZD Function centre,roof	●	●	●	●	●	○
5 Series	F10/F11	Body	GHAS Regulated differential lock	●	●	●	●	●	○
5 Series	F10/F11	Body	HKL Rear-lid lift	●	●	●	●	●	○
5 Series	F10/F11	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
5 Series	F10/F11	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
5 Series	F10/F11	Body	HUD Head-Up Display	●	●	●	●	●	○
5 Series	F10/F11	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
5 Series	F10/F11	Body	JBE Junction-box electronics	●	●	●	●	●	○
5 Series	F10/F11	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
5 Series	F10/F11	Body	INSTR Instrument cluster	●	●	●	●	●	○
5 Series	F10/F11	Body	NVE Night Vision Electronics	●	●	●	●	●	○
5 Series	F10/F11	Body	PDC Park Distance Control	●	●	●	●	●	○
5 Series	F10/F11	Body	PMA Parking assistant	●	●	●	●	●	○
5 Series	F10/F11	Body	RAD Radio	●	●	●	●	●	○
5 Series	F10/F11	Body	RDC Tyre pressure control	●	●	●	●	●	○
5 Series	F10/F11	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
5 Series	F10/F11	Body	SEC Supplementary control unit	●	●	●	●	●	○
5 Series	F10/F11	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
5 Series	F10/F11	Body	SMBF Seat module,passenger	●	●	●	●	●	○
5 Series	F10/F11	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
5 Series	F10/F11	Body	SME Accumulator-management electronics	●	●	●	●	●	○
5 Series	F10/F11	Body	SMFA Seat module,driver	●	●	●	●	●	○
5 Series	F10/F11	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
5 Series	F10/F11	Body	SVT Servotronic	●	●	●	●	●	○
5 Series	F10/F11	Body	SWW Lane change warning	●	●	●	●	●	○
5 Series	F10/F11	Body	SZL Switch centre, steering column	●	●	●	●	●	○
5 Series	F10/F11	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
5 Series	F10/F11	Body	TRSVc allround-view camera	●	●	●	●	●	○
5 Series	F10/F11	Body	ULF-SBX Interface box	●	●	●	●	●	○
5 Series	F10/F11	Body	ULF-SBX-H Interface box high	●	●	●	●	●	○
5 Series	F10/F11	Body	VM Video Module	●	●	●	●	●	○
5 Series	F10/F11	Body	VSW video switch	●	●	●	●	●	○
5 Series	F10/F11	Body	VTG Transfer case	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	F10/F11	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
5 Series	F10/F11	Body	SDARS Satellite tuner	●	●	●	●	●	○
5 Series	F18	Drive	CAS Car Access System	●	●	●	●	●	○
5 Series	F18	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
5 Series	F18	Drive	EGS transmission management	●	●	●	●	●	○
5 Series	F18	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
5 Series	F18	Drive	GWS Gear selector switch	●	●	●	●	●	○
5 Series	F18	Chassis	AL active steering	●	●	●	●	●	○
5 Series	F18	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
5 Series	F18	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	○
5 Series	F18	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	○
5 Series	F18	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	○
5 Series	F18	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	○
5 Series	F18	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
5 Series	F18	Chassis	EMF Parking brake	●	●	●	●	●	○
5 Series	F18	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
5 Series	F18	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
5 Series	F18	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
5 Series	F18	Body	ACC Active Cruise Control	●	●	●	●	●	○
5 Series	F18	Body	ACSM Crash Safety Module	●	●	●	●	●	○
5 Series	F18	Body	AHM Trailer module	●	●	●	●	●	○
5 Series	F18	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
5 Series	F18	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
5 Series	F18	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
5 Series	F18	Body	CID Central Information Display	●	●	●	●	●	○
5 Series	F18	Body	CON Controller	●	●	●	●	●	○
5 Series	F18	Body	DVDC DVD Changer	●	●	●	●	●	○
5 Series	F18	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
5 Series	F18	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
5 Series	F18	Body	FCON Rear compartment controller	●	●	●	●	●	○
5 Series	F18	Body	FD Rear-compartment display	●	●	●	●	●	○
5 Series	F18	Body	FD2 Rear-compartment display 2	●	●	●	●	●	○
5 Series	F18	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○
5 Series	F18	Body	FLA High Beam Assist	●	●	●	●	●	○
5 Series	F18	Body	FRM Footwell module	●	●	●	●	●	○
5 Series	F18	Body	FZD Function centre,roof	●	●	●	●	●	○
5 Series	F18	Body	HKL Rear-lid lift	●	●	●	●	●	○
5 Series	F18	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
5 Series	F18	Body	HUD Head-Up Display	●	●	●	●	●	○
5 Series	F18	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
5 Series	F18	Body	JBE Junction-box electronics	●	●	●	●	●	○
5 Series	F18	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
5 Series	F18	Body	INSTR Instrument cluster	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	F18	Body	NVE Night Vision Electronics	●	●	●	●	●	○
5 Series	F18	Body	PDC Park Distance Control	●	●	●	●	●	○
5 Series	F18	Body	PMA Parking assistant	●	●	●	●	●	○
5 Series	F18	Body	RAD Radio	●	●	●	●	●	○
5 Series	F18	Body	RDC Tyre pressure control	●	●	●	●	●	○
5 Series	F18	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
5 Series	F18	Body	SMBF Seat module,passenger	●	●	●	●	●	○
5 Series	F18	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
5 Series	F18	Body	SMFA Seat module,driver	●	●	●	●	●	○
5 Series	F18	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
5 Series	F18	Body	SWW Lane change warning	●	●	●	●	●	○
5 Series	F18	Body	SZL Switch centre, steering column	●	●	●	●	●	○
5 Series	F18	Body	TRSVL allround-view camera	●	●	●	●	●	○
5 Series	F18	Body	ULF-SBX Interface box	●	●	●	●	●	○
5 Series	F18	Body	ULF-SBX-H Interface box high	●	●	●	●	●	○
5 Series	F18	Body	VM Video Module	●	●	●	●	●	○
5 Series	F18	Body	VSW video switch	●	●	●	●	●	○
5 Series	F18	Body	VTG Transfer case	●	●	●	●	●	○
5 Series	F18	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
5 Series	F18	Body	SDARS Satellite tuner	●	●	●	●	●	○
6 Series	F12/F13	Drive	CAS Car Access System	●	●	●	●	●	○
6 Series	F12/F13	Drive	DDE Diesel Electronics	●	●	●	●	●	○
6 Series	F12/F13	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
6 Series	F12/F13	Drive	EGS transmission management	●	●	●	●	●	○
6 Series	F12/F13	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
6 Series	F12/F13	Drive	GWS Gear selector switch	●	●	●	●	●	○
6 Series	F12/F13	Chassis	AL active steering	●	●	●	●	●	○
6 Series	F12/F13	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EMF Parking brake	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
6 Series	F12/F13	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
6 Series	F12/F13	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
6 Series	F12/F13	Body	ACC Active Cruise Control	●	●	●	●	●	○
6 Series	F12/F13	Body	ACSM Crash Safety Module	●	●	●	●	●	○
6 Series	F12/F13	Body	AHM Trailer module	●	●	●	●	●	○
6 Series	F12/F13	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
6 Series	F12/F13	Body	ASD Active Sound Design	●	●	●	●	●	○
6 Series	F12/F13	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
6 Series	F12/F13	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
6 Series	F12/F13	Body	CID Central Information Display	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
6 Series	F12/F13	Body	CON Controller	●	●	●	●	●	○
6 Series	F12/F13	Body	CVM Convertible top module	●	●	●	●	●	○
6 Series	F12/F13	Body	DVDC DVD Changer	●	●	●	●	●	○
6 Series	F12/F13	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
6 Series	F12/F13	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
6 Series	F12/F13	Body	FD Rear-compartment display	●	●	●	●	●	○
6 Series	F12/F13	Body	FD2 Rear-compartment display 2	●	●	●	●	●	○
6 Series	F12/F13	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○
6 Series	F12/F13	Body	FLA High Beam Assist	●	●	●	●	●	○
6 Series	F12/F13	Body	FRM Footwell module	●	●	●	●	●	○
6 Series	F12/F13	Body	FZD Function centre,roof	●	●	●	●	●	○
6 Series	F12/F13	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
6 Series	F12/F13	Body	HUD Head-Up Display	●	●	●	●	●	○
6 Series	F12/F13	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
6 Series	F12/F13	Body	JBE Junction-box electronics	●	●	●	●	●	○
6 Series	F12/F13	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
6 Series	F12/F13	Body	INSTR Instrument cluster	●	●	●	●	●	○
6 Series	F12/F13	Body	NVE Night Vision Electronics	●	●	●	●	●	○
6 Series	F12/F13	Body	PDC Park Distance Control	●	●	●	●	●	○
6 Series	F12/F13	Body	PMA Parking assistant	●	●	●	●	●	○
6 Series	F12/F13	Body	RAD Radio	●	●	●	●	●	○
6 Series	F12/F13	Body	RDC Tyre pressure control	●	●	●	●	●	○
6 Series	F12/F13	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
6 Series	F12/F13	Body	SMBF Seat module,passenger	●	●	●	●	●	○
6 Series	F12/F13	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
6 Series	F12/F13	Body	SMFA Seat module,driver	●	●	●	●	●	○
6 Series	F12/F13	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
6 Series	F12/F13	Body	SVT Servotronic	●	●	●	●	●	○
6 Series	F12/F13	Body	SWW Lane change warning	●	●	●	●	●	○
6 Series	F12/F13	Body	SZL Switch centre, steering column	●	●	●	●	●	○
6 Series	F12/F13	Body	TRSVc allround-view camera	●	●	●	●	●	○
6 Series	F12/F13	Body	VM Video Module	●	●	●	●	●	○
6 Series	F12/F13	Body	VSW video switch	●	●	●	●	●	○
6 Series	F12/F13	Body	VTG Transfer case	●	●	●	●	●	○
6 Series	F12/F13	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
6 Series	F12/F13	Body	SDARS Satellite tuner	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	CAS Car Access System	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	DDE Diesel Electronics	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	EGS transmission management	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	GWS Gear selector switch	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	F01/F02/F04	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EMF Parking brake	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	AL active steering	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	INSTR Instrument cluster	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ACSM Crash Safety Module	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CIC Car Information Computer	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FZD Function centre,roof	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	PDC Park Distance Control	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FRM Footwell module	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	JBE Junction-box electronics	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ZGM Central Gateway Control Module	●	●	●	●	○	○
7 Series	F01/F02/F04	Body	SZL Switch centre, steering column	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CON Controller	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CID Central Information Display	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SMFA Seat module,driver	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SMBF Seat module,passenger	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	HUD Head-Up Display	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ULF-SBX-H Interface box high	●	●	●	●	●	●
7 Series	F01/F02/F04	Body	FLA High Beam Assist	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	DVDC DVD Changer	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	VSW video switch	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	HKL Rear-lid lift	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FD Rear-compartment display	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FD2 Rear-compartment display 2	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ACC Active Cruise Control	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	AHM Trailer module	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	EME Electric machine electronics	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FCON Rear compartment controller	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	F01/F02/F04	Body	GZAL Targeted illumination,left	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	GZAR Targeted illumination,right	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	LHML LED main light module,left	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	LHMR LED main light module,right	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	NVE Night Vision Electronics	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	RAD Radio	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	RDC Tyre pressure control	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SDARS Satellite tuner	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SME Accumulator-management electronics	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SVT Servotronic	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SWW Lane change warning	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	STML Headlight driver module,left	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	STMR Headlight driver module,right	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	TR SVC allround-view camera	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	TBX Touchbox	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ULF-SBX Interface box	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	VM Video Module	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	VTG Transfer case	●	●	●	●	●	○
X3 Series	F25	Drive	CAS Car Access System	●	●	●	●	●	○
X3 Series	F25	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X3 Series	F25	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X3 Series	F25	Drive	EGS transmission management	●	●	●	●	●	○
X3 Series	F25	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
X3 Series	F25	Drive	GWS Gear selector switch	●	●	●	●	●	○
X3 Series	F25	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X3 Series	F25	Chassis	EMF Parking brake	●	●	●	●	●	○
X3 Series	F25	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X3 Series	F25	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
X3 Series	F25	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
X3 Series	F25	Body	ACC Active Cruise Control	●	●	●	●	●	○
X3 Series	F25	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X3 Series	F25	Body	AHM Trailer module	●	●	●	●	●	○
X3 Series	F25	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X3 Series	F25	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
X3 Series	F25	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
X3 Series	F25	Body	CID Central Information Display	●	●	●	●	●	○
X3 Series	F25	Body	CON Controller	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X3 Series	F25	Body	DVDC DVD Changer	●	●	●	●	●	○
X3 Series	F25	Body	FLA High Beam Assist	●	●	●	●	●	○
X3 Series	F25	Body	FRM Footwell module	●	●	●	●	●	○
X3 Series	F25	Body	FZD Function centre,roof	●	●	●	●	●	○
X3 Series	F25	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X3 Series	F25	Body	HKL Rear-lid lift	●	●	●	●	●	○
X3 Series	F25	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X3 Series	F25	Body	HUD Head-Up Display	●	●	●	●	●	○
X3 Series	F25	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X3 Series	F25	Body	JBE Junction-box electronics	●	●	●	●	●	○
X3 Series	F25	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X3 Series	F25	Body	INSTR Instrument cluster	●	●	●	●	●	○
X3 Series	F25	Body	PDC Park Distance Control	●	●	●	●	●	○
X3 Series	F25	Body	RAD Radio	●	●	●	●	●	○
X3 Series	F25	Body	RDC Tyre pressure control	●	●	●	●	●	○
X3 Series	F25	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X3 Series	F25	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X3 Series	F25	Body	SMFA Seat module,driver	●	●	●	●	●	○
X3 Series	F25	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X3 Series	F25	Body	SWW Lane change warning	●	●	●	●	●	○
X3 Series	F25	Body	SZL Switch centre, steering column	●	●	●	●	●	○
X3 Series	F25	Body	TRSVK allround-view camera	●	●	●	●	●	○
X3 Series	F25	Body	VM Video Module	●	●	●	●	●	○
X3 Series	F25	Body	VTG Transfer case	●	●	●	●	●	○
X3 Series	F25	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X6 Series	E72	Drive	CAS Car Access System	●	●	●	●	●	○
X6 Series	E72	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X6 Series	E72	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
X6 Series	E72	Drive	EMPI Hybrid oil-pump activation	●	●	●	●	●	○
X6 Series	E72	Drive	GWS Gear selector switch	●	●	●	●	●	○
X6 Series	E72	Drive	TCM Hybrid-transmission control	●	●	●	●	●	○
X6 Series	E72	Drive	VTG Transfer case	●	●	●	●	●	○
X6 Series	E72	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X6 Series	E72	Chassis	DSM Hybrid parking lock	●	●	●	●	●	○
X6 Series	E72	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
X6 Series	E72	Chassis	EMF Parking brake	●	●	●	●	●	○
X6 Series	E72	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X6 Series	E72	Chassis	RDC Tyre pressure control	●	●	●	●	●	○
X6 Series	E72	Chassis	SBA Hybrid brake-actuation changeover	●	●	●	●	●	○
X6 Series	E72	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X6 Series	E72	Body	AHM Trailer module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X6 Series	E72	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X6 Series	E72	Body	APM Hybrid DC/DC converter	●	●	●	●	●	○
X6 Series	E72	Body	BCM Battery check module	●	●	●	●	●	○
X6 Series	E72	Body	CA Comfort access system	●	●	●	●	●	○
X6 Series	E72	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
X6 Series	E72	Body	CDC CD Changer	●	●	●	●	●	○
X6 Series	E72	Body	CCC-GW Gateway	●	●	●	●	●	○
X6 Series	E72	Body	CID Central Information Display	●	●	●	●	●	○
X6 Series	E72	Body	CON Controller	●	●	●	●	●	○
X6 Series	E72	Body	DVDC DVD Changer	●	●	●	●	●	○
X6 Series	E72	Body	EKK Electric A/C compressor	●	●	●	●	●	○
X6 Series	E72	Body	FD Rear-compartment display	●	●	●	●	●	○
X6 Series	E72	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○
X6 Series	E72	Body	FLA High Beam Assist	●	●	●	●	●	○
X6 Series	E72	Body	FRM2 Footwell module 2	●	●	●	●	●	○
X6 Series	E72	Body	FZD Function centre,roof	●	●	●	●	●	○
X6 Series	E72	Body	HCP Hybrid master control unit	●	●	●	●	●	○
X6 Series	E72	Body	HIM Hybrid Interface Module	●	●	●	●	●	○
X6 Series	E72	Body	HKL Rear-lid lift	●	●	●	●	●	○
X6 Series	E72	Body	HUD Head-Up Display	●	●	●	●	●	○
X6 Series	E72	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X6 Series	E72	Body	JBE2 Junction Box electronics	●	●	●	●	●	○
X6 Series	E72	Body	INSTR Instrument cluster	●	●	●	●	●	○
X6 Series	E72	Body	M-ASK-BO User interface	●	●	●	●	●	○
X6 Series	E72	Body	MCPA Hybrid electric-motor control 1	●	●	●	●	●	○
X6 Series	E72	Body	MCPB Hybrid electric-motor control 2	●	●	●	●	●	○
X6 Series	E72	Body	PDC Park Distance Control	●	●	●	●	●	○
X6 Series	E72	Body	RLSS Rain/light solar sensor	●	●	●	●	●	○
X6 Series	E72	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X6 Series	E72	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
X6 Series	E72	Body	SMFA Seat module,driver	●	●	●	●	●	○
X6 Series	E72	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X6 Series	E72	Body	TFE Hybrid pressure-tank electronics	●	●	●	●	●	○
X6 Series	E72	Body	TR SVC allround-view camera	●	●	●	●	●	○
X6 Series	E72	Body	ULF-SBX Interface box	●	●	●	●	●	○
X6 Series	E72	Body	ULF-SBX-H Interface box high	●	●	●	●	●	○
X6 Series	E72	Body	VM Video Module	●	●	●	●	●	○
X1 Series	E84	Drive	CAS Car Access System	●	●	●	●	●	○
X1 Series	E84	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X1 Series	E84	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X1 Series	E84	Drive	EGS transmission management	●	●	●	●	●	○
X1 Series	E84	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
X1 Series	E84	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X1 Series	E84	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X1 Series	E84	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X1 Series	E84	Body	AHM Trailer module	●	●	●	●	●	○
X1 Series	E84	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X1 Series	E84	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
X1 Series	E84	Body	CID Central Information Display	●	●	●	●	●	○
X1 Series	E84	Body	CON Controller	●	●	●	●	●	○
X1 Series	E84	Body	FLA High Beam Assist	●	●	●	●	●	○
X1 Series	E84	Body	FRM Footwell module	●	●	●	●	●	○
X1 Series	E84	Body	FZD Function centre,roof	●	●	●	●	●	○
X1 Series	E84	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X1 Series	E84	Body	JBE Junction-box electronics	●	●	●	●	●	○
X1 Series	E84	Body	INSTR Instrument cluster	●	●	●	●	●	○
X1 Series	E84	Body	PDC Park Distance Control	●	●	●	●	●	○
X1 Series	E84	Body	RDC Tyre pressure control	●	●	●	●	●	○
X1 Series	E84	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X1 Series	E84	Body	SMFA Seat module,driver	●	●	●	●	●	○
X1 Series	E84	Body	TRSVCA allround-view camera	●	●	●	●	●	○
X1 Series	E84	Body	VM Video Module	●	●	●	●	●	○
X1 Series	E84	Body	VTG Transfer case	●	●	●	●	●	○
X1 Series	E84	Body	CA Comfort access system	●	●	●	●	●	○
X1 Series	E84	Body	CDC CD Changer	●	●	●	●	●	○
X1 Series	E84	Body	CHAMP-BO User interface	●	●	●	●	●	○
X1 Series	E84	Body	CCC-GW Gateway	●	●	●	●	●	○
X1 Series	E84	Body	DAB Digital tuner	●	●	●	●	●	○
X1 Series	E84	Body	DWA anti-theft alarm system	●	●	●	●	●	○
X1 Series	E84	Body	RLSS Rain/light solar sensor	●	●	●	●	●	○
X1 Series	E84	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	○
X1 Series	E84	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
X1 Series	E84	Body	ULF-SBX Interface box	●	●	●	●	●	○
X1 Series	E84	Body	ULF-SBX-H Interface box High	●	●	●	●	●	○
2 Series	F22	Drive	CAS Car Access System	●	●	●	●	●	○
2 Series	F22	Drive	DDE Diesel Electronics	●	●	●	●	●	○
2 Series	F22	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
2 Series	F22	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
2 Series	F22	Drive	EGS transmission management	●	●	●	●	●	○
2 Series	F22	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
2 Series	F22	Drive	GWS Gear selector switch	●	●	●	●	●	○
2 Series	F22	Chassis	AL active steering	●	●	●	●	●	○
2 Series	F22	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
2 Series	F22	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
2 Series	F22	Chassis	EMF Parking brake	●	●	●	●	●	○
2 Series	F22	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
2 Series	F22	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
2 Series	F22	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
2 Series	F22	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
2 Series	F22	Body	ACC Active Cruise Control	●	●	●	●	●	○
2 Series	F22	Body	ACSM Crash Safety Module	●	●	●	●	●	○
2 Series	F22	Body	AHM Trailer module	●	●	●	●	●	○
2 Series	F22	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
2 Series	F22	Body	ASD Active Sound Design	●	●	●	●	●	○
2 Series	F22	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
2 Series	F22	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
2 Series	F22	Body	CIC Car Information Computer	●	●	●	●	●	○
2 Series	F22	Body	CON Controller	●	●	●	●	●	○
2 Series	F22	Body	CVM Convertible top module	●	●	●	●	●	○
2 Series	F22	Body	DVDC DVD Changer	●	●	●	●	●	○
2 Series	F22	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
2 Series	F22	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
2 Series	F22	Body	EME Electric machine electronics	●	●	●	●	●	○
2 Series	F22	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
2 Series	F22	Body	FLA High Beam Assist	●	●	●	●	●	○
2 Series	F22	Body	FRM Footwell module	●	●	●	●	●	○
2 Series	F22	Body	FZD Function centre,roof	●	●	●	●	●	○
2 Series	F22	Body	GHAS Regulated differential lock	●	●	●	●	●	○
2 Series	F22	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
2 Series	F22	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
2 Series	F22	Body	INSTR Instrument cluster	●	●	●	●	●	○
2 Series	F22	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
2 Series	F22	Body	PDC Park distance control	●	●	●	●	●	○
2 Series	F22	Body	PMA Parking assistant	●	●	●	●	●	○
2 Series	F22	Body	RAD Radio	●	●	●	●	●	○
2 Series	F22	Body	RDC Tyre pressure control	●	●	●	●	●	○
2 Series	F22	Body	SEC Supplementary control unit	●	●	●	●	●	○
2 Series	F22	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
2 Series	F22	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
2 Series	F22	Body	SMBF Seat module,passenger	●	●	●	●	●	○
2 Series	F22	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
2 Series	F22	Body	SME Accumulator-management electronics	●	●	●	●	●	○
2 Series	F22	Body	SMFA Seat module,driver	●	●	●	●	●	○
2 Series	F22	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
2 Series	F22	Body	SVT Servotronic	●	●	●	●	●	○
2 Series	F22	Body	SWW Lane change warning	●	●	●	●	●	○
2 Series	F22	Body	SZL Switch centre, steering column	●	●	●	●	●	○
2 Series	F22	Body	TR SVC_allround-view camera	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
2 Series	F22	Body	VM Video Module	●	●	●	●	●	○
2 Series	F22	Body	VTG Transfer case	●	●	●	●	●	○
2 Series	F22	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
3 Series	F34	Drive	CAS Car Access System	●	●	●	●	●	○
3 Series	F34	Drive	DDE Diesel Electronics	●	●	●	●	●	○
3 Series	F34	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
3 Series	F34	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
3 Series	F34	Drive	EGS transmission management	●	●	●	●	●	○
3 Series	F34	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
3 Series	F34	Drive	GWS Gear selector switch	●	●	●	●	●	○
3 Series	F34	Chassis	AL active steering	●	●	●	●	●	○
3 Series	F34	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
3 Series	F34	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
3 Series	F34	Chassis	EMF Parking brake	●	●	●	●	●	○
3 Series	F34	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
3 Series	F34	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
3 Series	F34	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
3 Series	F34	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
3 Series	F34	Body	ACC Active Cruise Control	●	●	●	●	●	○
3 Series	F34	Body	ACSM Crash Safety Module	●	●	●	●	●	○
3 Series	F34	Body	AHM Trailer module	●	●	●	●	●	○
3 Series	F34	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
3 Series	F34	Body	ASD Active Sound Design	●	●	●	●	●	○
3 Series	F34	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
3 Series	F34	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
3 Series	F34	Body	CIC Car Information Computer	●	●	●	●	●	○
3 Series	F34	Body	CON Controller	●	●	●	●	●	○
3 Series	F34	Body	CVM Convertible top module	●	●	●	●	●	○
3 Series	F34	Body	DVDC DVD Changer	●	●	●	●	●	○
3 Series	F34	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
3 Series	F34	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
3 Series	F34	Body	EME Electric machine electronics	●	●	●	●	●	○
3 Series	F34	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
3 Series	F34	Body	FLA High Beam Assist	●	●	●	●	●	○
3 Series	F34	Body	FRM Footwell module	●	●	●	●	●	○
3 Series	F34	Body	FZD Function centre,roof	●	●	●	●	●	○
3 Series	F34	Body	GHAS Regulated differential lock	●	●	●	●	●	○
3 Series	F34	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
3 Series	F34	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
3 Series	F34	Body	INSTR Instrument cluster	●	●	●	●	●	○
3 Series	F34	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
3 Series	F34	Body	PDC Park distance control	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	F34	Body	PMA Parking assistant	●	●	●	●	●	○
3 Series	F34	Body	RAD Radio	●	●	●	●	●	○
3 Series	F34	Body	RDC Tyre pressure control	●	●	●	●	●	○
3 Series	F34	Body	SEC Supplementary control unit	●	●	●	●	●	○
3 Series	F34	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
3 Series	F34	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
3 Series	F34	Body	SMBF Seat module,passenger	●	●	●	●	●	○
3 Series	F34	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
3 Series	F34	Body	SME Accumulator-management electronics	●	●	●	●	●	○
3 Series	F34	Body	SMFA Seat module,driver	●	●	●	●	●	○
3 Series	F34	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
3 Series	F34	Body	SVT Servotronic	●	●	●	●	●	○
3 Series	F34	Body	SWW Lane change warning	●	●	●	●	●	○
3 Series	F34	Body	SZL Switch centre, steering column	●	●	●	●	●	○
3 Series	F34	Body	TR SVC_allround-view camera	●	●	●	●	●	○
3 Series	F34	Body	VM Video Module	●	●	●	●	●	○
3 Series	F34	Body	VTG Transfer case	●	●	●	●	●	○
3 Series	F34	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
4 Series	F32/F33	Drive	CAS Car Access System	●	●	●	●	●	○
4 Series	F32/F33	Drive	DDE Diesel Electronics	●	●	●	●	●	○
4 Series	F32/F33	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
4 Series	F32/F33	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
4 Series	F32/F33	Drive	EGS transmission management	●	●	●	●	●	○
4 Series	F32/F33	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
4 Series	F32/F33	Drive	GWS Gear selector switch	●	●	●	●	●	○
4 Series	F32/F33	Chassis	AL active steering	●	●	●	●	●	○
4 Series	F32/F33	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
4 Series	F32/F33	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
4 Series	F32/F33	Chassis	EMF Parking brake	●	●	●	●	●	○
4 Series	F32/F33	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
4 Series	F32/F33	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
4 Series	F32/F33	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
4 Series	F32/F33	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
4 Series	F32/F33	Body	ACC Active Cruise Control	●	●	●	●	●	○
4 Series	F32/F33	Body	ACSM Crash Safety Module	●	●	●	●	●	○
4 Series	F32/F33	Body	AHM Trailer module	●	●	●	●	●	○
4 Series	F32/F33	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
4 Series	F32/F33	Body	ASD Active Sound Design	●	●	●	●	●	○
4 Series	F32/F33	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
4 Series	F32/F33	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
4 Series	F32/F33	Body	CIC Car Information Computer	●	●	●	●	●	○
4 Series	F32/F33	Body	CON Controller	●	●	●	●	●	○
4 Series	F32/F33	Body	CVM Convertible top module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
4 Series	F32/F33	Body	DVDC DVD Changer	●	●	●	●	●	○
4 Series	F32/F33	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
4 Series	F32/F33	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
4 Series	F32/F33	Body	EME Electric machine electronics	●	●	●	●	●	○
4 Series	F32/F33	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
4 Series	F32/F33	Body	FLA High Beam Assist	●	●	●	●	●	○
4 Series	F32/F33	Body	FRM Footwell module	●	●	●	●	●	○
4 Series	F32/F33	Body	FZD Function centre,roof	●	●	●	●	●	○
4 Series	F32/F33	Body	GHAS Regulated differential lock	●	●	●	●	●	○
4 Series	F32/F33	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
4 Series	F32/F33	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
4 Series	F32/F33	Body	INSTR Instrument cluster	●	●	●	●	●	○
4 Series	F32/F33	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
4 Series	F32/F33	Body	PDC Park distance control	●	●	●	●	●	○
4 Series	F32/F33	Body	PMA Parking assistant	●	●	●	●	●	○
4 Series	F32/F33	Body	RAD Radio	●	●	●	●	●	○
4 Series	F32/F33	Body	RDC Tyre pressure control	●	●	●	●	●	○
4 Series	F32/F33	Body	SEC Supplementary control unit	●	●	●	●	●	○
4 Series	F32/F33	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
4 Series	F32/F33	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
4 Series	F32/F33	Body	SMBF Seat module,passenger	●	●	●	●	●	○
4 Series	F32/F33	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
4 Series	F32/F33	Body	SME Accumulator-management electronics	●	●	●	●	●	○
4 Series	F32/F33	Body	SMFA Seat module,driver	●	●	●	●	●	○
4 Series	F32/F33	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
4 Series	F32/F33	Body	SVT Servotronic	●	●	●	●	●	○
4 Series	F32/F33	Body	SWW Lane change warning	●	●	●	●	●	○
4 Series	F32/F33	Body	SZL Switch centre, steering column	●	●	●	●	●	○
4 Series	F32/F33	Body	TRSVC_allround-view camera	●	●	●	●	●	○
4 Series	F32/F33	Body	VM Video Module	●	●	●	●	●	○
4 Series	F32/F33	Body	VTG Transfer case	●	●	●	●	●	○
4 Series	F32/F33	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
6 Series	F06	Drive	CAS Car Access System	●	●	●	●	●	○
6 Series	F06	Drive	DDE Diesel Electronics	●	●	●	●	●	○
6 Series	F06	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
6 Series	F06	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
6 Series	F06	Drive	EGS transmission management	●	●	●	●	●	○
6 Series	F06	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
6 Series	F06	Drive	GWS Gear selector switch	●	●	●	●	●	○
6 Series	F06	Chassis	AL active steering	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
6 Series	F06	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
6 Series	F06	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	○
6 Series	F06	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	○
6 Series	F06	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	○
6 Series	F06	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	○
6 Series	F06	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
6 Series	F06	Chassis	EMF Parking brake	●	●	●	●	●	○
6 Series	F06	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
6 Series	F06	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
6 Series	F06	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
6 Series	F06	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
6 Series	F06	Body	ACC Active Cruise Control	●	●	●	●	●	○
6 Series	F06	Body	ACSM Crash Safety Module	●	●	●	●	●	○
6 Series	F06	Body	AHM Trailer module	●	●	●	●	●	○
6 Series	F06	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
6 Series	F06	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
6 Series	F06	Body	ASD Active Sound Design	●	●	●	●	●	○
6 Series	F06	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
6 Series	F06	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
6 Series	F06	Body	CIC Car Information Computer	●	●	●	●	●	○
6 Series	F06	Body	CID Central information display	●	●	●	●	●	○
6 Series	F06	Body	CON Controller	●	●	●	●	●	○
6 Series	F06	Body	CVM Convertible top module	●	●	●	●	●	○
6 Series	F06	Body	DVDC DVD Changer	●	●	●	●	●	○
6 Series	F06	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
6 Series	F06	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
6 Series	F06	Body	EME Electric machine electronics	●	●	●	●	●	○
6 Series	F06	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
6 Series	F06	Body	FCON Rear compartment controller	●	●	●	●	●	○
6 Series	F06	Body	FD Rear-compartment display	●	●	●	●	●	○
6 Series	F06	Body	FD2 Rear-compartment display 2	●	●	●	●	●	○
6 Series	F06	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○
6 Series	F06	Body	FLA High Beam Assist	●	●	●	●	●	○
6 Series	F06	Body	FRM Footwell module	●	●	●	●	●	○
6 Series	F06	Body	FZD Function centre,roof	●	●	●	●	●	○
6 Series	F06	Body	GHAS Regulated differential lock	●	●	●	●	●	○
6 Series	F06	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
6 Series	F06	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
6 Series	F06	Body	HKL Rear-lid lift	●	●	●	●	●	○
6 Series	F06	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
6 Series	F06	Body	HUD Head-Up Display	●	●	●	●	●	○
6 Series	F06	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
6 Series	F06	Body	INSTR Instrument cluster	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
6 Series	F06	Body	JBE Junction-box electronics	●	●	●	●	●	○
6 Series	F06	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
6 Series	F06	Body	NVE Night Vision Electronics	●	●	●	●	●	○
6 Series	F06	Body	PDC Park distance control	●	●	●	●	●	○
6 Series	F06	Body	PMA Parking assistant	●	●	●	●	●	○
6 Series	F06	Body	RAD Radio	●	●	●	●	●	○
6 Series	F06	Body	RDC Tyre pressure control	●	●	●	●	●	○
6 Series	F06	Body	REM Rear electronic module	●	●	●	●	●	○
6 Series	F06	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
6 Series	F06	Body	SDARS Satellite tuner	●	●	●	●	●	○
6 Series	F06	Body	SEC Supplementary control unit	●	●	●	●	●	○
6 Series	F06	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
6 Series	F06	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
6 Series	F06	Body	SMBF Seat module,passenger	●	●	●	●	●	○
6 Series	F06	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
6 Series	F06	Body	SME Accumulator-management electronics	●	●	●	●	●	○
6 Series	F06	Body	SMFA Seat module,driver	●	●	●	●	●	○
6 Series	F06	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
6 Series	F06	Body	SVT Servotronic	●	●	●	●	●	○
6 Series	F06	Body	SWW Lane change warning	●	●	●	●	●	○
6 Series	F06	Body	SZL Switch centre, steering column	●	●	●	●	●	○
6 Series	F06	Body	SDARS Satellite tuner	●	●	●	●	●	○
6 Series	F06	Body	TRSV_C_allround-view camera	●	●	●	●	●	○
6 Series	F06	Body	TCU Telematic Control Unit	●	●	●	●	●	○
6 Series	F06	Body	ULF-SBX Interface box	●	●	●	●	●	○
6 Series	F06	Body	ULF-SBX-H Interface box high	●	●	●	●	●	○
6 Series	F06	Body	VM Video Module	●	●	●	●	●	○
6 Series	F06	Body	VSW video switch	●	●	●	●	●	○
6 Series	F06	Body	VTG Transfer case	●	●	●	●	●	○
6 Series	F06	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
I Series	I00/I12	Drive	CAS Car Access System	●	●	●	●	●	○
I Series	I00/I12	Drive	DDE Diesel Electronics	●	●	●	●	●	○
I Series	I00/I12	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
I Series	I00/I12	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
I Series	I00/I12	Drive	EGS transmission management	●	●	●	●	●	○
I Series	I00/I12	Drive	GWS Gear selector switch	●	●	●	●	●	○
I Series	I00/I12	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
I Series	I00/I12	Chassis	EMF Parking brake	●	●	●	●	●	○
I Series	I00/I12	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
I Series	I00/I12	Body	ACSM Crash Safety Module	●	●	●	●	●	○
I Series	I00/I12	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
I Series	I00/I12	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
I Series	I00/I12	Body	ASD Active Sound Design	●	●	●	●	●	○
I Series	I00/I12	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
I Series	I00/I12	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
I Series	I00/I12	Body	CIC Car Information Computer	●	●	●	●	●	○
I Series	I00/I12	Body	CON Controller	●	●	●	●	●	○
I Series	I00/I12	Body	EME Electric machine electronics	●	●	●	●	●	○
I Series	I00/I12	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
I Series	I00/I12	Body	FZD Function centre,roof	●	●	●	●	●	○
I Series	I00/I12	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
I Series	I00/I12	Body	INSTR Instrument cluster	●	●	●	●	●	○
I Series	I00/I12	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
I Series	I00/I12	Body	PMA Parking assistant	●	●	●	●	●	○
I Series	I00/I12	Body	RAD Radio	●	●	●	●	●	○
I Series	I00/I12	Body	SME Accumulator-management electronics	●	●	●	●	●	○
I Series	I00/I12	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	x5_F15	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	x5_F15	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	x5_F15	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	x5_F15	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	x5_F15	Drive	EGS transmission management	●	●	●	●	●	○
X Series	x5_F15	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
X Series	x5_F15	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	x5_F15	Drive	QMVH Lateral-moment distribution,rear axle	●	●	●	●	●	○
X Series	x5_F15	Chassis	AL active steering	●	●	●	●	●	○
X Series	x5_F15	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	x5_F15	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
X Series	x5_F15	Chassis	EMF Parking brake	●	●	●	●	●	○
X Series	x5_F15	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	x5_F15	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
X Series	x5_F15	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
X Series	x5_F15	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
X Series	x5_F15	Body	ACC Active Cruise Control	●	●	●	●	●	○
X Series	x5_F15	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	x5_F15	Body	AHM Trailer module	●	●	●	●	●	○
X Series	x5_F15	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
X Series	x5_F15	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	x5_F15	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	x5_F15	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
X Series	x5_F15	Body	CIC Car Information Computer	●	●	●	●	●	○
X Series	x5_F15	Body	CID Central information display	●	●	●	●	●	○
X Series	x5_F15	Body	CON Controller	●	●	●	●	●	○
X Series	x5_F15	Body	DVDC DVD Changer	●	●	●	●	●	○
X Series	x5_F15	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
X Series	x5_F15	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
X Series	x5_F15	Body	EME Electric machine electronics	●	●	●	●	●	○
X Series	x5_F15	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	x5_F15	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○
X Series	x5_F15	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	x5_F15	Body	FRM Footwell module	●	●	●	●	●	○
X Series	x5_F15	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	x5_F15	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	x5_F15	Body	HKL Rear-lid lift	●	●	●	●	●	○
X Series	x5_F15	Body	HUD Head-Up Display	●	●	●	●	●	○
X Series	x5_F15	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	x5_F15	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	x5_F15	Body	JBE Junction-box electronics	●	●	●	●	●	○
X Series	x5_F15	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	x5_F15	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	x5_F15	Body	PDC Park distance control	●	●	●	●	●	○
X Series	x5_F15	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	x5_F15	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	x5_F15	Body	RDC Tyre pressure control	●	●	●	●	●	○
X Series	x5_F15	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	x5_F15	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	x5_F15	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
X Series	x5_F15	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	x5_F15	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	x5_F15	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	x5_F15	Body	SVT Servotronic	●	●	●	●	●	○
X Series	x5_F15	Body	SWW Lane change warning	●	●	●	●	●	○
X Series	x5_F15	Body	STML Headlight driver module,left	●	●	●	●	●	○
X Series	x5_F15	Body	STMR Headlight driver module,right	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	x5_F15	Body	TRSVc allround-view camera	●	●	●	●	●	○
X Series	x5_F15	Body	TBX Touchbox	●	●	●	●	●	○
X Series	x5_F15	Body	VM Video Module	●	●	●	●	●	○
X Series	x5_F15	Body	VTG Transfer case	●	●	●	●	●	○
X Series	x5_F15	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
1 Series	F40	Body	ACSM Crash Safety Module	●	●	●	●	●	○
1 Series	F40	Body	AHM Trailer module	●	●	●	●	●	○
1 Series	F40	Body	ASD Active Sound Design	●	●	●	●	●	○
1 Series	F40	Body	CON Controller	●	●	●	●	●	○
1 Series	F40	Body	CSM Car Sharing Module	●	●	●	●	●	○
1 Series	F40	Body	ENS Ethernet switch	●	●	●	●	●	○
1 Series	F40	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
1 Series	F40	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
1 Series	F40	Body	FZD Function centre,roof	●	●	●	●	●	○
1 Series	F40	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
1 Series	F40	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
1 Series	F40	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
1 Series	F40	Body	HU-B Headunit Basis	●	●	●	●	●	○
1 Series	F40	Body	HU-H Headunit High	●	●	●	●	●	○
1 Series	F40	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
1 Series	F40	Body	INSTR Instrument cluster	●	●	●	●	●	○
1 Series	F40	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
1 Series	F40	Body	PMA Parking assistant	●	●	●	●	●	○
1 Series	F40	Body	RAM Receiver audio module	●	●	●	●	●	○
1 Series	F40	Body	SAS Optional equipment system	●	●	●	●	●	○
1 Series	F40	Body	SAS Optional equipment system 2	●	●	●	●	●	○
1 Series	F40	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
1 Series	F40	Body	SMFA Seat module,driver	●	●	●	●	●	○
1 Series	F40	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
1 Series	F40	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
1 Series	F40	Body	TCB Telematic Communication Box	●	●	●	●	●	○
1 Series	F40	Body	TRVC allround-view camera	●	●	●	●	●	○
1 Series	F40	Body	VIP Virtual integration system	●	●	●	●	●	○
1 Series	F40	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
1 Series	F40	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
1 Series	F40	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
1 Series	F40	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
1 Series	F40	Chassis	FRS Front radar sensor	●	●	●	●	●	○
1 Series	F40	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
1 Series	F40	Drive	CAS Car Access System	●	●	●	●	●	○
1 Series	F40	Drive	DDE Diesel Electronics	●	●	●	●	●	○
1 Series	F40	Drive	DME Digital Motor Electronics	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
1 Series	F40	Drive	EGS transmission management	●	●	●	●	●	○
1 Series	F40	Drive	GWS Gear selector switch	●	●	●	●	●	○
1 Series	F40	Drive	LMV Longitudinal torque distribution	●	●	●	●	●	○
1 Series	F52	Body	ACSM Crash Safety Module	●	●	●	●	●	○
1 Series	F52	Body	AHM Trailer module	●	●	●	●	●	○
1 Series	F52	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
1 Series	F52	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
1 Series	F52	Body	ASD Active Sound Design	●	●	●	●	●	○
1 Series	F52	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
1 Series	F52	Body	CIC Car Information Computer	●	●	●	●	●	○
1 Series	F52	Body	CON Controller	●	●	●	●	●	○
1 Series	F52	Body	DSP Digital Sound Processor	●	●	●	●	●	○
1 Series	F52	Body	DVDC DVD Changer	●	●	●	●	●	○
1 Series	F52	Body	FZD Function centre,roof	●	●	●	●	●	○
1 Series	F52	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
1 Series	F52	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
1 Series	F52	Body	INSTR Instrument cluster	●	●	●	●	●	○
1 Series	F52	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
1 Series	F52	Body	PMA Parking assistant	●	●	●	●	●	○
1 Series	F52	Body	SMFA Seat module,driver	●	●	●	●	●	○
1 Series	F52	Body	SZL Switch centre, steering column	●	●	●	●	●	○
1 Series	F52	Body	TBX Touchbox	●	●	●	●	●	○
1 Series	F52	Body	TR SVC allround-view camera	●	●	●	●	●	○
1 Series	F52	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
1 Series	F52	Chassis	AL active steering	●	●	●	●	●	○
1 Series	F52	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
1 Series	F52	Drive	CAS Car Access System	●	●	●	●	●	○
1 Series	F52	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
1 Series	F52	Drive	EGS transmission management	●	●	●	●	●	○
2 Series	F44	Body	ACSM Crash Safety Module	●	●	●	●	●	○
2 Series	F44	Body	AHM Trailer module	●	●	●	●	●	○
2 Series	F44	Body	ASD Active Sound Design	●	●	●	●	●	○
2 Series	F44	Body	CON Controller	●	●	●	●	●	○
2 Series	F44	Body	CSM Car Sharing Module	●	●	●	●	●	○
2 Series	F44	Body	ENS Ethernet switch	●	●	●	●	●	○
2 Series	F44	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
2 Series	F44	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
2 Series	F44	Body	FZD Function centre,roof	●	●	●	●	●	○
2 Series	F44	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
2 Series	F44	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
2 Series	F44	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
2 Series	F44	Body	HU-B Headunit Basis	●	●	●	●	●	○
2 Series	F44	Body	HU-H Headunit High	●	●	●	●	●	○
2 Series	F44	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
2 Series	F44	Body	INSTR Instrument cluster	●	●	●	●	●	○
2 Series	F44	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
2 Series	F44	Body	PMA Parking assistant	●	●	●	●	●	○
2 Series	F44	Body	RAM Receiver audio module	●	●	●	●	●	○
2 Series	F44	Body	SAS Optional equipment system	●	●	●	●	●	○
2 Series	F44	Body	SAS Optional equipment system 2	●	●	●	●	●	○
2 Series	F44	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
2 Series	F44	Body	SMFA Seat module,driver	●	●	●	●	●	○
2 Series	F44	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
2 Series	F44	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
2 Series	F44	Body	TCB Telematic Communication Box	●	●	●	●	●	○
2 Series	F44	Body	TR SVC allround-view camera	●	●	●	●	●	○
2 Series	F44	Body	VIP Virtual integration system	●	●	●	●	●	○
2 Series	F44	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
2 Series	F44	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
2 Series	F44	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
2 Series	F44	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
2 Series	F44	Chassis	FRS Front radar sensor	●	●	●	●	●	○
2 Series	F44	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
2 Series	F44	Drive	CAS Car Access System	●	●	●	●	●	○
2 Series	F44	Drive	DDE Diesel Electronics	●	●	●	●	●	○
2 Series	F44	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
2 Series	F44	Drive	EGS transmission management	●	●	●	●	●	○
2 Series	F44	Drive	GWS Gear selector switch	●	●	●	●	●	○
2 Series	F44	Drive	LMV Longitudinal torque distribution	●	●	●	●	●	○
2 Series	F46	Body	ACSM Crash Safety Module	●	●	●	●	●	○
2 Series	F46	Body	AHM Trailer module	●	●	●	●	●	○
2 Series	F46	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
2 Series	F46	Body	ASD Active Sound Design	●	●	●	●	●	○
2 Series	F46	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
2 Series	F46	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
2 Series	F46	Body	CIC Car Information Computer	●	●	●	●	●	○
2 Series	F46	Body	CON Controller	●	●	●	●	●	○
2 Series	F46	Body	CVM Convertible top module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
2 Series	F46	Body	DSP Digital Sound Processor	●	●	●	●	●	○
2 Series	F46	Body	DVDC DVD Changer	●	●	●	●	●	○
2 Series	F46	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
2 Series	F46	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
2 Series	F46	Body	EME Electric machine electronics	●	●	●	●	●	○
2 Series	F46	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
2 Series	F46	Body	FLA High Beam Assist	●	●	●	●	●	○
2 Series	F46	Body	FRM Footwell module	●	●	●	●	●	○
2 Series	F46	Body	FZD Function centre,roof	●	●	●	●	●	○
2 Series	F46	Body	GHAS Regulated differential lock	●	●	●	●	●	○
2 Series	F46	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
2 Series	F46	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
2 Series	F46	Body	INSTR Instrument cluster	●	●	●	●	●	○
2 Series	F46	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
2 Series	F46	Body	PDC Park distance control	●	●	●	●	●	○
2 Series	F46	Body	PMA Parking assistant	●	●	●	●	●	○
2 Series	F46	Body	RAD Radio	●	●	●	●	●	○
2 Series	F46	Body	SEC Supplementary control unit	●	●	●	●	●	○
2 Series	F46	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
2 Series	F46	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
2 Series	F46	Body	SMBF Seat module,passenger	●	●	●	●	●	○
2 Series	F46	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
2 Series	F46	Body	SME Accumulator-management electronics	●	●	●	●	●	○
2 Series	F46	Body	SMFA Seat module,driver	●	●	●	●	●	○
2 Series	F46	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
2 Series	F46	Body	SWW Lane change warning	●	●	●	●	●	○
2 Series	F46	Body	SZL Switch centre, steering column	●	●	●	●	●	○
2 Series	F46	Body	TBX Touchbox	●	●	●	●	●	○
2 Series	F46	Body	TRSVCA allround-view camera	●	●	●	●	●	○
2 Series	F46	Body	VM Video Module	●	●	●	●	●	○
2 Series	F46	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
2 Series	F46	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
2 Series	F46	Chassis	AL active steering	●	●	●	●	●	○
2 Series	F46	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
2 Series	F46	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
2 Series	F46	Chassis	EMF Parking brake	●	●	●	●	●	○
2 Series	F46	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
2 Series	F46	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
2 Series	F46	Chassis	RDC Tyre pressure control	●	●	●	●	●	○
2 Series	F46	Chassis	SVT Servotronic	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
2 Series	F46	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
2 Series	F46	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
2 Series	F46	Drive	CAS Car Access System	●	●	●	●	●	○
2 Series	F46	Drive	DDE Diesel Electronics	●	●	●	●	●	○
2 Series	F46	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
2 Series	F46	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
2 Series	F46	Drive	EGS transmission management	●	●	●	●	●	○
2 Series	F46	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
2 Series	F46	Drive	GWS Gear selector switch	●	●	●	●	●	○
2 Series	F46	Drive	VTG Transfer case	●	●	●	●	●	○
2 Series	F87	Body	ACSM Crash Safety Module	●	●	●	●	●	○
2 Series	F87	Body	AHM Trailer module	●	●	●	●	●	○
2 Series	F87	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
2 Series	F87	Body	ASD Active Sound Design	●	●	●	●	●	○
2 Series	F87	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
2 Series	F87	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
2 Series	F87	Body	CIC Car Information Computer	●	●	●	●	●	○
2 Series	F87	Body	CON Controller	●	●	●	●	●	○
2 Series	F87	Body	CVM Convertible top module	●	●	●	●	●	○
2 Series	F87	Body	DSP Digital Sound Processor	●	●	●	●	●	○
2 Series	F87	Body	DVDC DVD Changer	●	●	●	●	●	○
2 Series	F87	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
2 Series	F87	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
2 Series	F87	Body	EME Electric machine electronics	●	●	●	●	●	○
2 Series	F87	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
2 Series	F87	Body	FLA High Beam Assist	●	●	●	●	●	○
2 Series	F87	Body	FRM Footwell module	●	●	●	●	●	○
2 Series	F87	Body	FZD Function centre,roof	●	●	●	●	●	○
2 Series	F87	Body	GHAS Regulated differential lock	●	●	●	●	●	○
2 Series	F87	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
2 Series	F87	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
2 Series	F87	Body	INSTR Instrument cluster	●	●	●	●	●	○
2 Series	F87	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
2 Series	F87	Body	PDC Park distance control	●	●	●	●	●	○
2 Series	F87	Body	PMA Parking assistant	●	●	●	●	●	○
2 Series	F87	Body	RAD Radio	●	●	●	●	●	○
2 Series	F87	Body	SEC Supplementary control unit	●	●	●	●	●	○
2 Series	F87	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
2 Series	F87	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
2 Series	F87	Body	SMBF Seat module,passenger	●	●	●	●	●	○
2 Series	F87	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
2 Series	F87	Body	SME Accumulator-management electronics	●	●	●	●	●	○
2 Series	F87	Body	SMFA Seat module,driver	●	●	●	●	●	○
2 Series	F87	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
2 Series	F87	Body	SWW Lane change warning	●	●	●	●	●	○
2 Series	F87	Body	SZL Switch centre, steering column	●	●	●	●	●	○
2 Series	F87	Body	TBX Touchbox	●	●	●	●	●	○
2 Series	F87	Body	TR SVC allround-view camera	●	●	●	●	●	○
2 Series	F87	Body	VM Video Module	●	●	●	●	●	○
2 Series	F87	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
2 Series	F87	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
2 Series	F87	Chassis	AL active steering	●	●	●	●	●	○
2 Series	F87	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
2 Series	F87	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
2 Series	F87	Chassis	EMF Parking brake	●	●	●	●	●	○
2 Series	F87	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
2 Series	F87	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
2 Series	F87	Chassis	RDC Tyre pressure control	●	●	●	●	●	○
2 Series	F87	Chassis	SVT Servotronic	●	●	●	●	●	○
2 Series	F87	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
2 Series	F87	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
2 Series	F87	Drive	CAS Car Access System	●	●	●	●	●	○
2 Series	F87	Drive	DDE Diesel Electronics	●	●	●	●	●	○
2 Series	F87	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
2 Series	F87	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
2 Series	F87	Drive	EGS transmission management	●	●	●	●	●	○
2 Series	F87	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
2 Series	F87	Drive	GWS Gear selector switch	●	●	●	●	●	○
2 Series	F87	Drive	VTG Transfer case	●	●	●	●	●	○
3 Series	F35	Body	ACC Active Cruise Control	●	●	●	●	●	○
3 Series	F35	Body	ACSM Crash Safety Module	●	●	●	●	●	○
3 Series	F35	Body	AHM Trailer module	●	●	●	●	●	○
3 Series	F35	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
3 Series	F35	Body	ASD Active Sound Design	●	●	●	●	●	○
3 Series	F35	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
3 Series	F35	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
3 Series	F35	Body	CIC Car Information Computer	●	●	●	●	●	○
3 Series	F35	Body	CON Controller	●	●	●	●	●	○
3 Series	F35	Body	CVM Convertible top module	●	●	●	●	●	○
3 Series	F35	Body	DSP Digital Sound Processor	●	●	●	●	●	○
3 Series	F35	Body	DVDC DVD Changer	●	●	●	●	●	○
3 Series	F35	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
3 Series	F35	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
3 Series	F35	Body	EME Electric machine electronics	●	●	●	●	●	○
3 Series	F35	Body	EME2 Electrical machine electronics	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	F35	Body	FLA High Beam Assist	●	●	●	●	●	○
3 Series	F35	Body	FRM Footwell module	●	●	●	●	●	○
3 Series	F35	Body	FZD Function centre,roof	●	●	●	●	●	○
3 Series	F35	Body	GHAS Regulated differential lock	●	●	●	●	●	○
3 Series	F35	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
3 Series	F35	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
3 Series	F35	Body	INSTR Instrument cluster	●	●	●	●	●	○
3 Series	F35	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
3 Series	F35	Body	PDC Park distance control	●	●	●	●	●	○
3 Series	F35	Body	PMA Parking assistant	●	●	●	●	●	○
3 Series	F35	Body	RAD Radio	●	●	●	●	●	○
3 Series	F35	Body	RDC Tyre pressure control	●	●	●	●	●	○
3 Series	F35	Body	SEC Supplementary control unit	●	●	●	●	●	○
3 Series	F35	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
3 Series	F35	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
3 Series	F35	Body	SMBF Seat module,passenger	●	●	●	●	●	○
3 Series	F35	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
3 Series	F35	Body	SME Accumulator-management electronics	●	●	●	●	●	○
3 Series	F35	Body	SMFA Seat module,driver	●	●	●	●	●	○
3 Series	F35	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
3 Series	F35	Body	SVT Servotronic	●	●	●	●	●	○
3 Series	F35	Body	SWW Lane change warning	●	●	●	●	●	○
3 Series	F35	Body	SZL Switch centre, steering column	●	●	●	●	●	○
3 Series	F35	Body	TBX Touchbox	●	●	●	●	●	○
3 Series	F35	Body	TR SVC allround-view camera	●	●	●	●	●	○
3 Series	F35	Body	VM Video Module	●	●	●	●	●	○
3 Series	F35	Body	VTG Transfer case	●	●	●	●	●	○
3 Series	F35	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
3 Series	F35	Chassis	AL active steering	●	●	●	●	●	○
3 Series	F35	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
3 Series	F35	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
3 Series	F35	Chassis	EMF Parking brake	●	●	●	●	●	○
3 Series	F35	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
3 Series	F35	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
3 Series	F35	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
3 Series	F35	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
3 Series	F35	Drive	CAS Car Access System	●	●	●	●	●	○
3 Series	F35	Drive	DDE Diesel Electronics	●	●	●	●	●	○
3 Series	F35	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
3 Series	F35	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	F35	Drive	EGS transmission management	●	●	●	●	●	○
3 Series	F35	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
3 Series	F35	Drive	GWS Gear selector switch	●	●	●	●	●	○
3 Series	G20	Body	ACSM Crash Safety Module	●	●	●	●	●	○
3 Series	G20	Body	AHM Trailer module	●	●	●	●	●	○
3 Series	G20	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
3 Series	G20	Body	ASD Active Sound Design	●	●	●	●	●	○
3 Series	G20	Body	CON Controller	●	●	●	●	●	○
3 Series	G20	Body	CPM Car Pad Module	●	●	●	●	●	○
3 Series	G20	Body	CSM Car Sharing Module	●	●	●	●	●	○
3 Series	G20	Body	CVM Convertible top module	●	●	●	●	●	○
3 Series	G20	Body	DCS Driver Camera System	●	●	●	●	●	○
3 Series	G20	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
3 Series	G20	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
3 Series	G20	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
3 Series	G20	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
3 Series	G20	Body	ENS Ethernet switch	●	●	●	●	●	○
3 Series	G20	Body	FLA High Beam Assist	●	●	●	●	●	○
3 Series	G20	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
3 Series	G20	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
3 Series	G20	Body	FZD Function centre,roof	●	●	●	●	●	○
3 Series	G20	Body	GHAS Regulated differential lock	●	●	●	●	●	○
3 Series	G20	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
3 Series	G20	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
3 Series	G20	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
3 Series	G20	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
3 Series	G20	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
3 Series	G20	Body	HU-B Headunit Basis	●	●	●	●	●	○
3 Series	G20	Body	HU-H Headunit High	●	●	●	●	●	○
3 Series	G20	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
3 Series	G20	Body	INSTR Instrument cluster	●	●	●	●	●	○
3 Series	G20	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
3 Series	G20	Body	KLE Convenience charging electronics	●	●	●	●	●	○
3 Series	G20	Body	LEM Light effect manager	●	●	●	●	●	○
3 Series	G20	Body	NVE Night Vision Electronics	●	●	●	●	●	○
3 Series	G20	Body	PCU Power Control Unit	●	●	●	●	●	○
3 Series	G20	Body	PMA Parking assistant	●	●	●	●	●	○
3 Series	G20	Body	RAM Receiver audio module	●	●	●	●	●	○
3 Series	G20	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
3 Series	G20	Body	RLMAR Right outer rear light module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	G20	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
3 Series	G20	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
3 Series	G20	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
3 Series	G20	Body	SAS Optional equipment system 2	●	●	●	●	●	○
3 Series	G20	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
3 Series	G20	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
3 Series	G20	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
3 Series	G20	Body	SMBF Seat module,passenger	●	●	●	●	●	○
3 Series	G20	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
3 Series	G20	Body	SME Accumulator-management electronics	●	●	●	●	●	○
3 Series	G20	Body	SMFA Seat module,driver	●	●	●	●	●	○
3 Series	G20	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
3 Series	G20	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
3 Series	G20	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
3 Series	G20	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
3 Series	G20	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
3 Series	G20	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
3 Series	G20	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
3 Series	G20	Body	TCB Telematic Communication Box	●	●	●	●	●	○
3 Series	G20	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
3 Series	G20	Body	TR SVC allround-view camera	●	●	●	●	●	○
3 Series	G20	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
3 Series	G20	Body	VIP Virtual integration system	●	●	●	●	●	○
3 Series	G20	Body	VM Video Module	●	●	●	●	●	○
3 Series	G20	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
3 Series	G20	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
3 Series	G20	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
3 Series	G20	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
3 Series	G20	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
3 Series	G20	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
3 Series	G20	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
3 Series	G20	Chassis	FRS Front radar sensor	●	●	●	●	●	○
3 Series	G20	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
3 Series	G20	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
3 Series	G20	Drive	CAS Car Access System	●	●	●	●	●	○
3 Series	G20	Drive	DDE Digital Diesel Electronics	●	●	●	●	●	○
3 Series	G20	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
3 Series	G20	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	G20	Drive	EGS transmission management	●	●	●	●	●	○
3 Series	G20	Drive	GWS Gear selector switch	●	●	●	●	●	○
3 Series	G20	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
3 Series	G20	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
3 Series	G20	Drive	VTG Transfer case	●	●	●	●	●	○
3 Series	G21	Body	ACSM Crash Safety Module	●	●	●	●	●	○
3 Series	G21	Body	AHM Trailer module	●	●	●	●	●	○
3 Series	G21	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
3 Series	G21	Body	ASD Active Sound Design	●	●	●	●	●	○
3 Series	G21	Body	CON Controller	●	●	●	●	●	○
3 Series	G21	Body	CPM Car Pad Module	●	●	●	●	●	○
3 Series	G21	Body	CSM Car Sharing Module	●	●	●	●	●	○
3 Series	G21	Body	CVM Convertible top module	●	●	●	●	●	○
3 Series	G21	Body	DCS Driver Camera System	●	●	●	●	●	○
3 Series	G21	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
3 Series	G21	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
3 Series	G21	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
3 Series	G21	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
3 Series	G21	Body	ENS Ethernet switch	●	●	●	●	●	○
3 Series	G21	Body	FLA High Beam Assist	●	●	●	●	●	○
3 Series	G21	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
3 Series	G21	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
3 Series	G21	Body	FZD Function centre,roof	●	●	●	●	●	○
3 Series	G21	Body	GHAS Regulated differential lock	●	●	●	●	●	○
3 Series	G21	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
3 Series	G21	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
3 Series	G21	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
3 Series	G21	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
3 Series	G21	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
3 Series	G21	Body	HU-B Headunit Basis	●	●	●	●	●	○
3 Series	G21	Body	HU-H Headunit High	●	●	●	●	●	○
3 Series	G21	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
3 Series	G21	Body	INSTR Instrument cluster	●	●	●	●	●	○
3 Series	G21	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
3 Series	G21	Body	KLE Convenience charging electronics	●	●	●	●	●	○
3 Series	G21	Body	LEM Light effect manager	●	●	●	●	●	○
3 Series	G21	Body	NVE Night Vision Electronics	●	●	●	●	●	○
3 Series	G21	Body	PCU Power Control Unit	●	●	●	●	●	○
3 Series	G21	Body	PMA Parking assistant	●	●	●	●	●	○
3 Series	G21	Body	RAM Receiver audio module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	G21	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
3 Series	G21	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
3 Series	G21	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
3 Series	G21	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
3 Series	G21	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
3 Series	G21	Body	SAS Optional equipment system 2	●	●	●	●	●	○
3 Series	G21	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
3 Series	G21	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
3 Series	G21	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
3 Series	G21	Body	SMBF Seat module,passenger	●	●	●	●	●	○
3 Series	G21	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
3 Series	G21	Body	SME Accumulator-management electronics	●	●	●	●	●	○
3 Series	G21	Body	SMFA Seat module,driver	●	●	●	●	●	○
3 Series	G21	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
3 Series	G21	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
3 Series	G21	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
3 Series	G21	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
3 Series	G21	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
3 Series	G21	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
3 Series	G21	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
3 Series	G21	Body	TCB Telematic Communication Box	●	●	●	●	●	○
3 Series	G21	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
3 Series	G21	Body	TR SVC allround-view camera	●	●	●	●	●	○
3 Series	G21	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
3 Series	G21	Body	VIP Virtual integration system	●	●	●	●	●	○
3 Series	G21	Body	VM Video Module	●	●	●	●	●	○
3 Series	G21	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
3 Series	G21	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
3 Series	G21	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
3 Series	G21	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
3 Series	G21	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
3 Series	G21	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
3 Series	G21	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
3 Series	G21	Chassis	FRS Front radar sensor	●	●	●	●	●	○
3 Series	G21	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
3 Series	G21	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
3 Series	G21	Drive	CAS Car Access System	●	●	●	●	●	○
3 Series	G21	Drive	DDE Digital Diesel Electronics	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	G21	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
3 Series	G21	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
3 Series	G21	Drive	EGS transmission management	●	●	●	●	●	○
3 Series	G21	Drive	GWS Gear selector switch	●	●	●	●	●	○
3 Series	G21	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
3 Series	G21	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
3 Series	G21	Drive	VTG Transfer case	●	●	●	●	●	○
3 Series	G28	Body	ACSM Crash Safety Module	●	●	●	●	●	○
3 Series	G28	Body	AHM Trailer module	●	●	●	●	●	○
3 Series	G28	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
3 Series	G28	Body	ASD Active Sound Design	●	●	●	●	●	○
3 Series	G28	Body	CON Controller	●	●	●	●	●	○
3 Series	G28	Body	CPM Car Pad Module	●	●	●	●	●	○
3 Series	G28	Body	CSM Car Sharing Module	●	●	●	●	●	○
3 Series	G28	Body	CVM Convertible top module	●	●	●	●	●	○
3 Series	G28	Body	DCS Driver Camera System	●	●	●	●	●	○
3 Series	G28	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
3 Series	G28	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
3 Series	G28	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
3 Series	G28	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
3 Series	G28	Body	ENS Ethernet switch	●	●	●	●	●	○
3 Series	G28	Body	FLA High Beam Assist	●	●	●	●	●	○
3 Series	G28	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
3 Series	G28	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
3 Series	G28	Body	FZD Function centre,roof	●	●	●	●	●	○
3 Series	G28	Body	GHAS Regulated differential lock	●	●	●	●	●	○
3 Series	G28	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
3 Series	G28	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
3 Series	G28	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
3 Series	G28	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
3 Series	G28	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
3 Series	G28	Body	HU-B Headunit Basis	●	●	●	●	●	○
3 Series	G28	Body	HU-H Headunit High	●	●	●	●	●	○
3 Series	G28	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
3 Series	G28	Body	INSTR Instrument cluster	●	●	●	●	●	○
3 Series	G28	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
3 Series	G28	Body	KLE Convenience charging electronics	●	●	●	●	●	○
3 Series	G28	Body	LEM Light effect manager	●	●	●	●	●	○
3 Series	G28	Body	NVE Night Vision Electronics	●	●	●	●	●	○
3 Series	G28	Body	PCU Power Control Unit	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	G28	Body	PMA Parking assistant	●	●	●	●	●	○
3 Series	G28	Body	RAM Receiver audio module	●	●	●	●	●	○
3 Series	G28	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
3 Series	G28	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
3 Series	G28	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
3 Series	G28	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
3 Series	G28	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
3 Series	G28	Body	SAS Optional equipment system 2	●	●	●	●	●	○
3 Series	G28	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
3 Series	G28	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
3 Series	G28	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
3 Series	G28	Body	SMBF Seat module,passenger	●	●	●	●	●	○
3 Series	G28	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
3 Series	G28	Body	SME Accumulator-management electronics	●	●	●	●	●	○
3 Series	G28	Body	SMFA Seat module,driver	●	●	●	●	●	○
3 Series	G28	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
3 Series	G28	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
3 Series	G28	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
3 Series	G28	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
3 Series	G28	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
3 Series	G28	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
3 Series	G28	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
3 Series	G28	Body	TCB Telematic Communication Box	●	●	●	●	●	○
3 Series	G28	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
3 Series	G28	Body	TR SVC allround-view camera	●	●	●	●	●	○
3 Series	G28	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
3 Series	G28	Body	VIP Virtual integration system	●	●	●	●	●	○
3 Series	G28	Body	VM Video Module	●	●	●	●	●	○
3 Series	G28	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
3 Series	G28	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
3 Series	G28	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
3 Series	G28	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
3 Series	G28	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
3 Series	G28	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
3 Series	G28	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
3 Series	G28	Chassis	FRS Front radar sensor	●	●	●	●	●	○
3 Series	G28	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
3 Series	G28	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
3 Series	G28	Drive	CAS Car Access System	●	●	●	●	●	○
3 Series	G28	Drive	DDE Digital Diesel Electronics	●	●	●	●	●	○
3 Series	G28	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
3 Series	G28	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
3 Series	G28	Drive	EGS transmission management	●	●	●	●	●	○
3 Series	G28	Drive	GWS Gear selector switch	●	●	●	●	●	○
3 Series	G28	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
3 Series	G28	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
3 Series	G28	Drive	VTG Transfer case	●	●	●	●	●	○
5 Series	F07	Body	LHML LED main light module,left	●	●	●	●	●	○
5 Series	F07	Body	LHMR LED main light module,right	●	●	●	●	●	○
5 Series	F90	Body	ACSM Crash Safety Module	●	●	●	●	●	○
5 Series	F90	Body	AHM Trailer module	●	●	●	●	●	○
5 Series	F90	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
5 Series	F90	Body	ASD Active Sound Design	●	●	●	●	●	○
5 Series	F90	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
5 Series	F90	Body	CON Controller	●	●	●	●	●	○
5 Series	F90	Body	CVM Convertible top module	●	●	●	●	●	○
5 Series	F90	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
5 Series	F90	Body	FCON Rear compartment controller	●	●	●	●	●	○
5 Series	F90	Body	FLA High Beam Assist	●	●	●	●	●	○
5 Series	F90	Body	FZD Function centre,roof	●	●	●	●	●	○
5 Series	F90	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
5 Series	F90	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
5 Series	F90	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
5 Series	F90	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
5 Series	F90	Body	INSTR Instrument cluster	●	●	●	●	●	○
5 Series	F90	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
5 Series	F90	Body	KLE Convenience charging electronics	●	●	●	●	●	○
5 Series	F90	Body	LEM Light effect manager	●	●	●	●	●	○
5 Series	F90	Body	LIM Charge Interface Module	●	●	●	●	●	○
5 Series	F90	Body	NVE Night Vision Electronics	●	●	●	●	●	○
5 Series	F90	Body	PCU Power Control Unit	●	●	●	●	●	○
5 Series	F90	Body	PMA Parking assistant	●	●	●	●	●	○
5 Series	F90	Body	RAD Radio	●	●	●	●	●	○
5 Series	F90	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
5 Series	F90	Body	SAS Optional equipment system	●	●	●	●	●	○
5 Series	F90	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
5 Series	F90	Body	SEC Supplementary control unit	●	●	●	●	●	○
5 Series	F90	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
5 Series	F90	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
5 Series	F90	Body	SMBF Seat module,passenger	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	F90	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
5 Series	F90	Body	SME Accumulator-management electronics	●	●	●	●	●	○
5 Series	F90	Body	SMFA Seat module,driver	●	●	●	●	●	○
5 Series	F90	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
5 Series	F90	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
5 Series	F90	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
5 Series	F90	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
5 Series	F90	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
5 Series	F90	Body	SWW Lane change warning	●	●	●	●	●	○
5 Series	F90	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
5 Series	F90	Body	TR SVC allround-view camera	●	●	●	●	●	○
5 Series	F90	Body	VM Video Module	●	●	●	●	●	○
5 Series	F90	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
5 Series	F90	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
5 Series	F90	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
5 Series	F90	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
5 Series	F90	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
5 Series	F90	Chassis	EARSV Front electric ARS	●	●	●	●	●	○
5 Series	F90	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
5 Series	F90	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
5 Series	F90	Drive	CAS Car Access System	●	●	●	●	●	○
5 Series	F90	Drive	DDE Diesel Electronics	●	●	●	●	●	○
5 Series	F90	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
5 Series	F90	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
5 Series	F90	Drive	EGS transmission management	●	●	●	●	●	○
5 Series	F90	Drive	GWS Gear selector switch	●	●	●	●	●	○
5 Series	F90	Drive	VTG Transfer case	●	●	●	●	●	○
5 Series	G30/G31	Body	ACSM Crash Safety Module	●	●	●	●	●	○
5 Series	G30/G31	Body	CDM Coach door module	●	●	●	●	●	○
5 Series	G30/G31	Body	CIC Car Information Computer	●	●	●	●	●	○
5 Series	G30/G31	Body	CON Controller	●	●	●	●	●	○
5 Series	G30/G31	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
5 Series	G30/G31	Body	FCON Rear compartment controller	●	●	●	●	●	○
5 Series	G30/G31	Body	FZD Function centre,roof	●	●	●	●	●	○
5 Series	G30/G31	Body	GHAS Regulated differential lock	●	●	●	●	●	○
5 Series	G30/G31	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
5 Series	G30/G31	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
5 Series	G30/G31	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
5 Series	G30/G31	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
5 Series	G30/G31	Body	INSTR Instrument cluster	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	G30/G31	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
5 Series	G30/G31	Body	LEM Light effect manager	●	●	●	●	●	○
5 Series	G30/G31	Body	LHML LED main light module,left	●	●	●	●	●	○
5 Series	G30/G31	Body	LHMR LED main light module,right	●	●	●	●	●	○
5 Series	G30/G31	Body	LIM Chanrge Interface Module	●	●	●	●	●	○
5 Series	G30/G31	Body	PCU Power Control Unit	●	●	●	●	●	○
5 Series	G30/G31	Body	PMA Parking assistant	●	●	●	●	●	○
5 Series	G30/G31	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
5 Series	G30/G31	Body	SAS Optional equipment system	●	●	●	●	●	○
5 Series	G30/G31	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
5 Series	G30/G31	Body	SMBF Seat module,passenger	●	●	●	●	●	○
5 Series	G30/G31	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
5 Series	G30/G31	Body	SME Accumulator-management electronics	●	●	●	●	●	○
5 Series	G30/G31	Body	SMFA Seat module,driver	●	●	●	●	●	○
5 Series	G30/G31	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
5 Series	G30/G31	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
5 Series	G30/G31	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
5 Series	G30/G31	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
5 Series	G30/G31	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
5 Series	G30/G31	Body	SWW Lane change warning	●	●	●	●	●	○
5 Series	G30/G31	Body	TR SVC allround-view camera	●	●	●	●	●	○
5 Series	G30/G31	Body	VM Video Module	●	●	●	●	●	○
5 Series	G30/G31	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
5 Series	G30/G31	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
5 Series	G30/G31	Chassis	AL active steering	●	●	●	●	●	○
5 Series	G30/G31	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
5 Series	G30/G31	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
5 Series	G30/G31	Chassis	EARSV Front electric ARS	●	●	●	●	●	○
5 Series	G30/G31	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
5 Series	G30/G31	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
5 Series	G30/G31	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
5 Series	G30/G31	Drive	CAS Car Access System	●	●	●	●	●	○
5 Series	G30/G31	Drive	DDE Diesel Electronics	●	●	●	●	●	○
5 Series	G30/G31	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
5 Series	G30/G31	Drive	EGS transmission management	●	●	●	●	●	○
5 Series	G30/G31	Drive	GWS Gear selector switch	●	●	●	●	●	○
5 Series	G30/G31	Drive	VTG Transfer case	●	●	●	●	●	○
5 Series	G32	Body	ACSM Crash Safety Module	●	●	●	●	●	○
5 Series	G32	Body	CDM Coach door module	●	●	●	●	●	○
5 Series	G32	Body	CIC Car Information Computer	●	●	●	●	●	○
5 Series	G32	Body	CON Controller	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	G32	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
5 Series	G32	Body	FCON Rear compartment controller	●	●	●	●	●	○
5 Series	G32	Body	FZD Function centre,roof	●	●	●	●	●	○
5 Series	G32	Body	GHAS Regulated differential lock	●	●	●	●	●	○
5 Series	G32	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
5 Series	G32	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
5 Series	G32	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
5 Series	G32	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
5 Series	G32	Body	INSTR Instrument cluster	●	●	●	●	●	○
5 Series	G32	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
5 Series	G32	Body	LEM Light effect manager	●	●	●	●	●	○
5 Series	G32	Body	LHML LED main light module,left	●	●	●	●	●	○
5 Series	G32	Body	LHMR LED main light module,right	●	●	●	●	●	○
5 Series	G32	Body	LIM Chanrge Interface Module	●	●	●	●	●	○
5 Series	G32	Body	PCU Power Control Unit	●	●	●	●	●	○
5 Series	G32	Body	PMA Parking assistant	●	●	●	●	●	○
5 Series	G32	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
5 Series	G32	Body	SAS Optional equipment system	●	●	●	●	●	○
5 Series	G32	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
5 Series	G32	Body	SMBF Seat module,passenger	●	●	●	●	●	○
5 Series	G32	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
5 Series	G32	Body	SME Accumulator-management electronics	●	●	●	●	●	○
5 Series	G32	Body	SMFA Seat module,driver	●	●	●	●	●	○
5 Series	G32	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
5 Series	G32	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
5 Series	G32	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
5 Series	G32	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
5 Series	G32	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
5 Series	G32	Body	SWW Lane change warning	●	●	●	●	●	○
5 Series	G32	Body	TR SVC allround-view camera	●	●	●	●	●	○
5 Series	G32	Body	VM Video Module	●	●	●	●	●	○
5 Series	G32	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
5 Series	G32	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
5 Series	G32	Chassis	AL active steering	●	●	●	●	●	○
5 Series	G32	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
5 Series	G32	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
5 Series	G32	Chassis	EARSV Front electric ARS	●	●	●	●	●	○
5 Series	G32	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
5 Series	G32	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	G32	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
5 Series	G32	Drive	CAS Car Access System	●	●	●	●	●	○
5 Series	G32	Drive	DDE Diesel Electronics	●	●	●	●	●	○
5 Series	G32	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
5 Series	G32	Drive	EGS transmission management	●	●	●	●	●	○
5 Series	G32	Drive	GWS Gear selector switch	●	●	●	●	●	○
5 Series	G32	Drive	VTG Transfer case	●	●	●	●	●	○
5 Series	G38	Body	ACSM Crash Safety Module	●	●	●	●	●	○
5 Series	G38	Body	AHM Trailer module	●	●	●	●	●	○
5 Series	G38	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
5 Series	G38	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
5 Series	G38	Body	CDM Coach door module	●	●	●	●	●	○
5 Series	G38	Body	CON Controller	●	●	●	●	●	○
5 Series	G38	Body	CPM Car Pad Module	●	●	●	●	●	○
5 Series	G38	Body	CSM Car Sharing Module	●	●	●	●	●	○
5 Series	G38	Body	CVM Convertible top module	●	●	●	●	●	○
5 Series	G38	Body	DCS Driver Camera System	●	●	●	●	●	○
5 Series	G38	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
5 Series	G38	Body	ENS Ethernet switch	●	●	●	●	●	○
5 Series	G38	Body	FCON Rear compartment controller	●	●	●	●	●	○
5 Series	G38	Body	FLA High Beam Assist	●	●	●	●	●	○
5 Series	G38	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
5 Series	G38	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
5 Series	G38	Body	FRS Front radar sensor	●	●	●	●	●	○
5 Series	G38	Body	FZD Function centre,roof	●	●	●	●	●	○
5 Series	G38	Body	GHAS Regulated differential lock	●	●	●	●	●	○
5 Series	G38	Body	HFKM Tailgate function module	●	●	●	●	●	○
5 Series	G38	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
5 Series	G38	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
5 Series	G38	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
5 Series	G38	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
5 Series	G38	Body	HU-H Headunit High	●	●	●	●	●	○
5 Series	G38	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
5 Series	G38	Body	INSTR Instrument cluster	●	●	●	●	●	○
5 Series	G38	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
5 Series	G38	Body	KLE KLE Convenience charging electronics	●	●	●	●	●	○
5 Series	G38	Body	LEM Light effect manager	●	●	●	●	●	○
5 Series	G38	Body	NVE Night Vision Electronics	●	●	●	●	●	○
5 Series	G38	Body	PCU Power Control Unit	●	●	●	●	●	○
5 Series	G38	Body	PMA Parking assistant	●	●	●	●	●	○
5 Series	G38	Body	RAM Receiver audio module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	G38	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
5 Series	G38	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
5 Series	G38	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
5 Series	G38	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
5 Series	G38	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
5 Series	G38	Body	SAS Optional equipment system	●	●	●	●	●	○
5 Series	G38	Body	SAS Optional equipment system 2	●	●	●	●	●	○
5 Series	G38	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
5 Series	G38	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
5 Series	G38	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
5 Series	G38	Body	SMBF Seat module,passenger	●	●	●	●	●	○
5 Series	G38	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
5 Series	G38	Body	SME Accumulator-management electronics	●	●	●	●	●	○
5 Series	G38	Body	SMFA Seat module,driver	●	●	●	●	●	○
5 Series	G38	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
5 Series	G38	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
5 Series	G38	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
5 Series	G38	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
5 Series	G38	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
5 Series	G38	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
5 Series	G38	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
5 Series	G38	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
5 Series	G38	Body	TR SVC allround-view camera	●	●	●	●	●	○
5 Series	G38	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
5 Series	G38	Body	VIP Virtual integration system	●	●	●	●	●	○
5 Series	G38	Body	VM Video Module	●	●	●	●	●	○
5 Series	G38	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
5 Series	G38	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
5 Series	G38	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
5 Series	G38	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
5 Series	G38	Chassis	EARSV Front electric ARS	●	●	●	●	●	○
5 Series	G38	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
5 Series	G38	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
5 Series	G38	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
5 Series	G38	Drive	CAS Car Access System	●	●	●	●	●	○
5 Series	G38	Drive	DDE Diesel Electronics	●	●	●	●	●	○
5 Series	G38	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
5 Series	G38	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
5 Series	G38	Drive	EGS transmission management	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
5 Series	G38	Drive	GWS Gear selector switch	●	●	●	●	●	○
5 Series	G38	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
5 Series	G38	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
5 Series	G38	Drive	VTG Transfer case	●	●	●	●	●	○
7 Series	F03	Body	ACSM Crash Safety Module	●	●	●	●	●	○
7 Series	F03	Body	AHM Trailer module	●	●	●	●	●	○
7 Series	F03	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
7 Series	F03	Body	ASD Active Sound Design	●	●	●	●	●	○
7 Series	F03	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
7 Series	F03	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	○
7 Series	F03	Body	CDC CD Changer	●	●	●	●	●	○
7 Series	F03	Body	CDM Coach door module	●	●	●	●	●	○
7 Series	F03	Body	CIC Car Information Computer	●	●	●	●	●	○
7 Series	F03	Body	CID Central Information Display	●	●	●	●	●	○
7 Series	F03	Body	CON Controller	●	●	●	●	●	○
7 Series	F03	Body	CSM Car Sharing Module	●	●	●	●	●	○
7 Series	F03	Body	CVM Convertible top module	●	●	●	●	●	○
7 Series	F03	Body	DSP Digital Sound Processor	●	●	●	●	●	○
7 Series	F03	Body	DVDC DVD Changer	●	●	●	●	●	○
7 Series	F03	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
7 Series	F03	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
7 Series	F03	Body	EME Electric machine electronics	●	●	●	●	●	○
7 Series	F03	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
7 Series	F03	Body	FCON Rear compartment controller	●	●	●	●	●	○
7 Series	F03	Body	FD Rear-compartment display	●	●	●	●	●	○
7 Series	F03	Body	FD2 Rear-compartment display 2	●	●	●	●	●	○
7 Series	F03	Body	FKA Rear heater/air conditioning	●	●	●	●	●	○
7 Series	F03	Body	FLA High Beam Assist	●	●	●	●	●	○
7 Series	F03	Body	FRM Footwell module	●	●	●	●	●	○
7 Series	F03	Body	FZD Function centre,roof	●	●	●	●	●	○
7 Series	F03	Body	GHAS Regulated differential lock	●	●	●	●	●	○
7 Series	F03	Body	GZAL Targeted illumination,left	●	●	●	●	●	○
7 Series	F03	Body	GZAR Targeted illumination,right	●	●	●	●	●	○
7 Series	F03	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
7 Series	F03	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
7 Series	F03	Body	HKL Rear-lid lift	●	●	●	●	●	○
7 Series	F03	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
7 Series	F03	Body	HUD Head-Up Display	●	●	●	●	●	○
7 Series	F03	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
7 Series	F03	Body	INSTR Instrument cluster	●	●	●	●	●	○
7 Series	F03	Body	JBE Junction-box electronics	●	●	●	●	●	○
7 Series	F03	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	F03	Body	LHML LED main light module,left	●	●	●	●	●	○
7 Series	F03	Body	LHMR LED main light module,right	●	●	●	●	●	○
7 Series	F03	Body	LIM Chanrge Interface Module	●	●	●	●	●	○
7 Series	F03	Body	NVE Night Vision Electronics	●	●	●	●	●	○
7 Series	F03	Body	PCU Power Control Unit	●	●	●	●	●	○
7 Series	F03	Body	PDC Park Distance Control	●	●	●	●	●	○
7 Series	F03	Body	PMA Parking assistant	●	●	●	●	●	○
7 Series	F03	Body	RAD Radio	●	●	●	●	●	○
7 Series	F03	Body	RDME Range Extender Motor Electronics	●	●	●	●	●	○
7 Series	F03	Body	REME Range extender electrical machine electronics	●	●	●	●	●	○
7 Series	F03	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
7 Series	F03	Body	SAS Optional equipment system	●	●	●	●	●	○
7 Series	F03	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
7 Series	F03	Body	SDARS Satellite tuner	●	●	●	●	●	○
7 Series	F03	Body	SEC Supplementary control unit	●	●	●	●	●	○
7 Series	F03	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	○
7 Series	F03	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
7 Series	F03	Body	SMBF Seat module,passenger	●	●	●	●	●	○
7 Series	F03	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
7 Series	F03	Body	SME Accumulator-management electronics	●	●	●	●	●	○
7 Series	F03	Body	SMFA Seat module,driver	●	●	●	●	●	○
7 Series	F03	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
7 Series	F03	Body	STML Headlight driver module,left	●	●	●	●	●	○
7 Series	F03	Body	STMR Headlight driver module,right	●	●	●	●	●	○
7 Series	F03	Body	SWW Lane change warning	●	●	●	●	●	○
7 Series	F03	Body	SZL Switch centre, steering column	●	●	●	●	●	○
7 Series	F03	Body	TBX Touchbox	●	●	●	●	●	○
7 Series	F03	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
7 Series	F03	Body	TRSVc allround-view camera	●	●	●	●	●	○
7 Series	F03	Body	ULF-SBX Interface box	●	●	●	●	●	○
7 Series	F03	Body	ULF-SBX-H Interface box high	●	●	●	●	●	○
7 Series	F03	Body	VM Video Module	●	●	●	●	●	○
7 Series	F03	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
7 Series	F03	Body	VSW video switch	●	●	●	●	●	○
7 Series	F03	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
7 Series	F03	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
7 Series	F03	Chassis	AL active steering	●	●	●	●	●	○
7 Series	F03	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
7 Series	F03	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	○
7 Series	F03	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	○
7 Series	F03	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	F03	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	○
7 Series	F03	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
7 Series	F03	Chassis	EMF Parking brake	●	●	●	●	●	○
7 Series	F03	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
7 Series	F03	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
7 Series	F03	Chassis	RDC Tyre pressure control	●	●	●	●	●	○
7 Series	F03	Chassis	SVT Servotronic	●	●	●	●	●	○
7 Series	F03	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
7 Series	F03	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
7 Series	F03	Drive	CAS Car Access System	●	●	●	●	●	○
7 Series	F03	Drive	DDE Diesel Electronics	●	●	●	●	●	○
7 Series	F03	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
7 Series	F03	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
7 Series	F03	Drive	EGS transmission management	●	●	●	●	●	○
7 Series	F03	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
7 Series	F03	Drive	GWS Gear selector switch	●	●	●	●	●	○
7 Series	F03	Drive	VTG Transfer case	●	●	●	●	●	○
7 Series	G11/G12	Body	ACSM Crash Safety Module	●	●	●	●	●	○
7 Series	G11/G12	Body	AHM Trailer module	●	●	●	●	●	○
7 Series	G11/G12	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
7 Series	G11/G12	Body	ASD Active Sound Design	●	●	●	●	●	○
7 Series	G11/G12	Body	CON Controller	●	●	●	●	●	○
7 Series	G11/G12	Body	CPM Car Pad Module	●	●	●	●	●	○
7 Series	G11/G12	Body	CSM Car Sharing Module	●	●	●	●	●	○
7 Series	G11/G12	Body	CVM Convertible top module	●	●	●	●	●	○
7 Series	G11/G12	Body	DCS Driver Camera System	●	●	●	●	●	○
7 Series	G11/G12	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
7 Series	G11/G12	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
7 Series	G11/G12	Body	ENS Ethernet switch	●	●	●	●	●	○
7 Series	G11/G12	Body	FLA High Beam Assist	●	●	●	●	●	○
7 Series	G11/G12	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
7 Series	G11/G12	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
7 Series	G11/G12	Body	FZD Function centre,roof	●	●	●	●	●	○
7 Series	G11/G12	Body	GHAS Regulated differential lock	●	●	●	●	●	○
7 Series	G11/G12	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
7 Series	G11/G12	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
7 Series	G11/G12	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
7 Series	G11/G12	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
7 Series	G11/G12	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
7 Series	G11/G12	Body	HU-H Headunit High	●	●	●	●	●	○
7 Series	G11/G12	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	G11/G12	Body	INSTR Instrument cluster	●	●	●	●	●	○
7 Series	G11/G12	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
7 Series	G11/G12	Body	KLE Convenience charging electronics	●	●	●	●	●	○
7 Series	G11/G12	Body	LEM Light effect manager	●	●	●	●	●	○
7 Series	G11/G12	Body	NVE Night Vision Electronics	●	●	●	●	●	○
7 Series	G11/G12	Body	PCU Power Control Unit	●	●	●	●	●	○
7 Series	G11/G12	Body	PMA Parking assistant	●	●	●	●	●	○
7 Series	G11/G12	Body	RAM Receiver audio module	●	●	●	●	●	○
7 Series	G11/G12	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
7 Series	G11/G12	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
7 Series	G11/G12	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
7 Series	G11/G12	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
7 Series	G11/G12	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
7 Series	G11/G12	Body	SAS Optional equipment system 2	●	●	●	●	●	○
7 Series	G11/G12	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
7 Series	G11/G12	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
7 Series	G11/G12	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
7 Series	G11/G12	Body	SMBF Seat module,passenger	●	●	●	●	●	○
7 Series	G11/G12	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
7 Series	G11/G12	Body	SME Accumulator-management electronics	●	●	●	●	●	○
7 Series	G11/G12	Body	SMFA Seat module,driver	●	●	●	●	●	○
7 Series	G11/G12	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
7 Series	G11/G12	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
7 Series	G11/G12	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
7 Series	G11/G12	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
7 Series	G11/G12	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
7 Series	G11/G12	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
7 Series	G11/G12	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
7 Series	G11/G12	Body	SWW Lane change warning	●	●	●	●	●	○
7 Series	G11/G12	Body	TCB Telematic Communication Box	●	●	●	●	●	○
7 Series	G11/G12	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
7 Series	G11/G12	Body	TR SVC allround-view camera	●	●	●	●	●	○
7 Series	G11/G12	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
7 Series	G11/G12	Body	VIP Virtual integration system	●	●	●	●	●	○
7 Series	G11/G12	Body	VM Video Module	●	●	●	●	●	○
7 Series	G11/G12	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
7 Series	G11/G12	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
7 Series	G11/G12	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
7 Series	G11/G12	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
7 Series	G11/G12	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
7 Series	G11/G12	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
7 Series	G11/G12	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
7 Series	G11/G12	Chassis	FRS Front radar sensor	●	●	●	●	●	○
7 Series	G11/G12	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
7 Series	G11/G12	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
7 Series	G11/G12	Drive	CAS Car Access System	●	●	●	●	●	○
7 Series	G11/G12	Drive	DDE Diesel Electronics	●	●	●	●	●	○
7 Series	G11/G12	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
7 Series	G11/G12	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
7 Series	G11/G12	Drive	EGS transmission management	●	●	●	●	●	○
7 Series	G11/G12	Drive	GWS Gear selector switch	●	●	●	●	●	○
7 Series	G11/G12	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
7 Series	G11/G12	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
7 Series	G11/G12	Drive	VTG Transfer case	●	●	●	●	●	○
8 Series	F91	Body	ACSM Crash Safety Module	●	●	●	●	●	○
8 Series	F91	Body	AHM Trailer module	●	●	●	●	●	○
8 Series	F91	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
8 Series	F91	Body	CON Controller	●	●	●	●	●	○
8 Series	F91	Body	CPM Car Pad Module	●	●	●	●	●	○
8 Series	F91	Body	CVM Convertible top module	●	●	●	●	●	○
8 Series	F91	Body	DCS Driver Camera System	●	●	●	●	●	○
8 Series	F91	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
8 Series	F91	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
8 Series	F91	Body	FLA High Beam Assist	●	●	●	●	●	○
8 Series	F91	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
8 Series	F91	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
8 Series	F91	Body	FZD Function centre,roof	●	●	●	●	●	○
8 Series	F91	Body	GHAS Regulated differential lock	●	●	●	●	●	○
8 Series	F91	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
8 Series	F91	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
8 Series	F91	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
8 Series	F91	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
8 Series	F91	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
8 Series	F91	Body	HU-H Headunit High	●	●	●	●	●	○
8 Series	F91	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
8 Series	F91	Body	INSTR Instrument cluster	●	●	●	●	●	○
8 Series	F91	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	F91	Body	KLE Convenience charging electronics	●	●	●	●	●	○
8 Series	F91	Body	LEM Light effect manager	●	●	●	●	●	○
8 Series	F91	Body	NVE Night Vision Electronics	●	●	●	●	●	○
8 Series	F91	Body	PCU Power Control Unit	●	●	●	●	●	○
8 Series	F91	Body	PMA Parking assistant	●	●	●	●	●	○
8 Series	F91	Body	RAM Receiver audio module	●	●	●	●	●	○
8 Series	F91	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
8 Series	F91	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
8 Series	F91	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
8 Series	F91	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
8 Series	F91	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
8 Series	F91	Body	SAS Optional equipment system 2	●	●	●	●	●	○
8 Series	F91	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
8 Series	F91	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
8 Series	F91	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
8 Series	F91	Body	SMBF Seat module,passenger	●	●	●	●	●	○
8 Series	F91	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
8 Series	F91	Body	SME Accumulator-management electronics	●	●	●	●	●	○
8 Series	F91	Body	SMFA Seat module,driver	●	●	●	●	●	○
8 Series	F91	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
8 Series	F91	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
8 Series	F91	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
8 Series	F91	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
8 Series	F91	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
8 Series	F91	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
8 Series	F91	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
8 Series	F91	Body	TCB Telematic Communication Box	●	●	●	●	●	○
8 Series	F91	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
8 Series	F91	Body	TRSVc allround-view camera	●	●	●	●	●	○
8 Series	F91	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
8 Series	F91	Body	VIP Virtual integration system	●	●	●	●	●	○
8 Series	F91	Body	VM Video Module	●	●	●	●	●	○
8 Series	F91	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
8 Series	F91	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
8 Series	F91	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
8 Series	F91	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
8 Series	F91	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
8 Series	F91	Chassis	FRS Front radar sensor	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	F91	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
8 Series	F91	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
8 Series	F91	Drive	CAS Car Access System	●	●	●	●	●	○
8 Series	F91	Drive	DDE Diesel Electronics	●	●	●	●	●	○
8 Series	F91	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
8 Series	F91	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
8 Series	F91	Drive	EGS transmission management	●	●	●	●	●	○
8 Series	F91	Drive	GWS Gear selector switch	●	●	●	●	●	○
8 Series	F91	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
8 Series	F91	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
8 Series	F91	Drive	VTG Transfer case	●	●	●	●	●	○
8 Series	F92	Body	ACSM Crash Safety Module	●	●	●	●	●	○
8 Series	F92	Body	AHM Trailer module	●	●	●	●	●	○
8 Series	F92	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
8 Series	F92	Body	CON Controller	●	●	●	●	●	○
8 Series	F92	Body	CPM Car Pad Module	●	●	●	●	●	○
8 Series	F92	Body	CVM Convertible top module	●	●	●	●	●	○
8 Series	F92	Body	DCS Driver Camera System	●	●	●	●	●	○
8 Series	F92	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
8 Series	F92	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
8 Series	F92	Body	FLA High Beam Assist	●	●	●	●	●	○
8 Series	F92	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
8 Series	F92	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
8 Series	F92	Body	FZD Function centre,roof	●	●	●	●	●	○
8 Series	F92	Body	GHAS Regulated differential lock	●	●	●	●	●	○
8 Series	F92	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
8 Series	F92	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
8 Series	F92	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
8 Series	F92	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
8 Series	F92	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
8 Series	F92	Body	HU-H Headunit High	●	●	●	●	●	○
8 Series	F92	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
8 Series	F92	Body	INSTR Instrument cluster	●	●	●	●	●	○
8 Series	F92	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
8 Series	F92	Body	KLE Convenience charging electronics	●	●	●	●	●	○
8 Series	F92	Body	LEM Light effect manager	●	●	●	●	●	○
8 Series	F92	Body	NVE Night Vision Electronics	●	●	●	●	●	○
8 Series	F92	Body	PCU Power Control Unit	●	●	●	●	●	○
8 Series	F92	Body	PMA Parking assistant	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	F92	Body	RAM Receiver audio module	●	●	●	●	●	○
8 Series	F92	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
8 Series	F92	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
8 Series	F92	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
8 Series	F92	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
8 Series	F92	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
8 Series	F92	Body	SAS Optional equipment system 2	●	●	●	●	●	○
8 Series	F92	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
8 Series	F92	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
8 Series	F92	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
8 Series	F92	Body	SMBF Seat module,passenger	●	●	●	●	●	○
8 Series	F92	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
8 Series	F92	Body	SME Accumulator-management electronics	●	●	●	●	●	○
8 Series	F92	Body	SMFA Seat module,driver	●	●	●	●	●	○
8 Series	F92	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
8 Series	F92	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
8 Series	F92	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
8 Series	F92	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
8 Series	F92	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
8 Series	F92	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
8 Series	F92	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
8 Series	F92	Body	TCB Telematic Communication Box	●	●	●	●	●	○
8 Series	F92	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
8 Series	F92	Body	TR SVC allround-view camera	●	●	●	●	●	○
8 Series	F92	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
8 Series	F92	Body	VIP Virtual integration system	●	●	●	●	●	○
8 Series	F92	Body	VM Video Module	●	●	●	●	●	○
8 Series	F92	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
8 Series	F92	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
8 Series	F92	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
8 Series	F92	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
8 Series	F92	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
8 Series	F92	Chassis	FRS Front radar sensor	●	●	●	●	●	○
8 Series	F92	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
8 Series	F92	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
8 Series	F92	Drive	CAS Car Access System	●	●	●	●	●	○
8 Series	F92	Drive	DDE Diesel Electronics	●	●	●	●	●	○
8 Series	F92	Drive	DME Digital Motor Electronics	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	F92	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
8 Series	F92	Drive	EGS transmission management	●	●	●	●	●	○
8 Series	F92	Drive	GWS Gear selector switch	●	●	●	●	●	○
8 Series	F92	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
8 Series	F92	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
8 Series	F92	Drive	VTG Transfer case	●	●	●	●	●	○
8 Series	F93	Body	ACSM Crash Safety Module	●	●	●	●	●	○
8 Series	F93	Body	AHM Trailer module	●	●	●	●	●	○
8 Series	F93	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
8 Series	F93	Body	CON Controller	●	●	●	●	●	○
8 Series	F93	Body	CPM Car Pad Module	●	●	●	●	●	○
8 Series	F93	Body	CVM Convertible top module	●	●	●	●	●	○
8 Series	F93	Body	DCS Driver Camera System	●	●	●	●	●	○
8 Series	F93	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
8 Series	F93	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
8 Series	F93	Body	FLA High Beam Assist	●	●	●	●	●	○
8 Series	F93	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
8 Series	F93	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
8 Series	F93	Body	FZD Function centre,roof	●	●	●	●	●	○
8 Series	F93	Body	GHAS Regulated differential lock	●	●	●	●	●	○
8 Series	F93	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
8 Series	F93	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
8 Series	F93	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
8 Series	F93	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
8 Series	F93	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
8 Series	F93	Body	HU-H Headunit High	●	●	●	●	●	○
8 Series	F93	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
8 Series	F93	Body	INSTR Instrument cluster	●	●	●	●	●	○
8 Series	F93	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
8 Series	F93	Body	KLE Convenience charging electronics	●	●	●	●	●	○
8 Series	F93	Body	LEM Light effect manager	●	●	●	●	●	○
8 Series	F93	Body	NVE Night Vision Electronics	●	●	●	●	●	○
8 Series	F93	Body	PCU Power Control Unit	●	●	●	●	●	○
8 Series	F93	Body	PMA Parking assistant	●	●	●	●	●	○
8 Series	F93	Body	RAM Receiver audio module	●	●	●	●	●	○
8 Series	F93	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
8 Series	F93	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
8 Series	F93	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
8 Series	F93	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
8 Series	F93	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	F93	Body	SAS Optional equipment system 2	●	●	●	●	●	○
8 Series	F93	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
8 Series	F93	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
8 Series	F93	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
8 Series	F93	Body	SMBF Seat module,passenger	●	●	●	●	●	○
8 Series	F93	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
8 Series	F93	Body	SME Accumulator-management electronics	●	●	●	●	●	○
8 Series	F93	Body	SMFA Seat module,driver	●	●	●	●	●	○
8 Series	F93	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
8 Series	F93	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
8 Series	F93	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
8 Series	F93	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
8 Series	F93	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
8 Series	F93	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
8 Series	F93	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
8 Series	F93	Body	TCB Telematic Communication Box	●	●	●	●	●	○
8 Series	F93	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
8 Series	F93	Body	TR SVC allround-view camera	●	●	●	●	●	○
8 Series	F93	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
8 Series	F93	Body	VIP Virtual integration system	●	●	●	●	●	○
8 Series	F93	Body	VM Video Module	●	●	●	●	●	○
8 Series	F93	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
8 Series	F93	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
8 Series	F93	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
8 Series	F93	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
8 Series	F93	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
8 Series	F93	Chassis	FRS Front radar sensor	●	●	●	●	●	○
8 Series	F93	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
8 Series	F93	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
8 Series	F93	Drive	CAS Car Access System	●	●	●	●	●	○
8 Series	F93	Drive	DDE Diesel Electronics	●	●	●	●	●	○
8 Series	F93	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
8 Series	F93	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
8 Series	F93	Drive	EGS transmission management	●	●	●	●	●	○
8 Series	F93	Drive	GWS Gear selector switch	●	●	●	●	●	○
8 Series	F93	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
8 Series	F93	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
8 Series	F93	Drive	VTG Transfer case	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	G14	Body	ACSM Crash Safety Module	●	●	●	●	●	○
8 Series	G14	Body	AHM Trailer module	●	●	●	●	●	○
8 Series	G14	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
8 Series	G14	Body	CON Controller	●	●	●	●	●	○
8 Series	G14	Body	CPM Car Pad Module	●	●	●	●	●	○
8 Series	G14	Body	CVM Convertible top module	●	●	●	●	●	○
8 Series	G14	Body	DCS Driver Camera System	●	●	●	●	●	○
8 Series	G14	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
8 Series	G14	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
8 Series	G14	Body	FLA High Beam Assist	●	●	●	●	●	○
8 Series	G14	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
8 Series	G14	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
8 Series	G14	Body	FZD Function centre,roof	●	●	●	●	●	○
8 Series	G14	Body	GHAS Regulated differential lock	●	●	●	●	●	○
8 Series	G14	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
8 Series	G14	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
8 Series	G14	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
8 Series	G14	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
8 Series	G14	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
8 Series	G14	Body	HU-H Headunit High	●	●	●	●	●	○
8 Series	G14	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
8 Series	G14	Body	INSTR Instrument cluster	●	●	●	●	●	○
8 Series	G14	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
8 Series	G14	Body	KLE Convenience charging electronics	●	●	●	●	●	○
8 Series	G14	Body	LEM Light effect manager	●	●	●	●	●	○
8 Series	G14	Body	NVE Night Vision Electronics	●	●	●	●	●	○
8 Series	G14	Body	PCU Power Control Unit	●	●	●	●	●	○
8 Series	G14	Body	PMA Parking assistant	●	●	●	●	●	○
8 Series	G14	Body	RAM Receiver audio module	●	●	●	●	●	○
8 Series	G14	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
8 Series	G14	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
8 Series	G14	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
8 Series	G14	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
8 Series	G14	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
8 Series	G14	Body	SAS Optional equipment system 2	●	●	●	●	●	○
8 Series	G14	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
8 Series	G14	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
8 Series	G14	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
8 Series	G14	Body	SMBF Seat module,passenger	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	G14	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
8 Series	G14	Body	SME Accumulator-management electronics	●	●	●	●	●	○
8 Series	G14	Body	SMFA Seat module,driver	●	●	●	●	●	○
8 Series	G14	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
8 Series	G14	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
8 Series	G14	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
8 Series	G14	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
8 Series	G14	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
8 Series	G14	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
8 Series	G14	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
8 Series	G14	Body	TCB Telematic Communication Box	●	●	●	●	●	○
8 Series	G14	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
8 Series	G14	Body	TR SVC allround-view camera	●	●	●	●	●	○
8 Series	G14	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
8 Series	G14	Body	VIP Virtual integration system	●	●	●	●	●	○
8 Series	G14	Body	VM Video Module	●	●	●	●	●	○
8 Series	G14	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
8 Series	G14	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
8 Series	G14	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
8 Series	G14	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
8 Series	G14	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
8 Series	G14	Chassis	FRS Front radar sensor	●	●	●	●	●	○
8 Series	G14	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
8 Series	G14	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
8 Series	G14	Drive	CAS Car Access System	●	●	●	●	●	○
8 Series	G14	Drive	DDE Diesel Electronics	●	●	●	●	●	○
8 Series	G14	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
8 Series	G14	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
8 Series	G14	Drive	EGS transmission management	●	●	●	●	●	○
8 Series	G14	Drive	GWS Gear selector switch	●	●	●	●	●	○
8 Series	G14	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
8 Series	G14	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
8 Series	G14	Drive	VTG Transfer case	●	●	●	●	●	○
8 Series	G15	Body	ACSM Crash Safety Module	●	●	●	●	●	○
8 Series	G15	Body	AHM Trailer module	●	●	●	●	●	○
8 Series	G15	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
8 Series	G15	Body	CON Controller	●	●	●	●	●	○
8 Series	G15	Body	CPM Car Pad Module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	G15	Body	CVM Convertible top module	●	●	●	●	●	○
8 Series	G15	Body	DCS Driver Camera System	●	●	●	●	●	○
8 Series	G15	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
8 Series	G15	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
8 Series	G15	Body	FLA High Beam Assist	●	●	●	●	●	○
8 Series	G15	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
8 Series	G15	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
8 Series	G15	Body	FZD Function centre,roof	●	●	●	●	●	○
8 Series	G15	Body	GHAS Regulated differential lock	●	●	●	●	●	○
8 Series	G15	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
8 Series	G15	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
8 Series	G15	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
8 Series	G15	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
8 Series	G15	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
8 Series	G15	Body	HU-H Headunit High	●	●	●	●	●	○
8 Series	G15	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
8 Series	G15	Body	INSTR Instrument cluster	●	●	●	●	●	○
8 Series	G15	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
8 Series	G15	Body	KLE Convenience charging electronics	●	●	●	●	●	○
8 Series	G15	Body	LEM Light effect manager	●	●	●	●	●	○
8 Series	G15	Body	NVE Night Vision Electronics	●	●	●	●	●	○
8 Series	G15	Body	PCU Power Control Unit	●	●	●	●	●	○
8 Series	G15	Body	PMA Parking assistant	●	●	●	●	●	○
8 Series	G15	Body	RAM Receiver audio module	●	●	●	●	●	○
8 Series	G15	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
8 Series	G15	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
8 Series	G15	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
8 Series	G15	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
8 Series	G15	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
8 Series	G15	Body	SAS Optional equipment system 2	●	●	●	●	●	○
8 Series	G15	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
8 Series	G15	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
8 Series	G15	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
8 Series	G15	Body	SMBF Seat module,passenger	●	●	●	●	●	○
8 Series	G15	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
8 Series	G15	Body	SME Accumulator-management electronics	●	●	●	●	●	○
8 Series	G15	Body	SMFA Seat module,driver	●	●	●	●	●	○
8 Series	G15	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	G15	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
8 Series	G15	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
8 Series	G15	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
8 Series	G15	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
8 Series	G15	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
8 Series	G15	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
8 Series	G15	Body	TCB Telematic Communication Box	●	●	●	●	●	○
8 Series	G15	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
8 Series	G15	Body	TR SVC allround-view camera	●	●	●	●	●	○
8 Series	G15	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
8 Series	G15	Body	VIP Virtual integration system	●	●	●	●	●	○
8 Series	G15	Body	VM Video Module	●	●	●	●	●	○
8 Series	G15	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
8 Series	G15	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
8 Series	G15	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
8 Series	G15	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
8 Series	G15	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
8 Series	G15	Chassis	FRS Front radar sensor	●	●	●	●	●	○
8 Series	G15	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
8 Series	G15	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
8 Series	G15	Drive	CAS Car Access System	●	●	●	●	●	○
8 Series	G15	Drive	DDE Diesel Electronics	●	●	●	●	●	○
8 Series	G15	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
8 Series	G15	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
8 Series	G15	Drive	EGS transmission management	●	●	●	●	●	○
8 Series	G15	Drive	GWS Gear selector switch	●	●	●	●	●	○
8 Series	G15	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
8 Series	G15	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
8 Series	G15	Drive	VTG Transfer case	●	●	●	●	●	○
8 Series	G16	Body	ACSM Crash Safety Module	●	●	●	●	●	○
8 Series	G16	Body	AHM Trailer module	●	●	●	●	●	○
8 Series	G16	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
8 Series	G16	Body	CON Controller	●	●	●	●	●	○
8 Series	G16	Body	CPM Car Pad Module	●	●	●	●	●	○
8 Series	G16	Body	CVM Convertible top module	●	●	●	●	●	○
8 Series	G16	Body	DCS Driver Camera System	●	●	●	●	●	○
8 Series	G16	Body	EMAR SV Front electric active roll stabilisation	●	●	●	●	●	○
8 Series	G16	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
8 Series	G16	Body	FLA High Beam Assist	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	G16	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
8 Series	G16	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
8 Series	G16	Body	FZD Function centre,roof	●	●	●	●	●	○
8 Series	G16	Body	GHAS Regulated differential lock	●	●	●	●	●	○
8 Series	G16	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
8 Series	G16	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
8 Series	G16	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
8 Series	G16	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
8 Series	G16	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
8 Series	G16	Body	HU-H Headunit High	●	●	●	●	●	○
8 Series	G16	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
8 Series	G16	Body	INSTR Instrument cluster	●	●	●	●	●	○
8 Series	G16	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
8 Series	G16	Body	KLE Convenience charging electronics	●	●	●	●	●	○
8 Series	G16	Body	LEM Light effect manager	●	●	●	●	●	○
8 Series	G16	Body	NVE Night Vision Electronics	●	●	●	●	●	○
8 Series	G16	Body	PCU Power Control Unit	●	●	●	●	●	○
8 Series	G16	Body	PMA Parking assistant	●	●	●	●	●	○
8 Series	G16	Body	RAM Receiver audio module	●	●	●	●	●	○
8 Series	G16	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
8 Series	G16	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
8 Series	G16	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
8 Series	G16	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
8 Series	G16	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
8 Series	G16	Body	SAS Optional equipment system 2	●	●	●	●	●	○
8 Series	G16	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
8 Series	G16	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
8 Series	G16	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
8 Series	G16	Body	SMBF Seat module,passenger	●	●	●	●	●	○
8 Series	G16	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
8 Series	G16	Body	SME Accumulator-management electronics	●	●	●	●	●	○
8 Series	G16	Body	SMFA Seat module,driver	●	●	●	●	●	○
8 Series	G16	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
8 Series	G16	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
8 Series	G16	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
8 Series	G16	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
8 Series	G16	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
8 Series	G16	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
8 Series	G16	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
8 Series	G16	Body	TCB Telematic Communication Box	●	●	●	●	●	○
8 Series	G16	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
8 Series	G16	Body	TR SVC allround-view camera	●	●	●	●	●	○
8 Series	G16	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
8 Series	G16	Body	VIP Virtual integration system	●	●	●	●	●	○
8 Series	G16	Body	VM Video Module	●	●	●	●	●	○
8 Series	G16	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
8 Series	G16	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
8 Series	G16	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
8 Series	G16	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
8 Series	G16	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
8 Series	G16	Chassis	FRS Front radar sensor	●	●	●	●	●	○
8 Series	G16	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
8 Series	G16	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
8 Series	G16	Drive	CAS Car Access System	●	●	●	●	●	○
8 Series	G16	Drive	DDE Diesel Electronics	●	●	●	●	●	○
8 Series	G16	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
8 Series	G16	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
8 Series	G16	Drive	EGS transmission management	●	●	●	●	●	○
8 Series	G16	Drive	GWS Gear selector switch	●	●	●	●	●	○
8 Series	G16	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
8 Series	G16	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
8 Series	G16	Drive	VTG Transfer case	●	●	●	●	●	○
I Series	I15	Body	ACSM Crash Safety Module	●	●	●	●	●	○
I Series	I15	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
I Series	I15	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
I Series	I15	Body	ASD Active Sound Design	●	●	●	●	●	○
I Series	I15	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
I Series	I15	Body	CIC Car Information Computer	●	●	●	●	●	○
I Series	I15	Body	CON Controller	●	●	●	●	●	○
I Series	I15	Body	CVM Convertible top module	●	●	●	●	●	○
I Series	I15	Body	CVM Convertible top module 2	●	●	●	●	●	○
I Series	I15	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
I Series	I15	Body	FZD Function centre,roof	●	●	●	●	●	○
I Series	I15	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
I Series	I15	Body	INSTR Instrument cluster	●	●	●	●	●	○
I Series	I15	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
I Series	I15	Body	LHML LED main light module,left	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
I Series	I15	Body	LHMR LED main light module,right	●	●	●	●	●	○
I Series	I15	Body	LIM Chanrge Interface Module	●	●	●	●	●	○
I Series	I15	Body	PMA Parking assistant	●	●	●	●	●	○
I Series	I15	Body	RAD Radio	●	●	●	●	●	○
I Series	I15	Body	REME Range extender electrical machine electronics	●	●	●	●	●	○
I Series	I15	Body	SAS Optional equipment system	●	●	●	●	●	○
I Series	I15	Body	SMBF Seat module,passenger	●	●	●	●	●	○
I Series	I15	Body	SME Accumulator-management electronics	●	●	●	●	●	○
I Series	I15	Body	SMFA Seat module,driver	●	●	●	●	●	○
I Series	I15	Body	TBX Touchbox	●	●	●	●	●	○
I Series	I15	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
I Series	I15	Body	TR SVC allround-view camera	●	●	●	●	●	○
I Series	I15	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
I Series	I15	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
I Series	I15	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
I Series	I15	Chassis	EMF Parking brake	●	●	●	●	●	○
I Series	I15	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
I Series	I15	Drive	CAS Car Access System	●	●	●	●	●	○
I Series	I15	Drive	DDE Diesel Electronics	●	●	●	●	●	○
I Series	I15	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
I Series	I15	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
I Series	I15	Drive	EGS transmission management	●	●	●	●	●	○
I Series	I15	Drive	GWS Gear selector switch	●	●	●	●	●	○
MINI	MINI_F57	Body	ACSM Crash Safety Module	●	●	●	●	●	○
MINI	MINI_F57	Body	AHM Trailer module	●	●	●	●	●	○
MINI	MINI_F57	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
MINI	MINI_F57	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
MINI	MINI_F57	Body	ASD Active Sound Design	●	●	●	●	●	○
MINI	MINI_F57	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
MINI	MINI_F57	Body	CIC Car Information Computer	●	●	●	●	●	○
MINI	MINI_F57	Body	CON Controller	●	●	●	●	●	○
MINI	MINI_F57	Body	DSP Digital Sound Processor	●	●	●	●	●	○
MINI	MINI_F57	Body	DVDC DVD Changer	●	●	●	●	●	○
MINI	MINI_F57	Body	FZD Function centre,roof	●	●	●	●	●	○
MINI	MINI_F57	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
MINI	MINI_F57	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
MINI	MINI_F57	Body	INSTR Instrument cluster	●	●	●	●	●	○
MINI	MINI_F57	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
MINI	MINI_F57	Body	PMA Parking assistant	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
MINI	MINI_F57	Body	SMFA Seat module,driver	●	●	●	●	●	○
MINI	MINI_F57	Body	SZL Switch centre, steering column	●	●	●	●	●	○
MINI	MINI_F57	Body	TBX Touchbox	●	●	●	●	●	○
MINI	MINI_F57	Body	TR SVC allround-view camera	●	●	●	●	●	○
MINI	MINI_F57	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
MINI	MINI_F57	Chassis	AL active steering	●	●	●	●	●	○
MINI	MINI_F57	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
MINI	MINI_F57	Drive	CAS Car Access System	●	●	●	●	●	○
MINI	MINI_F57	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
MINI	MINI_F57	Drive	EGS transmission management	●	●	●	●	●	○
MINI	MINI_F60	Body	ACSM Crash Safety Module	●	●	●	●	●	○
MINI	MINI_F60	Body	AHM Trailer module	●	●	●	●	●	○
MINI	MINI_F60	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
MINI	MINI_F60	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
MINI	MINI_F60	Body	ASD Active Sound Design	●	●	●	●	●	○
MINI	MINI_F60	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
MINI	MINI_F60	Body	CIC Car Information Computer	●	●	●	●	●	○
MINI	MINI_F60	Body	CON Controller	●	●	●	●	●	○
MINI	MINI_F60	Body	DSP Digital Sound Processor	●	●	●	●	●	○
MINI	MINI_F60	Body	DVDC DVD Changer	●	●	●	●	●	○
MINI	MINI_F60	Body	FZD Function centre,roof	●	●	●	●	●	○
MINI	MINI_F60	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
MINI	MINI_F60	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
MINI	MINI_F60	Body	INSTR Instrument cluster	●	●	●	●	●	○
MINI	MINI_F60	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
MINI	MINI_F60	Body	PMA Parking assistant	●	●	●	●	●	○
MINI	MINI_F60	Body	SMFA Seat module,driver	●	●	●	●	●	○
MINI	MINI_F60	Body	SZL Switch centre, steering column	●	●	●	●	●	○
MINI	MINI_F60	Body	TBX Touchbox	●	●	●	●	●	○
MINI	MINI_F60	Body	TR SVC allround-view camera	●	●	●	●	●	○
MINI	MINI_F60	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
MINI	MINI_F60	Chassis	AL active steering	●	●	●	●	●	○
MINI	MINI_F60	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
MINI	MINI_F60	Drive	CAS Car Access System	●	●	●	●	●	○
MINI	MINI_F60	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
MINI	MINI_F60	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X1_F48	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X1_F48	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X1_F48	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
X Series	X1_F48	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X1_F48	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X1_F48	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X1_F48	Body	CIC Car Information Computer	●	●	●	●	●	○
X Series	X1_F48	Body	CON Controller	●	●	●	●	●	○
X Series	X1_F48	Body	DSP Digital Sound Processor	●	●	●	●	●	○
X Series	X1_F48	Body	DVDC DVD Changer	●	●	●	●	●	○
X Series	X1_F48	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X1_F48	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X1_F48	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X1_F48	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X1_F48	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X1_F48	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X1_F48	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X1_F48	Body	SZL Switch centre, steering column	●	●	●	●	●	○
X Series	X1_F48	Body	TBX Touchbox	●	●	●	●	●	○
X Series	X1_F48	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X1_F48	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X1_F48	Chassis	AL active steering	●	●	●	●	●	○
X Series	X1_F48	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X1_F48	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X1_F48	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X1_F48	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X1_F49	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X1_F49	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X1_F49	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
X Series	X1_F49	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X1_F49	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X1_F49	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
X Series	X1_F49	Body	CIC Car Information Computer	●	●	●	●	●	○
X Series	X1_F49	Body	CON Controller	●	●	●	●	●	○
X Series	X1_F49	Body	DSP Digital Sound Processor	●	●	●	●	●	○
X Series	X1_F49	Body	DVDC DVD Changer	●	●	●	●	●	○
X Series	X1_F49	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X1_F49	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X1_F49	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X1_F49	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X1_F49	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X1_F49	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X1_F49	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X1_F49	Body	SZL Switch centre, steering column	●	●	●	●	●	○
X Series	X1_F49	Body	TBX Touchbox	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X1_F49	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X1_F49	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X1_F49	Chassis	AL active steering	●	●	●	●	●	○
X Series	X1_F49	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X1_F49	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X1_F49	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X1_F49	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X2_F39	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X2_F39	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X2_F39	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	○
X Series	X2_F39	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X2_F39	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X2_F39	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	○
X Series	X2_F39	Body	CHRONO Chronometer	●	●	●	●	●	○
X Series	X2_F39	Body	CIC Car Information Computer	●	●	●	●	●	○
X Series	X2_F39	Body	CON Controller	●	●	●	●	●	○
X Series	X2_F39	Body	CSM Car Sharing Module	●	●	●	●	●	○
X Series	X2_F39	Body	CVM Convertible top module	●	●	●	●	●	○
X Series	X2_F39	Body	DSP Digital Sound Processor	●	●	●	●	●	○
X Series	X2_F39	Body	DVDC DVD Changer	●	●	●	●	●	○
X Series	X2_F39	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
X Series	X2_F39	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
X Series	X2_F39	Body	EME Electric machine electronics	●	●	●	●	●	○
X Series	X2_F39	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X2_F39	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X2_F39	Body	FRM Footwell module	●	●	●	●	●	○
X Series	X2_F39	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X2_F39	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X2_F39	Body	GZAL Targeted illumination,left	●	●	●	●	●	○
X Series	X2_F39	Body	GZAR Targeted illumination,right	●	●	●	●	●	○
X Series	X2_F39	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X2_F39	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X2_F39	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X2_F39	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X2_F39	Body	LHML LED main light module,left	●	●	●	●	●	○
X Series	X2_F39	Body	LHMR LED main light module,right	●	●	●	●	●	○
X Series	X2_F39	Body	LIM Charge Interface Module	●	●	●	●	●	○
X Series	X2_F39	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X2_F39	Body	PDC Park distance control	●	●	●	●	●	○
X Series	X2_F39	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X2_F39	Body	RDME Range Extender Motor Electronics	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X2_F39	Body	REME Range extender electrical machine electronics	●	●	●	●	●	○
X Series	X2_F39	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X2_F39	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X2_F39	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
X Series	X2_F39	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X2_F39	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X2_F39	Body	STML Headlight driver module,left	●	●	●	●	●	○
X Series	X2_F39	Body	STMR Headlight driver module,right	●	●	●	●	●	○
X Series	X2_F39	Body	SWW Lane change warning	●	●	●	●	●	○
X Series	X2_F39	Body	SZL Switch centre, steering column	●	●	●	●	●	○
X Series	X2_F39	Body	TBX Touchbox	●	●	●	●	●	○
X Series	X2_F39	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X2_F39	Body	VM Video Module	●	●	●	●	●	○
X Series	X2_F39	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X2_F39	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
X Series	X2_F39	Chassis	AL active steering	●	●	●	●	●	○
X Series	X2_F39	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X2_F39	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
X Series	X2_F39	Chassis	EMF Parking brake	●	●	●	●	●	○
X Series	X2_F39	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X2_F39	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○
X Series	X2_F39	Chassis	RDC Tyre pressure control	●	●	●	●	●	○
X Series	X2_F39	Chassis	SVT Servotronic	●	●	●	●	●	○
X Series	X2_F39	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	○
X Series	X2_F39	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	○
X Series	X2_F39	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X2_F39	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X2_F39	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X2_F39	Drive	EKPS Fuel-pump control	●	●	●	●	●	○
X Series	X2_F39	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X2_F39	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X3_F97	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X3_F97	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X3_F97	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X3_F97	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X3_F97	Body	CON Controller	●	●	●	●	●	○
X Series	X3_F97	Body	CPM Car Pad Module	●	●	●	●	●	○
X Series	X3_F97	Body	CSM Car Sharing Module	●	●	●	●	●	○
X Series	X3_F97	Body	CVM Convertible top module	●	●	●	●	●	○
X Series	X3_F97	Body	EMAR SV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X3_F97	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X3_F97	Body	ENS Ethernet switch	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X3_F97	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X3_F97	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X3_F97	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X3_F97	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X3_F97	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X3_F97	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X3_F97	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X3_F97	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X3_F97	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X3_F97	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X3_F97	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X3_F97	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X3_F97	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X3_F97	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X3_F97	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X3_F97	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X3_F97	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X3_F97	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X3_F97	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X3_F97	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X3_F97	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X3_F97	Body	SAS Optional equipment system	●	●	●	●	●	○
X Series	X3_F97	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X3_F97	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X3_F97	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
X Series	X3_F97	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
X Series	X3_F97	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X3_F97	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X Series	X3_F97	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X3_F97	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X3_F97	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X3_F97	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
X Series	X3_F97	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
X Series	X3_F97	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X3_F97	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X3_F97	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X3_F97	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X3_F97	Body	SWW Lane change warning	●	●	●	●	●	○
X Series	X3_F97	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X3_F97	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X3_F97	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X3_F97	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X3_F97	Body	VM Video Module	●	●	●	●	●	○
X Series	X3_F97	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
X Series	X3_F97	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X3_F97	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
X Series	X3_F97	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X3_F97	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X3_F97	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
X Series	X3_F97	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X3_F97	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X3_F97	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X3_F97	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X3_F97	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X3_F97	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X3_F97	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X3_F97	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X3_F98	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X3_F98	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X3_F98	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X3_F98	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X3_F98	Body	CON Controller	●	●	●	●	●	○
X Series	X3_F98	Body	CPM Car Pad Module	●	●	●	●	●	○
X Series	X3_F98	Body	CSM Car Sharing Module	●	●	●	●	●	○
X Series	X3_F98	Body	CVM Convertible top module	●	●	●	●	●	○
X Series	X3_F98	Body	EMAR SV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X3_F98	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X3_F98	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X3_F98	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X3_F98	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X3_F98	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X3_F98	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X3_F98	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X3_F98	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X3_F98	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X3_F98	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X3_F98	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X3_F98	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X3_F98	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X3_F98	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X3_F98	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X3_F98	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X3_F98	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X3_F98	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X3_F98	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X3_F98	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X3_F98	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X3_F98	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X3_F98	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X3_F98	Body	SAS Optional equipment system	●	●	●	●	●	○
X Series	X3_F98	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X3_F98	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X3_F98	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
X Series	X3_F98	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
X Series	X3_F98	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X3_F98	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X Series	X3_F98	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X3_F98	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X3_F98	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X3_F98	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
X Series	X3_F98	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
X Series	X3_F98	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X3_F98	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X3_F98	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X3_F98	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X3_F98	Body	SWW Lane change warning	●	●	●	●	●	○
X Series	X3_F98	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X3_F98	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X3_F98	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X3_F98	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X3_F98	Body	VM Video Module	●	●	●	●	●	○
X Series	X3_F98	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
X Series	X3_F98	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X3_F98	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
X Series	X3_F98	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X3_F98	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X3_F98	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
X Series	X3_F98	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X3_F98	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X3_F98	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X3_F98	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X3_F98	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X3_F98	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X3_F98	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X3_F98	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X3_G01	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X3_G01	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X3_G01	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X3_G01	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X3_G01	Body	CON Controller	●	●	●	●	●	○
X Series	X3_G01	Body	CPM Car Pad Module	●	●	●	●	●	○
X Series	X3_G01	Body	CSM Car Sharing Module	●	●	●	●	●	○
X Series	X3_G01	Body	CVM Convertible top module	●	●	●	●	●	○
X Series	X3_G01	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X3_G01	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X3_G01	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X3_G01	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X3_G01	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X3_G01	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X3_G01	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X3_G01	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X3_G01	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X3_G01	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X3_G01	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X3_G01	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X3_G01	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X3_G01	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X3_G01	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X3_G01	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X3_G01	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X3_G01	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X3_G01	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X3_G01	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X3_G01	Body	NVE Night Vision Electronics	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X3_G01	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X3_G01	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X3_G01	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X3_G01	Body	SAS Optional equipment system	●	●	●	●	●	○
X Series	X3_G01	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X3_G01	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X3_G01	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
X Series	X3_G01	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
X Series	X3_G01	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X3_G01	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X Series	X3_G01	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X3_G01	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X3_G01	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X3_G01	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
X Series	X3_G01	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
X Series	X3_G01	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X3_G01	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X3_G01	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X3_G01	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X3_G01	Body	SWW Lane change warning	●	●	●	●	●	○
X Series	X3_G01	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X3_G01	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X3_G01	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X3_G01	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X3_G01	Body	VM Video Module	●	●	●	●	●	○
X Series	X3_G01	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
X Series	X3_G01	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X3_G01	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
X Series	X3_G01	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X3_G01	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X3_G01	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
X Series	X3_G01	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X3_G01	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X3_G01	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X3_G01	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X3_G01	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X3_G01	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X3_G01	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X3_G01	Drive	VTG Transfer case	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X3_G08	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X3_G08	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X3_G08	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X3_G08	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X3_G08	Body	CON Controller	●	●	●	●	●	○
X Series	X3_G08	Body	CPM Car Pad Module	●	●	●	●	●	○
X Series	X3_G08	Body	CSM Car Sharing Module	●	●	●	●	●	○
X Series	X3_G08	Body	CVM Convertible top module	●	●	●	●	●	○
X Series	X3_G08	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X3_G08	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X3_G08	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X3_G08	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X3_G08	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X3_G08	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X3_G08	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X3_G08	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X3_G08	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X3_G08	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X3_G08	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X3_G08	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X3_G08	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X3_G08	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X3_G08	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X3_G08	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X3_G08	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X3_G08	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X3_G08	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X3_G08	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X3_G08	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X3_G08	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X3_G08	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X3_G08	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X3_G08	Body	SAS Optional equipment system	●	●	●	●	●	○
X Series	X3_G08	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X3_G08	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X3_G08	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
X Series	X3_G08	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
X Series	X3_G08	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X3_G08	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X3_G08	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X3_G08	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X3_G08	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X3_G08	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
X Series	X3_G08	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
X Series	X3_G08	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X3_G08	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X3_G08	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X3_G08	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X3_G08	Body	SWW Lane change warning	●	●	●	●	●	○
X Series	X3_G08	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X3_G08	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X3_G08	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X3_G08	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X3_G08	Body	VM Video Module	●	●	●	●	●	○
X Series	X3_G08	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
X Series	X3_G08	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X3_G08	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
X Series	X3_G08	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X3_G08	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X3_G08	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
X Series	X3_G08	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X3_G08	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X3_G08	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X3_G08	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X3_G08	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X3_G08	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X3_G08	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X3_G08	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X4_G02	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X4_G02	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X4_G02	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X4_G02	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X4_G02	Body	CON Controller	●	●	●	●	●	○
X Series	X4_G02	Body	CPM Car Pad Module	●	●	●	●	●	○
X Series	X4_G02	Body	CSM Car Sharing Module	●	●	●	●	●	○
X Series	X4_G02	Body	CVM Convertible top module	●	●	●	●	●	○
X Series	X4_G02	Body	EMAR SV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X4_G02	Body	EME2 Electrical machine electronics	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X4_G02	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X4_G02	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X4_G02	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X4_G02	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X4_G02	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X4_G02	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X4_G02	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X4_G02	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X4_G02	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X4_G02	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X4_G02	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X4_G02	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X4_G02	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X4_G02	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X4_G02	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X4_G02	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X4_G02	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X4_G02	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X4_G02	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X4_G02	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X4_G02	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X4_G02	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X4_G02	Body	SAS Optional equipment system	●	●	●	●	●	○
X Series	X4_G02	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X4_G02	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X4_G02	Body	SECU1 Supplementary control unit	●	●	●	●	●	○
X Series	X4_G02	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
X Series	X4_G02	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X4_G02	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X Series	X4_G02	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X4_G02	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X4_G02	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X4_G02	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○
X Series	X4_G02	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
X Series	X4_G02	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X4_G02	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X4_G02	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X4_G02	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X4_G02	Body	SWW Lane change warning	●	●	●	●	●	○
X Series	X4_G02	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X4_G02	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X4_G02	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X4_G02	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X4_G02	Body	VM Video Module	●	●	●	●	●	○
X Series	X4_G02	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
X Series	X4_G02	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X4_G02	Chassis	ACC Active Cruise Control	●	●	●	●	●	○
X Series	X4_G02	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X4_G02	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X4_G02	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
X Series	X4_G02	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X4_G02	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X4_G02	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X4_G02	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X4_G02	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X4_G02	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X4_G02	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X4_G02	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X5_F95	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X5_F95	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X5_F95	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X5_F95	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X5_F95	Body	CON Controller	●	●	●	●	●	○
X Series	X5_F95	Body	DCS Driver Camera System	●	●	●	●	●	○
X Series	X5_F95	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
X Series	X5_F95	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
X Series	X5_F95	Body	EMAR SV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X5_F95	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X5_F95	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X5_F95	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X5_F95	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X5_F95	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X5_F95	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X5_F95	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X5_F95	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X5_F95	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X5_F95	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X5_F95	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X5_F95	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X5_F95	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X5_F95	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X5_F95	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X5_F95	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X5_F95	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X5_F95	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X5_F95	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X5_F95	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X5_F95	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X5_F95	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X5_F95	Body	RAM Receiver audio module	●	●	●	●	●	○
X Series	X5_F95	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
X Series	X5_F95	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
X Series	X5_F95	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
X Series	X5_F95	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
X Series	X5_F95	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X5_F95	Body	SAS Optional equipment system 2	●	●	●	●	●	○
X Series	X5_F95	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X5_F95	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X5_F95	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X5_F95	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X Series	X5_F95	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X5_F95	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X5_F95	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X5_F95	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X5_F95	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X5_F95	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X5_F95	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X5_F95	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X5_F95	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X5_F95	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X5_F95	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X5_F95	Body	VIP Virtual integration system	●	●	●	●	●	○
X Series	X5_F95	Body	VM Video Module	●	●	●	●	●	○
X Series	X5_F95	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X5_F95	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X5_F95	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X5_F95	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
X Series	X5_F95	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X5_F95	Chassis	FRS Front radar sensor	●	●	●	●	●	○
X Series	X5_F95	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
X Series	X5_F95	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
X Series	X5_F95	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X5_F95	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X5_F95	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X5_F95	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X5_F95	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X5_F95	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X5_F95	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
X Series	X5_F95	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
X Series	X5_F95	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X5_G05	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X5_G05	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X5_G05	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X5_G05	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X5_G05	Body	CON Controller	●	●	●	●	●	○
X Series	X5_G05	Body	DCS Driver Camera System	●	●	●	●	●	○
X Series	X5_G05	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
X Series	X5_G05	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
X Series	X5_G05	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X5_G05	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X5_G05	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X5_G05	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X5_G05	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X5_G05	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X5_G05	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X5_G05	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X5_G05	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X5_G05	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X5_G05	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X5_G05	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X5_G05	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X5_G05	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X5_G05	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X5_G05	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X5_G05	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X5_G05	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X5_G05	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X5_G05	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X5_G05	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X5_G05	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X5_G05	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X5_G05	Body	RAM Receiver audio module	●	●	●	●	●	○
X Series	X5_G05	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
X Series	X5_G05	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
X Series	X5_G05	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
X Series	X5_G05	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
X Series	X5_G05	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X5_G05	Body	SAS Optional equipment system 2	●	●	●	●	●	○
X Series	X5_G05	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X5_G05	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X5_G05	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X5_G05	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X Series	X5_G05	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X5_G05	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X5_G05	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X5_G05	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X5_G05	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X5_G05	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X5_G05	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X5_G05	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X5_G05	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X5_G05	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X5_G05	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X5_G05	Body	VIP Virtual integration system	●	●	●	●	●	○
X Series	X5_G05	Body	VM Video Module	●	●	●	●	●	○
X Series	X5_G05	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X5_G05	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X5_G05	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X5_G05	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
X Series	X5_G05	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X5_G05	Chassis	FRS Front radar sensor	●	●	●	●	●	○
X Series	X5_G05	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X5_G05	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
X Series	X5_G05	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X5_G05	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X5_G05	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X5_G05	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X5_G05	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X5_G05	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X5_G05	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
X Series	X5_G05	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
X Series	X5_G05	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X6_F96	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X6_F96	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X6_F96	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X6_F96	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X6_F96	Body	CON Controller	●	●	●	●	●	○
X Series	X6_F96	Body	DCS Driver Camera System	●	●	●	●	●	○
X Series	X6_F96	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
X Series	X6_F96	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
X Series	X6_F96	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X6_F96	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X6_F96	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X6_F96	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X6_F96	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X6_F96	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X6_F96	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X6_F96	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X6_F96	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X6_F96	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X6_F96	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X6_F96	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X6_F96	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X6_F96	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X6_F96	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X6_F96	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X6_F96	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X6_F96	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X6_F96	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X6_F96	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X6_F96	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X6_F96	Body	PCU Power Control Unit	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X6_F96	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X6_F96	Body	RAM Receiver audio module	●	●	●	●	●	○
X Series	X6_F96	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
X Series	X6_F96	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
X Series	X6_F96	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
X Series	X6_F96	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
X Series	X6_F96	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X6_F96	Body	SAS Optional equipment system 2	●	●	●	●	●	○
X Series	X6_F96	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X6_F96	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X6_F96	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X6_F96	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X Series	X6_F96	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X6_F96	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X6_F96	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X6_F96	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X6_F96	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X6_F96	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X6_F96	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X6_F96	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X6_F96	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X6_F96	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X6_F96	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X6_F96	Body	VIP Virtual integration system	●	●	●	●	●	○
X Series	X6_F96	Body	VM Video Module	●	●	●	●	●	○
X Series	X6_F96	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X6_F96	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X6_F96	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X6_F96	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
X Series	X6_F96	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X6_F96	Chassis	FRS Front radar sensor	●	●	●	●	●	○
X Series	X6_F96	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
X Series	X6_F96	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
X Series	X6_F96	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X6_F96	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X6_F96	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X6_F96	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X6_F96	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X6_F96	Drive	GWS Gear selector switch	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X6_F96	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
X Series	X6_F96	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
X Series	X6_F96	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X6_G06	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X6_G06	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X6_G06	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X6_G06	Body	ASD Active Sound Design	●	●	●	●	●	○
X Series	X6_G06	Body	CON Controller	●	●	●	●	●	○
X Series	X6_G06	Body	DCS Driver Camera System	●	●	●	●	●	○
X Series	X6_G06	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
X Series	X6_G06	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
X Series	X6_G06	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X6_G06	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X6_G06	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X6_G06	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X6_G06	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X6_G06	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X6_G06	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X6_G06	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X6_G06	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X6_G06	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X6_G06	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X6_G06	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X6_G06	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X6_G06	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X6_G06	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X6_G06	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X6_G06	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X6_G06	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X6_G06	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X6_G06	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X6_G06	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X6_G06	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X6_G06	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X6_G06	Body	RAM Receiver audio module	●	●	●	●	●	○
X Series	X6_G06	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
X Series	X6_G06	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
X Series	X6_G06	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
X Series	X6_G06	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
X Series	X6_G06	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X6_G06	Body	SAS Optional equipment system 2	●	●	●	●	●	○
X Series	X6_G06	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X6_G06	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X6_G06	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X6_G06	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
X Series	X6_G06	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X6_G06	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X6_G06	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X6_G06	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X6_G06	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X6_G06	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X6_G06	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X6_G06	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X6_G06	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X6_G06	Body	TRSVc allround-view camera	●	●	●	●	●	○
X Series	X6_G06	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X6_G06	Body	VIP Virtual integration system	●	●	●	●	●	○
X Series	X6_G06	Body	VM Video Module	●	●	●	●	●	○
X Series	X6_G06	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X6_G06	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X6_G06	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X6_G06	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
X Series	X6_G06	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X6_G06	Chassis	FRS Front radar sensor	●	●	●	●	●	○
X Series	X6_G06	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
X Series	X6_G06	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
X Series	X6_G06	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X6_G06	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X6_G06	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X6_G06	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X6_G06	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X6_G06	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X6_G06	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
X Series	X6_G06	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
X Series	X6_G06	Drive	VTG Transfer case	●	●	●	●	●	○
X Series	X7_G07	Body	ACSM Crash Safety Module	●	●	●	●	●	○
X Series	X7_G07	Body	AHM Trailer module	●	●	●	●	●	○
X Series	X7_G07	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	○
X Series	X7_G07	Body	ASD Active Sound Design	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X7_G07	Body	CON Controller	●	●	●	●	●	○
X Series	X7_G07	Body	DCS Driver Camera System	●	●	●	●	●	○
X Series	X7_G07	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
X Series	X7_G07	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○
X Series	X7_G07	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
X Series	X7_G07	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
X Series	X7_G07	Body	ENS Ethernet switch	●	●	●	●	●	○
X Series	X7_G07	Body	FLA High Beam Assist	●	●	●	●	●	○
X Series	X7_G07	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
X Series	X7_G07	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
X Series	X7_G07	Body	FZD Function centre,roof	●	●	●	●	●	○
X Series	X7_G07	Body	GHAS Regulated differential lock	●	●	●	●	●	○
X Series	X7_G07	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
X Series	X7_G07	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
X Series	X7_G07	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
X Series	X7_G07	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
X Series	X7_G07	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
X Series	X7_G07	Body	HU-B Headunit Basis	●	●	●	●	●	○
X Series	X7_G07	Body	HU-H Headunit High	●	●	●	●	●	○
X Series	X7_G07	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
X Series	X7_G07	Body	INSTR Instrument cluster	●	●	●	●	●	○
X Series	X7_G07	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
X Series	X7_G07	Body	KLE Convenience charging electronics	●	●	●	●	●	○
X Series	X7_G07	Body	LEM Light effect manager	●	●	●	●	●	○
X Series	X7_G07	Body	NVE Night Vision Electronics	●	●	●	●	●	○
X Series	X7_G07	Body	PCU Power Control Unit	●	●	●	●	●	○
X Series	X7_G07	Body	PMA Parking assistant	●	●	●	●	●	○
X Series	X7_G07	Body	RAM Receiver audio module	●	●	●	●	●	○
X Series	X7_G07	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
X Series	X7_G07	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
X Series	X7_G07	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
X Series	X7_G07	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
X Series	X7_G07	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
X Series	X7_G07	Body	SAS Optional equipment system 2	●	●	●	●	●	○
X Series	X7_G07	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
X Series	X7_G07	Body	SEC Supplementary control unit	●	●	●	●	●	○
X Series	X7_G07	Body	SMBF Seat module,passenger	●	●	●	●	●	○
X Series	X7_G07	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
X Series	X7_G07	Body	SME Accumulator-management electronics	●	●	●	●	●	○
X Series	X7_G07	Body	SMFA Seat module,driver	●	●	●	●	●	○
X Series	X7_G07	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
X Series	X7_G07	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
X Series	X7_G07	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
X Series	X7_G07	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
X Series	X7_G07	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
X Series	X7_G07	Body	TCB Telematic Communication Box	●	●	●	●	●	○
X Series	X7_G07	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
X Series	X7_G07	Body	TR SVC allround-view camera	●	●	●	●	●	○
X Series	X7_G07	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
X Series	X7_G07	Body	VIP Virtual integration system	●	●	●	●	●	○
X Series	X7_G07	Body	VM Video Module	●	●	●	●	●	○
X Series	X7_G07	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
X Series	X7_G07	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
X Series	X7_G07	Chassis	EARSH Rear electric ARS	●	●	●	●	●	○
X Series	X7_G07	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
X Series	X7_G07	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
X Series	X7_G07	Chassis	FRS Front radar sensor	●	●	●	●	●	○
X Series	X7_G07	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
X Series	X7_G07	Drive	BATT48 Battery electronics 48 volts	●	●	●	●	●	○
X Series	X7_G07	Drive	CAS Car Access System	●	●	●	●	●	○
X Series	X7_G07	Drive	DDE Diesel Electronics	●	●	●	●	●	○
X Series	X7_G07	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
X Series	X7_G07	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
X Series	X7_G07	Drive	EGS transmission management	●	●	●	●	●	○
X Series	X7_G07	Drive	GWS Gear selector switch	●	●	●	●	●	○
X Series	X7_G07	Drive	PCU48 Power Control Unit 48 volts	●	●	●	●	●	○
X Series	X7_G07	Drive	SGR48 Starter motor generator 48 volts	●	●	●	●	●	○
X Series	X7_G07	Drive	VTG Transfer case	●	●	●	●	●	○
Z Series	Z4_G29	Body	ACSM Crash Safety Module	●	●	●	●	●	○
Z Series	Z4_G29	Body	AHM Trailer module	●	●	●	●	●	○
Z Series	Z4_G29	Body	ASD Active Sound Design	●	●	●	●	●	○
Z Series	Z4_G29	Body	CON Controller	●	●	●	●	●	○
Z Series	Z4_G29	Body	CPM Car Pad Module	●	●	●	●	●	○
Z Series	Z4_G29	Body	CSM Car Sharing Module	●	●	●	●	●	○
Z Series	Z4_G29	Body	CVM Convertible top module	●	●	●	●	●	○
Z Series	Z4_G29	Body	DCS Driver Camera System	●	●	●	●	●	○
Z Series	Z4_G29	Body	EMALI Electric-motor reel, left	●	●	●	●	●	○
Z Series	Z4_G29	Body	EMARE Electric-motor reel, right	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
Z Series	Z4_G29	Body	EMARSV Front electric active roll stabilisation	●	●	●	●	●	○
Z Series	Z4_G29	Body	EME2 Electrical machine electronics	●	●	●	●	●	○
Z Series	Z4_G29	Body	ENS Ethernet switch	●	●	●	●	●	○
Z Series	Z4_G29	Body	FLA High Beam Assist	●	●	●	●	●	○
Z Series	Z4_G29	Body	FLEL Frontal Light Electronics left	●	●	●	●	●	○
Z Series	Z4_G29	Body	FLER Frontal Light Electronics right	●	●	●	●	●	○
Z Series	Z4_G29	Body	FZD Function centre,roof	●	●	●	●	●	○
Z Series	Z4_G29	Body	GHAS Regulated differential lock	●	●	●	●	●	○
Z Series	Z4_G29	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	○
Z Series	Z4_G29	Body	HKL Automatic luggage compartment lid actuation	●	●	●	●	●	○
Z Series	Z4_G29	Body	HRSNL Rear radar sensor near range	●	●	●	●	●	○
Z Series	Z4_G29	Body	HRSNR Rear radar sensor near range right	●	●	●	●	●	○
Z Series	Z4_G29	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	○
Z Series	Z4_G29	Body	HU-B Headunit Basis	●	●	●	●	●	○
Z Series	Z4_G29	Body	HU-H Headunit High	●	●	●	●	●	○
Z Series	Z4_G29	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	○
Z Series	Z4_G29	Body	INSTR Instrument cluster	●	●	●	●	●	○
Z Series	Z4_G29	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	○
Z Series	Z4_G29	Body	KLE Convenience charging electronics	●	●	●	●	●	○
Z Series	Z4_G29	Body	LEM Light effect manager	●	●	●	●	●	○
Z Series	Z4_G29	Body	NVE Night Vision Electronics	●	●	●	●	●	○
Z Series	Z4_G29	Body	PCU Power Control Unit	●	●	●	●	●	○
Z Series	Z4_G29	Body	PMA Parking assistant	●	●	●	●	●	○
Z Series	Z4_G29	Body	RAM Receiver audio module	●	●	●	●	●	○
Z Series	Z4_G29	Body	RLMAL Left outer rear light module	●	●	●	●	●	○
Z Series	Z4_G29	Body	RLMAR Right outer rear light module	●	●	●	●	●	○
Z Series	Z4_G29	Body	RLMIL Left inner rear light module	●	●	●	●	●	○
Z Series	Z4_G29	Body	RLMIR Right inner rear light module	●	●	●	●	●	○
Z Series	Z4_G29	Body	RSE Rear Seat Entertainment	●	●	●	●	●	○
Z Series	Z4_G29	Body	SAS Optional equipment system 2	●	●	●	●	●	○
Z Series	Z4_G29	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	○
Z Series	Z4_G29	Body	SINE Siren and tilt sensor	●	●	●	●	●	○
Z Series	Z4_G29	Body	SMBF Seat module,passenger	●	●	●	●	●	○
Z Series	Z4_G29	Body	SMBFH Seat module,passenger's side,rear	●	●	●	●	●	○
Z Series	Z4_G29	Body	SME Accumulator-management electronics	●	●	●	●	●	○
Z Series	Z4_G29	Body	SMFA Seat module,driver	●	●	●	●	●	○
Z Series	Z4_G29	Body	SMFAH Seat module,driver's side,rear	●	●	●	●	●	○
Z Series	Z4_G29	Body	SPNMHL Rear left seat inflator module	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

series	Model Series	Part	Systems	Ecu info	Read DTC	Erase DTC	Live Data	Component activation	physical HW
Z Series	Z4_G29	Body	SPNMHR Rear right seat inflator module	●	●	●	●	●	○
Z Series	Z4_G29	Body	SPNMVL Front left seat inflator module	●	●	●	●	●	○
Z Series	Z4_G29	Body	SPNMVR Front right seat inflator module	●	●	●	●	●	○
Z Series	Z4_G29	Body	SRSNVL Side radar sensor near range front left	●	●	●	●	●	○
Z Series	Z4_G29	Body	SRSNVR Side radar sensor near range front right	●	●	●	●	●	○
Z Series	Z4_G29	Body	TCB Telematic Communication Box	●	●	●	●	●	○
Z Series	Z4_G29	Body	TFE Hybrid pressure refuelling electronic control unit	●	●	●	●	●	○
Z Series	Z4_G29	Body	TR SVC allround-view camera	●	●	●	●	●	○
Z Series	Z4_G29	Body	VDP Vertical dynamics platform	●	●	●	●	●	○
Z Series	Z4_G29	Body	VIP Virtual integration system	●	●	●	●	●	○
Z Series	Z4_G29	Body	VM Video Module	●	●	●	●	●	○
Z Series	Z4_G29	Body	VSG Vehicle Sound Generator	●	●	●	●	●	○
Z Series	Z4_G29	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○
Z Series	Z4_G29	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	○
Z Series	Z4_G29	Chassis	EARS Rear electric ARS	●	●	●	●	●	○
Z Series	Z4_G29	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	○
Z Series	Z4_G29	Chassis	ELV Electrical steering column adjustment	●	●	●	●	●	○
Z Series	Z4_G29	Chassis	EPS Electronic Power Steering	●	●	●	●	●	○
Z Series	Z4_G29	Chassis	FRS Front radar sensor	●	●	●	●	●	○
Z Series	Z4_G29	Chassis	FRSF Long-distance range front radar sensor	●	●	●	●	●	○
Z Series	Z4_G29	Drive	CAS Car Access System	●	●	●	●	●	○
Z Series	Z4_G29	Drive	DDE Diesel Electronics	●	●	●	●	●	○
Z Series	Z4_G29	Drive	DME Digital Motor Electronics	●	●	●	●	●	○
Z Series	Z4_G29	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	○
Z Series	Z4_G29	Drive	EGS transmission management	●	●	●	●	●	○
Z Series	Z4_G29	Drive	GWS Gear selector switch	●	●	●	●	●	○
Z Series	Z4_G29	Drive	VTG Transfer case	●	●	●	●	●	○

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Chassis	ABS/DSC final check	●	7_E38
Body	Access, tank and extraction line		
Body	Activate Bluetooth and emergency		
Body	Activate Bluetooth and emergency call		
Drive	Activation, DMTL pump		
Drive	Activation, pre-supply pump	●	X5_E53
Drive	Activation, EDK actuator, full-load stop	●	3_E36
Drive	Adapt transmission fully		
Drive	Activate refuel detection	●	X_E70
Drive	Adapt transmission Fully	●	3_E46
Drive	Adaptations, low-pressure exhaust-gas recirculation	●	X_E70
Drive	Adjust the idle speed	●	X_E71
Body	Advanced diagnostics	●	X_E53
Body	Adaptation, reversing camera, to MASK/CHAMP		
Body	Add production date		
Drive	Add production date		
Body	Add tuner profiles	○	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			X5_E70
Chassis	Adjust ACC sensor	○	X6_E71
			1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			6_E63/E64
			7_E65
Drive	Adjust injector	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93 5_F10/F11
			5_F18
			X6_E71 Z4_E89
Chassis	Adjust long-range sensor	○	6_E63/E64
Chassis	Adjustment steering-angle sensor	●	Z4_E85/E86 X6_E71 3_F30
Drive	Adjustment, consumption indicator	●	5_E39
Drive	Adjustment, idle speed	※	3_E46
			5_E39
			7_E38
			X5_E53
Chassis	Adjustment	●	7_E38
Chassis	Adjustment, shock absorber	●	7_E65
Chassis	Adjustment, steering-angle sensor	※	3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X3_E83
			X5_E53
			X5_E70
Chassis	Adjustment,DSC unit(4-cyl.)	●	X6_E71
			Z4_E85/E86
Chassis	Adjustment,steering-angle sensor	●	1_E81/E82/E87/E88
Drive	After working on hydraulic system		3_E46
Drive	Air-mass flow sensor	※	1_E81/E82/E87/E88 3_E46
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X3_E83
			X5_E53
			X5_E70
Body	ALBBF initialization		X6_E71
			Z4_E85/E86 5_F10 7_F01/F02/F04
Chassis	All sensors		3_E46
Body	Analysis of prompters	●	X5_E53
Chassis	Assembly mode	●	7_E65
Body	Assembly position	●	7_E65
Drive	Assembly test, electric throttle valve	●	1_E81/E82/E87/E88
Drive	Additive rate adjustment	●	5_E39
E81/E82/E87/E88			
Drive	Automatic engine START-STOP	●	3_E90/E91/E92/E93 5_E61/E60
7_F01			
Body	A/C compressor inlet protection	●	1_F20 3_F35
CHASSIS	Activate compressor	●	7_F01/F02/F04

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Drive	Activation/deactivation terminal 15	▲	5_F07 5_F18 7_F01/F02/F04 X3_F25 X5_F15
Body	Adaptation, undervoltage limit	▲	5_F18 7_F01/F02/F04
Drive	Adjust injection system	●	7_F01/F02/F04
CHASSIS	Adjustment, ICM sensor system	●	3_F30 5_F10 5_F18
CHASSIS	ARS: Study the adjustment value	●	7_F01/F02/F04
Body	Audio	●	3_F30
Drive	Activation DMTL pump	●	3_E46 5_E39
Drive	Automatic air flap control	●	3_E90/E91/E92/E93
Body	All-round vision camera	▲	X5_F15
CHASSIS	Auxiliary battery (20 volts EPS): Register battery replacement	▲	6_F13
Body	Active SDARS	▲	X5_F15
Drive	Balance test	●	3_E46 3_E90/E91/E92/E93
Drive	Battery registration	●	1_E81/E82/E87/E88
Drive	Before working on hydraulic system		
Drive	Bleed hydraulic system		
Chassis	Bleed routine	●	1_E81/E82/E87/E88
			6_E63/E64
			X5_E53
			X5_E70
Chassis	Bleeding procedure for special cases	●	5_E60/E61
			6_E63/E64
Chassis	Bleeding procedure, left-hand drive		
Chassis	Bleeding procedure, right-hand drive		
Chassis	Bleeding, precharging pump circuit	●	7_E38
Chassis	Bleeding, DSC hydraulics	●	3_E46
			3_E90/E91/E92/E93
			5_E39
			7_E38
			7_E65
			X5_E53
Drive	Bleeding, fuel system	●	1_E81/E82/E87/E88 3_E46
			3_E90/E91/E92/E93
			5_E60/E61
			7_E65 X_E53 X_E70 XE83
Chassis	Bleeding/Ventilation	●	3_E46
Drive	Bleed vanos	●	5_E60/E61
Drive	Boost pressure controller test	●	X5_E53
Body	Boil-off test		
Drive	Basic injection rate at start	●	X_E83
Body	Bistable relays	●	3_E90/E91/E92/E93
Chassis	Brake bleeding procedure	●	X1_E84 3_F30 5_F10 5_F18
Drive	Calculate accumulator prepressurizing pressure	●	3_E46
Chassis	Calibration of DSC sensor	※	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			X5_E70
Chassis	Calibration of DSC unit	●	1_E81/E82/E87/E88
Body	Calibration, filler recording		7_E65
Body	Calibration, Lane Departure Warning		
Body	Calibration, reversing camera		
Drive	CAS reset	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			X5_E70
			X6_E71
Drive	CAS, DME/DDE alignment	●	7_F01/F02/F04
			5_F10/F11
Chassis	CBS correction, Tester data	●	5_E60/E61 7_E65
			1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X5_E70
			X6_E71
			7_F01/F02/F04
Chassis	CBS correction, vehicle data	●	5_F10/F11
			1_E81/E82/E87/E88

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
	CBS functionality,engine oil,disturbed	●	3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
Body	Change emergency number		
Body	Change telephone data		
Drive	Check static setting of injection pump		
Chassis	Check wheel control joints		
Chassis	Check, air supply system	※	X5_E53
			X5_E70
			X6_E71
Body	Check, blocking diodes		7_E65
Chassis	Check, compressor relay	※	7_E65
			X5_E53
			X5_E70
Chassis	Check, lifting and lowering	●	X5_E70
			X6_E71
Chassis	Check, raise/lower function	●	7_E65
			5_E39
			7_E65
Chassis	Check, ride-level sensors	※	X5_E53
			X5_E70
			X6_E71
Chassis	Check, solenoid valve	●	X5_E53
Chassis	Check, supply, pressure accumulator	●	X5_E53
Chassis	Check, valve, pressure accumulator	●	X5_E53
Chassis	CIM control unit	●	7_E65
Drive	Clear adaptation	●	1_E81/E82/E87/E88 3_E36 3_E46
			3_E90/E91/E92/E93 5_E39
			5_E60/E61
			7_E65
			X_E53
Drive	Clear mixture adaptation	●	3_E46
			3_E90/E91/E92/E93 5_E39
Body	Closed-circuit current test, CE electrical system		7_E65
Drive	Clutch adaptation	●	3_E90/E91/E92/E93
Drive	CO adjustment	●	1_E81/E82/E87/E88 3_E30 3_E36
			3_E46
			3_E90/E91/E92/E93
			5_E39
			5_E60/E61
			7_E38
			7_E65
Body	Coding data	●	7_E65
			Z4_E85/E86
Drive	Compression test	●	3_E90/E91/E92/E93 5_E60 X_E53
Drive	Compression test (maximum valve lift)		
Drive	Compression test (maximum valve)		
Drive	Compression-pressure check		
Body	Compressor/initial startup		
			3_E36[>9803]
Chassis	Connection, brake lines	●	3_E46
			Z3_E36
Chassis	Connection, speed sensor	※	3_E36[>9803]
			3_E46
			Z3_E36
			1_E81/E82/E87/E88
Drive	Consumption calculation	▲	3_E90/E91/E92/E93 X5_E53
			5_F10/F11 5_F18 7_F01/F02/F04
Drive	Consumption indicator	●	3_E90/E91/E92/E93
			3_E46
			5_E39
Chassis	Control-unit replacement	●	7_E38
			X5_E53
			Z8_E52
Body	Coolant compressor/initial start-up	※	5_E60/E61
			6_E63/E64
Body	Correct picture geometry		
Body	Correct picture position		
Body	Correct tuner		
Body	Correct volume		
			1_E81/E82/E87/E88

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Body	Create boot file again	○	3_E90/E91/E92/E935_E60/E61
			6_E63/E64
			X5_E70
			X6_E71
Drive	Charge air pressure controller	●	1_E81/E82/E87/E88 3_E46
			3_E90/E91/E92/E93 5_E60/E61
Drive	Check of interchanged oxygen sensors	●	7_E65
Drive	Check of variable intake manifold	●	7_E65
Drive	Check of wastegate valve	●	3_E90/E91/E92/E93
Drive	Check setting of injection pump	●	5_E39
Drive	Clear adaptations	●	7_E38 1_F20 3_F30 5_F10/F11
			5_F18 7_F01/F02/F04 Z4_E89
Body	Cluster Test	●	7_E65
Body	CTM: Rear module emergency access	●	E_E89
Body	Calibration run for flap motors	●	1_F20 3_F35
Chassis	Capacitor box: Register change	●	5_F18
Drive	Cooling system ventilation	●	1_F20 3_F35
Body	Change personalisation data of remote key	▲	X5_F15
	Charging the battery via diagnostic socket	▲	X1_E84
Drive	Data adjustment,mechatronics	●	3_E90/E91/E92/E93
Drive	DDE-CAS	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93 5_E60/E61
			7_E65
			X5_E70 5_F10 7_F01/F02/F04
Drive	DDE-EWSIII	●	3_E46 5_E60/E61
Body	Deactivate transport-lock function		
Drive	Defines engage Neutral	●	5_E60/E61
			5_E60/E61
Drive	Delete adaptations/variants	●	6_E63/E64
			7_E65
			7_E65
Chassis	Delete energy saving mode	●	X5_E70
			X6_E71
Chassis	Delete line mode	●	5_E39
			X5_E53
Body	Delete persistant data		7_E65
Body	Delete transport mode	●	1_E81/E82/E87/E88
			3_E46
			3_E90/E91/E92/E93
			5_E39
			5_E60/E61
			6_E63/E64
			7_E65
			X3_E83
			X5_E53
			X5_E70
			X6_E71
			Z4_E85/E86
			Z8_E52
5_F18			
Body	Delivery position	●	5_E60/E61
			7_E65
Drive	Diagnostic function		3_E90/E91/E92/E93 3_E46
			Z4_E85/E86
Drive	Diagnostic module for tank leakage(DMTL)		1_E81/E82/E87/E88 5_E60/E61
Body	Disable/enable	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X5_E70
Body	Disable/enable key	●	X6_E71
			3_E36[>9803]
			3_E46
			5_E39
			7_E38
			X3_E83
			X5_E53
			Z3_E36
			Z4_E85/E86
			Z8_E52
			3_E36[>9803]
			3_E46
			5_E39

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Drive	Disable/enable key	●	7_E38
			X3_E83
			X5_E53
			Z3_E36
			Z4_E85/E86
			Z8_E52
Drive	Disengage gear		3_E46
Drive	Display, OBD readiness codes		
MAINTENANCE	Delete the transport mode	▲	X1_E84
Drive	DME (DDE)-EWS-III adjustment		
			1_E81/E82/E87/E88
Drive	DME-CAS	●	3_E90/E91/E92/E93
			7_E65
Drive	DME-EWS-III		
Body	Drain/fill refrigerant circuit		
Body	DVD lock		
Chassis	DSC sensors check	●	5_E60/E61 6_E63/E64
Drive	Detection, reset air conditioning and VANOS admission-pressure pump	●	3_E30
Drive	DMTL (US only)	●	3_E36
Drive	Drivers door module	●	5_E60/E61
Drive	DDE-EWS adjustment	●	X_E83
Body	Deactivate transport lock function	●	3_E46
Drive	Delete adaptation variable camshaft timing control	●	3_E90/E91/E92/E93 Z4_E89
Drive	Diengage gear	●	3_E46
Drive	Diesel particulate filter: request regeneration	●	X_E70
Drive	Diesel particulate filter: Replacement	●	X_E70
Drive	DME: Clear adaptations	●	1_E81/E82/E87/E88 X_E70
Drive	DME: Delete adaptation variable camshaft timing control	▲	1_E81/E82/E87/E88 5_F10 X_E70
Drive	DME: Reset adaptation values and versions	●	X_E71
Body	Deleting Personal Profile	●	3_F35
Drive	Display and reset adaptation values	▲	3_E90/E91/E92/E93 5_E60/E61
			5_F10/F11 7_F01/F02/F04 X5_E70
Body	Driver's seat standardisation	●	1_F20 3_F35 5_F10/F11 5_F18
			7_F01/F02/F04 X3_F25
Body	Driver's side normalisation	●	5_F10/F11 5_F18 7_F01/F02/F04
Chassis	DSC control unit adjustment	●	3_F30
Chassis	DSC: Brake bleeding procedure	▲	5_F18 7_F01/F02/F04
Chassis	DSC: Brake line mix-up test	●	X1_E84 5_F18 7_F01/F02/F04
Drive	Data saving DDE	●	7_F01/F02/F04 5_F10/F11
Chassis	DSC sensor adjustment	●	X1_E84
Body	Display:Service interval reset with tester	●	X3_E83
Body	Deactivate transportation retainer	●	X3_E83
Body	Delete the personal profile	▲	3_F34 5_F18
Drive	EGR valve		
Drive	Electric fuel pump	●	5_F10/F11 7_F01/F02/F04
Body	Enable seat occupancy mat		
Chassis	End stop	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
Drive	Engage any gear	●	3_E46
			5_E60/E61
Drive	Engine internal pressure		
Body	Enter retrofitting		
Drive	EOBD readiness codes	●	3_E90/E91/E92/E93
Body	Evaluate battery charge state	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			X5_E70
			X6_E71
Body	Evaluate closed-circuit current monitoring	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			X5_E70
			X6_E71 7_F01/F02/F04 5_F10
Drive	EWS Reset function	●	X3_F25
			X5_E70
			X6_E71
Drive	EWS/DDE alignment	●	3_E46 X_E53
Drive	EWS/DME adjustment	●	3_E36
Drive	EWS/DME alignment	●	3_E36 3_E46 5_E39 7_E38 Z3_E36
Drive	EWS-DME/DDE adjustment	●	3_E30
Chassis	Execute braking-in program	●	X5_E70

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
			X6_E71
Drive	Exhaust-gas recirculation	●	5_E39 5_F10 7_F01/F02/F04
			5_F10/F11
Drive	Exhaust-Gas circulation	●	1_E81/E82/E87/E88
Drive	E-BOX fan	●	3_E90/E91/E92/E93
Drive	ECU programming information	●	3_E46
Drive	Electric coolant pump test	●	7_E65
Drive	Engine internal pressure	●	3_E46 3_E90/E91/E92/E93 7_E65
Drive	Evaluate closed circuit current	●	7_E65
Drive	Evaluate closed circuit current monitoring	●	1_E81/E82/E87/E88 5_E60/E61
Drive	EWS-DME/DDE adjustment	●	3_E30
Drive	Exhaust backpressure sensor	●	1_E81/E82/E87/E88
Drive	Exhaust backpressure test	●	3_E90/E91/E92/E93
Drive	Exhaust gas recirculation	●	3_E46 3_E90/E91/E92/E93 5_E39
			7_E65 X5_E53
Drive	Exhaust gas recirculation map	●	5_E39
Drive	Exhaust-GAS controller	●	5_E60/E61
Drive	Exhaust-gas recirculation	●	3_E90/E91/E92/E93 5_E60/E61
			X_E83
Body	ECU coding information	●	3_E46
			5_E39
DRIVE	EGR adaptation	●	3_E90/E91/E92/E93 X_E70
Body	Enable seat occupancy detection system	●	1_E81/E82/E87/E88
DRIVE	Engage gear	●	3_E46
DRIVE	Engine control: Limit quantity adjustment	●	X_E83
DRIVE	Engine control: Mean quantity adaptation	●	X_E83 X_E70 3_E90/E91/E92/E93
DRIVE	Evaluate closed-circuit current monitoring	●	X_E70/E71
Chassis	Electric steering lock: Normalisation	●	7_F01/F02/F04
Chassis	Electric steering lock: Partial normalisation	●	7_F01/F02/F04
Chassis	EPS start-up	▲	3_F30 5_F10
Chassis	EPS: Initial steering startup	●	1_F20
			1_F20 3_F35 5_F10/F11 5_F18
Body	Evaluate state of battery charge	●	7_F01/F02/F04
			X3_F25
Chassis	Electrical steering column adjustment normalisation	▲	X5_F15
Chassis	Fault lamp on sporadically	●	5_E39
			X5_E53
			6_E63/E64
Chassis	Fault, sensors, learn values	※	7_E65
			X5_E70
			X6_E71
Body	Fill/drain PRS pressure accumulator		
Chassis	Final ABS checks	●	7_E38
Drive	Function test, mixed-up oxygen sensors		
Drive	Fuel injector matching	●	1_E81/E82/E87/E88
Drive	Fitted components	●	3_E36
Drive	Fuel pressure test	●	X5_E53
Drive	Fuel tank leakage	●	7_E65
Drive	Fuel temp sensor	●	3_E46
Drive	Full load limiting delivery	●	5_E39
Drive	Fuel consumption display	●	X6_E71 Z4_E89
Drive	Fuel consumption display adjustment	●	3_E90/E91/E92/E93
Drive	Fuel quality recognition	●	X6_E71
Drive	FEM_KL 15 activation/deactivation	●	1_F20 3_F35
Chassis	Filling and discharge air from air below	●	7_F01/F02/F04
Body	Front passager side normalisation	●	1_F20 3_F35 5_F10/F11
			7_F01/F02/F04
Body	Front passenger seat, seat standardisation	●	7_F01/F02/F04
Drive	Fuel injector adaptation	●	7_F01/F02/F04
Drive	Fuel grade display	●	5_F10/F11 7_F01/F02/F04
Drive	Function test mixed-up oxygen sensor	●	3_E46 5_E39
Drive	Fuel quality display	▲	X5_F15
Drive	Glow plug heater test	●	X5_E53
DRIVE	Glow elements	●	7_F01/F02/F04 5_F10/F11
Body	Handset log-on/off		
			5_E60/E61
Body	Heating test run	●	6_E63/E64
			7_E65
Chassis	Hydraulic mix up check	●	7_E38
Chassis	HSR function check(deflection test)	▲	6_F13
			1_E81/E82/E87/E88 3_E36
			3_E46
			3_E90/E91/E92/E93
			5_E39

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Drive	Idle speed	●	5_E60/E61
			6_E63/E64
			7_E38
			7_E65
			X3_E83
			X5_E53
			X5_E70
			X6_E71
			Z4_E85/E86 Z4_E89 1_F20 3_F35
			5_F10/F11 5_F18 7_F01/02/04
	X_F25		
Drive	Idling quality	●	5_E60 X3_E83 X6_E71
Body	Initial operation, A/C compressor	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			X5_E70
	X6_E71		
Chassis	Initial setting, switch-on state	●	7_E65
Body	Initialisation	▲	5_E60/E61
			6_E63/E64
	7_E65 5_F18 X5_F15		
Body	Initialize power window	▲	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X5_E70
			X6_E71 1_F20 3_F35 5_F10/F11
			5_F18 7_F01/F02/F04 X3_F25
	X5_F15		
Body	Initialize power-window drive	●	5_E60/E61
Body	Initialize rain sensor	▲	3_E46
			5_E39
			5_E60/E61
			6_E63/E64
			7_E65
			X3_E83
			X5_E53
			Z4_E85/E86 X5_F15
	1E_81/E82/E87/E88		
Body	Initialize rain/light sensor	●	3_E90/E91/E92/E93
Body	Initialize rain/light solar sensor	●	X5_E70
			X6_E71
Body	Initialize slide/tilt sunroof	▲	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X5_E70
			X6_E71 1_F20 3_F30 3_F35
			5_F10/F11 5_F18 7_F01/F02/F04
	X3_F25 X5_F15		
Body	Initialized telematics services		
Drive	Injection deactivation	●	5_E60/E61
Drive	Injection rate	※	1_E81/E82/E87/E88
			5_E39
			5_E60/E61
			7_E38
			7_E65
			X_E83
			X5_E53
			X5_E70
Drive	Injector classification		
Drive	Injector program map		
Drive	Injector rate adjustment	●	3_E46
			3_E90/E91/E92/E93
			X5_E53 5_F10/F11 7_F01/F02/F04
Chassis	Inquiry, line mode	●	5_E39
			X5_E53
Chassis	Inquiry, transport mode	●	5_E39
			X5_E53
Drive	Injection program map	●	X5_E53
Drive	Injection rate	●	3_E90/E91/E92/E93
			X5_E53
Body	Initial operation,A/C compressor	●	3_E90/E91/E92/E93

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Body	Initialise lights	●	X5_E53
			1_E81/E82/E87/E88
Drive	Injection quantity compensation	●	X5_E70
			X6_E71
			X_E83
Drive	Injector equalisation	●	X6_E71
Body	Initialisation of rain-light-solar-condensation sensor	●	7_F01/F02/F04
Body	Initialise new headlight driver module and teach-in turn indicator	▲	3_F34 7_F01/F02/F04 X5_F15
Body	Initialization	●	7_F01/F02/F04
Body	Initialize audio operation at rear	●	5_F10/F11 5_F18 7_F01/F02/F04
Body	Initialize FlexRay	●	1_F20 3_F35 5_F10/F11 5_F18
			7_F01/F02/F04 X3_F25
Body	Initialization, automatic tailgate actuation	▲	X5_F15
Body	Initialising boot lid lift	▲	7_F01/F02/F04 3_F34
Body	Individual test for aerals in vehicle	▲	X5_F15
Body	Key status		
DRIVE	Key	●	Z_E36
			3_E46
			5_E39
			6_E63/E64
			7_E38
			7_E65
Chassis	Lateral acceleration sensor	※	X5_E53
			X5_E70
			X6_E71
			Z3_E36
			Z4_E85/E86
			Z8_E52
Body	Leak test, valves		
			3_E46
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X3_E83
			X5_E70
			Z4_E85/E86 5_F10/F11 5_F18
			7_F01/F02/F04
Drive	Learning/writing,zero-gear sensor	●	3_E90/E91/E92/E93
Drive	Limitation delivery		
Body	Log handset in and off		
Body	Log keypad handset on/off		
Body	Log mobile phone on		
Body	Log off CKPH		
Body	Log on CKPH		
Body	Log on snap-in adapter		
Body	Log remote control key on/off		
Body	Log-on/off CKPH		
Chassis	Longitudinal acceleration sensor adjustment	●	1_E81/E82/E87/E88 5_E61/E60
Drive	Leakage diagnosis test	●	3_E36
Drive	Learn valvetronic limit positions	●	3_E46 3_E90/E91/E92/E93 7_E65
Drive	Limitation delivery	●	5_E39 5_E60/E61 7_E65 X5_E53
Body	Lock airbag	●	1_F20 3_F30 3_F35 5_F10/F11
			7_F01/F02/F04
Body	Lock and enable master key	●	1_F20 3_F30 3_F35 5_F10/F11
			7_F01/F02/F04 X3_F35
Body	Lock and enable remote control key	▲	X5_F15
Drive	Mechanical components/function	●	7_E65
			1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X3_E83
			X5_E53
			X5_E70
			X6_E71
Drive	MFL and air conditioning	●	3_E46 5_E39 5_E60/E61 X_E53
			1_E81/E82/E87/E88
			3_E46
			3_E90/E91/E92/E93
			5_E39
			5_E60/E61

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Chassis	Mix-up check, brake lines	●	6_E63/E64
			7_E38
			7_E65
			X3_E83
			X5_E53
			X5_E70
			X6_E71
			Z4_E85/E86
			Z8_E52 1_F20 3_F30 3_F35 5_F18 5_F10/F11 7_F01/F02/F04 X3_F25
Body	MOST ring, save configuration		
Drive	Minimum stroke adjustment	●	3_E90/E91/E92/E93 7_E65
Drive	Mixture adaptation	●	3_E36
Drive	Mixture preparation	●	7_E38
Body	MOST: Storing the desired configuration	●	1_F20 3_F35
Body	MOST ring: Store configuration	●	3_E90/E91/E92/E93
Chassis	Normalization		
Body	Normalization, longitudinal adjustment, driver's side		
Body	Normalization, longitudinal seat adjustment, driver's side		
Body	Newly address the air distribution flap motors	●	1_F20 3_F35 7_F01/F02/F04
Drive	Notice symptoms:Engine hum E83	●	X3_E83
Body	Normalisation of the forward/back seat adjustment, drive	▲	X5_E70
Drive	OBD readiness codes		
Drive	Offset, sensor, longitudinal acceleration	●	3_E46 5_E39
Drive	Oil adjustment	●	3_E90/E91/E92/E93
Drive	Oil change	●	X3_E83
Drive	Oil change, QMVH	●	X6_E71
Drive	Oil level check	●	3_E46
Drive	Oil-level adjustment	▲	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X3_E83
			X5_E70
			X6_E71
Body	Operating parameter of evaporator temperature	●	5_E60/E61
			6_E63/E64
Body	Optimization, seat-heating parameter (E83)		
Drive	Operation on roller dynamometer	●	3_E30 3_E36
Drive	Oxygen sensor mixed up check	●	5_E60/E61
Drive	Oxygen sensors, Banks 1 and 2	●	3_E90/E91/E92/E93
Body	Outside temperature influence	●	7_E38
Drive	Oil balancing	●	1_F20 3_F35 7_F01/F02/F04
Drive	Operational smoothness measurement	●	3_E90/E91/E92/E93
Drive	Parking lock,function test	●	3_E90/E91/E92/E93
Drive	Parking lock,hook test	●	3_E90/E91/E92/E93
Body	Personalisation number	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X5_E70
Drive	Plausible start times		X6_E71
			X6_E71
Chassis	Positioning-travel check	●	7_E65
Body	Power down command	▲	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X5_E70
			X6_E71 1_F20 3_F35 5_F10/F11 5_F18 7_F01/F02/F04 X3_F25
			X5_F15
Chassis	Preparation, wheel/axle alignment	○	X5_E70
			X6_E71
Chassis	Pressure sensor, front axle	●	6_E63/E64
			7_E65
			X5_E70
Chassis	Pressure sensors	●	X6_E71
			3_E46
			Z3_E36
			Z4_E85/E86

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Drive	Program all adjustments	●	5_E39 7_E38
Body	Program seat-occupancy mat		
Chassis	Protective deactivation	●	5_E39 X5_E53
Drive	Pump program map	●	5_E39
Chassis	Parking brake: Initial operation	●	7_F01/F02/F04
Chassis	Parking brake: Workshop mode	●	7_F01/F02/F04
Drive	PRE-supply pump test	●	5_E39
Drive	Power management: Evaluating the battery state of charge	●	X_E70/E71
Chassis	Parking brake: Bedding-in procedure	●	7_F01/F02/F04
Body	Perform flap-motor calibration run	▲	1_F20 3_F35 5_F10/F11 5_F18 7_F01/F02/F04 X5_F15
Drive	Preheating control unit	●	3_E90/E91/E92/E93
Body	Persentation mode	▲	3_F34 5_F18 X5_F15
Drive	Read DDE measured values	●	X3_E83 3_E46 3_E90/E91/E92/E93
Drive	Quantity mean-value adaptation	●	5_E60/E61 5_F10/F11 7_F01/F02/F04
Drive	Rail-pressure regulating valve	●	3_E90/E91/E92/E93 5_F10/F11 7_F01/F02/F04
Chassis	Rate of rotation sensor	●	3_E46 5_E39 7_E38 X5_E53 Z8_E52
Body	Reactivation, BMW Assist		
Drive	Read AV accumulator		
Body	Read coding data	●	1_E81/E82/E87/E88 3_E46 3_E90/E91/E92/E93 5_E39 5_E60/E61 6_E63/E64 7_E38 X3_E83 X5_E53 X5_E70 X6_E71 Z4_E85/E86 Z8_E52
Chassis	Read in vehicle identification no. (ABS/ASC)	●	3_E46 Z3_E36
Drive	Read measured values	●	1_E81/E82/E87/E88 3_E46 3_E90/E91/E92/E93 5_E60/E61 7_E65
Body	Read operating data	●	7_E38
Body	Read out data	○	1_E81/E82/E87/E88 3_E90/E91/E92/E93 5_E60/E61 6_E63/E64 7_E65 X5_E70 X6_E71
Body	Read out operating data	●	3_E46 5_E39 X3_E83 X5_E53 Z4_E85/E86 Z8_E52
Body	Read out/write: kilometre readings, operating modes		
Drive	Read/delete adaptations	●	5_E60/E61
Body	Re-address flap motors	▲	1_E81/E82/E87/E88 3_E90/E91/E92/E93 X5_E70 X6_E71 3_F30 5_F18 X3_F25
Drive	Recalibration, transmission		
Body	Recode seat-occupancy mat		
Drive	Record engine operating data	●	3_E90/E91/E92/E93
Drive	Reduce hydraulic pressure		
Body	Re-establish delivery status		
Drive	Regeneration, particulate filter	●	3_E90/E91/E92/E93 5_F10/F11 7_F01/F02/F04
Drive	Regeneration,nitrogen-oxide catalytic converter	●	3_E90/E91/E92/E93

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Drive	Refrigerant compressor	●	5_E60/E61 7_E65
Body	Register battery change	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			X5_E70
Body	Register battery replacement	●	X6_E71
			1_E81/E82/E87/E88
			3_E90/E91/E92/E93 7_E65
			X5_E70
Body	Relieve tension on feed line		X6_E71 1_F20 3_F30 3_F35
			5_F10/F11 5_F18 7_F01/F02/F04
Drive	Remove Valvetronic servomotor		
Drive	Remove Valvetronic servomotor servomotor	●	7_E65
Drive	Repair	●	X3_E83
			X5_E70
			X6_E71
Drive	Replacement and repair	●	5_E60/E61
Drive	Replacement, particulate filter	●	5_F10/F11 3_E90/E91/E92/E93
Drive	Replacement,nitrogen-oxide catalytic converter		
Drive	Replacement/adaptation, CVT transmission		
Body	Request: service refueling (hot refuelling)		
Drive	Reset adaptations		
Body	Reset BMW Assist		
	Reset CBS Condition Based Service	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X5_E70
Drive	Reset clutch characteristic		X6_E71
Body	Reset HIP module	○	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			X5_E70
Body	Reset internal ELV fault counter	●	X6_E71
			3_E90/E91/E92/E93
Drive	Reset learning functions	●	5_E60/E61
			1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			6_E63/E64
			7_E65
			X3_E83
Chassis	Reset ABS motor relay clock counter	●	X5_E70
			5_E39 7_E38
Body	Reset malfunction lock		
Body	Reset service interval indicator		
Drive	Reset starter interlock	▲	1_F20 5_F10 7_F01/F02/F04
Drive	Reset variants		3_F34
Drive	Reset pressure control	●	1_E81/E82/E87/E88
			3_E90/E91/E92/E93
Chassis	Ride-height adjustment	●	5_E39
			X5_E53
Chassis	Ride-level adjustment	○	7_E65
			X5_E53
			X5_E70
			X6_E71
Chassis	Run flat indicator	●	1_E81/E82/E87/E88
Drive	Rail pressure control, system test	●	3_E46
Drive	Read Program number	●	3_E36
Drive	Read/Clear adaptations	●	5_E60/E61 3_E90/E91/E92/E93
Drive	Reset engine control unit pairing (PMS)	●	5_E39
Drive	Reset LVS values	●	3_E90/E91/E92/E93
Drive	Reset maximum engine coolant temperature reached	●	5_E39
Drive	Reset oil-change interval	●	5_E60/E61
Drive	Rail pressure control valve, measured values	●	1_E81/E82/E87/E88
DRIVE	Remote key test	●	3_E90/E91/E92/E93
Body	Rear driver's side normalisation	●	5_E60/E61
			5_F10/F11 7_F01/F02/F04

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Body	Rear front passager side normalisation	●	5_F10/F11 7_F01/F02/F04
Drive	Register starter exchange	●	5_F10/F11 7_F01/F02/F04
Drive	Remote key: Change personalization data	●	1_F20 3_F30 3_F35 5_F10/F11 5_F18 7_F01/F02/F04 X3_F25
Drive	Reset EWS	●	7_F01/F02/F04
Drive	Reset starter lock	●	5_F18 7_F01/F02/F04 x5_F15
Drive	Resetting adaption functions	●	5_F10/F11
Chassis	Ride height adjustment	▲	3_F30 5_F10/F11 7_F01/F02/F04
Chassis	Ride height sensor check	●	7_F01/F02/F04
Body	Run-in protection for A/C compressor	▲	3_F30 5_F18 7_F01/F02/F04 X3_F25
Drive	Reset the adaption of the electric fuel pump	●	3_E90/E91/E92/E93
Drive	Read and delete Swirl flap adaptation	●	3_E90/E91/E92/E93
Body	Readdress flap motors	▲	X5_F15
Drive	Resetting adaptation functions	▲	X5_E70
Drive	Reset the production mode for the fuel pump control module	▲	5_F18
Chassis	Rear axle wheel alignment	▲	6_F13
Body	Satellite	●	7_E65 Z4_E85/E86
Body	Save configuration		
Body	Save configuration of MOST ring		
Drive	Self-learning cycle		
Body	Service action, general module 5	●	X3_E83
Body	Set transport mode	●	3_F30 5_F18
Body	Set/delete opening limitation		
Drive	Setpoint/actual-value comparison, idle speed	●	5_E39 X3_E83
Chassis	Shock-absorber performance	●	7_E65 3_E90/E91/E92/E93
Drive	Start basic injection quantity	※	X5_E53 X5_E70
Chassis	Start startup	●	6_E63/E64 7_E65 X5_E70 X6_E71
Drive	Starting basic injection quantity	●	1_E81/E82/E87/E88 5_E60/E61
Drive	Starting fuel delivery	※	3_E46 5_E39 5_E60/E61 7_E38 7_E65 X3_E83 X5_E53
Drive	Starting torque	●	3_E90/E91/E92/E93 5_F10/F11 7_F01/F02/F04
Chassis	Startup	●	X5_E70 X6_E71 6_E63/E64
Chassis	Startup fault	○	7_E65 X5_E70 X6_E71
Drive	Startup QMVH	●	X6_E71 1_E81/E82/E87/E88
Chassis	Startup/adjustment active front steering	※	6_E63/E64 X5_E70 X6_E71 1_E81/E82/E87/E88 3_E46
Chassis	Steering-angle sensor	●	5_E60/E61 6_E63/E64 X6_E71
Body	Subsequent evaluation TCU		
Drive	Swirl-flap pump		
Drive	System check MSA		
Chassis	System startup after control-unit replace	●	7_E65
Body	System test	●	7_E38
Drive	Safety test	●	5_E39
Drive	Secondary air system	●	3_E36
Drive	Secondary air test	●	5_E60/E61
Drive	Set point/ Actual value comparison	●	3_E36
Drive	Smooth running controller	●	3_E46 3_E90/E91/E92/E93 5_F10/F11 7_F01/F02/F04
Drive	Smooth running measurement	●	3_E30 3_E36 3_E46 5_E39 7_E38 X_E53
Drive	Solenoid valve, Secondary air test	●	5_E39
Drive	Start fuel delivery	●	5_E39

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Drive	Start of injection map	●	5_E39
Drive	Start quantity	●	5_E39
Drive	Swirl flap actuator	●	3_E46 5_E60/E61
Drive	SCR system: Adjustment	●	X_E70
Body	Seat belt force limiter	●	6_E63/E64
Body	Seat occupancy detector	●	5_E60/E61
			Z_E85/E86
Drive	Selector lever test	●	3_E90/E91/E92/E93
			5_E60/E61
Body	Sensitivity level	●	3_E46
Body	Sleep mode	●	3_E46 7_E38 X_E53
Drive	Smooth running control	●	X_E83
Body	Seat-occupancy detector, passenger	●	3_F30
Body	Solar rain/light fogging sensor	●	1_F20 3_F30
Chassis	Start-up, brake pedal angle sensor	●	1_F20 3_F35
Chassis	Steering angle sensor adjustment	●	X1_E84 5_F18 7_F01/F02/F04
Chassis	Supply, damper satellite, front left	●	7_F01/F02/F04
Chassis	Supply, damper satellite, front right	●	7_F01/F02/F04
Chassis	Supply, damper satellite, rear left	●	7_F01/F02/F04
Chassis	Supply, damper satellite, rear right	●	7_F01/F02/F04
Drive	Swirl-flap actuator	●	5_F10/F11 7_F01/F02/F04
BODY	Start safety system (airbag): system time	●	Z_E85/E86
Drive	set point actual-value comparison idle speed	●	3_E46 5_E39
Drive	System check MSA	●	3_E90/E91/E92/E93
Drive	System check, automatic engine start-stop function	●	3_E90/E91/E92/E93
Chassis	Start-up Active Steering	▲	6_F13
Chassis	Start-up HSR rotor position sensor	▲	6_F13
MAINTENANCE	setting the transport mode	▲	X1_E84
Drive	Teach in characteristic clutch-valve values	●	3_E46
Drive	Teach in clutch slip point	●	3_E46
Body	Teach in radio remote control		
Drive	Teach in transmission		
Drive	Teach in valve characteristic curve	●	3_E90/E91/E92/E93
Drive	Test code + adaptation values		
Drive	Tolerance test, intermediate lever	●	7_E65
Drive	Transmission adaptation	●	3_E90/E91/E92/E93
Body	Trigger roll bar	●	6_E63/E64
Body	Tuner, Japan		
Body	Tuner, New Zealand		
Body	Tuner,Japan		
Chassis	Tyre defect indicator	●	5_E60/E61
			6_E63/E64
Drive	Tank leak diagnosis module DMTL	●	X5_E53
Drive	Tank leak system check DMTL	●	X5_E53
Drive	Tank leakage diagnosis	●	3_E90/E91/E92/E93 5_E60/E61
			7_E65
Drive	Tank leakage system check	●	7_E38
Drive	Tank leakage test	●	5_E39 7_E38
Drive	Tank venting valve (E36 US)	●	3_E36
Drive	Tank venting valve (E39)	●	5_E39
Drive	Test procedures	●	X5_E53
Drive	Throttle valve actuator group test	●	3_E90/E91/E92/E93 5_E60/E61
Drive	Transfer CO values to exchange control module	●	3_E30
			3_E30
			3_E46
Drive	Transport mode	●	7_E38
			X_E53
			X_E83
Drive	Test modules	●	5_E39
BODY	Transport lock	●	5_E39
			7_E38
body	Teach in radio remote control	●	7_F01/F02/F04
Drive	Transmission control unit: Reset learning function	●	7_F01/F02/F04
body	Tyre pressure control	●	3_F30
Drive	Test runs(idle speed)	●	3_E90/E91/E92/E93
Body	Unblock fault memory		
			1_E81/E82/E87/E88
			3_E90/E91/E92/E93
			5_E60/E61
			6_E63/E64
			7_E65
			X5_E70
			X6_E71 5_F10/F11 5_F18
			7_F01/F02/F04 X3_F25 X5_F15
Body	Unlocking	▲	

BMW_Pro_v1.46 Function List

NOTES:

- This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Part	Components	Supportion	bodytype
Chassis	Valves	●	5_E39
			X5_E53
Chassis	Vent pressure accumulator	○	X5_E53
Body	Vent SRA	●	7_E65
Chassis	Ventilation	●	3_E46 Z3_E36
Chassis	Ventilation routine	●	X5_E70
			X6_E71
Drive	Venting, clutch slave cylinder	●	3_E46
Drive	Venting, cooling system	●	3_E90/E91/E92/E93 7_E65
			5_F10/F11 5_F18 7_F01/F02/F04
Drive	Venting, transmission actuator	●	3_E46
			X6_E71
Drive	Venting,cooling system		
			5_E60/E61
Body	Vertical adjustment	●	6_E63/E64
			7_E65
Chassis	Vertical-acceleration-sensor adjustment	●	X5_E70
			X6_E71
Drive	Vacuum pump system test	●	5_E60/E61
Drive	Vacuum system test	●	5_E60/E61
Drive	Valvetronic adaptation	●	7_E65
Drive	Vanos control test	●	7_E65
Drive	VANOS test	●	X5_E53
Drive	VANOS: approach assembly position	●	3_E30
Drive	Variable valve gear	●	3_E46
Drive	Valvetronic adaptation limit positions	▲	X_E70 1_F20 3_F35
Drive	Valvetronic: start-up	▲	X_E70
Drive	Ventilation, cooling system		1_E81/E82/E87/E88
			X_E70
Drive	Valvetronic running-in phase	●	5_F10/F11 5_F18 X3_F25 Z4_E89
Chassis	VDM: Initial operation	●	7_F01/F02/F04
Drive	VTG:replace control unit	●	X3_F25
Body	VA calibration body general module	●	5_E60
			3_E46
Body	With tester	●	X3_E83
			Z4_E85/E86
			3_E46
Body	Without tester	●	X3_E83
			Z4_E85/E86
			7_E65
Chassis	Workshop braking-in	●	7_F01/F02/F04
			5_F10/F11
Chassis	Workshop mode	●	X5_E70
			X6_E71
Body	Write key variant		
Body	Windows initialisation	●	7_E65

BMW_Pro_v1.46 Function List

NOTES:

● This function is supported. ☆ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Subfunction	Subfunction	E Series	F Series	
Initial Report		●	●	
Vehicle information		●	●	
Encodings	Complete Coding		●	
	Selective Coding		●	
	Control Unit List		●	
Program Encodings	Scheduled Update	●	●	
	Complete Update	●	●	
	Selective Update	●	●	
	Control Unit List	●	●	
CAR/KEY MEMORY (Brush h	*		●	
Retrofit / Modification	*			
Programming Post-processing	*	●	●	
Special Measure	Calculate Navigation Activation Code			
	Update Integration Level			
	Custom Programming			