

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	131 TOFAS	1.6 I.E ECO	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	131 TOFAS	1.6 I.E ECO	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	131 TOFAS	1.6 I.E ECO	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	131 TOFAS	1.6 I.E ECO	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	131 TOFAS	1.6 I.E ECO	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Zeroing of self-adaption parameters	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Oil change	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Oil temperature sensor replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Timing sensor and/or cam replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	UniAir module replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Supercharging system components replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Neutral signal learn	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	MultiAir rolling finger replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Phonic wheel replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Performance limiting deactivation	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Rpm sensor and/or distribution belt replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Downstream lambda sensor and/or catalyzer and/or injectors replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Motorised throttle replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Replacement injectors	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Fuel supply system component replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Startup with code card	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/EObD Injection(EP 0.9 engine)	Special Functions	Rpm sensor and/or timing chain replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Read fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Erase fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Read data stream	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Supercharging system components replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Timing sensor and/or cam replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Neutral signal learn	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	MultiAir rolling finger replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Motorised throttle replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Performance limiting deactivation	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Oil change	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Oil temperature sensor replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Phonic wheel replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Replacement injectors	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Fuel supply system component replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Downstream lambda sensor and/or catalyzer and/or injectors replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	Rpm sensor and/or timing chain replacement	
-	-	500	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSW CF6/EObD Injection (EP 0.9 engine)	Special Functions	UniAir module replacement	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	500	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	500	0.9 TURBO TWIN AIR	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	500	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	500	0.9 TURBO TWIN AIR	Siemens Airbag (EP-Proxi)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Siemens Airbag (EP-Proxi)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Siemens Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Siemens Airbag (EP-Proxi)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Siemens Airbag (EP-Proxi)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Single-zone Climate Control (EP)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Single-zone Climate Control (EP)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	500	0.9 TURBO TWIN AIR	Denso One-zone Climate Control System PTC (EP)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Denso One-zone Climate Control System PTC (EP)	Read fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Denso One-zone Climate Control System PTC (EP)	Erase fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Denso One-zone Climate Control System PTC (EP)	Read data stream	-	
-	-	500	0.9 TURBO TWIN AIR	Denso One-zone Climate Control System PTC (EP)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Denso One-zone Climate Control System PTC (EP)	Special Functions	Flap actuators learning test	
-	-	500	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	500	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Special Functions	Headlamp pos. correct.	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Special Functions	Servicing information delete	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Special Functions	Reset odometer	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Special Functions	Seat belts alarm exclusion	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Special Functions	Seat belts alarm enable	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Special Functions	Instrument panel replacement	
-	-	500	0.9 TURBO TWIN AIR	Marelli Instrument Panel (EP) 2	Special Functions	Instrument panel lighting	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Read fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Erase fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Read data stream	-	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Special Functions	Reset odometer	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Special Functions	Seat belts alarm exclusion	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Special Functions	Seat belts alarm enable	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Special Functions	Servicing information delete	
-	-	500	0.9 TURBO TWIN AIR	Marelli TFT Instrument Panel	Special Functions	Instrument panel replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Special Functions	Key programming	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Special Functions	Inertia switch rearm (FIS)	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Special Functions	Indicators command enable/disable	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Special Functions	Country standards change	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Special Functions	Power mode gearbox	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Special Functions	Roof control unit initialisation	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 2	Special Functions	Exit shipping mode	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Read fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Erase fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Read data stream	-	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Steering wheel levers replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Tunnel lever replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Longitudinal acceleration sensor replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Control unit replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Gearbox replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Hydraulic kit replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	ECO/SPORT switch replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Gearbox oil accumulator replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Clutch replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Electropump replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Pump relay replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	AUTO switch replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	500	0.9 TURBO TWIN AIR	Delphi Body Computer (EP)	Special Functions	Sensor replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox oil accumulator replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Control unit replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Hydraulic kit replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Clutch replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Tunnel lever replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Steering wheel levers replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration signal learn	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	ECO/SPORT switch replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Pump relay replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	AUTO switch replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Electropump replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Sensor replacement	
-	-	500	0.9 TURBO TWIN AIR	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration sensor replacement	
-	-	500	0.9 TURBO TWIN AIR	Denso Heater (EP)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Heater (EP)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Heater (EP)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Heater (EP)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Denso Heater (EP)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo 3ch Parking Control Unit (EP)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo 3ch Parking Control Unit (EP)	Read fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo 3ch Parking Control Unit (EP)	Erase fault code	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo 3ch Parking Control Unit (EP)	Read data stream	-	
-	-	500	0.9 TURBO TWIN AIR	Valeo 3ch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	500	0.9 TURBO TWIN AIR	Valeo 3ch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	500	0.9 TURBO TWIN AIR	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Live Data	-	
-	-	500	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	500	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	500	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	500	0.9 TURBO TWIN AIR	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Read ECU Information	-	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Read fault code	-	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Erase fault code	-	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Read data stream	-	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Actuation Test	-	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Cam edges zeroing (VVT)	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Startup with code card	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Throttle learn storage	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Zeroing of self-adaption parameters	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Neutral signal learn	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Clutch pedal learning	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Phonic wheel learn reset	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Fuel supply manifold bleed	
-	-	500	1.2 8V	Magneti Marelli 9GF CF6 Injection (EP 1.2 engine)	Special Functions	Vehicle configuration deletion	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read fault code	-	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Erase fault code	-	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read data stream	-	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Actuation Test	-	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Cam edges zeroing (VVT)	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Startup with code card	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Throttle learn storage	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Zeroing of self-adaption parameters	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Vehicle configuration deletion	
-	-	500	1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Phonic wheel learn reset	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	500	1.2 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	500	1.2 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	500	1.2 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	500	1.2 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	500	1.2 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	500	1.2 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	500	1.2 8V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	500	1.2 8V	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	500	1.2 8V	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	500	1.2 8V	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	500	1.2 8V	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	500	1.2 8V	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	500	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	500	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	500	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	500	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	500	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	500	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	500	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	500	1.2 8V	Siemens Airbag (EP-Proxy)	Read ECU Information	-	
-	-	500	1.2 8V	Siemens Airbag (EP-Proxy)	Read Fault Code	-	
-	-	500	1.2 8V	Siemens Airbag (EP-Proxy)	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	500	1.2 8V	Siemens Airbag (EP-Proxi)	Live Data	-	
-	-	500	1.2 8V	Siemens Airbag (EP-Proxi)	Actuation Test	-	
-	-	500	1.2 8V	Denso Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Denso Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	500	1.2 8V	Denso Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	500	1.2 8V	Denso Single-zone Climate Control (EP)	Live Data	-	
-	-	500	1.2 8V	Denso Single-zone Climate Control (EP)	Actuation Test	-	
-	-	500	1.2 8V	Denso Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	500	1.2 8V	Denso One-zone Climate Control System PTC (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Denso One-zone Climate Control System PTC (EP)	Read fault code	-	
-	-	500	1.2 8V	Denso One-zone Climate Control System PTC (EP)	Erase fault code	-	
-	-	500	1.2 8V	Denso One-zone Climate Control System PTC (EP)	Read data stream	-	
-	-	500	1.2 8V	Denso One-zone Climate Control System PTC (EP)	Actuation Test	-	
-	-	500	1.2 8V	Denso One-zone Climate Control System PTC (EP)	Special Functions	Flap actuators learning test	
-	-	500	1.2 8V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	500	1.2 8V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	500	1.2 8V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	500	1.2 8V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	500	1.2 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	500	1.2 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Read ECU Information	-	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Read Fault Code	-	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Erase Fault Code	-	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Live Data	-	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Actuation Test	-	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Special Functions	Headlamp pos. correct.	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Special Functions	Servicing information delete	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Special Functions	Reset odometer	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Special Functions	Seat belts alarm exclusion	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Special Functions	Seat belts alarm enable	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Special Functions	Instrument panel replacement	
-	-	500	1.2 8V	Marelli Instrument Panel (EP) 2	Special Functions	Instrument panel lighting	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Read ECU Information	-	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Read fault code	-	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Erase fault code	-	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Read data stream	-	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Special Functions	Reset odometer	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Special Functions	Seat belts alarm exclusion	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Special Functions	Seat belts alarm enable	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Special Functions	Servicing information delete	
-	-	500	1.2 8V	Marelli TFT Instrument Panel	Special Functions	Instrument panel replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Read ECU Information	-	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Read Fault Code	-	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Erase Fault Code	-	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Live Data	-	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Actuation Test	-	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Special Functions	Key programming	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Special Functions	Inertia switch rearm (FIS)	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Special Functions	Indicators command enable/disable	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Special Functions	Country standards change	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Special Functions	Power mode gearbox	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Special Functions	Roof control unit initialisation	
-	-	500	1.2 8V	Delphi Body Computer (EP) 2	Special Functions	Exit shipping mode	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Read fault code	-	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Erase fault code	-	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Read data stream	-	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Steering wheel levers replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Tunnel lever replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Longitudinal acceleration sensor replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Control unit replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Gearbox replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Hydraulic kit replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	ECO/SPORT switch replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Gearbox oil accumulator replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Clutch replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Electropump replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Pump relay replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	AUTO switch replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	500	1.2 8V	Delphi Body Computer (EP)	Special Functions	Sensor replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Read ECU Information	-	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Read Fault Code	-	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Erase Fault Code	-	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Live Data	-	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Actuation Test	-	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox oil accumulator replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Control unit replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Hydraulic kit replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Clutch replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Tunnel lever replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Steering wheel levers replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration signal learn	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	ECO/SPORT switch replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Pump relay replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	AUTO switch replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Electropump replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Sensor replacement	
-	-	500	1.2 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration sensor replacement	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Read ECU Information	-	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Read Fault Code	-	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Erase Fault Code	-	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Live Data	-	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Actuation Test	-	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	500	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Cam edges zeroing (VVT)	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Read ECU Information	-	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Erase Fault Code	-	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Live Data	-	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Actuation Test	-	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Startup with code card	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	500	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Neutral signal learn	
-	-	500	1.2 8V	Denso Heater (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Denso Heater (EP)	Read Fault Code	-	
-	-	500	1.2 8V	Denso Heater (EP)	Erase Fault Code	-	
-	-	500	1.2 8V	Denso Heater (EP)	Live Data	-	
-	-	500	1.2 8V	Denso Heater (EP)	Actuation Test	-	
-	-	500	1.2 8V	Valeo 3ch Parking Control Unit (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Valeo 3ch Parking Control Unit (EP)	Read fault code	-	
-	-	500	1.2 8V	Valeo 3ch Parking Control Unit (EP)	Erase fault code	-	
-	-	500	1.2 8V	Valeo 3ch Parking Control Unit (EP)	Read data stream	-	
-	-	500	1.2 8V	Valeo 3ch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	500	1.2 8V	Valeo 3ch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	500	1.2 8V	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	500	1.2 8V	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	500	1.2 8V	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	500	1.2 8V	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	500	1.2 8V	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	500	1.2 8V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	500	1.2 8V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	500	1.2 8V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	500	1.2 8V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	500	1.2 8V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	500	1.2 8V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	500	1.2 8V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	500	1.2 8V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read ECU Information	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read fault code	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Erase fault code	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read data stream	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Actuation Test	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector codes read	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 1	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 2	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 3	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 4	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector replacement (per bank)	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Neutral signal learn	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Air flow meter sensor replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Differential pressure sensor replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Mechanical waste-gate valve replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Oil change	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Phonic wheel replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Rail pressure sensor replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement lambda sensor	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Speed limit setting	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter regeneration	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Startup with code card	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Throttle test	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	EGR valve test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Glow plug preheating circuit test	
-	-	500	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Automatic configuration read	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Live Data	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Actuation Test	-	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	500	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	500	1.3 JTD	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	500	1.3 JTD	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	500	1.3 JTD	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	500	1.3 JTD	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	500	1.3 JTD	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	500	1.3 JTD	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	500	1.3 JTD	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	500	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	500	1.3 JTD	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	500	1.3 JTD	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	500	1.3 JTD	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	500	1.3 JTD	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	500	1.3 JTD	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	500	1.3 JTD	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	500	1.3 JTD	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	500	1.3 JTD	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	500	1.3 JTD	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	500	1.3 JTD	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	500	1.3 JTD	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	500	1.3 JTD	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	500	1.3 JTD	Siemens Airbag (EP-Proxy)	Read ECU Information	-	
-	-	500	1.3 JTD	Siemens Airbag (EP-Proxy)	Read Fault Code	-	
-	-	500	1.3 JTD	Siemens Airbag (EP-Proxy)	Erase Fault Code	-	
-	-	500	1.3 JTD	Siemens Airbag (EP-Proxy)	Live Data	-	
-	-	500	1.3 JTD	Siemens Airbag (EP-Proxy)	Actuation Test	-	
-	-	500	1.3 JTD	Denso Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	500	1.3 JTD	Denso Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	500	1.3 JTD	Denso Single-zone Climate Control (EP)	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	500	1.3 JTD	Denso Single-zone Climate Control (EP)	Live Data	-	
-	-	500	1.3 JTD	Denso Single-zone Climate Control (EP)	Actuation Test	-	
-	-	500	1.3 JTD	Denso Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	500	1.3 JTD	Denso One-zone Climate Control System PTC (EP)	Read ECU Information	-	
-	-	500	1.3 JTD	Denso One-zone Climate Control System PTC (EP)	Read fault code	-	
-	-	500	1.3 JTD	Denso One-zone Climate Control System PTC (EP)	Erase fault code	-	
-	-	500	1.3 JTD	Denso One-zone Climate Control System PTC (EP)	Read data stream	-	
-	-	500	1.3 JTD	Denso One-zone Climate Control System PTC (EP)	Actuation Test	-	
-	-	500	1.3 JTD	Denso One-zone Climate Control System PTC (EP)	Special Functions	Flap actuators learning test	
-	-	500	1.3 JTD	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	500	1.3 JTD	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	500	1.3 JTD	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	500	1.3 JTD	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	500	1.3 JTD	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	500	1.3 JTD	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Read ECU Information	-	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Read Fault Code	-	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Erase Fault Code	-	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Live Data	-	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Actuation Test	-	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Special Functions	Headlamp pos. correct.	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Special Functions	Servicing information delete	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Special Functions	Reset odometer	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Special Functions	Seat belts alarm exclusion	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Special Functions	Seat belts alarm enable	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Special Functions	Instrument panel replacement	
-	-	500	1.3 JTD	Marelli Instrument Panel (EP) 2	Special Functions	Instrument panel lighting	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Read ECU Information	-	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Read fault code	-	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Erase fault code	-	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Read data stream	-	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Special Functions	Reset odometer	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Special Functions	Seat belts alarm exclusion	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Special Functions	Seat belts alarm enable	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Special Functions	Servicing information delete	
-	-	500	1.3 JTD	Marelli TFT Instrument Panel	Special Functions	Instrument panel replacement	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Read ECU Information	-	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Read Fault Code	-	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Erase Fault Code	-	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Live Data	-	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Actuation Test	-	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Key programming	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Inertia switch rearm (FIS)	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Indicators command enable/disable	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Country standards change	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Power mode gearbox	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Roof control unit initialisation	
-	-	500	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Exit shipping mode	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	500	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	500	1.3 JTD	Denso Heater (EP)	Read ECU Information	-	
-	-	500	1.3 JTD	Denso Heater (EP)	Read Fault Code	-	
-	-	500	1.3 JTD	Denso Heater (EP)	Erase Fault Code	-	
-	-	500	1.3 JTD	Denso Heater (EP)	Live Data	-	
-	-	500	1.3 JTD	Denso Heater (EP)	Actuation Test	-	
-	-	500	1.3 JTD	Valeo 3ch Parking Control Unit (EP)	Read ECU Information	-	
-	-	500	1.3 JTD	Valeo 3ch Parking Control Unit (EP)	Read fault code	-	
-	-	500	1.3 JTD	Valeo 3ch Parking Control Unit (EP)	Erase fault code	-	
-	-	500	1.3 JTD	Valeo 3ch Parking Control Unit (EP)	Read data stream	-	
-	-	500	1.3 JTD	Valeo 3ch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	500	1.3 JTD	Valeo 3ch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	500	1.3 JTD	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	500	1.3 JTD	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	500	1.3 JTD	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	500	1.3 JTD	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	500	1.3 JTD	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	500	1.3 JTD	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	500	1.3 JTD	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	500	1.3 JTD	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	500	1.3 JTD	Lauberhorn Convergence (EP)	Live Data	-	
-	-	500	1.3 JTD	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	500	1.3 JTD	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	500	1.3 JTD	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	500	1.3 JTD	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	500	1.4 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	500	1.4 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	500	1.4 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	500	1.4 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	500	1.4 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	500	1.4 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	500	1.4 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	500	1.4 16V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	500	1.4 16V	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	500	1.4 16V	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	500	1.4 16V	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	500	1.4 16V	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	500	1.4 16V	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	500	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	500	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	500	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	500	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	500	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	500	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	500	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Read ECU Information	-	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Read Fault Code	-	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Erase Fault Code	-	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Live Data	-	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Actuation Test	-	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Knock counter reset	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Overboost counter reset	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	500	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	500	1.4 16V	Siemens Airbag (EP-Proxi)	Read ECU Information	-	
-	-	500	1.4 16V	Siemens Airbag (EP-Proxi)	Read Fault Code	-	
-	-	500	1.4 16V	Siemens Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	500	1.4 16V	Siemens Airbag (EP-Proxi)	Live Data	-	
-	-	500	1.4 16V	Siemens Airbag (EP-Proxi)	Actuation Test	-	
-	-	500	1.4 16V	Denso Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	500	1.4 16V	Denso Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	500	1.4 16V	Denso Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	500	1.4 16V	Denso Single-zone Climate Control (EP)	Live Data	-	
-	-	500	1.4 16V	Denso Single-zone Climate Control (EP)	Actuation Test	-	
-	-	500	1.4 16V	Denso Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	500	1.4 16V	Denso One-zone Climate Control System PTC (EP)	Read ECU Information	-	
-	-	500	1.4 16V	Denso One-zone Climate Control System PTC (EP)	Read fault code	-	
-	-	500	1.4 16V	Denso One-zone Climate Control System PTC (EP)	Erase fault code	-	
-	-	500	1.4 16V	Denso One-zone Climate Control System PTC (EP)	Read data stream	-	
-	-	500	1.4 16V	Denso One-zone Climate Control System PTC (EP)	Actuation Test	-	
-	-	500	1.4 16V	Denso One-zone Climate Control System PTC (EP)	Special Functions	Flap actuators learning test	
-	-	500	1.4 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	500	1.4 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	500	1.4 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	500	1.4 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	500	1.4 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	500	1.4 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Read ECU Information	-	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Read Fault Code	-	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Erase Fault Code	-	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Live Data	-	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Actuation Test	-	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Special Functions	Headlamp pos. correct.	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Special Functions	Servicing information delete	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Special Functions	Reset odometer	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Special Functions	Seat belts alarm exclusion	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Special Functions	Seat belts alarm enable	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Special Functions	Instrument panel replacement	
-	-	500	1.4 16V	Marelli Instrument Panel (EP) 2	Special Functions	Instrument panel lighting	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Read ECU Information	-	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Read fault code	-	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Erase fault code	-	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Read data stream	-	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Special Functions	Reset odometer	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Special Functions	Seat belts alarm exclusion	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Special Functions	Seat belts alarm enable	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Special Functions	Servicing information delete	
-	-	500	1.4 16V	Marelli TFT Instrument Panel	Special Functions	Instrument panel replacement	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Read ECU Information	-	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Read Fault Code	-	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Erase Fault Code	-	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Live Data	-	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Actuation Test	-	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Special Functions	Key programming	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Special Functions	Inertia switch rear (FIS)	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Special Functions	Indicators command enable/disable	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Special Functions	Country standards change	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Special Functions	Power mode gearbox	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Special Functions	Roof control unit initialisation	
-	-	500	1.4 16V	Delphi Body Computer (EP) 2	Special Functions	Exit shipping mode	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Read ECU Information	-	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Read Fault Code	-	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Erase Fault Code	-	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Live Data	-	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Actuation Test	-	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox oil accumulator replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Control unit replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Hydraulic kit replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Clutch replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Tunnel lever replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Steering wheel levers replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration signal learn	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	ECO/SPORT switch replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Pump relay replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	AUTO switch replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Electropump replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Sensor replacement	
-	-	500	1.4 16V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration sensor replacement	
-	-	500	1.4 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	500	1.4 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	500	1.4 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	500	1.4 16V	Denso Heater (EP)	Live Data	-	
-	-	500	1.4 16V	Denso Heater (EP)	Actuation Test	-	
-	-	500	1.4 16V	Valeo 3ch Parking Control Unit (EP)	Read ECU Information	-	
-	-	500	1.4 16V	Valeo 3ch Parking Control Unit (EP)	Read fault code	-	
-	-	500	1.4 16V	Valeo 3ch Parking Control Unit (EP)	Erase fault code	-	
-	-	500	1.4 16V	Valeo 3ch Parking Control Unit (EP)	Read data stream	-	
-	-	500	1.4 16V	Valeo 3ch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	500	1.4 16V	Valeo 3ch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	500	1.4 16V	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	500	1.4 16V	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	500	1.4 16V	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	500	1.4 16V	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	500	1.4 16V	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	500	1.4 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	500	1.4 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	500	1.4 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	500	1.4 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	500	1.4 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	500	1.4 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	500	1.4 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	500	1.4 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection	Live Data	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection	Actuation Test	-	
-	-	BARCETTA	16V ASPIRATO	Bosch 5.3 ABS	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO	Bosch 5.3 ABS	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	Bosch 5.3 ABS	Live Data	-	
-	-	BARCETTA	16V ASPIRATO	Bosch 5.3 ABS	Actuation Test	-	
-	-	BARCETTA	16V ASPIRATO	TRW MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO	TRW MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	TRW MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	TRW MY 97 Airbag (2F-2P)	Live Data	-	
-	-	BARCETTA	16V ASPIRATO	TRW MY 97 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO	TRW MY 97 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	TRW MY 97 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	TRW MY 97 Airbag (2F-2P-1)	Live Data	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection (eng. 1.8 16V '98)	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection (eng. 1.8 16V '98)	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection (eng. 1.8 16V '98)	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection (eng. 1.8 16V '98)	Live Data	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection (eng. 1.8 16V '98)	Actuation Test	-	
-	-	BARCETTA	16V ASPIRATO	Hitachi MPI Injection (eng. 1.8 16V '98)	Special Functions	Startup with code card	
-	-	BARCETTA	16V ASPIRATO	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BARCETTA	16V ASPIRATO	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BARCETTA	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	BARCETTA	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	BARCETTA	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	BARCETTA	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	BARCETTA	16V ASPIRATO CF3	Bosch 5.3 ABS	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO CF3	Bosch 5.3 ABS	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	Bosch 5.3 ABS	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BARCETTA	16V ASPIRATO CF3	Bosch 5.3 ABS	Live Data	-	
-	-	BARCETTA	16V ASPIRATO CF3	Bosch 5.3 ABS	Actuation Test	-	
-	-	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Airbag (2F-2P)	Live Data	-	
-	-	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Airbag (2F-2P-1)	Live Data	-	
-	-	BARCETTA	16V ASPIRATO CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BARCETTA	16V ASPIRATO CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BARCETTA	16V ASPIRATO CF3	Hitachi EOBD Injection	Read ECU Information	-	
-	-	BARCETTA	16V ASPIRATO CF3	Hitachi EOBD Injection	Read Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	Hitachi EOBD Injection	Erase Fault Code	-	
-	-	BARCETTA	16V ASPIRATO CF3	Hitachi EOBD Injection	Live Data	-	
-	-	BARCETTA	16V ASPIRATO CF3	Hitachi EOBD Injection	Actuation Test	-	
-	-	BARCETTA	16V ASPIRATO CF3	Hitachi EOBD Injection	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.4 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO (198)	1.4 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO (198)	1.4 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO (198)	1.4 16V	Continental Airbag (Proxy)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Continental Airbag (Proxy)	Read fault code	-	
-	-	BRAVO (198)	1.4 16V	Continental Airbag (Proxy)	Erase fault code	-	
-	-	BRAVO (198)	1.4 16V	Continental Airbag (Proxy)	Read data stream	-	
-	-	BRAVO (198)	1.4 16V	Injection Landi Renzo LC02 Gas	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Injection Landi Renzo LC02 Gas	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Injection Landi Renzo LC02 Gas	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Injection Landi Renzo LC02 Gas	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Injection Landi Renzo LC02 Gas	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Marelli Climate Control	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli Climate Control	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ABS	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.4 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.4 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO (198)	1.4 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO (198)	1.4 16V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO (198)	1.4 16V	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Knock counter reset	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Overboost counter reset	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Neutral signal learn	
-	-	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	BRAVO (198)	1.4 16V	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Driver's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Driver's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Passenger's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO (198)	1.4 16V	TRW Lane Control Control Unit (HALF)	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO (198)	1.4 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Read Data Stream	-	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Actuation Test	-	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Special Functions	Timing sensor and/or cam replacement	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Special Functions	Knock sensor and/or spark plug replacement	
-	-	BRAVO (198)	1.4 16V	Bosch motronic injection me7.9.10 / SDU CF5/EOBD LPG (eng. 1.4)	Special Functions	Supercharging system components replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.4 TURBO 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO (198)	1.4 TURBO 16V	Continental Airbag (Proxy)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Continental Airbag (Proxy)	Read fault code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Continental Airbag (Proxy)	Erase fault code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Continental Airbag (Proxy)	Read data stream	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Climate Control	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Climate Control	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ABS	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	ECO/SPORT switch replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Electropump replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch bleed	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Knock counter reset	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Overboost counter reset	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Neutral signal learn	
-	-	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Read fault code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Erase fault code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Read data stream	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Read fault code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Erase fault code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Read data stream	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Oil change	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Oil temperature sensor replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Downstream lambda sensor and/or catalyzer and/or injectors replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Motorised throttle replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Neutral signal learn	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	MultiAir rolling finger replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Phonic wheel replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Rpm sensor and/or distribution belt replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Supercharging system components replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	Timing sensor and/or cam replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	Special Functions	UniAir module replacement	
-	-	BRAVO (198)	1.4 TURBO 16V	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Driver's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Driver's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Passenger's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.4 TURBO 16V	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW Lane Control Control Unit (HALF)	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Convergence Lauberhorn Cl	Live Data	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.4 TURBO 16V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO (198)	1.6 MJET 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO (198)	1.6 MJET 16V	Continental Airbag (Proxy)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Continental Airbag (Proxy)	Read fault code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Continental Airbag (Proxy)	Erase fault code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Continental Airbag (Proxy)	Read data stream	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Climate Control	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Climate Control	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ABS	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	ECO/SPORT switch replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Electropump replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch bleed	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	New actuators	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO (198)	1.6 MJET 16V	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Driver's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Driver's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Passenger's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector codes read	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Control unit replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Neutral signal learn	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	BRAVO (198)	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Convergence Lauberhorn Cl	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.6 MJET 16V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Continental Airbag (Proxy)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Continental Airbag (Proxy)	Read fault code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Continental Airbag (Proxy)	Erase fault code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Continental Airbag (Proxy)	Read data stream	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Climate Control	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Climate Control	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ABS	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Read Fault Code	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	ECO/SPORT switch replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Electropump replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch bleed	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	New actuators	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector codes read	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Control unit replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read fault code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Erase fault code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read data stream	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Live Data	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	BRAVO (198)	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO (198)	1.9 MJET 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO (198)	1.9 MJET 16V	Continental Airbag (Proxy)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Continental Airbag (Proxy)	Read fault code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Continental Airbag (Proxy)	Erase fault code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Continental Airbag (Proxy)	Read data stream	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Climate Control	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Climate Control	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ABS	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO (198)	1.9 MJET 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO (198)	1.9 MJET 16V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO (198)	1.9 MJET 16V	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Driver's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Driver's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Passenger's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	TRW Lane Control Control Unit (HALF)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.9 MJET 16V	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Convergence Lauberhorn Cl	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 16V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 16V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.9 MJET 16V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO (198)	1.9 MJET 8V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO (198)	1.9 MJET 8V	Continental Airbag (Proxy)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Continental Airbag (Proxy)	Read fault code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Continental Airbag (Proxy)	Erase fault code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Continental Airbag (Proxy)	Read data stream	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Climate Control	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Climate Control	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ABS	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO (198)	1.9 MJET 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO (198)	1.9 MJET 8V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO (198)	1.9 MJET 8V	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Driver's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Driver's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Passenger's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW Lane Control Control Unit (HALF)	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Convergence Lauberhorn C1	Live Data	-	
-	-	BRAVO (198)	1.9 MJET 8V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	BRAVO (198)	1.9 MJET 8V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	BRAVO (198)	1.9 MJET 8V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO (198)	2.0 MJET 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO (198)	2.0 MJET 16V	Continental Airbag (Proxy)	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Continental Airbag (Proxy)	Read fault code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Continental Airbag (Proxy)	Erase fault code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Continental Airbag (Proxy)	Read data stream	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Climate Control	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Climate Control	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ABS	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO (198)	2.0 MJET 16V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO (198)	2.0 MJET 16V	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Driver's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Driver's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Passenger's Seat Lear 3	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO (198)	2.0 MJET 16V	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Startup with code card	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector codes read	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Control unit replacement	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	BRAVO (198)	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	BRAVO (198)	2.0 MJET 16V	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW Lane Control Control Unit (HALF)	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Convergence Lauberhorn C1	Live Data	-	
-	-	BRAVO (198)	2.0 MJET 16V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	BRAVO (198)	2.0 MJET 16V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	BRAVO (198)	2.0 MJET 16V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO-BRAVA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'01 100 16V CF3	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Hitachi EOBD Injection	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Hitachi EOBD Injection	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Hitachi EOBD Injection	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Hitachi EOBD Injection	Live Data	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Hitachi EOBD Injection	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Hitachi EOBD Injection	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'01 115 16V CF3	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Bosch Motronic ME7.3H4 EOBD Injection	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Bosch Motronic ME7.3H4 EOBD Injection	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Bosch Motronic ME7.3H4 EOBD Injection	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Bosch Motronic ME7.3H4 EOBD Injection	Live Data	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Bosch Motronic ME7.3H4 EOBD Injection	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Bosch Motronic ME7.3H4 EOBD Injection	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'01 80 16V CF3	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Borletti MCC55F Climate Control	Erase Fault Code	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'01 JTD 100 CF3	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Live Data	-	
-	-	BRAVO-BRAVA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Actuation Test	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	BRAVO-BRAVA	1.4 12V	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	BRAVO-BRAVA	1.4 12V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.4 12V	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	1.4 12V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	1.4 12V	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.6 16V	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	1.6 16V	Magneti Marelli IAW IAF/IAB Injection	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.6 16V	Magneti Marelli IAW IAF/IAB Injection	Read fault code	-	
-	-	BRAVO-BRAVA	1.6 16V	Magneti Marelli IAW IAF/IAB Injection	Erase fault code	-	
-	-	BRAVO-BRAVA	1.6 16V	Magneti Marelli IAW IAF/IAB Injection	Read data stream	-	
-	-	BRAVO-BRAVA	1.6 16V	Magneti Marelli IAW IAF/IAB Injection	Actuation Test	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	BRAVO-BRAVA	1.6 16V	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	BRAVO-BRAVA	1.6 16V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.6 16V	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	1.6 16V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	1.6 16V	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	1.8 16V	Hitachi MPI Injection	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.8 16V	Hitachi MPI Injection	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	Hitachi MPI Injection	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	Hitachi MPI Injection	Live Data	-	
-	-	BRAVO-BRAVA	1.8 16V	Hitachi MPI Injection	Actuation Test	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	BRAVO-BRAVA	1.8 16V	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	BRAVO-BRAVA	1.8 16V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.8 16V	Teves ABS MK20/MK70	Read fault code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO-BRAVA	1.8 16V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	1.8 16V	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 D	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	BRAVO-BRAVA	1.9 D	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	BRAVO-BRAVA	1.9 D	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 D	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	1.9 D	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	1.9 D	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Lucas DPNC Diesel Injection	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Lucas DPNC Diesel Injection	Read fault code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Lucas DPNC Diesel Injection	Erase fault code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Lucas DPNC Diesel Injection	Read data stream	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	1.9 TD 100CV	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	1.9 TD 75CV	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Read ECU Information	-	
-	-	BRAVO-BRAVA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Read Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Live Data	-	
-	-	BRAVO-BRAVA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Actuation Test	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO-BRAVA	2.0 20V	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	BRAVO-BRAVA	2.0 20V	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	BRAVO-BRAVA	2.0 20V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	2.0 20V	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	2.0 20V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	2.0 20V	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Live Data	-	
-	-	BRAVO-BRAVA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'99 100 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 100 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'99 100 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 100 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 100 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 100 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'99 100 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 100 16V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 100 16V	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'99 100 16V	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Live Data	-	
-	-	BRAVO-BRAVA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'99 115 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 115 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'99 115 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 115 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 115 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 115 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'99 115 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 115 16V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 115 16V	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'99 115 16V	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Live Data	-	
-	-	BRAVO-BRAVA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'99 155 20V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 155 20V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'99 155 20V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 155 20V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 155 20V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 155 20V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO-BRAVA	'99 155 20V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'99 155 20V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 155 20V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 155 20V	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'99 155 20V	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Live Data	-	
-	-	BRAVO-BRAVA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Special Functions	Startup with code card	
-	-	BRAVO-BRAVA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Special Functions	Reset self-adapt. param. and idle act.	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'99 80 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 80 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'99 80 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 80 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 80 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 80 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'99 80 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 80 16V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 80 16V	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'99 80 16V	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Live Data	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Special Functions	Electronic key release	
-	-	BRAVO-BRAVA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Special Functions	EGR(Exhaust Gas Recycling)	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F)	Live Data	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-2L-S)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-2L-S)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-2L-S)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-2L-S)	Live Data	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-2L)	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-2L)	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-2L)	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Breed MY 97 Airbag (2F-2L)	Live Data	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Borletti MCC55F Climate Control	Live Data	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	BRAVO-BRAVA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Teves ABS MK20/MK70	Read fault code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Teves ABS MK20/MK70	Erase fault code	-	
-	-	BRAVO-BRAVA	'99 JTD 105	Teves ABS MK20/MK70	Read data stream	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Climate Control	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Climate Control	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ABS	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (left)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (left)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (left)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (left)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (left)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (left)	Special Functions	System calibration	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (right)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (right)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (right)	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (right)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO VAN	1.6 MJET 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO VAN	1.6 MJET 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	ECO/SPORT switch replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Electropump replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch bleed	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	New actuators	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO VAN	1.6 MJET 16V	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Driver's Seat Lear 3	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO VAN	1.6 MJET 16V	Driver's Seat Lear 3	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Passenger's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Startup with code card	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector codes read	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Control unit replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	BRAVO VAN	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V	Convergence Lauberhorn C1	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	BRAVO VAN	1.6 MJET 16V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Climate Control	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Climate Control	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Climate Control	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Climate Control	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Climate Control	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ABS	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ABS	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ABS	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ABS	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ABS	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 VDC ABS	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (left)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (left)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (left)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (left)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (left)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (left)	Special Functions	System calibration	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (right)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (right)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (right)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Litronic Discharge Headlamp (right)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch 8 ASR ABS	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	ECO/SPORT switch replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Electropump replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch bleed	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	New actuators	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Key programming	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Siren serial line check	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Ultrasound sensor check	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Tilt sensor check (if present)	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Dusk and rain sensors check	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Indicators command enable/disable	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Body Computer 8	Special Functions	Inertia switch rearm (FIS)	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Driver's Seat Lear 3	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Passenger's Seat Lear 3	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	TRW Lane Control Control Unit (HALF)	Special Functions	System calibration	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Radio Navigator	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Radio Navigator	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Radio Navigator	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Radio Navigator	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Marelli Radio Navigator	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Convergence Lauberhorn C1	Live Data	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Convergence Lauberhorn C1	Actuation Test	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Continental Airbag (Proxy)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Continental Airbag (Proxy)	Read fault code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Continental Airbag (Proxy)	Erase fault code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Continental Airbag (Proxy)	Read data stream	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read fault code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Erase fault code	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read data stream	-	
-	-	BRAVO VAN	1.6 MJET 16V MY2014	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 06F Enhanced Injection	Read ECU Information	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 06F Enhanced Injection	Read Fault Code	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 06F Enhanced Injection	Erase Fault Code	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 06F Enhanced Injection	Live Data	-	
-	-	CINQUECENTO	1108 I.E. ECO	Magneti Marelli IAW 06F Enhanced Injection	Actuation Test	-	
-	-	CINQUECENTO	1108 I.E. ECO	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	CINQUECENTO	1108 I.E. ECO	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	CINQUECENTO	1108 I.E. ECO	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	CINQUECENTO	1108 I.E. ECO	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	CINQUECENTO	1108 I.E. ECO	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	CINQUECENTO	703 ECO	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	CINQUECENTO	703 ECO	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	CINQUECENTO	703 ECO	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	CINQUECENTO	703 ECO	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	CINQUECENTO	703 ECO	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Injection	Read ECU Information	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Injection	Read Fault Code	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Injection	Erase Fault Code	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Injection	Live Data	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Injection	Actuation Test	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Enhanced Injection	Read ECU Information	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Enhanced Injection	Read Fault Code	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Enhanced Injection	Erase Fault Code	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Enhanced Injection	Live Data	-	
-	-	CINQUECENTO	903 I.E ECO	Magneti Marelli IAW 06F Enhanced Injection	Actuation Test	-	
-	-	CINQUECENTO	903 I.E ECO	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	CINQUECENTO	903 I.E ECO	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	CINQUECENTO	903 I.E ECO	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	CINQUECENTO	903 I.E ECO	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	CINQUECENTO	903 I.E ECO	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	COUPE'	'01 1.8 16V CF3	Bosch 5.3 ABS	Read ECU Information	-	
-	-	COUPE'	'01 1.8 16V CF3	Bosch 5.3 ABS	Read Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	Bosch 5.3 ABS	Live Data	-	
-	-	COUPE'	'01 1.8 16V CF3	Bosch 5.3 ABS	Actuation Test	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	TRW MY 97 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	COUPE'	'01 1.8 16V CF3	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	COUPE'	'01 1.8 16V CF3	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	Borletti MCC55F Climate Control	Live Data	-	
-	-	COUPE'	'01 1.8 16V CF3	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	COUPE'	'01 1.8 16V CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	COUPE'	'01 1.8 16V CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	COUPE'	'01 1.8 16V CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	COUPE'	'01 1.8 16V CF3	Hitachi EOBD Injection	Read ECU Information	-	
-	-	COUPE'	'01 1.8 16V CF3	Hitachi EOBD Injection	Read Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	Hitachi EOBD Injection	Erase Fault Code	-	
-	-	COUPE'	'01 1.8 16V CF3	Hitachi EOBD Injection	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	COUPE'	'01 1.8 16V CF3	Hitachi EOBD Injection	Actuation Test	-	
-	-	COUPE'	'01 1.8 16V CF3	Hitachi EOBD Injection	Special Functions	Startup with code card	
-	-	COUPE'	16V ASPIRATO	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	COUPE'	16V ASPIRATO	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	COUPE'	16V ASPIRATO	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	COUPE'	16V ASPIRATO	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	COUPE'	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	COUPE'	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	COUPE'	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	COUPE'	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	COUPE'	16V ASPIRATO	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	COUPE'	16V TURBO	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	COUPE'	16V TURBO	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	COUPE'	16V TURBO	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	COUPE'	16V TURBO	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	COUPE'	16V TURBO	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	COUPE'	16V TURBO	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	COUPE'	16V TURBO	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	COUPE'	16V TURBO	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	COUPE'	16V TURBO	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	COUPE'	'96 1.8 16V	Hitachi MPI Injection	Read ECU Information	-	
-	-	COUPE'	'96 1.8 16V	Hitachi MPI Injection	Read Fault Code	-	
-	-	COUPE'	'96 1.8 16V	Hitachi MPI Injection	Erase Fault Code	-	
-	-	COUPE'	'96 1.8 16V	Hitachi MPI Injection	Live Data	-	
-	-	COUPE'	'96 1.8 16V	Hitachi MPI Injection	Actuation Test	-	
-	-	COUPE'	'96 1.8 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	COUPE'	'96 1.8 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	COUPE'	'96 1.8 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	COUPE'	'96 1.8 16V	Bosch 5.3 ABS	Live Data	-	
-	-	COUPE'	'96 1.8 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	COUPE'	'96 1.8 16V	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	COUPE'	'96 1.8 16V	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	COUPE'	'96 1.8 16V	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	COUPE'	'96 1.8 16V	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	COUPE'	'96 1.8 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	COUPE'	'96 1.8 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	COUPE'	'96 1.8 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	COUPE'	'96 1.8 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	COUPE'	'96 1.8 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	COUPE'	'96 1.8 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	COUPE'	'96 1.8 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	COUPE'	'96 1.8 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	COUPE'	'96 1.8 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	COUPE'	'96 1.8 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	COUPE'	'96 1.8 16V	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	COUPE'	'96 1.8 16V	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	COUPE'	'96 1.8 16V	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	COUPE'	'96 1.8 16V	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	COUPE'	'96 1.8 16V	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	COUPE'	'96 2.0 20V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	COUPE'	'96 2.0 20V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	COUPE'	'96 2.0 20V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 20V	Bosch 5.3 ABS	Live Data	-	
-	-	COUPE'	'96 2.0 20V	Bosch 5.3 ABS	Actuation Test	-	
-	-	COUPE'	'96 2.0 20V	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	COUPE'	'96 2.0 20V	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	COUPE'	'96 2.0 20V	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 20V	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	COUPE'	'96 2.0 20V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	COUPE'	'96 2.0 20V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	COUPE'	'96 2.0 20V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 20V	Borletti MCC55F Climate Control	Live Data	-	
-	-	COUPE'	'96 2.0 20V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	COUPE'	'96 2.0 20V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	COUPE'	'96 2.0 20V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	COUPE'	'96 2.0 20V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 20V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	COUPE'	'96 2.0 20V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	COUPE'	'96 2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Read ECU Information	-	
-	-	COUPE'	'96 2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Read Fault Code	-	
-	-	COUPE'	'96 2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Live Data	-	
-	-	COUPE'	'96 2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Actuation Test	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch 5.3 ABS	Live Data	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch 5.3 ABS	Actuation Test	-	
-	-	COUPE'	'96 2.0 TURBO 20V	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	COUPE'	'96 2.0 TURBO 20V	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Borletti MCC55F Climate Control	Live Data	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	COUPE'	'96 2.0 TURBO 20V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	COUPE'	'96 2.0 TURBO 20V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	COUPE'	'96 2.0 TURBO 20V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch Motronic M2.10.4 Injection (2.0 20v T eng.)	Read Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch Motronic M2.10.4 Injection (2.0 20v T eng.)	Erase Fault Code	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch Motronic M2.10.4 Injection (2.0 20v T eng.)	Live Data	-	
-	-	COUPE'	'96 2.0 TURBO 20V	Bosch Motronic M2.10.4 Injection (2.0 20v T eng.)	Actuation Test	-	
-	-	COUPE'	'98 1.8 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	COUPE'	'98 1.8 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	COUPE'	'98 1.8 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	COUPE'	'98 1.8 16V	Bosch 5.3 ABS	Live Data	-	
-	-	COUPE'	'98 1.8 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	COUPE'	'98 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Read ECU Information	-	
-	-	COUPE'	'98 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Read Fault Code	-	
-	-	COUPE'	'98 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Erase Fault Code	-	
-	-	COUPE'	'98 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Live Data	-	
-	-	COUPE'	'98 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Actuation Test	-	
-	-	COUPE'	'98 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Special Functions	Startup with code card	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F-2P-2L-I)	Read ECU Information	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F-2P-2L-I)	Read Fault Code	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F-2P-2L-I)	Erase Fault Code	-	
-	-	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F-2P-2L-I)	Live Data	-	
-	-	COUPE'	'98 1.8 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	COUPE'	'98 1.8 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	COUPE'	'98 1.8 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	COUPE'	'98 1.8 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	COUPE'	'98 1.8 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	COUPE'	'98 1.8 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	COUPE'	'98 1.8 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	COUPE'	'98 1.8 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	COUPE'	'98 1.8 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	COUPE'	'98 1.8 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	COUPE'	'98 2.0 20V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	COUPE'	'98 2.0 20V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	COUPE'	'98 2.0 20V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	COUPE'	'98 2.0 20V	Bosch 5.3 ABS	Live Data	-	
-	-	COUPE'	'98 2.0 20V	Bosch 5.3 ABS	Actuation Test	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	COUPE'	'98 2.0 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Read ECU Information	-	
-	-	COUPE'	'98 2.0 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Read Fault Code	-	
-	-	COUPE'	'98 2.0 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Erase Fault Code	-	
-	-	COUPE'	'98 2.0 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Live Data	-	
-	-	COUPE'	'98 2.0 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Actuation Test	-	
-	-	COUPE'	'98 2.0 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Special Functions	Startup with code card	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-2P-2L-I)	Read ECU Information	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-2P-2L-I)	Read Fault Code	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-2P-2L-I)	Erase Fault Code	-	
-	-	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-2P-2L-I)	Live Data	-	
-	-	COUPE'	'98 2.0 20V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	COUPE'	'98 2.0 20V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	COUPE'	'98 2.0 20V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	COUPE'	'98 2.0 20V	Borletti MCC55F Climate Control	Live Data	-	
-	-	COUPE'	'98 2.0 20V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	COUPE'	'98 2.0 20V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	COUPE'	'98 2.0 20V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	COUPE'	'98 2.0 20V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	COUPE'	'98 2.0 20V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	COUPE'	'98 2.0 20V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch 5.3 ABS	Live Data	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch Motronic M1.7 Injection (2.0 16v eng.)	Read Fault Code	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch Motronic M1.7 Injection (2.0 16v eng.)	Erase Fault Code	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch Motronic M1.7 Injection (2.0 16v eng.)	Live Data	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch Motronic M1.7 Injection (2.0 16v eng. El. key)	Read Fault Code	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch Motronic M1.7 Injection (2.0 16v eng. El. key)	Erase Fault Code	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch Motronic M1.7 Injection (2.0 16v eng. El. key)	Live Data	-	
-	-	CROMA (154)	'92 2.0 I.E 16V	Bosch Motronic M1.7 Injection (2.0 16v eng. El. key)	Actuation Test	-	
-	-	CROMA (154)	'92 2.5 V6	Bosch Motronic M1.7 Injection (V6 2.5 El. Key eng.)	Read Fault Code	-	
-	-	CROMA (154)	'92 2.5 V6	Bosch Motronic M1.7 Injection (V6 2.5 El. Key eng.)	Erase Fault Code	-	
-	-	CROMA (154)	'92 2.5 V6	Bosch Motronic M1.7 Injection (V6 2.5 El. Key eng.)	Live Data	-	
-	-	CROMA (154)	'92 2.5 V6	Bosch Motronic M1.7 Injection (V6 2.5 El. Key eng.)	Actuation Test	-	
-	-	CROMA (154)	'92 2.5 V6	Bosch Motronic M1.7 Injection (V6 2.5 eng.)	Read Fault Code	-	
-	-	CROMA (154)	'92 2.5 V6	Bosch Motronic M1.7 Injection (V6 2.5 eng.)	Live Data	-	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Special Functions	Yaw sensor calibration	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Special Functions	Lateral accel. sensor calibration	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Special Functions	Pressure sensor calibration	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Special Functions	Longit. acc. sensor calibration	
-	-	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	Special Functions	Steering angle calibration	
-	-	CROMA (194)	1.8 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Valeo Parking Control Unit	Live Data	-	
-	-	CROMA (194)	1.8 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	CROMA (194)	1.8 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-2T-I)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-2T-I)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-2T-I)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-2T-I)	Live Data	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-2T-I)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-2T-I)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-I)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-I)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-I)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-I)	Live Data	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-I)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-I)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	1.8 16V	Driver's Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Driver's Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Driver's Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Driver's Seat Lear 2	Live Data	-	
-	-	CROMA (194)	1.8 16V	Driver's Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Passenger Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Passenger Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Passenger Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Passenger Seat Lear 2	Live Data	-	
-	-	CROMA (194)	1.8 16V	Passenger Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	CROMA (194)	1.8 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Live Data	-	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Special Functions	Headlamp pos. correct.	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Special Functions	Inputs status	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Special Functions	Servicing information delete	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Special Functions	Reset odometer	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm exclusion	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm enable	
-	-	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	Special Functions	Instrument panel replacement	
-	-	CROMA (194)	1.8 16V	Driver's Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Driver's Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Driver's Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Driver's Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.8 16V	Driver's Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Live Data	-	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Special Functions	LH distribution flap learn	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Special Functions	LH mixing flap learn	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Special Functions	RH distribution flap learn	
-	-	CROMA (194)	1.8 16V	Valeo Climate Control (Two-zone)	Special Functions	RH mixing flap learn	
-	-	CROMA (194)	1.8 16V	Passenger Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Passenger Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Passenger Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Passenger Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.8 16V	Passenger Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Boot G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Boot G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Boot G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Boot G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.8 16V	Boot G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Poor Steering TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Poor Steering TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Poor Steering TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Poor Steering TRW 2	Live Data	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Live Data	-	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Special Functions	Siren serial line check	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Special Functions	Ultrasound sensor check	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Special Functions	Tilt sensor check (if present)	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Special Functions	Dusk and rain sensors check	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Special Functions	Window wash system check	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Special Functions	Power mode gearbox	
-	-	CROMA (194)	1.8 16V	Body Computer Marelli 3	Special Functions	Indicators command enable/disable	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Live Data	-	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Special Functions	Steering lock/unlock	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Special Functions	Key command	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Special Functions	Seat heating relay (if present)	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Special Functions	Electropump replacement	
-	-	CROMA (194)	1.8 16V	Steering Lock TRW 2	Special Functions	End of line / service self-calibration	
-	-	CROMA (194)	1.8 16V	Electronic Key TRW (Teg Reader)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Electronic Key TRW (Teg Reader)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Electronic Key TRW (Teg Reader)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Electronic Key TRW (Teg Reader)	Live Data	-	
-	-	CROMA (194)	1.8 16V	Electronic Key TRW (Teg Reader)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	CROMA (194)	1.8 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (eng. 1.8)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (eng. 1.8)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (eng. 1.8)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (eng. 1.8)	Live Data	-	
-	-	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (eng. 1.8)	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (eng. 1.8)	Special Functions	Zeroing of self-adaption parameters	
-	-	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (eng. 1.8)	Special Functions	Phonic wheel learn reset	
-	-	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (eng. 1.8)	Special Functions	Startup with code card	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	1.8 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	1.8 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Marelli Radio Navigator	Live Data	-	
-	-	CROMA (194)	1.8 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Special Functions	Yaw sensor calibration	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Special Functions	Lateral accel. sensor calibration	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Special Functions	Pressure sensor calibration	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Special Functions	Longit. acc. sensor calibration	
-	-	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	Special Functions	Steering angle calibration	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Parking Control Unit	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Seat Lear 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Seat Lear 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Special Functions	Headlamp pos. correct.	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Special Functions	Inputs status	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Special Functions	Servicing information delete	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Special Functions	Reset odometer	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm exclusion	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm enable	
-	-	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	Special Functions	Instrument panel replacement	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Driver's Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Special Functions	LH distribution flap learn	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Special Functions	LH mixing flap learn	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Special Functions	RH distribution flap learn	
-	-	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-zone)	Special Functions	RH mixing flap learn	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Passenger Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Boot G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Boot G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Boot G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Boot G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Boot G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Poor Steering TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Poor Steering TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Poor Steering TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Poor Steering TRW 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Special Functions	Siren serial line check	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Special Functions	Ultrasound sensor check	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Special Functions	Tilt sensor check (if present)	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Special Functions	Dusk and rain sensors check	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Special Functions	Window wash system check	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Special Functions	Power mode gearbox	
-	-	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	Special Functions	Indicators command enable/disable	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Special Functions	Steering lock/unlock	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Special Functions	Key command	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Special Functions	Seat heating relay (if present)	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Special Functions	Electropump replacement	
-	-	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	Special Functions	End of line / service self-calibration	
-	-	CROMA (194)	1.9 MJET 16V	Electronic Key TRW (Teg Reader)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Electronic Key TRW (Teg Reader)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	1.9 MJET 16V	Electronic Key TRW (Teg Reader)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Electronic Key TRW (Teg Reader)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Electronic Key TRW (Teg Reader)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	CROMA (194)	1.9 MJET 16V	Automatic Gearbox Aisin AF40-6	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Automatic Gearbox Aisin AF40-6	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Automatic Gearbox Aisin AF40-6	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Automatic Gearbox Aisin AF40-6	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Automatic Gearbox Aisin AF40-6	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Automatic Gearbox Aisin AF40-6	Special Functions	Gearbox lever position learn	
-	-	CROMA (194)	1.9 MJET 16V	Automatic Gearbox Aisin AF40-6	Special Functions	Self-adaptation parameter erasure	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	1.9 MJET 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli Radio Navigator	Live Data	-	
-	-	CROMA (194)	1.9 MJET 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Special Functions	Yaw sensor calibration	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Special Functions	Lateral accel. sensor calibration	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Special Functions	Pressure sensor calibration	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Special Functions	Longit. acc. sensor calibration	
-	-	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	Special Functions	Steering angle calibration	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Parking Control Unit	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Startup with code card	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Seat Lear 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Seat Lear 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Special Functions	Headlamp pos. correct.	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Special Functions	Inputs status	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Special Functions	Servicing information delete	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Special Functions	Reset odometer	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm exclusion	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm enable	
-	-	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	Special Functions	Instrument panel replacement	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Driver's Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Special Functions	LH distribution flap learn	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Special Functions	LH mixing flap learn	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Special Functions	RH distribution flap learn	
-	-	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-zone)	Special Functions	RH mixing flap learn	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Passenger Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Boot G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Boot G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Boot G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Boot G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Boot G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Poor Steering TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Poor Steering TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Poor Steering TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Poor Steering TRW 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Special Functions	Siren serial line check	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Special Functions	Ultrasound sensor check	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Special Functions	Tilt sensor check (if present)	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Special Functions	Dusk and rain sensors check	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Special Functions	Window wash system check	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Special Functions	Power mode gearbox	
-	-	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	Special Functions	Indicators command enable/disable	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Special Functions	Steering lock/unlock	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Special Functions	Key command	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Special Functions	Seat heating relay (if present)	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Special Functions	Electropump replacement	
-	-	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	Special Functions	End of line / service self-calibration	
-	-	CROMA (194)	1.9 MJET 8V	Electronic Key TRW (Teg Reader)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Electronic Key TRW (Teg Reader)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Electronic Key TRW (Teg Reader)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Electronic Key TRW (Teg Reader)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Electronic Key TRW (Teg Reader)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft Convergence	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	1.9 MJET 8V	Marelli Radio Navigator	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli Radio Navigator	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli Radio Navigator	Live Data	-	
-	-	CROMA (194)	1.9 MJET 8V	Marelli Radio Navigator	Actuation Test	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Aisin YLII 5 Automatic Gearbox(1)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Aisin YLII 5 Automatic Gearbox(1)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Aisin YLII 5 Automatic Gearbox(1)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Aisin YLII 5 Automatic Gearbox(1)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Aisin YLII 5 Automatic Gearbox(1)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Special Functions	Yaw sensor calibration	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Special Functions	Lateral accel. sensor calibration	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Special Functions	Pressure sensor calibration	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Special Functions	Longit. acc. sensor calibration	
-	-	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	Special Functions	Steering angle calibration	
-	-	CROMA (194)	2.2 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Valeo Parking Control Unit	Live Data	-	
-	-	CROMA (194)	2.2 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	CROMA (194)	2.2 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	2.2 16V	Driver's Seat Lear 2	Read ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	2.2 16V	Driver's Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Driver's Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Driver's Seat Lear 2	Live Data	-	
-	-	CROMA (194)	2.2 16V	Driver's Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Passenger Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Passenger Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Passenger Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Passenger Seat Lear 2	Live Data	-	
-	-	CROMA (194)	2.2 16V	Passenger Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Live Data	-	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Special Functions	Headlamp pos. correct.	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Special Functions	Inputs status	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Special Functions	Servicing information delete	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Special Functions	Reset odometer	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm exclusion	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm enable	
-	-	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	Special Functions	Instrument panel replacement	
-	-	CROMA (194)	2.2 16V	Driver's Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Driver's Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Driver's Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Driver's Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	2.2 16V	Driver's Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Special Functions	LH distribution flap learn	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Special Functions	LH mixing flap learn	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Special Functions	RH distribution flap learn	
-	-	CROMA (194)	2.2 16V	Valeo Climate Control (Two-zone)	Special Functions	RH mixing flap learn	
-	-	CROMA (194)	2.2 16V	Passenger Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Passenger Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Passenger Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Passenger Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	2.2 16V	Passenger Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Boot G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Boot G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Boot G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Boot G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	2.2 16V	Boot G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Poor Steering TRW 2	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Poor Steering TRW 2	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Poor Steering TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Poor Steering TRW 2	Live Data	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Live Data	-	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Special Functions	Siren serial line check	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Special Functions	Ultrasound sensor check	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Special Functions	Tilt sensor check (if present)	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Special Functions	Dusk and rain sensors check	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Special Functions	Window wash system check	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Special Functions	Power mode gearbox	
-	-	CROMA (194)	2.2 16V	Body Computer Marelli 3	Special Functions	Indicators command enable/disable	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Live Data	-	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Special Functions	Steering lock/unlock	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Special Functions	Key command	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Special Functions	Seat heating relay (if present)	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Special Functions	Electropump replacement	
-	-	CROMA (194)	2.2 16V	Steering Lock TRW 2	Special Functions	End of line / service self-calibration	
-	-	CROMA (194)	2.2 16V	Electronic Key TRW (Teg Reader)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Electronic Key TRW (Teg Reader)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Electronic Key TRW (Teg Reader)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Electronic Key TRW (Teg Reader)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Electronic Key TRW (Teg Reader)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	2.2 16V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	CROMA (194)	2.2 16V	Motorola Injection CF4/E0BD (eng. 2.2)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Motorola Injection CF4/E0BD (eng. 2.2)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Motorola Injection CF4/E0BD (eng. 2.2)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Motorola Injection CF4/E0BD (eng. 2.2)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Motorola Injection CF4/E0BD (eng. 2.2)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Motorola Injection CF4/E0BD (eng. 2.2)	Special Functions	Cruise control learn zeroing	
-	-	CROMA (194)	2.2 16V	Motorola Injection CF4/E0BD (eng. 2.2)	Special Functions	Phonic wheel learn reset	
-	-	CROMA (194)	2.2 16V	Motorola Injection CF4/E0BD (eng. 2.2)	Special Functions	Startup with code card	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	2.2 16V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	2.2 16V	Marelli Radio Navigator	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Marelli Radio Navigator	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Marelli Radio Navigator	Live Data	-	
-	-	CROMA (194)	2.2 16V	Marelli Radio Navigator	Actuation Test	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Special Functions	Yaw sensor calibration	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Special Functions	Lateral accel. sensor calibration	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Special Functions	Pressure sensor calibration	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Special Functions	Longit. acc. sensor calibration	
-	-	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	Special Functions	Steering angle calibration	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Parking Control Unit	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	Special Functions	Accept configuration	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPP)	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Seat Lear 2	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Seat Lear 2	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Seat Lear 2	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Seat Lear 2	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Seat Lear 2	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Seat Lear 2	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Left)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Left)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Left)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Left)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Left)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Left)	Special Functions	System calibration	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Special Functions	Headlamp pos. correct.	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Special Functions	Inputs status	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Special Functions	Servicing information delete	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Special Functions	Reset odometer	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm exclusion	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Special Functions	Seat belts alarm enable	
-	-	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	Special Functions	Instrument panel replacement	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Driver's Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Special Functions	LH distribution flap learn	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Special Functions	LH mixing flap learn	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Special Functions	RH distribution flap learn	
-	-	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-zone)	Special Functions	RH mixing flap learn	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Door G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Door G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Door G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Door G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Passenger Door G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Boot G.E. Procond 3	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Boot G.E. Procond 3	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Boot G.E. Procond 3	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Boot G.E. Procond 3	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Boot G.E. Procond 3	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Poor Steering TRW 2	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Poor Steering TRW 2	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Poor Steering TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Poor Steering TRW 2	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-2P-2L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Special Functions	Siren serial line check	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Special Functions	Ultrasound sensor check	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Special Functions	Tilt sensor check (if present)	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Special Functions	Dusk and rain sensors check	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Special Functions	Window wash system check	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Special Functions	Power mode gearbox	
-	-	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	Special Functions	Indicators command enable/disable	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Special Functions	Steering lock/unlock	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Special Functions	Key command	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Special Functions	Seat heating relay (if present)	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Special Functions	Electropump replacement	
-	-	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	Special Functions	End of line / service self-calibration	
-	-	CROMA (194)	2.4 MJET 20V	Electronic Key TRW (Teg Reader)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Electronic Key TRW (Teg Reader)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Electronic Key TRW (Teg Reader)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Electronic Key TRW (Teg Reader)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Electronic Key TRW (Teg Reader)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Special Functions	Antenna replacement	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Special Functions	Control unit replacement	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Special Functions	Alarm deletion	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Special Functions	Wheel transmitters learning	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Special Functions	Control unit activation	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Special Functions	Control unit deactivation	
-	-	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW 2	Special Functions	Alarm state check	
-	-	CROMA (194)	2.4 MJET 20V	Automatic Gearbox Aisin AF40-6	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Automatic Gearbox Aisin AF40-6	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Automatic Gearbox Aisin AF40-6	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Automatic Gearbox Aisin AF40-6	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Automatic Gearbox Aisin AF40-6	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Automatic Gearbox Aisin AF40-6	Special Functions	Gearbox lever position learn	
-	-	CROMA (194)	2.4 MJET 20V	Automatic Gearbox Aisin AF40-6	Special Functions	Self-adaptation parameter erasure	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft Convergence	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Airbag TRW MY 03 (2F-4P-4L-2T-1G-1)	Special Functions	Memory mode write	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	CROMA (194)	2.4 MJET 20V	Marelli Radio Navigator	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli Radio Navigator	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli Radio Navigator	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli Radio Navigator	Live Data	-	
-	-	CROMA (194)	2.4 MJET 20V	Marelli Radio Navigator	Actuation Test	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Right)	Read ECU Information	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Right)	Read Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Right)	Erase Fault Code	-	
-	-	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Right)	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 59F Injection	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 59F Injection	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 59F Injection	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 59F Injection	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 59F Injection	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 59F Injection	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' (119)	1.2 8V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.2 8V	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Cluster	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	DOBLO' (119)	1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' (119)	1.2 8V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.2 8V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' (119)	1.2 8V	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' (119)	1.2 8V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' (119)	1.2 8V	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' (119)	1.3 JTD	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.3 JTD	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Cluster	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 1 injector classification	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 2 injector classification	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 3 injector classification	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 4 injector classification	
-	-	DOBLO' (119)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector classification (4 cyl. bank)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' (119)	1.3 JTD	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' (119)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	DOBLO' (119)	1.3 JTD	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' (119)	1.3 JTD	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' (119)	1.3 JTD	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' (119)	1.3 JTD	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' (119)	1.4 8V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.4 8V	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Cluster	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' (119)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phonic wheel learn reset	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Throttle learn storage	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Vehicle configuration deletion	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Cruise control learn	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Air conditioner learn	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phase sensor learn zeroing	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Erase Fault Code	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Live Data	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Actuation Test	-	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Phonic wheel learn reset	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Throttle learn storage	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Vehicle configuration deletion	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Cruise control learn	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Air conditioner learn	
-	-	DOBLO' (119)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Phase sensor learn zeroing	
-	-	DOBLO' (119)	1.4 8V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' (119)	1.4 8V	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' (119)	1.4 8V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' (119)	1.4 8V	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' (119)	1.6 16V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.6 16V	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Cluster	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Throttle learn storage	
-	-	DOBLO' (119)	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Throttle learn storage	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.6 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' (119)	1.6 16V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (119)	1.6 16V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' (119)	1.6 16V	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' (119)	1.6 16V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' (119)	1.6 16V	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' (119)	1.8 8V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.8 8V	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Cluster	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.8 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' (119)	1.8 8V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Read Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Live Data	-	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Actuation Test	-	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Self-adapting parameters zeroing (air)	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Self-adapting parameters zeroing (knock)	
-	-	DOBLO' (119)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Zeroing fan mode learn	
-	-	DOBLO' (119)	1.8 8V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' (119)	1.8 8V	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' (119)	1.8 8V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' (119)	1.8 8V	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' (119)	1.9 DS	Lucas Epic DCU3F Diesel Injection	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Lucas Epic DCU3F Diesel Injection	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Lucas Epic DCU3F Diesel Injection	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Lucas Epic DCU3F Diesel Injection	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Lucas Epic DCU3F Diesel Injection	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Lucas Epic DCU3F Diesel Injection	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' (119)	1.9 DS	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.9 DS	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Cluster	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Read ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.9 DS	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' (119)	1.9 DS	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.9 DS	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 DS	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' (119)	1.9 DS	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' (119)	1.9 DS	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-I)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-I)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-I)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-I)	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-I)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-I)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-I)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-I)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-I)	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-I)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' (119)	1.9 JTD	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.9 JTD	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Cluster	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	DOBLO' (119)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' (119)	1.9 JTD	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Live Data	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Actuation Test	-	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Startup with code card	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	DOBLO' (119)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' (119)	1.9 JTD	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' (119)	1.9 JTD	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' (119)	1.9 JTD	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' (119)	1.9 JTD	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Cluster	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Lambda sensor check	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Startup with code card	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Read Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Erase Fault Code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Actuation Test	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injector 1	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injector 2	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injector 3	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injector 4	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Petrol pump relay	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas solenoid valve relay	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injectors relay	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' (119)	BIPOWER-GPOWER	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Key programming	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (152)	1.3 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (152)	1.3 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Air bag (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Air bag (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Air bag (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Air bag (EP)	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Air bag (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read fault code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Erase fault code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read data stream	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector codes read	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Neutral signal learn	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Air flow meter sensor replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Differential pressure sensor replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Mechanical waste-gate valve replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Oil change	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Phonic wheel replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement lambda sensor	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter regeneration	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Startup with code card	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Throttle test	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	EGR valve test	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Glow plug preheating circuit test	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Automatic configuration read	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (152)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (152)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (152)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Key programming	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Inertia switch rear (FIS)	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (152)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (152)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (152)	1.4 16V	Bosch Air bag(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Air bag(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Air bag(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Air bag(EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Air bag(EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.4 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Knock counter reset	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Overboost counter reset	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Read fault code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Erase fault code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Read data stream	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Special Functions	Neutral signal learn	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Special Functions	Overboost counter reset	
-	-	DOBLO' (152)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/E0BD (1.4 eng.)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (152)	1.4 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (152)	1.4 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (152)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (152)	1.4 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.4 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Key programming	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (152)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (152)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Air bag(EP)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Air bag(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Air bag(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Air bag(EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Air bag(EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read fault code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Erase fault code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read data stream	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Neutral signal learn	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Overboost counter reset	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (152)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Knock counter reset	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Overboost counter reset	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (152)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (152)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer(EP) 5	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Key programming	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (152)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (152)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Air bag (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Air bag (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Air bag (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Air bag (EP)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Air bag (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Gearbox oil accumulator replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Control unit replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Gearbox replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Hydraulic kit replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Clutch replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Tunnel lever replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Steering wheel levers replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Longitudinal acceleration signal learn	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	ECO/SPORT switch replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Pump relay replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Electropump replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Sensor replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector codes read	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Manual system configuration	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration read	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration write	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Startup with code card	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve test	
-	-	DOBLO' (152)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Glow plug preheating circuit test	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (152)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (152)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read fault code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Erase fault code	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read data stream	-	
-	-	DOBLO' (152)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Key programming	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (152)	2.0 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (152)	2.0 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Air bag(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Air bag(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Air bag(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Air bag(EP)	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Air bag(EP)	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector codes read	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Manual system configuration	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration read	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration write	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Startup with code card	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve test	
-	-	DOBLO' (152)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Glow plug preheating circuit test	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (152)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (152)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ E0BD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ E0BD CAN (EP 1.6/2.0 eng.)	Read fault code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ E0BD CAN (EP 1.6/2.0 eng.)	Erase fault code	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ E0BD CAN (EP 1.6/2.0 eng.)	Read data stream	-	
-	-	DOBLO' (152)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ E0BD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Key programming	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (152)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (152)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Air bag(EP)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Air bag(EP)	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Air bag(EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Air bag(EP)	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Air bag(EP)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Knock sensor and/or spark plug replacement	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Timing sensor and/or cam replacement	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Supercharging system components replacement	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Startup with code card	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Read fault code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Erase fault code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Read data stream	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (152)	NATURAL POWER	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (152)	NATURAL POWER	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (152)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (152)	NATURAL POWER	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (152)	NATURAL POWER	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (152)	NATURAL POWER	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (152)	NATURAL POWER	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (152)	NATURAL POWER	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (152)	NATURAL POWER	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Key programming	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (263)	1.3 MJET 16V	Delphi Body Computer(EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (263)	1.3 MJET 16V	Continental MK60EC ABS(EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag(EP)	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag(EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	EGR valve test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read fault code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Erase fault code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read data stream	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector codes read	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Neutral signal learn	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Air flow meter sensor replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Differential pressure sensor replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Mechanical waste-gate valve replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Oil change	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Phonic wheel replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement lambda sensor	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter regeneration	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Startup with code card	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Throttle test	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	EGR valve test	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Glow plug preheating circuit test	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Automatic configuration read	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (263)	1.3 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (263)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (263)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Key programming	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (263)	1.4 16V	Delphi Body Computer(EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (263)	1.4 16V	Continental MK60EC ABS(EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag(EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag(EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.4 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Knock counter reset	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Overboost counter reset	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read fault code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Erase fault code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read data stream	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Neutral signal learn	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Overboost counter reset	
-	-	DOBLO' (263)	1.4 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (263)	1.4 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (263)	1.4 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (263)	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (263)	1.4 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.4 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Key programming	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (263)	1.4 TURBO 16V	Delphi Body Computer(EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (263)	1.4 TURBO 16V	Continental MK60EC ABS(EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag(EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag(EP)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read fault code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Erase fault code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Read data stream	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Neutral signal learn	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Overboost counter reset	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me17.3.0 CF6/EOBD (1.4 eng.)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (263)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Knock counter reset	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Overboost counter reset	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (263)	1.4 TURBO 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (263)	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Actuation Test	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Key programming	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (263)	1.6 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (263)	1.6 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Gearbox oil accumulator replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Control unit replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Gearbox replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Hydraulic kit replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Clutch replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Tunnel lever replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Steering wheel levers replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Longitudinal acceleration signal learn	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	ECO/SPORT switch replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Pump relay replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Electropump replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Sensor replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector codes read	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Manual system configuration	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration read	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration write	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Startup with code card	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve test	
-	-	DOBLO' (263)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Glow plug preheating circuit test	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (263)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (263)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read fault code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Erase fault code	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read data stream	-	
-	-	DOBLO' (263)	1.6 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso 3 Mono-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Key programming	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Indicators command enable/disable	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (263)	2.0 MJET 16V	Delphi Body Computer (EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (263)	2.0 MJET 16V	Continental MK60EC ABS (EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP)	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP)	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector codes read	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Manual system configuration	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration read	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration write	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Startup with code card	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve test	
-	-	DOBLO' (263)	2.0 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Glow plug preheating circuit test	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (263)	2.0 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (263)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	2.0 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read fault code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Erase fault code	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Read data stream	-	
-	-	DOBLO' (263)	2.0 MJET 16V	Bosch diesel injection EDC17C49 CF5/5+ EOBD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso 3 Mono-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Key programming	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Inertia switch rearm (FIS)	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Indicators command enable/disable	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Country standards change	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Power mode gearbox	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Roof control unit initialisation	
-	-	DOBLO' (263)	NATURAL POWER	Delphi Body Computer(EP) 5	Special Functions	Exit shipping mode	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Steering angle reset	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Steering angle calibration	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Pressure sensor calibration	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Load valves calibration	
-	-	DOBLO' (263)	NATURAL POWER	Continental MK60EC ABS(EP)	Special Functions	Pilot valves calibration	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag(EP)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag(EP)	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag(EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag(EP)	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag(EP)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag (EP) 2	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag (EP) 2	Read fault code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag (EP) 2	Erase fault code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag (EP) 2	Read data stream	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Airbag (EP) 2	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Knock sensor and/or spark plug replacement	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Timing sensor and/or cam replacement	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Supercharging system components replacement	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Me7.9.10 CF5/E0BD Injection (EP 1.4 eng.)	Special Functions	Startup with code card	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Read fault code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Erase fault code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Read data stream	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Motronic Injection Me17.3.0 CF6/E0BD CNG (EP eng. 1.4)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' (263)	NATURAL POWER	Denso Heater (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso Heater (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso Heater (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso Heater (EP)	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Denso Heater (EP)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	NATURAL POWER	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DOBLO' (263)	NATURAL POWER	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	DOBLO' (263)	NATURAL POWER	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	DOBLO' (263)	NATURAL POWER	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DOBLO' (263)	NATURAL POWER	Lauberhorn Convergence (EP)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' (263)	NATURAL POWER	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DOBLO' (263)	NATURAL POWER	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DOBLO' (263)	NATURAL POWER	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DOBLO' (263)	NATURAL POWER	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DOBLO' (263)	NATURAL POWER	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' CARGO (223)	1.3 JTD	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Cluster	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 1 injector classification	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 2 injector classification	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 3 injector classification	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 4 injector classification	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector classification (4 cyl. bank)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	DOBLO' CARGO (223)	1.3 JTD	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' CARGO (223)	1.3 JTD	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-I)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-I)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-I)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-I)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (2F-2P-I)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' CARGO (223)	1.4 8V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Cluster	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' CARGO (223)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Startup with code card	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phonic wheel learn reset	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Throttle learn storage	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Vehicle configuration deletion	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Cruise control learn	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Air conditioner learn	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phase sensor learn zeroing	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Live Data	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Startup with code card	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Phonic wheel learn reset	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Throttle learn storage	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Vehicle configuration deletion	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Cruise control learn	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Air conditioner learn	
-	-	DOBLO' CARGO (223)	1.4 8V	Magneti Marelli IAW 5SF Injection (eng. 1.4 8v) Extra EEC	Special Functions	Phase sensor learn zeroing	
-	-	DOBLO' CARGO (223)	1.4 8V	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' CARGO (223)	1.4 8V	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' CARGO (223)	1.9 JTD	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Cluster	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch EDC15 CF3/E0BD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch EDC15 CF3/E0BD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch EDC15 CF3/E0BD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' CARGO (223)	1.9 JTD	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Live Data	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' CARGO (223)	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DOBLO' CARGO (223)	1.9 JTD	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' CARGO (223)	1.9 JTD	Teves ABS MK20/MK70	Read data stream	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Autoliv MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Cluster	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Cluster	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Cluster	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Cluster	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Cluster	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Metatron 6A0 Gas Injection	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Lambda sensor check	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Startup with code card	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Read Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Erase Fault Code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Live Data	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Actuation Test	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 1	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 2	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 3	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 4	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Petrol pump relay	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas solenoid valve relay	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injectors relay	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Zeroing of self-adaption parameters	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Teves ABS MK20/MK70	Read ECU Information	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Teves ABS MK20/MK70	Read fault code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Teves ABS MK20/MK70	Erase fault code	-	
-	-	DOBLO' CARGO (223)	BIPOWER-GPOWER	Teves ABS MK20/MK70	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO FL (250)	2.0 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO FL (250)	2.0 JTD	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO FL (250)	2.0 JTD	Continental Air Springs	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Continental Air Springs	Read Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Continental Air Springs	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Continental Air Springs	Live Data	-	
-	-	DUCATO FL (250)	2.0 JTD	Continental Air Springs	Special Functions	Vehicle geometry height setting	
-	-	DUCATO FL (250)	2.0 JTD	Continental Air Springs	Special Functions	Forced trim correction	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DUCATO FL (250)	2.0 JTD	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.0 JTD	Lauberhorn Convergence (EP)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO FL (250)	2.0 JTD	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DUCATO FL (250)	2.0 JTD	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DUCATO FL (250)	2.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Read fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Recognition of speed sensor type	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Static test	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Steering angle calibration	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	CMM intervention	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 (EP)	Read fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 (EP)	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 (EP)	Special Functions	Recognition of speed sensor type	
-	-	DUCATO FL (250)	2.0 JTD	Bosch ABS 9 (EP)	Special Functions	Static test	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Read fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Erase fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Special Functions	Key programming	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Special Functions	Indicators command enable/disable	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Special Functions	Country standards change	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Special Functions	Power mode gearbox	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Special Functions	Driver's side wind. lift. motion	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Special Functions	Pass. side wind.lift. motion	
-	-	DUCATO FL (250)	2.0 JTD	Marelli 11 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Read fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Erase fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Special Functions	Headlamp pos. correct.	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Special Functions	Servicing information delete	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Special Functions	Reset odometer	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Special Functions	Seat belts alarm exclusion	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Special Functions	Seat belts alarm enable	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Special Functions	Instrument panel replacement	
-	-	DUCATO FL (250)	2.0 JTD	Marelli Cluster (EP) 4	Special Functions	Chronotachigraph control unit (CCT)	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxy) 2	Read fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxy) 2	Erase fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	TRW Airbag (EP-Proxy) 2	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Read fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Erase fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Actuation Test	-	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Injector codes read	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Differential pressure sensor replacement	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	EGR valve replacement	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Oil change	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Speed limit setting	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Particulate filter regeneration	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Startup with code card	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	EGR valve test	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Glow plug preheating circuit test	
-	-	DUCATO FL (250)	2.0 JTD	Bosch Diesel Injection EDC17C49 CF5/5+ EOBD CAN (EP 2.0 eng.)	Special Functions	Control unit replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read ECU Information	-	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Erase fault code	-	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read data stream	-	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Pump relay replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Tunnel lever replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Control unit replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Gearbox replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Hydraulic kit replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Gearbox oil accumulator replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Clutch replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Electropump replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Sensor replacement	
-	-	DUCATO FL (250)	2.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	'UP Function' switch replacement	
-	-	DUCATO FL (250)	2.3 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO FL (250)	2.3 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO FL (250)	2.3 JTD	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO FL (250)	2.3 JTD	Continental Air Springs	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Continental Air Springs	Read Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Continental Air Springs	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Continental Air Springs	Live Data	-	
-	-	DUCATO FL (250)	2.3 JTD	Continental Air Springs	Special Functions	Vehicle geometry height setting	
-	-	DUCATO FL (250)	2.3 JTD	Continental Air Springs	Special Functions	Forced trim correction	
-	-	DUCATO FL (250)	2.3 JTD	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DUCATO FL (250)	2.3 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DUCATO FL (250)	2.3 JTD	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DUCATO FL (250)	2.3 JTD	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DUCATO FL (250)	2.3 JTD	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	DUCATO FL (250)	2.3 JTD	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DUCATO FL (250)	2.3 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Denso Single-Zone Automatic Climate Control (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read data stream	-	
-	-	DUCATO FL (250)	2.3 JTD	Denso Single-Zone Automatic Climate Control (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Denso Single-Zone Automatic Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Read fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Read data stream	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Recognition of speed sensor type	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Static test	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Steering angle calibration	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 ESP (EP)	Special Functions	CMM intervention	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 (EP)	Read fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 (EP)	Read data stream	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 (EP)	Special Functions	Recognition of speed sensor type	
-	-	DUCATO FL (250)	2.3 JTD	Bosch ABS 9 (EP)	Special Functions	Static test	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Read fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Erase fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Read data stream	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Injector codes read	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Air flow meter sensor replacement	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Differential pressure sensor replacement	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Neutral signal learn	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Oil change	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Particulate filter replacement	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Phonic wheel replacement	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Pre-catalyzer replacement	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Replacement lambda sensor	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Particulate filter regeneration	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Throttle test	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	EGR valve test	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Startup with code card	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 2.3 JTD eng.)	Special Functions	Automatic configuration read	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Read fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Erase fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Read data stream	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Special Functions	Key programming	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Special Functions	Indicators command enable/disable	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Special Functions	Country standards change	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Special Functions	Power mode gearbox	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Special Functions	Driver's side wind. lift. motion	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Special Functions	Pass. side wind.lift. motion	
-	-	DUCATO FL (250)	2.3 JTD	Marelli 11 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Read fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Erase fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Read data stream	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Actuation Test	-	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Special Functions	Headlamp pos. correct.	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Special Functions	Servicing information delete	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Special Functions	Reset odometer	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Special Functions	Seat belts alarm exclusion	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Special Functions	Seat belts alarm enable	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Special Functions	Instrument panel replacement	
-	-	DUCATO FL (250)	2.3 JTD	Marelli Cluster (EP) 4	Special Functions	Chronotachigraph control unit (CCT)	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxy) 2	Read fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxy) 2	Erase fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	TRW Airbag (EP-Proxy) 2	Read data stream	-	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read ECU Information	-	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Erase fault code	-	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read data stream	-	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Pump relay replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Tunnel lever replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Control unit replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Gearbox replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Hydraulic kit replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Gearbox oil accumulator replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Clutch replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Electropump replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Sensor replacement	
-	-	DUCATO FL (250)	2.3 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	'UP Function' switch replacement	
-	-	DUCATO FL (250)	3.0 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO FL (250)	3.0 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO FL (250)	3.0 JTD	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO FL (250)	3.0 JTD	Continental Air Springs	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Continental Air Springs	Read Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Continental Air Springs	Erase Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Continental Air Springs	Live Data	-	
-	-	DUCATO FL (250)	3.0 JTD	Continental Air Springs	Special Functions	Vehicle geometry height setting	
-	-	DUCATO FL (250)	3.0 JTD	Continental Air Springs	Special Functions	Forced trim correction	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	DUCATO FL (250)	3.0 JTD	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	DUCATO FL (250)	3.0 JTD	Lauberhorn Convergence (EP)	Live Data	-	
-	-	DUCATO FL (250)	3.0 JTD	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO FL (250)	3.0 JTD	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	DUCATO FL (250)	3.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Read data stream	-	
-	-	DUCATO FL (250)	3.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Denso Single-Zone Automatic Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Read fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Read data stream	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Recognition of speed sensor type	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Static test	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	Steering angle calibration	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 ESP (EP)	Special Functions	CMM intervention	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 (EP)	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 (EP)	Read fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 (EP)	Erase fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 (EP)	Read data stream	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 (EP)	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 (EP)	Special Functions	Recognition of speed sensor type	
-	-	DUCATO FL (250)	3.0 JTD	Bosch ABS 9 (EP)	Special Functions	Static test	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Read fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Erase fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Read data stream	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Special Functions	Key programming	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Special Functions	Indicators command enable/disable	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Special Functions	Country standards change	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Special Functions	Power mode gearbox	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Special Functions	Driver's side wind. lift. motion	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Special Functions	Pass. side wind.lift. motion	
-	-	DUCATO FL (250)	3.0 JTD	Marelli 11 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Read fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Erase fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Read data stream	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Special Functions	Headlamp pos. correct.	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Special Functions	Servicing information delete	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Special Functions	Reset odometer	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Special Functions	Seat belts alarm exclusion	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Special Functions	Seat belts alarm enable	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Special Functions	Instrument panel replacement	
-	-	DUCATO FL (250)	3.0 JTD	Marelli Cluster (EP) 4	Special Functions	Chronotachigraph control unit (CCT)	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxy) 2	Read fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxy) 2	Erase fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	TRW Airbag (EP-Proxy) 2	Read data stream	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Read fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Erase fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Read data stream	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Actuation Test	-	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Injector codes read	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Differential pressure sensor replacement	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Oil change	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Particulate filter replacement	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Pre-catalyzer replacement	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Speed limit setting	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Particulate filter regeneration	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Startup with code card	
-	-	DUCATO FL (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 CF5/5+ EOBD CAN (EP 3.0 eng.)	Special Functions	Automatic configuration read	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read ECU Information	-	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Erase fault code	-	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Read data stream	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Pump relay replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Tunnel lever replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Control unit replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Gearbox replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Hydraulic kit replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Gearbox oil accumulator replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Clutch replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Electropump replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	Sensor replacement	
-	-	DUCATO FL (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348 2	Special Functions	'UP Function' switch replacement	
-	-	DUCATO (230)	1.9 TDS	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	1.9 TDS	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	1.9 TDS	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	1.9 TDS	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	1.9 TDS	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	1.9 TDS ECO	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	1.9 TDS ECO	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	1.9 TDS ECO	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	1.9 TDS ECO	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	1.9 TDS ECO	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	1.9 TDS ECO	Breed MY 97 Airbag (1F-2P)	Read ECU Information	-	
-	-	DUCATO (230)	1.9 TDS ECO	Breed MY 97 Airbag (1F-2P)	Read Fault Code	-	
-	-	DUCATO (230)	1.9 TDS ECO	Breed MY 97 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (230)	1.9 TDS ECO	Breed MY 97 Airbag (1F-2P)	Live Data	-	
-	-	DUCATO (230)	19 DS	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	19 DS	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	19 DS	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	19 DS	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	19 DS	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.0 BZ KAT	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	2.0 BZ KAT	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	2.0 BZ KAT	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	2.0 BZ KAT	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	2.0 BZ KAT	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.0 BZ KAT	Breed MY 97 Airbag (1F-2P)	Read ECU Information	-	
-	-	DUCATO (230)	2.0 BZ KAT	Breed MY 97 Airbag (1F-2P)	Read Fault Code	-	
-	-	DUCATO (230)	2.0 BZ KAT	Breed MY 97 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (230)	2.0 BZ KAT	Breed MY 97 Airbag (1F-2P)	Live Data	-	
-	-	DUCATO (230)	2.0 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	2.0 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	2.0 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	2.0 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	2.0 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.0 JTD	Breed MY 97 Airbag (1F-2P)	Read ECU Information	-	
-	-	DUCATO (230)	2.0 JTD	Breed MY 97 Airbag (1F-2P)	Read Fault Code	-	
-	-	DUCATO (230)	2.0 JTD	Breed MY 97 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (230)	2.0 JTD	Breed MY 97 Airbag (1F-2P)	Live Data	-	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read ECU Information	-	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read Fault Code	-	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Erase Fault Code	-	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Live Data	-	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Actuation Test	-	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Startup with code card	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Cruise control learn zeroing	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Conditioner learn zeroing	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Injector classification	
-	-	DUCATO (230)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Speed limit setting	
-	-	DUCATO (230)	2.5 DS	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	2.5 DS	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	2.5 DS	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	2.5 DS	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	2.5 DS	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.5 TDS	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	2.5 TDS	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	2.5 TDS	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	2.5 TDS	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	2.5 TDS	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.5 TDS ECO	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	2.5 TDS ECO	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	2.5 TDS ECO	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	2.5 TDS ECO	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	2.5 TDS ECO	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.8 DS	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	2.8 DS	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	2.8 DS	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	2.8 DS	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	2.8 DS	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.8 DS	Breed MY 97 Airbag (1F-2P)	Read ECU Information	-	
-	-	DUCATO (230)	2.8 DS	Breed MY 97 Airbag (1F-2P)	Read Fault Code	-	
-	-	DUCATO (230)	2.8 DS	Breed MY 97 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (230)	2.8 DS	Breed MY 97 Airbag (1F-2P)	Live Data	-	
-	-	DUCATO (230)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Read ECU Information	-	
-	-	DUCATO (230)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Read Fault Code	-	
-	-	DUCATO (230)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Erase Fault Code	-	
-	-	DUCATO (230)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Live Data	-	
-	-	DUCATO (230)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Special Functions	Zeroing of self-adaption parameters	
-	-	DUCATO (230)	2.8 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	2.8 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (230)	2.8 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	2.8 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	2.8 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.8 JTD	Breed MY 97 Airbag (1F-2P)	Read ECU Information	-	
-	-	DUCATO (230)	2.8 JTD	Breed MY 97 Airbag (1F-2P)	Read Fault Code	-	
-	-	DUCATO (230)	2.8 JTD	Breed MY 97 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (230)	2.8 JTD	Breed MY 97 Airbag (1F-2P)	Live Data	-	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read ECU Information	-	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read Fault Code	-	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Erase Fault Code	-	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Live Data	-	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Actuation Test	-	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Startup with code card	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Cruise control learn zeroing	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Conditioner learn zeroing	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Injector classification	
-	-	DUCATO (230)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Speed limit setting	
-	-	DUCATO (230)	2.8 TDS	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (230)	2.8 TDS	Bosch 5.3 ABS	Read Fault Code	-	



**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (230)	2.8 TDS	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (230)	2.8 TDS	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (230)	2.8 TDS	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (230)	2.8 TDS	Breed MY 97 Airbag (1F-2P)	Read ECU Information	-	
-	-	DUCATO (230)	2.8 TDS	Breed MY 97 Airbag (1F-2P)	Read Fault Code	-	
-	-	DUCATO (230)	2.8 TDS	Breed MY 97 Airbag (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (230)	2.8 TDS	Breed MY 97 Airbag (1F-2P)	Live Data	-	
-	-	DUCATO (244)	2	Magneti Marelli MM4.8P Injection (EI.Key)	Read ECU Information	-	
-	-	DUCATO (244)	2	Magneti Marelli MM4.8P Injection (EI.Key)	Read Fault Code	-	
-	-	DUCATO (244)	2	Magneti Marelli MM4.8P Injection (EI.Key)	Erase Fault Code	-	
-	-	DUCATO (244)	2	Magneti Marelli MM4.8P Injection (EI.Key)	Live Data	-	
-	-	DUCATO (244)	2	Magneti Marelli MM4.8P Injection (EI.Key)	Actuation Test	-	
-	-	DUCATO (244)	2	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (244)	2	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (244)	2	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (244)	2	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (244)	2	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (244)	2	Bosch 5.3 ASR ABS	Read ECU Information	-	
-	-	DUCATO (244)	2	Bosch 5.3 ASR ABS	Read Fault Code	-	
-	-	DUCATO (244)	2	Bosch 5.3 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (244)	2	Bosch 5.3 ASR ABS	Live Data	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-2P)	Read ECU Information	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-2P)	Read Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-2P)	Live Data	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-2P)	Actuation Test	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-3P)	Read ECU Information	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-3P)	Read Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-3P)	Erase Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-3P)	Live Data	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (1F-3P)	Actuation Test	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-I)	Read ECU Information	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-I)	Read Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-I)	Erase Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-I)	Live Data	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-I)	Actuation Test	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-3P-I)	Read ECU Information	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-3P-I)	Read Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-3P-I)	Erase Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-3P-I)	Live Data	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-3P-I)	Actuation Test	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-2L-I)	Read ECU Information	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-2L-I)	Read Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-2L-I)	Erase Fault Code	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-2L-I)	Live Data	-	
-	-	DUCATO (244)	2	Siemens Airbag MY 99 (2F-2P-2L-I)	Actuation Test	-	
-	-	DUCATO (244)	2	Bosch ABS 5.3 (4x4)	Read ECU Information	-	
-	-	DUCATO (244)	2	Bosch ABS 5.3 (4x4)	Read Fault Code	-	
-	-	DUCATO (244)	2	Bosch ABS 5.3 (4x4)	Erase Fault Code	-	
-	-	DUCATO (244)	2	Bosch ABS 5.3 (4x4)	Live Data	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	2	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	2	Marelli code 2 electronic key	Read ECU Information	-	
-	-	DUCATO (244)	2	Marelli code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	2	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	DUCATO (244)	2	Marelli code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	2	Marelli code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	2	Marelli code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	2	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	2	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ASR ABS	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ASR ABS	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Bosch 5.3 ASR ABS	Live Data	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-2P)	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-2P)	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-2P)	Live Data	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-2P)	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-3P)	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-3P)	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-3P)	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-3P)	Live Data	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (1F-3P)	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-I)	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-I)	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-I)	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-I)	Live Data	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-I)	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-3P-I)	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-3P-I)	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-3P-I)	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-3P-I)	Live Data	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-3P-I)	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Live Data	-	
-	-	DUCATO (244)	2.0 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Live Data	-	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Startup with code card	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Cruise control learn zeroing	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Conditioner learn zeroing	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Injector classification	
-	-	DUCATO (244)	2.0 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Speed limit setting	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	2.0 JTD	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	2.0 JTD	Marelli code 2 electronic key	Read ECU Information	-	
-	-	DUCATO (244)	2.0 JTD	Marelli code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	DUCATO (244)	2.0 JTD	Marelli code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	2.0 JTD	Marelli code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	2.0 JTD	Marelli code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	2.0 JTD	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	2.0 JTD	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ASR ABS	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ASR ABS	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 5.3 ASR ABS	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-2P)	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-2P)	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-2P)	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-2P)	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-3P)	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-3P)	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-3P)	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-3P)	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (1F-3P)	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-1)	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-1)	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-1)	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-1)	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-1)	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-3P-1)	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-3P-1)	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-3P-1)	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-3P-1)	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-3P-1)	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Startup with code card	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Cruise control learn zeroing	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Conditioner learn zeroing	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Injector classification	
-	-	DUCATO (244)	2.3 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Speed limit setting	
-	-	DUCATO (244)	2.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Read ECU Information	-	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Read Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Erase Fault Code	-	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Live Data	-	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Actuation Test	-	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Startup with code card	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Injector codes read	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Oil change (only for version with DPF)	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Control unit replacement	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	

## Diagnostic List Fiat\_v9.10

Remark:  
1. ✓ : means that the system has this function  
2. - : means that the system does not have this function  
3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EObD Diesel Injection (eng 2.3/3.0)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EObD Diesel Injection (eng 2.3/3.0)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EObD Diesel Injection (eng 2.3/3.0)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	DUCATO (244)	2.3 JTD	Bosch EDC16C39 CF4/EObD Diesel Injection (eng 2.3/3.0)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Read Fault Code		
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Erase Fault Code		
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Read Data Stream		
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Actuation Test		
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Read Fault Code		
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Erase Fault Code		
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Read Data Stream		
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Actuation Test		
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	2.3 JTD	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	2.3 JTD	Marelli code 2 electronic key	Read ECU Information		
-	-	DUCATO (244)	2.3 JTD	Marelli code 2 electronic key	Read Fault Code		
-	-	DUCATO (244)	2.3 JTD	Marelli code 2 electronic key	Clear Fault Code		
-	-	DUCATO (244)	2.3 JTD	Marelli code 2 electronic key	Read Data Stream		
-	-	DUCATO (244)	2.3 JTD	Marelli code 2 electronic key	Actuation Test		
-	-	DUCATO (244)	2.3 JTD	Marelli code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	2.3 JTD	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	2.3 JTD	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Live Data		
-	-	DUCATO (244)	2.8 JTD	Automatic Gearbox ZF 4HP20(KW2)	Special Functions	Zeroing of self-adaption parameters	
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ABS	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ABS	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ABS	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ABS	Live Data		
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ABS	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ASR ABS	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ASR ABS	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ASR ABS	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Bosch 5.3 ASR ABS	Live Data		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-2P)	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-2P)	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-2P)	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-2P)	Live Data		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-2P)	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-3P)	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-3P)	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-3P)	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-3P)	Live Data		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (1F-3P)	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-I)	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-I)	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-I)	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-I)	Live Data		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-I)	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-3P-I)	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-3P-I)	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-3P-I)	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-3P-I)	Live Data		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-3P-I)	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Live Data		
-	-	DUCATO (244)	2.8 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Bosch ABS 5.3 (4x4)	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Bosch ABS 5.3 (4x4)	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Bosch ABS 5.3 (4x4)	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Bosch ABS 5.3 (4x4)	Live Data		
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Live Data		
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Startup with code card	
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Cruise control learn zeroing	
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Conditioner learn zeroing	
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Injector classification	
-	-	DUCATO (244)	2.8 JTD	Diesel Bosch EDC15 CF3 Injection (eng. 2.0/2.3/2.8)	Special Functions	Speed limit setting	
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Read Data Stream		
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Erase Fault Code		
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Read Data Stream		
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	2.8 JTD	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	2.8 JTD	Marelli code 2 electronic key	Read ECU Information		
-	-	DUCATO (244)	2.8 JTD	Marelli code 2 electronic key	Read Fault Code		
-	-	DUCATO (244)	2.8 JTD	Marelli code 2 electronic key	Clear Fault Code		
-	-	DUCATO (244)	2.8 JTD	Marelli code 2 electronic key	Read Data Stream		
-	-	DUCATO (244)	2.8 JTD	Marelli code 2 electronic key	Actuation Test		
-	-	DUCATO (244)	2.8 JTD	Marelli code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	2.8 JTD	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	2.8 JTD	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	BIPOWER-GPOWER	Magneti Marelli MM4.8P Injection (EI.Key)	Read ECU Information		
-	-	DUCATO (244)	BIPOWER-GPOWER	Magneti Marelli MM4.8P Injection (EI.Key)	Read Fault Code		
-	-	DUCATO (244)	BIPOWER-GPOWER	Magneti Marelli MM4.8P Injection (EI.Key)	Erase Fault Code		
-	-	DUCATO (244)	BIPOWER-GPOWER	Magneti Marelli MM4.8P Injection (EI.Key)	Live Data		
-	-	DUCATO (244)	BIPOWER-GPOWER	Magneti Marelli MM4.8P Injection (EI.Key)	Actuation Test		
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ABS	Read ECU Information		
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ABS	Read Fault Code		
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ABS	Erase Fault Code		
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ABS	Live Data		
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ABS	Actuation Test		

## Diagnostic List Fiat\_v9.10

Remark:  
 1. √ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ASR ABS	Read ECU Information	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ASR ABS	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Bosch 5.3 ASR ABS	Live Data	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-2P)	Read ECU Information	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-2P)	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-2P)	Erase Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-2P)	Live Data	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-2P)	Actuation Test	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-3P)	Read ECU Information	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-3P)	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-3P)	Erase Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-3P)	Live Data	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (1F-3P)	Actuation Test	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Read ECU Information	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Erase Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Live Data	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Actuation Test	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-3P-I)	Read ECU Information	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-3P-I)	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-3P-I)	Erase Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-3P-I)	Live Data	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-3P-I)	Actuation Test	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Read ECU Information	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Erase Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Live Data	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Actuation Test	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	BIPOWER-GPOWER	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (244)	BIPOWER-GPOWER	Marelli code 2 electronic key	Read ECU Information	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Marelli code 2 electronic key	Read Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Marelli code 2 electronic key	Read Data Stream	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Marelli code 2 electronic key	Actuation Test	-	
-	-	DUCATO (244)	BIPOWER-GPOWER	Marelli code 2 electronic key	Special Functions	Key status	
-	-	DUCATO (244)	BIPOWER-GPOWER	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	DUCATO (244)	BIPOWER-GPOWER	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	DUCATO (250)	2.2 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ABS	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft Convergence	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	2.2 JTD	TRW 1 Airbag (Proxi)	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	TRW 1 Airbag (Proxi)	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	TRW 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	TRW 1 Airbag (Proxi)	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	TRW 1 Airbag (Proxi)	Actuation Test	-	
-	-	DUCATO (250)	2.2 JTD	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	DUCATO (250)	2.2 JTD	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	DUCATO (250)	2.2 JTD	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	2.2 JTD	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	2.2 JTD	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO (250)	2.2 JTD	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO (250)	2.2 JTD	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Read ECU Information	-	
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Read Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Erase Fault Code	-	
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Actuation Test	-	-
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Special Functions	Headlamp pos. correct.	-
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Special Functions	Inputs status	-
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Special Functions	Servicing information delete	-
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Special Functions	Oil change servicing information delete	-
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Special Functions	Reset odometer	-
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm exclusion	-
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm enable	-
-	-	DUCATO (250)	2.2 JTD	Marelli Instrument Cluster (1)	Special Functions	Instrument panel replacement	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Read ECU Information	-	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Read Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Erase Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Live Data	-	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Actuation Test	-	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Startup with code card	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Oil change	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Replacement of injector cyl. 1	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Replacement of injector cyl. 2	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Replacement of injector cyl. 3	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Replacement of injector cyl. 4	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Injector replacement (per bank)	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Speed limit	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	High pressure pump replacement	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Pilot injection learn	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Zeroing of self-adaption parameters	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Automatic configuration read	-
-	-	DUCATO (250)	2.2 JTD	Visteon CF4/EOBD Diesel Injection (eng. 2.2)	Special Functions	Automatic configuration write	-
-	-	DUCATO (250)	2.2 JTD	Bosch Parking Control Unit (1)	Read ECU Information	-	-
-	-	DUCATO (250)	2.2 JTD	Bosch Parking Control Unit (1)	Read Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Bosch Parking Control Unit (1)	Erase Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Bosch Parking Control Unit (1)	Live Data	-	-
-	-	DUCATO (250)	2.2 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	-
-	-	DUCATO (250)	2.2 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	-
-	-	DUCATO (250)	2.2 JTD	Continental Air Springs	Read ECU Information	-	-
-	-	DUCATO (250)	2.2 JTD	Continental Air Springs	Read Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Continental Air Springs	Erase Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Continental Air Springs	Live Data	-	-
-	-	DUCATO (250)	2.2 JTD	Continental Air Springs	Special Functions	Vehicle geometry height setting	-
-	-	DUCATO (250)	2.2 JTD	Continental Air Springs	Special Functions	Forced trim correction	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Read ECU Information	-	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Read Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Erase Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Live Data	-	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Actuation Test	-	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Special Functions	Key programming	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Special Functions	Siren serial line check	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Special Functions	Tilt sensor check (if present)	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Special Functions	Dusk and rain sensors check	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Special Functions	Indicators command enable/disable	-
-	-	DUCATO (250)	2.2 JTD	Marelli Body Computer 6	Special Functions	Country standards change	-
-	-	DUCATO (250)	2.2 JTD	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	-
-	-	DUCATO (250)	2.2 JTD	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Climate Control Denso 2 (Single-zone)	Live Data	-	-
-	-	DUCATO (250)	2.2 JTD	Climate Control Denso 2 (Single-zone)	Actuation Test	-	-
-	-	DUCATO (250)	2.2 JTD	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	-
-	-	DUCATO (250)	2.2 JTD	Convergence Lauberhorn C1	Read ECU Information	-	-
-	-	DUCATO (250)	2.2 JTD	Convergence Lauberhorn C1	Read Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Convergence Lauberhorn C1	Erase Fault Code	-	-
-	-	DUCATO (250)	2.2 JTD	Convergence Lauberhorn C1	Live Data	-	-
-	-	DUCATO (250)	2.2 JTD	Convergence Lauberhorn C1	Actuation Test	-	-
-	-	DUCATO (250)	2.2 JTD	Convergence Lauberhorn C1	Special Functions	Convergence system restart	-
-	-	DUCATO (250)	2.2 JTD	Convergence Lauberhorn C1	Special Functions	Audio system test	-
-	-	DUCATO (250)	2.3 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Sagem SpeedPro Power Steering	Live Data	-	-
-	-	DUCATO (250)	2.3 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Sagem SpeedPro Power Steering	Live Data	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ABS	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ABS	Read Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ABS	Erase Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ABS	Live Data	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ABS	Actuation Test	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 VDC ABS	Live Data	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Read Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Live Data	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Actuation Test	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Read Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Live Data	-	-
-	-	DUCATO (250)	2.3 JTD	Bosch 8 ASR ABS	Actuation Test	-	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft Convergence	Live Data	-	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft Convergence	Actuation Test	-	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	-
-	-	DUCATO (250)	2.3 JTD	TRW 1 Airbag (Proxi)	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	TRW 1 Airbag (Proxi)	Read Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	TRW 1 Airbag (Proxi)	Erase Fault Code	-	-
-	-	DUCATO (250)	2.3 JTD	TRW 1 Airbag (Proxi)	Live Data	-	-
-	-	DUCATO (250)	2.3 JTD	TRW 1 Airbag (Proxi)	Actuation Test	-	-
-	-	DUCATO (250)	2.3 JTD	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	TRW Airbag (EP-Proxy) 3	Read fault code	-	-
-	-	DUCATO (250)	2.3 JTD	TRW Airbag (EP-Proxy) 3	Erase fault code	-	-
-	-	DUCATO (250)	2.3 JTD	TRW Airbag (EP-Proxy) 3	TRW data stream	-	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft C3 Convergence	Read ECU Information	-	-
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft C3 Convergence	Read Fault Code	-	-

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	2.3 JTD	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	2.3 JTD	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO (250)	2.3 JTD	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO (250)	2.3 JTD	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Read ECU Information	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Read Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Actuation Test	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Special Functions	Headlamp pos. correct.	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Special Functions	Inputs status	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Special Functions	Servicing information delete	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Special Functions	Oil change servicing information delete	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Special Functions	Reset odometer	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm exclusion	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm enable	
-	-	DUCATO (250)	2.3 JTD	Marelli Instrument Cluster (1)	Special Functions	Instrument panel replacement	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Read ECU Information	-	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Read Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Actuation Test	-	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Startup with code card	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Injector codes read	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Oil change (only for version with DPF)	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Control unit replacement	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	DUCATO (250)	2.3 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DUCATO (250)	2.3 JTD	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	DUCATO (250)	2.3 JTD	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Bosch Parking Control Unit (1)	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	DUCATO (250)	2.3 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	DUCATO (250)	2.3 JTD	Continental Air Springs	Read ECU Information	-	
-	-	DUCATO (250)	2.3 JTD	Continental Air Springs	Read Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Continental Air Springs	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Continental Air Springs	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Continental Air Springs	Special Functions	Vehicle geometry height setting	
-	-	DUCATO (250)	2.3 JTD	Continental Air Springs	Special Functions	Forced trim correction	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Read ECU Information	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Read Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Actuation Test	-	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Special Functions	Key programming	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Special Functions	Siren serial line check	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Special Functions	Tilt sensor check (if present)	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Special Functions	Dusk and rain sensors check	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Special Functions	Indicators command enable/disable	
-	-	DUCATO (250)	2.3 JTD	Marelli Body Computer 6	Special Functions	Country standards change	
-	-	DUCATO (250)	2.3 JTD	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	DUCATO (250)	2.3 JTD	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	DUCATO (250)	2.3 JTD	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	DUCATO (250)	2.3 JTD	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	DUCATO (250)	2.3 JTD	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	DUCATO (250)	2.3 JTD	Convergence Lauberhorn C1	Live Data	-	
-	-	DUCATO (250)	2.3 JTD	Convergence Lauberhorn C1	Actuation Test	-	
-	-	DUCATO (250)	2.3 JTD	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	DUCATO (250)	2.3 JTD	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	DUCATO (250)	3.0 16V CNG	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Sagem SpeedPro Power Steering	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1, ✓ : means that the system has this function  
 2, - : means that the system does not have this function  
 3.compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	3.0 16V CNG	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Special Functions	Startup with code card	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Special Functions	Speed limit setting	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Special Functions	Replacement of lambda sensor and/or spark plugs and/or injectors	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Special Functions	Phonic wheel and/or phase sensor and/or rev sensor replacement	
-	-	DUCATO (250)	3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Netural Power(eng. 3. 0)	Special Functions	Replacement of pressure/temperature sensor in methane rail	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ABS	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ABS	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ABS	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ABS	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ABS	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 VDC ABS	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 VDC ABS	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft Convergence	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	3.0 16V CNG	TRW 1 Airbag (Proxi)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	TRW 1 Airbag (Proxi)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	TRW 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	TRW 1 Airbag (Proxi)	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	TRW 1 Airbag (Proxi)	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	DUCATO (250)	3.0 16V CNG	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	DUCATO (250)	3.0 16V CNG	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	3.0 16V CNG	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	3.0 16V CNG	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Headlamp pos. correct.	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Inputs status	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Servicing information delete	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Oil change servicing information delete	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Reset odometer	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm exclusion	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm enable	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Instrument panel replacement	
-	-	DUCATO (250)	3.0 16V CNG	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch Parking Control Unit (1)	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	DUCATO (250)	3.0 16V CNG	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	DUCATO (250)	3.0 16V CNG	Continental Air Springs	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Continental Air Springs	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Continental Air Springs	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Continental Air Springs	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Continental Air Springs	Special Functions	Vehicle geometry height setting	
-	-	DUCATO (250)	3.0 16V CNG	Continental Air Springs	Special Functions	Forced trim correction	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Special Functions	Key programming	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Special Functions	Siren serial line check	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Special Functions	Tilt sensor check (if present)	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Special Functions	Dusk and rain sensors check	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Special Functions	Indicators command enable/disable	
-	-	DUCATO (250)	3.0 16V CNG	Marelli Body Computer 6	Special Functions	Country standards change	
-	-	DUCATO (250)	3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	DUCATO (250)	3.0 16V CNG	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	DUCATO (250)	3.0 16V CNG	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 16V CNG	Convergence Lauberhorn Cl	Live Data	-	
-	-	DUCATO (250)	3.0 16V CNG	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	DUCATO (250)	3.0 16V CNG	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	DUCATO (250)	3.0 16V CNG	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	DUCATO (250)	3.0 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Startup with code card	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Injector codes read	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Oil change	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Speed limit setting	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Particulate filter replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Differential pressure sensor replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Particulate filter regeneration	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Replacement lambda sensor	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Air flow meter sensor replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Pre-catalyzer replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Variable geometry turbo replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch Diesel Injection EDC17CP52 EURO V/EOBD(eng.3.0)	Special Functions	Control unit replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ABS	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft Convergence	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	3.0 JTD	TRW 1 Airbag (Proxi)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	TRW 1 Airbag (Proxi)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	TRW 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	TRW 1 Airbag (Proxi)	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	TRW 1 Airbag (Proxi)	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	DUCATO (250)	3.0 JTD	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	DUCATO (250)	3.0 JTD	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	3.0 JTD	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	3.0 JTD	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Special Functions	Headlamp pos. correct.	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Special Functions	Inputs status	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Special Functions	Servicing information delete	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Special Functions	Oil change servicing information delete	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Special Functions	Reset odometer	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm exclusion	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm enable	
-	-	DUCATO (250)	3.0 JTD	Marelli Instrument Cluster (1)	Special Functions	Instrument panel replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Startup with code card	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Injector codes read	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Oil change (only for version with DPF)	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Control unit replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	DUCATO (250)	3.0 JTD	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DUCATO (250)	3.0 JTD	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Parking Control Unit (1)	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	DUCATO (250)	3.0 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	DUCATO (250)	3.0 JTD	Continental Air Springs	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Continental Air Springs	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Continental Air Springs	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Continental Air Springs	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Continental Air Springs	Special Functions	Vehicle geometry height setting	
-	-	DUCATO (250)	3.0 JTD	Continental Air Springs	Special Functions	Forced trim correction	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Special Functions	Key programming	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Special Functions	Siren serial line check	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Special Functions	Tilt sensor check (if present)	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Special Functions	Dusk and rain sensors check	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Special Functions	Indicators command enable/disable	
-	-	DUCATO (250)	3.0 JTD	Marelli Body Computer 6	Special Functions	Country standards change	
-	-	DUCATO (250)	3.0 JTD	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Clutch self-calibration enable	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Clutch replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Tunnel lever replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	'UP Function' switch replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Gearbox oil accumulator replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Longitudinal acceleration signal learn	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Electropump replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	End of line / service self-calibration	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Gearbox replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Clutch bleed	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Accumulator depressurisation	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Pump relay replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Hydraulic kit replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Gearbox and hydraulic KIT replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Calculation of clutch degradation index	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	DUCATO (250)	3.0 JTD	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Sensor replacement	
-	-	DUCATO (250)	3.0 JTD	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	DUCATO (250)	3.0 JTD	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	DUCATO (250)	3.0 JTD	Convergence Lauberhorn Cl	Live Data	-	
-	-	DUCATO (250)	3.0 JTD	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	DUCATO (250)	3.0 JTD	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	DUCATO (250)	3.0 JTD	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Startup with code card	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Injector codes read	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Oil change	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Speed limit setting	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Particulate filter replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Differential pressure sensor replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Particulate filter regeneration	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Replacement lambda sensor	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Air flow meter sensor replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Pre-catalyzer replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Variable geometry turbo replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Diesel Injection EDC17CP52 EURO V/EOBD (eng. 3.0)	Special Functions	Control unit replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ABS	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ABS	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ABS	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ABS	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ABS	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 VDC ABS	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 VDC ABS	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft Convergence	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW 1 Airbag (Proxi)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW 1 Airbag (Proxi)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW 1 Airbag (Proxi)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW 1 Airbag (Proxi)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW Airbag (EP-Proxy) 3	Read fault code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Special Functions	Headlamp pos. correct.	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Special Functions	Inputs status	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Special Functions	Servicing information delete	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Special Functions	Oil change servicing information delete	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Special Functions	Reset odometer	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm exclusion	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm enable	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Instrument Cluster (1)	Special Functions	Instrument panel replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Startup with code card	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Injector codes read	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 1	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 2	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 3	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Replacement of injector cyl. 4	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Injector replacement (per bank)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Oil change (only for version with DPF)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Control unit replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Rail pressure sensor replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch EDC16C39 CF4/EOBD Diesel Injection (eng 2.3/3.0)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Parking Control Unit (1)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Continental Air Springs	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Continental Air Springs	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Continental Air Springs	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Continental Air Springs	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Continental Air Springs	Special Functions	Vehicle geometry height setting	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Continental Air Springs	Special Functions	Forced trim correction	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Special Functions	Key programming	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Special Functions	Siren serial line check	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Special Functions	Tilt sensor check (if present)	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Special Functions	Dusk and rain sensors check	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Special Functions	Indicators command enable/disable	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Marelli Body Computer 6	Special Functions	Country standards change	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Clutch self-calibration enable	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Clutch replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Tunnel lever replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	'UP Function' switch replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Gearbox oil accumulator replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Longitudinal acceleration signal learn	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Electropump replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	End of line / service self-calibration	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Gearbox replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Clutch bleed	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Accumulator depressurisation	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Pump relay replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Hydraulic kit replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Gearbox and hydraulic KIT replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Calculation of clutch degradation index	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Automatic Gearbox Marelli Selespeed CFC348	Special Functions	Sensor replacement	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Convergence Lauberhorn Cl	Live Data	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	DUCATO (250)	MINIBUS 16+1 SEATS	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Sagem SpeedPro Power Steering	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Sagem SpeedPro Power Steering	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Sagem SpeedPro Power Steering	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Sagem SpeedPro Power Steering	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Special Functions	Startup with code card	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Special Functions	Speed limit setting	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Special Functions	Replacement of lambda sensor and/or spark plugs and/or injectors	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Special Functions	Phonic wheel and/or phase sensor and/or rev sensor replacement	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Injection Magneti Marelli IAW 5SF4 Neutral Power(eng. 3.0)	Special Functions	Replacement of pressure/temperature sensor in methane rail	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ABS	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ABS	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ABS	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ABS	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ABS	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 VDC ABS	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 VDC ABS	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch 8 ASR ABS	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft Convergence	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW 1 Airbag (Proxi)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW 1 Airbag (Proxi)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW 1 Airbag (Proxi)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW 1 Airbag (Proxi)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft C3 Convergence	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft C3 Convergence	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft C3 Convergence	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft C3 Convergence	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft C3 Convergence	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft C3 Convergence	Special Functions	Convergence system restart	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli/Microsoft C3 Convergence	Special Functions	Audio system test	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Actia Chronotachigraph	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Actia Chronotachigraph	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Actia Chronotachigraph	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Actia Chronotachigraph	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Actia Chronotachigraph	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Actia Chronotachigraph	Special Functions	System configuration write	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Headlamp pos. correct.	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Inputs status	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Servicing information delete	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Oil change servicing information delete	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Reset odometer	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm exclusion	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Seat belts alarm enable	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Instrument Cluster (1)	Special Functions	Instrument panel replacement	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch Parking Control Unit (1)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Continental Air Springs	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Continental Air Springs	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Continental Air Springs	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Continental Air Springs	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Continental Air Springs	Special Functions	Vehicle geometry height setting	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Continental Air Springs	Special Functions	Forced trim correction	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Special Functions	Key programming	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Special Functions	Siren serial line check	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Special Functions	Tilt sensor check (if present)	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Special Functions	Dusk and rain sensors check	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Special Functions	Indicators command enable/disable	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Marelli Body Computer 6	Special Functions	Country standards change	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Convergence Lauberhorn C1	Live Data	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Convergence Lauberhorn C1	Actuation Test	-	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	DUCATO (250)	MINIBUS 3.0 16V CNG	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Gearbox oil accumulator replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Control unit replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Gearbox replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Hydraulic kit replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Clutch replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Tunnel lever replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Steering wheel levers replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Longitudinal acceleration signal learn	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	ECO/SPORT switch replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Pump relay replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Electropump replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	FIORINO (225)	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Sensor replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD (EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read fault code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Erase fault code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read data stream	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector codes read	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 1	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 2	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 3	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 4	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector replacement (per bank)	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Neutral signal learn	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Air flow meter sensor replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Differential pressure sensor replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Mechanical waste-gate valve replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Oil change	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Phonic wheel replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Rail pressure sensor replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement lambda sensor	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Speed limit setting	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter regeneration	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Startup with code card	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Throttle test	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	EGR valve test	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Glow plug preheating circuit test	
-	-	FIORINO (225)	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Automatic configuration read	
-	-	FIORINO (225)	1.3 JTD	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	FIORINO (225)	1.3 JTD	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	FIORINO (225)	1.3 JTD	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	FIORINO (225)	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	ECO switch replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Electropump replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch bleed	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line self-calibration	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	New actuators	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Hydraulic kit replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Special Functions	Key programming	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Special Functions	Inertia switch rearm (FIS)	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Special Functions	Indicators command enable/disable	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Special Functions	Country standards change	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Special Functions	Power mode gearbox	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Special Functions	Roof control unit initialisation	
-	-	FIORINO (225)	1.3 JTD	DELPHI Body Computer (EP) 2	Special Functions	Exit shipping mode	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	FIORINO (225)	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	FIORINO (225)	1.3 JTD	Autoliv 2 Airbag (Proxi)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Autoliv 2 Airbag (Proxi)	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Autoliv 2 Airbag (Proxi)	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Autoliv 2 Airbag (Proxi)	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Autoliv 2 Airbag (Proxi)	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	FIORINO (225)	1.3 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	FIORINO (225)	1.3 JTD	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.3 JTD	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.3 JTD	Lauberhorn Convergence (EP)	Live Data	-	
-	-	FIORINO (225)	1.3 JTD	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.3 JTD	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	FIORINO (225)	1.3 JTD	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Special Functions	Startup with code card	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	FIORINO (225)	1.4 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	FIORINO (225)	1.4 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	FIORINO (225)	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	FIORINO (225)	1.4 8V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	FIORINO (225)	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Live Data	-	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Special Functions	Key programming	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Special Functions	Inertia switch rearm (FIS)	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Special Functions	Indicators command enable/disable	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Special Functions	Country standards change	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Special Functions	Power mode gearbox	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Special Functions	Roof control unit initialisation	
-	-	FIORINO (225)	1.4 8V	DELPHI Body Computer (EP) 2	Special Functions	Exit shipping mode	
-	-	FIORINO (225)	1.4 8V	Autoliv 2 Airbag (Proxi)	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	Autoliv 2 Airbag (Proxi)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Autoliv 2 Airbag (Proxi)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Autoliv 2 Airbag (Proxi)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Autoliv 2 Airbag (Proxi)	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	FIORINO (225)	1.4 8V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Special Functions	Startup with code card	
-	-	FIORINO (225)	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Startup with code card	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	FIORINO (225)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	FIORINO (225)	1.4 8V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	FIORINO (225)	1.4 8V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	FIORINO (225)	1.4 8V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	FIORINO (225)	1.4 8V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	FIORINO (225)	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	FIORINO (225)	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Read ECU Information	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Read Fault Code	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Erase Fault Code	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Live Data	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Actuation Test	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Live Data	-	
-	-	FIORINO (255)	1.4 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	FIORINO (255)	1.4 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Read Fault Code	-	
-	-	FIORINO (255)	1.4 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Erase Fault Code	-	
-	-	FIORINO (255)	1.4 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Live Data	-	
-	-	FIORINO (255)	1.4 I.E.	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	FIORINO (255)	1.4 I.E.	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	FIORINO (255)	1.4 I.E.	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	FIORINO (255)	1.6 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	FIORINO (255)	1.6 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	FIORINO (255)	1.6 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	FIORINO (255)	1.6 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Live Data	-	
-	-	FIORINO (255)	1.6 I.E GASOLINA	Magnetic Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	FIORINO (255)	1.6 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Read Fault Code	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	FIORINO (255)	1.6 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Erase Fault Code	-	
-	-	FIORINO (255)	1.6 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Live Data	-	
-	-	FIORINO (255)	1.6 I.E.	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	FIORINO (255)	1.6 I.E.	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	FIORINO (255)	1.6 I.E.	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	FIORINO (255)	1.6 I.E.	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	FIORINO (255)	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	FIORINO (255)	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	FIORINO (255)	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	FIORINO (255)	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	FIORINO (255)	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	FIORINO (255)	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	FIORINO (255)	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	FIORINO (255)	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	FIORINO (255)	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	FIORINO (255)	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	FIORINO (255)	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	FIORINO (255)	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	FIORINO (255)	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.2 8V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.2 8V	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.2 8V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO	1.2 8V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Special Functions	Window wash system check	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Special Functions	Rain sensor	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.2 8V	Delphi Body Computer (EP)	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.2 8V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO	1.2 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.2 8V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.2 8V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.2 8V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Actuation Test	-	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Special Functions	Startup with code card	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8V)	Special Functions	Neutral signal learn	
-	-	GRANDE PUNTO	1.2 8V	Siemens Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.2 8V	Siemens Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Siemens Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.2 8V	Siemens Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.2 8V	Siemens Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Window wash system check	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Rain sensor	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	ECO switch replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Electropump replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch bleed	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line self-calibration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	New actuators	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Hydraulic kit replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	GRANDE PUNTO	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Actuation Test	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	GRANDE PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	
-	-	GRANDE PUNTO	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.4 16V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.4 16V	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.4 16V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO	1.4 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.4 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Special Functions	Window wash system check	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Special Functions	Rain sensor	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 16V	Delphi Body Computer (EP)	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.4 16V	Bosch Injection Motronic Me7.6.3 CF4/EOBD (EP eng. 16v)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Injection Motronic Me7.6.3 CF4/EOBD (EP eng. 16v)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Injection Motronic Me7.6.3 CF4/EOBD (EP eng. 16v)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Injection Motronic Me7.6.3 CF4/EOBD (EP eng. 16v)	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Injection Motronic Me7.6.3 CF4/EOBD (EP eng. 16v)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Injection Motronic Me7.6.3 CF4/EOBD (EP eng. 16v)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 16V	Bosch Injection Motronic Me7.6.3 CF4/EOBD (EP eng. 16v)	Special Functions	Self-learnt functions reset	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Me7.6.3 Injection (EP eng. 16v) Outside EEC	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Me7.6.3 Injection (EP eng. 16v) Outside EEC	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Me7.6.3 Injection (EP eng. 16v) Outside EEC	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Me7.6.3 Injection (EP eng. 16v) Outside EEC	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Me7.6.3 Injection (EP eng. 16v) Outside EEC	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Me7.6.3 Injection (EP eng. 16v) Outside EEC	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Me7.6.3 Injection (EP eng. 16v) Outside EEC	Special Functions	Self-learnt functions reset	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Knock counter reset	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Overboost counter reset	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO	1.4 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.4 16V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 8V	Injection Landi Renzo LCO2 Gas	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Injection Landi Renzo LCO2 Gas	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Injection Landi Renzo LCO2 Gas	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Injection Landi Renzo LCO2 Gas	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Injection Landi Renzo LCO2 Gas	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.4 8V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.4 8V	TRW Airbag (EP-Proxy)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Airbag (EP-Proxy)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Airbag (EP-Proxy)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Airbag (EP-Proxy)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Airbag (EP-Proxy)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.4 8V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO	1.4 8V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Special Functions	Window wash system check	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Special Functions	Rain sensor	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 8V	Delphi Body Computer (EP)	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.4 8V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO	1.4 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox oil accumulator replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Hydraulic kit replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Clutch replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Tunnel lever replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Steering wheel levers replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration signal learn	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	ECO/SPORT switch replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Pump relay replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	AUTO switch replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Electropump replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Sensor replacement	
-	-	GRANDE PUNTO	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration sensor replacement	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Special Functions	Startup with code card	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read fault code	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Erase fault code	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read data stream	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.4 8V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Vehicle configuration deletion	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Neutral signal learn	
-	-	GRANDE PUNTO	1.4 8V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.4 8V	Siemens Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 8V	Siemens Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Siemens Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 8V	Siemens Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 8V	Siemens Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.4 TURBO 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Special Functions	Window wash system check	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Special Functions	Rain sensor	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Speed limit setting	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Knock counter reset	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Overboost counter reset	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Siemens Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Siemens Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Siemens Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Siemens Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.4 TURBO 16V	Siemens Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector codes read	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Speed limit setting	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration read	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/E0BD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration write	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve test	
-	-	GRANDE PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Glow plug preheating circuit test	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.6 MJET 16V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.6 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.6 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.6 MJET 16V	Siemens Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Siemens Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Siemens Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Siemens Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.6 MJET 16V	Siemens Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Injector codes read	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Replacement of injector cyl. 1	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Replacement of injector cyl. 2	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Replacement of injector cyl. 3	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Replacement of injector cyl. 4	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Injector replacement (per bank)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Oil change (only for version with DPF)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Rail pressure sensor replacement	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Automatic configuration read	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Automatic configuration write	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP eng. 1.9)	Special Functions	Self-learnt functions reset	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.9 MJET 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Special Functions	Window wash system check	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Special Functions	Rain sensor	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 2 Power Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 2 Power Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 2 Power Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 2 Power Steering	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Injector codes read	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Replacement of injector cyl. 1	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Replacement of injector cyl. 2	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Replacement of injector cyl. 3	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Replacement of injector cyl. 4	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Injector replacement (per bank)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Oil change (only for version with DPF)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Differential pressure sensor replacement (only for version with DPF)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Pre-catalyser replacement (only for version with DPFF)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Rail pressure sensor replacement	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Automatic configuration read	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Automatic configuration write	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Startup with code card	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP eng. 1.9) Outside EEC	Special Functions	Self-learnt functions reset	
-	-	GRANDE PUNTO	1.9 MJET 8V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO	1.9 MJET 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO	1.9 MJET 8V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO	1.9 MJET 8V	Siemens Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Siemens Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Siemens Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Siemens Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO	1.9 MJET 8V	Siemens Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD(EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Key programming	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Window wash system check	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Rain sensor	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	Special Functions	Country standards change	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	DELPHI (EP) 2 Power Steering	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	DELPHI (EP) 2 Power Steering	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	DELPHI (EP) 2 Power Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	DELPHI (EP) 2 Power Steering	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	DELPHI (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	ECO switch replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Electropump replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch bleed	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line self-calibration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	New actuators	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Hydraulic kit replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.3 MJET 16V	Siemens Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Airbag (EP-Proxi)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Airbag (EP-Proxi)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Airbag (EP-Proxi)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Airbag (EP-Proxi)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Airbag (EP-Proxi)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Climate Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Climate Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Climate Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Climate Control (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Climate Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Heater (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Heater (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Heater (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Heater (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Denso Heater (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	GRANDE PUNTO VAN	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Special Functions	Key programming	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Special Functions	Window wash system check	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Special Functions	Rain sensor	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Special Functions	Exit shipping mode	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	Special Functions	Country standards change	
-	-	GRANDE PUNTO VAN	1.4 8V	DELPHI (EP) 2 Power Steering	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	DELPHI (EP) 2 Power Steering	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	DELPHI (EP) 2 Power Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	DELPHI (EP) 2 Power Steering	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	DELPHI (EP) 2 Power Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Startup with code card	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP eng. 8V) Outside EEC	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read fault code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Erase fault code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Read data stream	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO VAN	1.4 8V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	GRANDE PUNTO VAN	1.4 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Gearbox oil accumulator replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Control unit replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Gearbox replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Hydraulic kit replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Clutch replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Tunnel lever replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Steering wheel levers replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Longitudinal acceleration signal learn	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	ECO/SPORT switch replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Pump relay replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	AUTO switch replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Electropump replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Sensor replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Longitudinal acceleration sensor replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP eng. 8V)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Key programming	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Inertia switch rearm (FIS)	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Indicators command enable/disable	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Country standards change	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Power mode gearbox	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Roof control unit initialisation	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	Special Functions	Exit shipping mode	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	GRANDE PUNTO VAN	1.4 8V	Continental Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Continental Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Continental Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Continental Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Continental Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Startup with code card	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Neutral signal learn	
-	-	GRANDE PUNTO VAN	1.4 8V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	GRANDE PUNTO VAN	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	GRANDE PUNTO VAN	1.4 8V	Siemens Airbag (EP-Proxy) 2	Read ECU Information	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Siemens Airbag (EP-Proxy) 2	Read Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Siemens Airbag (EP-Proxy) 2	Erase Fault Code	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Siemens Airbag (EP-Proxy) 2	Live Data	-	
-	-	GRANDE PUNTO VAN	1.4 8V	Siemens Airbag (EP-Proxy) 2	Actuation Test	-	
-	-	IDEA	1.2 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA	1.2 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA	1.2 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA	1.2 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA	1.2 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read ECU Information	-	
-	-	IDEA	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read Fault Code	-	
-	-	IDEA	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Live Data	-	
-	-	IDEA	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Actuation Test	-	
-	-	IDEA	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Special Functions	Startup with code card	
-	-	IDEA	1.2 16V	Single BITRON Driver's Door	Read ECU Information	-	
-	-	IDEA	1.2 16V	Single BITRON Driver's Door	Read Fault Code	-	
-	-	IDEA	1.2 16V	Single BITRON Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Single BITRON Driver's Door	Live Data	-	
-	-	IDEA	1.2 16V	Single BITRON Driver's Door	Actuation Test	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.2 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA	1.2 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA	1.2 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Bosch 8 ABS	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.2 16V	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA	1.2 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA	1.2 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA	1.2 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA	1.2 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA	1.2 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	IDEA	1.2 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	IDEA	1.2 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	IDEA	1.2 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	IDEA	1.2 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	IDEA	1.2 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	IDEA	1.2 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	IDEA	1.2 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.2 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	IDEA	1.2 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	IDEA	1.2 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	IDEA	1.2 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	IDEA	1.2 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	IDEA	1.2 16V	G.E. Procond Boot	Live Data	-	
-	-	IDEA	1.2 16V	G.E. Procond Boot	Actuation Test	-	
-	-	IDEA	1.2 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	IDEA	1.2 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	IDEA	1.2 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	IDEA	1.2 16V	TRW 1 Power Steering	Live Data	-	
-	-	IDEA	1.2 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.2 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Read ECU Information	-	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Read Fault Code	-	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Live Data	-	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Actuation Test	-	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Special Functions	Key programming	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Special Functions	Siren serial line check	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Special Functions	Ultrasound sensor check	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Special Functions	Tilt sensor check (if present)	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.2 16V	Marelli Body Computer 1	Special Functions	Window wash system check	
-	-	IDEA	1.2 16V	Denso Climate Control 1 (Two-zone)	Read ECU Information	-	
-	-	IDEA	1.2 16V	Denso Climate Control 1 (Two-zone)	Read Fault Code	-	
-	-	IDEA	1.2 16V	Denso Climate Control 1 (Two-zone)	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Denso Climate Control 1 (Two-zone)	Live Data	-	
-	-	IDEA	1.2 16V	Denso Climate Control 1 (Two-zone)	Actuation Test	-	
-	-	IDEA	1.2 16V	Denso Climate Control 1 (Two-zone)	Special Functions	Flap actuators learning test	
-	-	IDEA	1.2 16V	Denso Climate Control 1 (Two-zone)	Special Functions	Pollution sensor test	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Read ECU Information	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Read Fault Code	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Live Data	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Actuation Test	-	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Special Functions	Inputs status	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Special Functions	Reset odometer	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.2 16V	Single Driver's Door G.E. Procond	Read ECU Information	-	
-	-	IDEA	1.2 16V	Single Driver's Door G.E. Procond	Read Fault Code	-	
-	-	IDEA	1.2 16V	Single Driver's Door G.E. Procond	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Single Driver's Door G.E. Procond	Live Data	-	
-	-	IDEA	1.2 16V	Single Driver's Door G.E. Procond	Actuation Test	-	
-	-	IDEA	1.2 16V	Schrader Tyre Pressure Check	Read ECU Information	-	
-	-	IDEA	1.2 16V	Schrader Tyre Pressure Check	Read Fault Code	-	
-	-	IDEA	1.2 16V	Schrader Tyre Pressure Check	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Schrader Tyre Pressure Check	Live Data	-	
-	-	IDEA	1.2 16V	Schrader Tyre Pressure Check	Special Functions	Wheel transmitters learning	
-	-	IDEA	1.2 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	IDEA	1.2 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	IDEA	1.2 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	IDEA	1.2 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	IDEA	1.2 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA	1.2 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA	1.2 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA	1.2 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA	1.2 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA	1.2 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA	1.2 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	IDEA	1.2 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	IDEA	1.2 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	IDEA	1.2 16V	TRW 3 Electric Steering	Live Data	-	
-	-	IDEA	1.2 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.2 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	IDEA	1.2 16V	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA	1.2 16V	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA	1.2 16V	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA	1.2 16V	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA	1.2 16V	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA	1.2 16V	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.2 16V	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.2 16V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	IDEA	1.2 16V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	IDEA	1.2 16V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	IDEA	1.2 16V	Convergence Lauberhorn Cl	Live Data	-	
-	-	IDEA	1.2 16V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	IDEA	1.2 16V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	IDEA	1.2 16V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	IDEA	1.3 JTD	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA	1.3 JTD	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA	1.3 JTD	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 1 injector classification	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 2 injector classification	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 3 injector classification	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 4 injector classification	
-	-	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector classification (4 cyl. bank)	
-	-	IDEA	1.3 JTD	Single BITRON Driver's Door	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Single BITRON Driver's Door	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Single BITRON Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Single BITRON Driver's Door	Live Data	-	
-	-	IDEA	1.3 JTD	Single BITRON Driver's Door	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	IDEA	1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA	1.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA	1.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA	1.3 JTD	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	IDEA	1.3 JTD	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	IDEA	1.3 JTD	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	G.E. Procond Passenger Door	Live Data	-	
-	-	IDEA	1.3 JTD	G.E. Procond Passenger Door	Actuation Test	-	
-	-	IDEA	1.3 JTD	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	IDEA	1.3 JTD	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	IDEA	1.3 JTD	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	G.E. Procond Driver's Door	Live Data	-	
-	-	IDEA	1.3 JTD	G.E. Procond Driver's Door	Actuation Test	-	
-	-	IDEA	1.3 JTD	G.E. Procond Boot	Read ECU Information	-	
-	-	IDEA	1.3 JTD	G.E. Procond Boot	Read Fault Code	-	
-	-	IDEA	1.3 JTD	G.E. Procond Boot	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	G.E. Procond Boot	Live Data	-	
-	-	IDEA	1.3 JTD	G.E. Procond Boot	Actuation Test	-	
-	-	IDEA	1.3 JTD	TRW 1 Power Steering	Read ECU Information	-	
-	-	IDEA	1.3 JTD	TRW 1 Power Steering	Read Fault Code	-	
-	-	IDEA	1.3 JTD	TRW 1 Power Steering	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	TRW 1 Power Steering	Live Data	-	
-	-	IDEA	1.3 JTD	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.3 JTD	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Special Functions	Key programming	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Special Functions	Siren serial line check	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Special Functions	Ultrasound sensor check	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Special Functions	Tilt sensor check (if present)	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.3 JTD	Marelli Body Computer 1	Special Functions	Window wash system check	
-	-	IDEA	1.3 JTD	Denso Climate Control 1 (Two-zone)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Denso Climate Control 1 (Two-zone)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Denso Climate Control 1 (Two-zone)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Denso Climate Control 1 (Two-zone)	Live Data	-	
-	-	IDEA	1.3 JTD	Denso Climate Control 1 (Two-zone)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Denso Climate Control 1 (Two-zone)	Special Functions	Flap actuators learning test	
-	-	IDEA	1.3 JTD	Denso Climate Control 1 (Two-zone)	Special Functions	Pollution sensor test	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Inputs status	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Reset odometer	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.3 JTD	Single Driver's Door G.E. Procond	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Single Driver's Door G.E. Procond	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Single Driver's Door G.E. Procond	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Single Driver's Door G.E. Procond	Live Data	-	
-	-	IDEA	1.3 JTD	Single Driver's Door G.E. Procond	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Statistical data deletion	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Tunnel lever replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	SPORT switch replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Steering wheel levers replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Electropump replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	End of line / service self-calibration	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch bleed	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Accumulator depressurisation	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch self-calibration enable	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Pump relay replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Gearbox replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Pump replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	CITY switch replacement	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Deletion of statistical data relating to errors	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Calculation of clutch degradation index	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Engagement lever pin securing screw diagnosis	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	New actuators	
-	-	IDEA	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Selection lever return diagnosis	
-	-	IDEA	1.3 JTD	Schrader Tyre Pressure Check	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Schrader Tyre Pressure Check	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Schrader Tyre Pressure Check	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Schrader Tyre Pressure Check	Live Data	-	
-	-	IDEA	1.3 JTD	Schrader Tyre Pressure Check	Special Functions	Wheel transmitters learning	
-	-	IDEA	1.3 JTD	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	IDEA	1.3 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA	1.3 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Oil change	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	IDEA	1.3 JTD	TRW 3 Electric Steering	Read ECU Information	-	
-	-	IDEA	1.3 JTD	TRW 3 Electric Steering	Read Fault Code	-	
-	-	IDEA	1.3 JTD	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	TRW 3 Electric Steering	Live Data	-	
-	-	IDEA	1.3 JTD	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.3 JTD	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	IDEA	1.3 JTD	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA	1.3 JTD	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA	1.3 JTD	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA	1.3 JTD	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.3 JTD	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Live Data	-	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Actuation Test	-	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Clutch replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Tunnel lever replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Gearbox oil accumulator replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Longitudinal acceleration signal learn	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	ECO switch replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Electropump replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Gearbox replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Clutch bleed	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Accumulator depressurisation	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Clutch self-calibration enable	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Pump relay replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Hydraulic kit replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Gearbox and hydraulic KIT replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Calculation of clutch degradation index	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	IDEA	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308F	Special Functions	End of line / service self-calibration	
-	-	IDEA	1.3 JTD	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	IDEA	1.3 JTD	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	IDEA	1.3 JTD	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	IDEA	1.3 JTD	Convergence Lauberhorn Cl	Live Data	-	
-	-	IDEA	1.3 JTD	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	IDEA	1.3 JTD	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	IDEA	1.3 JTD	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	IDEA	1.4 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	IDEA	1.4 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	IDEA	1.4 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	IDEA	1.4 16V	TRW 3 Electric Steering	Live Data	-	
-	-	IDEA	1.4 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.4 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	IDEA	1.4 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA	1.4 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA	1.4 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA	1.4 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA	1.4 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read ECU Information	-	
-	-	IDEA	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read Fault Code	-	
-	-	IDEA	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Live Data	-	
-	-	IDEA	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Actuation Test	-	
-	-	IDEA	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Special Functions	Startup with code card	
-	-	IDEA	1.4 16V	Single BITRON Driver's Door	Read ECU Information	-	
-	-	IDEA	1.4 16V	Single BITRON Driver's Door	Read Fault Code	-	
-	-	IDEA	1.4 16V	Single BITRON Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Single BITRON Driver's Door	Live Data	-	
-	-	IDEA	1.4 16V	Single BITRON Driver's Door	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Electropump replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch bleed	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Pump replacement	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Deletion of statistical data relating to errors	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	New actuators	
-	-	IDEA	1.4 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA	1.4 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA	1.4 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Bosch 8 ABS	Live Data	-	
-	-	IDEA	1.4 16V	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA	1.4 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA	1.4 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA	1.4 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA	1.4 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA	1.4 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	IDEA	1.4 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	IDEA	1.4 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	IDEA	1.4 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	IDEA	1.4 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	IDEA	1.4 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	IDEA	1.4 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	IDEA	1.4 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.4 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	IDEA	1.4 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	IDEA	1.4 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	IDEA	1.4 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	IDEA	1.4 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	IDEA	1.4 16V	G.E. Procond Boot	Live Data	-	
-	-	IDEA	1.4 16V	G.E. Procond Boot	Actuation Test	-	
-	-	IDEA	1.4 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	IDEA	1.4 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	IDEA	1.4 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	IDEA	1.4 16V	TRW 1 Power Steering	Live Data	-	
-	-	IDEA	1.4 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.4 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Live Data	-	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Special Functions	Key programming	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Special Functions	Siren serial line check	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Special Functions	Ultrasound sensor check	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Special Functions	Tilt sensor check (if present)	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.4 16V	Marelli Body Computer 1	Special Functions	Window wash system check	
-	-	IDEA	1.4 16V	Denso Climate Control 1 (Two-zone)	Read ECU Information	-	
-	-	IDEA	1.4 16V	Denso Climate Control 1 (Two-zone)	Read Fault Code	-	
-	-	IDEA	1.4 16V	Denso Climate Control 1 (Two-zone)	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Denso Climate Control 1 (Two-zone)	Live Data	-	
-	-	IDEA	1.4 16V	Denso Climate Control 1 (Two-zone)	Actuation Test	-	
-	-	IDEA	1.4 16V	Denso Climate Control 1 (Two-zone)	Special Functions	Flap actuators learning test	
-	-	IDEA	1.4 16V	Denso Climate Control 1 (Two-zone)	Special Functions	Pollution sensor test	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Live Data	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Inputs status	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Reset odometer	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.4 16V	Single Driver's Door G.E. Procond	Read ECU Information	-	
-	-	IDEA	1.4 16V	Single Driver's Door G.E. Procond	Read Fault Code	-	
-	-	IDEA	1.4 16V	Single Driver's Door G.E. Procond	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Single Driver's Door G.E. Procond	Live Data	-	
-	-	IDEA	1.4 16V	Single Driver's Door G.E. Procond	Actuation Test	-	
-	-	IDEA	1.4 16V	Schrader Tyre Pressure Check	Read ECU Information	-	
-	-	IDEA	1.4 16V	Schrader Tyre Pressure Check	Read Fault Code	-	
-	-	IDEA	1.4 16V	Schrader Tyre Pressure Check	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Schrader Tyre Pressure Check	Live Data	-	
-	-	IDEA	1.4 16V	Schrader Tyre Pressure Check	Special Functions	Wheel transmitters learning	
-	-	IDEA	1.4 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	IDEA	1.4 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA	1.4 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Live Data	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Clutch replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	ECO switch replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Electropump replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Clutch bleed	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	IDEA	1.4 16V	Marelli Selespeed CFC328 Automatic Gearbox	Special Functions	New actuators	
-	-	IDEA	1.4 16V	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA	1.4 16V	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA	1.4 16V	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA	1.4 16V	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA	1.4 16V	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA	1.4 16V	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.4 16V	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Read ECU Information	-	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Read Fault Code	-	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Live Data	-	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Actuation Test	-	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Startup with code card	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Knock counter reset	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Overboost counter reset	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Neutral signal learn	
-	-	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	IDEA	1.4 16V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	IDEA	1.4 16V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	IDEA	1.4 16V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	IDEA	1.4 16V	Convergence Lauberhorn Cl	Live Data	-	
-	-	IDEA	1.4 16V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	IDEA	1.4 16V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	IDEA	1.4 16V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	IDEA	1.4 8V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	IDEA	1.4 8V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	IDEA	1.4 8V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	IDEA	1.4 8V	TRW 3 Electric Steering	Live Data	-	
-	-	IDEA	1.4 8V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.4 8V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	IDEA	1.4 8V	Injection Landi Renzo LC02 Gas	Read ECU Information	-	
-	-	IDEA	1.4 8V	Injection Landi Renzo LC02 Gas	Read Fault Code	-	
-	-	IDEA	1.4 8V	Injection Landi Renzo LC02 Gas	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Injection Landi Renzo LC02 Gas	Live Data	-	
-	-	IDEA	1.4 8V	Injection Landi Renzo LC02 Gas	Actuation Test	-	
-	-	IDEA	1.4 8V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA	1.4 8V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA	1.4 8V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA	1.4 8V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA	1.4 8V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.4 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA	1.4 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA	1.4 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Bosch 8 ABS	Live Data	-	
-	-	IDEA	1.4 8V	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA	1.4 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA	1.4 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA	1.4 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA	1.4 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA	1.4 8V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	IDEA	1.4 8V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	IDEA	1.4 8V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	IDEA	1.4 8V	G.E. Procond Passenger Door	Live Data	-	
-	-	IDEA	1.4 8V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	IDEA	1.4 8V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	IDEA	1.4 8V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	IDEA	1.4 8V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.4 8V	G.E. Procond Driver's Door	Live Data	-	
-	-	IDEA	1.4 8V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	IDEA	1.4 8V	G.E. Procond Boot	Read ECU Information	-	
-	-	IDEA	1.4 8V	G.E. Procond Boot	Read Fault Code	-	
-	-	IDEA	1.4 8V	G.E. Procond Boot	Erase Fault Code	-	
-	-	IDEA	1.4 8V	G.E. Procond Boot	Live Data	-	
-	-	IDEA	1.4 8V	G.E. Procond Boot	Actuation Test	-	
-	-	IDEA	1.4 8V	TRW 1 Power Steering	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.4 8V	TRW 1 Power Steering	Read Fault Code	-	
-	-	IDEA	1.4 8V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	IDEA	1.4 8V	TRW 1 Power Steering	Live Data	-	
-	-	IDEA	1.4 8V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.4 8V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Read ECU Information	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Read Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Live Data	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Actuation Test	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Special Functions	Key programming	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Special Functions	Siren serial line check	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Special Functions	Ultrasound sensor check	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Special Functions	Tilt sensor check (if present)	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.4 8V	Marelli Body Computer 1	Special Functions	Window wash system check	
-	-	IDEA	1.4 8V	Denso Climate Control 1 (Two-zone)	Read ECU Information	-	
-	-	IDEA	1.4 8V	Denso Climate Control 1 (Two-zone)	Read Fault Code	-	
-	-	IDEA	1.4 8V	Denso Climate Control 1 (Two-zone)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Denso Climate Control 1 (Two-zone)	Live Data	-	
-	-	IDEA	1.4 8V	Denso Climate Control 1 (Two-zone)	Actuation Test	-	
-	-	IDEA	1.4 8V	Denso Climate Control 1 (Two-zone)	Special Functions	Flap actuators learning test	
-	-	IDEA	1.4 8V	Denso Climate Control 1 (Two-zone)	Special Functions	Pollution sensor test	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Read ECU Information	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Read Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Live Data	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Actuation Test	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Special Functions	Inputs status	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Special Functions	Reset odometer	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.4 8V	Single Driver's Door G.E. Procond	Read ECU Information	-	
-	-	IDEA	1.4 8V	Single Driver's Door G.E. Procond	Read Fault Code	-	
-	-	IDEA	1.4 8V	Single Driver's Door G.E. Procond	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Single Driver's Door G.E. Procond	Live Data	-	
-	-	IDEA	1.4 8V	Single Driver's Door G.E. Procond	Actuation Test	-	
-	-	IDEA	1.4 8V	Schrader Tyre Pressure Check	Read ECU Information	-	
-	-	IDEA	1.4 8V	Schrader Tyre Pressure Check	Read Fault Code	-	
-	-	IDEA	1.4 8V	Schrader Tyre Pressure Check	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Schrader Tyre Pressure Check	Live Data	-	
-	-	IDEA	1.4 8V	Schrader Tyre Pressure Check	Special Functions	Wheel transmitters learning	
-	-	IDEA	1.4 8V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	IDEA	1.4 8V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	IDEA	1.4 8V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	IDEA	1.4 8V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read ECU Information	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read Fault Code	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Live Data	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Actuation Test	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Startup with code card	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phonic wheel learn reset	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Throttle learn storage	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Vehicle configuration deletion	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Cruise control learn	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Air conditioner learn	
-	-	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phase sensor learn zeroing	
-	-	IDEA	1.4 8V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA	1.4 8V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA	1.4 8V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA	1.4 8V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA	1.4 8V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA	1.4 8V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA	1.4 8V	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA	1.4 8V	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA	1.4 8V	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA	1.4 8V	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA	1.4 8V	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA	1.4 8V	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.4 8V	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.4 8V	Injection, Bosch Motronic Me7.9.9 (1.4 eng.)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.4 8V	Injection, Bosch Motronic Me7.9.9 (1.4 eng.)	Read Fault Code	-	
-	-	IDEA	1.4 8V	Injection, Bosch Motronic Me7.9.9 (1.4 eng.)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Injection, Bosch Motronic Me7.9.9 (1.4 eng.)	Live Data	-	
-	-	IDEA	1.4 8V	Injection, Bosch Motronic Me7.9.9 (1.4 eng.)	Actuation Test	-	
-	-	IDEA	1.4 8V	Injection, Bosch Motronic Me7.9.9 (1.4 eng.)	Special Functions	Startup with code card	
-	-	IDEA	1.4 8V	Injection, Bosch Motronic Me7.9.9 (1.4 eng.)	Special Functions	Fuel supply system	
-	-	IDEA	1.4 8V	Injection, Bosch Motronic Me7.9.9 (1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	IDEA	1.4 8V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	IDEA	1.4 8V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	IDEA	1.4 8V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Convergence Lauberhorn Cl	Live Data	-	
-	-	IDEA	1.4 8V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	IDEA	1.4 8V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	IDEA	1.4 8V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Read ECU Information	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Read Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Live Data	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Actuation Test	-	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Servicing information delete	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Inputs status	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Oil change servicing information delete	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Reset odometer	
-	-	IDEA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Read ECU Information	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Read Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Live Data	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Actuation Test	-	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Special Functions	Key programming	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Special Functions	Window wash system check	
-	-	IDEA	1.4 8V	Marelli Body Computer 2	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Read ECU Information	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Read Fault Code	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Erase Fault Code	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Read Data Stream	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Actuation Test	-	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Special Functions	Startup with code card	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Special Functions	Phonic wheel learn reset	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Special Functions	Self-adapting parameters zeroing	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Special Functions	Throttle learn storage	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Special Functions	Vehicle configuration deletion	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Special Functions	Air conditioner learn	
-	-	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	Special Functions	Phase sensor learn zeroing	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Read ECU Information	-	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Read Fault Code	-	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Live Data	-	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Actuation Test	-	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Phonic wheel learn reset	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Throttle learn storage	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Vehicle configuration deletion	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Air/Fuel learn setting	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Alcohol fuel setting	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Petrol fuel setting	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Air conditioner learn	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Startup with code card	
-	-	IDEA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Phase sensor learn zeroing	
-	-	IDEA	1.6 16V	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	IDEA	1.6 16V	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	IDEA	1.6 16V	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	IDEA	1.6 16V	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	IDEA	1.6 16V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	IDEA	1.6 16V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	IDEA	1.6 16V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	IDEA	1.6 16V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	IDEA	1.6 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA	1.6 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA	1.6 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA	1.6 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA	1.6 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA	1.6 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA	1.6 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA	1.6 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Bosch 8 ABS	Live Data	-	
-	-	IDEA	1.6 16V	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA	1.6 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA	1.6 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA	1.6 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA	1.6 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Read ECU Information	-	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Read Fault Code	-	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Live Data	-	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Actuation Test	-	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Servicing information delete	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Inputs status	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Oil change servicing information delete	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Reset odometer	
-	-	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Read ECU Information	-	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Read Fault Code	-	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Live Data	-	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Actuation Test	-	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Special Functions	Key programming	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Special Functions	Window wash system check	
-	-	IDEA	1.6 16V	Marelli Body Computer 2	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.6 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA	1.6 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA	1.6 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Marelli/Microsoft Convergence	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.6 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA	1.6 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA	1.6 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA	1.6 16V	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA	1.6 16V	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA	1.6 16V	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA	1.6 16V	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA	1.6 16V	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA	1.6 16V	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.6 16V	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.6 16V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	IDEA	1.6 16V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	IDEA	1.6 16V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	IDEA	1.6 16V	Convergence Lauberhorn Cl	Live Data	-	
-	-	IDEA	1.6 16V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	IDEA	1.6 16V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	IDEA	1.6 16V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	IDEA	1.6 MJET 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW 3 Electric Steering	Live Data	-	
-	-	IDEA	1.6 MJET 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.6 MJET 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	IDEA	1.6 MJET 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA	1.6 MJET 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.6 MJET 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 ABS	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Boot	Live Data	-	
-	-	IDEA	1.6 MJET 16V	G.E. Procond Boot	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW 1 Power Steering	Live Data	-	
-	-	IDEA	1.6 MJET 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.6 MJET 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.6 MJET 16V	Denso Climate Control 1 (Two-zone)	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Denso Climate Control 1 (Two-zone)	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Denso Climate Control 1 (Two-zone)	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Denso Climate Control 1 (Two-zone)	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Denso Climate Control 1 (Two-zone)	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Denso Climate Control 1 (Two-zone)	Special Functions	Flap actuators learning test	
-	-	IDEA	1.6 MJET 16V	Denso Climate Control 1 (Two-zone)	Special Functions	Pollution sensor test	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Special Functions	Inputs status	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Special Functions	Reset odometer	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	Special Functions	Instrument panel replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.6 MJET 16V	Single Driver's Door G.E. Procond	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Single Driver's Door G.E. Procond	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Single Driver's Door G.E. Procond	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Single Driver's Door G.E. Procond	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Single Driver's Door G.E. Procond	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Schrader Tyre Pressure Check	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Schrader Tyre Pressure Check	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Schrader Tyre Pressure Check	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Schrader Tyre Pressure Check	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Schrader Tyre Pressure Check	Special Functions	Wheel transmitters learning	
-	-	IDEA	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA	1.6 MJET 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Startup with code card	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector codes read	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Control unit replacement	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	IDEA	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	IDEA	1.6 MJET 16V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	IDEA	1.6 MJET 16V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	IDEA	1.6 MJET 16V	Convergence Lauberhorn C1	Live Data	-	
-	-	IDEA	1.6 MJET 16V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	IDEA	1.6 MJET 16V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	IDEA	1.6 MJET 16V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	IDEA	1.8 8V	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	IDEA	1.8 8V	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	IDEA	1.8 8V	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	IDEA	1.8 8V	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	IDEA	1.8 8V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	IDEA	1.8 8V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	IDEA	1.8 8V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	IDEA	1.8 8V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	IDEA	1.8 8V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA	1.8 8V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA	1.8 8V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA	1.8 8V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA	1.8 8V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA	1.8 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA	1.8 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA	1.8 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Bosch 8 ABS	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.8 8V	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA	1.8 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA	1.8 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA	1.8 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA	1.8 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Read ECU Information	-	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Read Fault Code	-	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Live Data	-	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Actuation Test	-	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Servicing information delete	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Inputs status	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Oil change servicing information delete	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Reset odometer	
-	-	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Read ECU Information	-	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Read Fault Code	-	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Live Data	-	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Actuation Test	-	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Special Functions	Key programming	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Special Functions	Window wash system check	
-	-	IDEA	1.8 8V	Marelli Body Computer 2	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.8 8V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA	1.8 8V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA	1.8 8V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA	1.8 8V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA	1.8 8V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA	1.8 8V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Read ECU Information	-	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Read Fault Code	-	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Live Data	-	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Actuation Test	-	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Startup with code card	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Self-adapting parameters zeroing (air)	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Self-adapting parameters zeroing (knock)	
-	-	IDEA	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Zeroing fan mode learn	
-	-	IDEA	1.8 8V	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA	1.8 8V	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA	1.8 8V	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA	1.8 8V	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA	1.8 8V	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA	1.8 8V	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.8 8V	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.8 8V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	IDEA	1.8 8V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	IDEA	1.8 8V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	IDEA	1.8 8V	Convergence Lauberhorn Cl	Live Data	-	
-	-	IDEA	1.8 8V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	IDEA	1.8 8V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	IDEA	1.8 8V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	IDEA	1.9 JTD	TRW 3 Electric Steering	Read ECU Information	-	
-	-	IDEA	1.9 JTD	TRW 3 Electric Steering	Read Fault Code	-	
-	-	IDEA	1.9 JTD	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	TRW 3 Electric Steering	Live Data	-	
-	-	IDEA	1.9 JTD	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.9 JTD	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	IDEA	1.9 JTD	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA	1.9 JTD	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA	1.9 JTD	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA	1.9 JTD	Single BITRON Driver's Door	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Single BITRON Driver's Door	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Single BITRON Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Single BITRON Driver's Door	Live Data	-	
-	-	IDEA	1.9 JTD	Single BITRON Driver's Door	Actuation Test	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.9 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Bosch 8 ABS	Live Data	-	
-	-	IDEA	1.9 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA	1.9 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA	1.9 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA	1.9 JTD	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	IDEA	1.9 JTD	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	IDEA	1.9 JTD	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	G.E. Procond Passenger Door	Live Data	-	
-	-	IDEA	1.9 JTD	G.E. Procond Passenger Door	Actuation Test	-	
-	-	IDEA	1.9 JTD	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	IDEA	1.9 JTD	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	IDEA	1.9 JTD	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	G.E. Procond Driver's Door	Live Data	-	
-	-	IDEA	1.9 JTD	G.E. Procond Driver's Door	Actuation Test	-	
-	-	IDEA	1.9 JTD	G.E. Procond Boot	Read ECU Information	-	
-	-	IDEA	1.9 JTD	G.E. Procond Boot	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.9 JTD	G.E. Procond Boot	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	G.E. Procond Boot	Live Data	-	
-	-	IDEA	1.9 JTD	G.E. Procond Boot	Actuation Test	-	
-	-	IDEA	1.9 JTD	TRW 1 Power Steering	Read ECU Information	-	
-	-	IDEA	1.9 JTD	TRW 1 Power Steering	Read Fault Code	-	
-	-	IDEA	1.9 JTD	TRW 1 Power Steering	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	TRW 1 Power Steering	Live Data	-	
-	-	IDEA	1.9 JTD	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	IDEA	1.9 JTD	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Live Data	-	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Actuation Test	-	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Special Functions	Key programming	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Special Functions	Siren serial line check	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Special Functions	Ultrasound sensor check	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Special Functions	Tilt sensor check (if present)	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.9 JTD	Marelli Body Computer 1	Special Functions	Window wash system check	
-	-	IDEA	1.9 JTD	Denso Climate Control 1 (Two-zone)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Denso Climate Control 1 (Two-zone)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Denso Climate Control 1 (Two-zone)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Denso Climate Control 1 (Two-zone)	Live Data	-	
-	-	IDEA	1.9 JTD	Denso Climate Control 1 (Two-zone)	Actuation Test	-	
-	-	IDEA	1.9 JTD	Denso Climate Control 1 (Two-zone)	Special Functions	Flap actuators learning test	
-	-	IDEA	1.9 JTD	Denso Climate Control 1 (Two-zone)	Special Functions	Pollution sensor test	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Live Data	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Actuation Test	-	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Special Functions	Headlamp pos. correct.	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Special Functions	Inputs status	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Special Functions	Reset odometer	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm enable	
-	-	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	Special Functions	Instrument panel replacement	
-	-	IDEA	1.9 JTD	Single Driver's Door G.E. Procond	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Single Driver's Door G.E. Procond	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Single Driver's Door G.E. Procond	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Single Driver's Door G.E. Procond	Live Data	-	
-	-	IDEA	1.9 JTD	Single Driver's Door G.E. Procond	Actuation Test	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Live Data	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Actuation Test	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Special Functions	Startup with code card	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Special Functions	Injector codes read	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Special Functions	Cyl. 1 injector classification	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Special Functions	Cyl. 2 injector classification	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Special Functions	Cyl. 3 injector classification	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Special Functions	Cyl. 4 injector classification	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	Special Functions	Injector classification (4 cyl. bank)	
-	-	IDEA	1.9 JTD	Schrader Tyre Pressure Check	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Schrader Tyre Pressure Check	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Schrader Tyre Pressure Check	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Schrader Tyre Pressure Check	Live Data	-	
-	-	IDEA	1.9 JTD	Schrader Tyre Pressure Check	Special Functions	Wheel transmitters learning	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Live Data	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Actuation Test	-	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Startup with code card	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Injector codes read	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Replacement injectors (4 cyl. bank)	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Control unit replacement	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Replacement of control unit and injectors	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Air flow sensor replacement	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Replacement lambda sensor	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	IDEA	1.9 JTD	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	IDEA	1.9 JTD	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	IDEA	1.9 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA	1.9 JTD	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA	1.9 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA	1.9 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA	1.9 JTD	Marelli 7 Body Computer	Read ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA	1.9 JTD	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA	1.9 JTD	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA	1.9 JTD	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA	1.9 JTD	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA	1.9 JTD	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA	1.9 JTD	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	IDEA	1.9 JTD	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	IDEA	1.9 JTD	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	IDEA	1.9 JTD	Convergence Lauberhorn Cl	Live Data	-	
-	-	IDEA	1.9 JTD	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	IDEA	1.9 JTD	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	IDEA	1.9 JTD	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Read ECU Information	-	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Read Fault Code	-	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Erase Fault Code	-	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Live Data	-	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Actuation Test	-	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Phonic wheel learn reset	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Throttle learn storage	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Vehicle configuration deletion	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Air/Fuel learn setting	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Alcohol fuel setting	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Petrol fuel setting	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Air conditioner learn	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Startup with code card	
-	-	IDEA	1.8 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Phase sensor learn zeroing	
-	-	IDEA VAN	1.3 JTD	TRW 3 Electric Steering	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	TRW 3 Electric Steering	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW 3 Electric Steering	Live Data	-	
-	-	IDEA VAN	1.3 JTD	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	IDEA VAN	1.3 JTD	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Clutch replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Tunnel lever replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Gearbox oil accumulator replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Longitudinal acceleration signal learn	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	ECO switch replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Electropump replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Gearbox replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Clutch bleed	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Accumulator depressurisation	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Clutch self-calibration enable	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Pump relay replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Hydraulic kit replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Gearbox and hydraulic KIT replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Calculation of clutch degradation index	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	Special Functions	End of line / service self-calibration	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Oil change	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	IDEA VAN	1.3 JTD	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA VAN	1.3 JTD	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 1 injector classification	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 2 injector classification	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 3 injector classification	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 4 injector classification	
-	-	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector classification (4 cyl. bank)	
-	-	IDEA VAN	1.3 JTD	Single Bitron Driver's Door	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Single Bitron Driver's Door	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Single Bitron Driver's Door	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Single Bitron Driver's Door	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Single Bitron Driver's Door	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	IDEA VAN	1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Passenger Door	Live Data	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Passenger Door	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Driver's Door	Live Data	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Driver's Door	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Boot	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Boot	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Boot	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Boot	Live Data	-	
-	-	IDEA VAN	1.3 JTD	G.E. Procond Boot	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	TRW 1 Power Steering	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	TRW 1 Power Steering	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW 1 Power Steering	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW 1 Power Steering	Live Data	-	
-	-	IDEA VAN	1.3 JTD	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	IDEA VAN	1.3 JTD	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Special Functions	Memory mode write	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Special Functions	Key programming	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Special Functions	Siren serial line check	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Special Functions	Ultrasound sensor check	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Special Functions	Tilt sensor check (if present)	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Special Functions	Dusk and rain sensors check	
-	-	IDEA VAN	1.3 JTD	Marelli Body Computer 1	Special Functions	Window wash system check	
-	-	IDEA VAN	1.3 JTD	Denso Climate Control 1 (Two-zone)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Denso Climate Control 1 (Two-zone)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Denso Climate Control 1 (Two-zone)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Denso Climate Control 1 (Two-zone)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Denso Climate Control 1 (Two-zone)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Denso Climate Control 1 (Two-zone)	Special Functions	Flap actuators learning test	
-	-	IDEA VAN	1.3 JTD	Denso Climate Control 1 (Two-zone)	Special Functions	Pollution sensor test	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Headlamp pos. correct.	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Inputs status	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Reset odometer	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm enable	
-	-	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	Special Functions	Instrument panel replacement	
-	-	IDEA VAN	1.3 JTD	Single Driver's Door G.E. Procond	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Single Driver's Door G.E. Procond	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Single Driver's Door G.E. Procond	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Single Driver's Door G.E. Procond	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Single Driver's Door G.E. Procond	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Statistical data deletion	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Tunnel lever replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	SPORT switch replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Steering wheel levers replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Electropump replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	End of line / service self-calibration	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch bleed	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Accumulator depressurisation	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch self-calibration enable	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Pump relay replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Gearbox replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Pump replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	CITY switch replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Deletion of statistical data relating to errors	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Calculation of clutch degradation index	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Engagement lever pin securing screw diagnosis	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	New actuators	
-	-	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Selection lever return diagnosis	
-	-	IDEA VAN	1.3 JTD	Schrader Tyre Pressure Check	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Schrader Tyre Pressure Check	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Schrader Tyre Pressure Check	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Schrader Tyre Pressure Check	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Schrader Tyre Pressure Check	Special Functions	Wheel transmitters learning	
-	-	IDEA VAN	1.3 JTD	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	IDEA VAN	1.3 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA VAN	1.3 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA VAN	1.4 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW 3 Electric Steering	Live Data	-	
-	-	IDEA VAN	1.4 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	IDEA VAN	1.4 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	IDEA VAN	1.4 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Valeo Parking Control Unit	Live Data	-	
-	-	IDEA VAN	1.4 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	IDEA VAN	1.4 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	IDEA VAN	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Live Data	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Special Functions	Startup with code card	
-	-	IDEA VAN	1.4 16V	Single Bitron Driver's Door	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Single Bitron Driver's Door	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Single Bitron Driver's Door	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Single Bitron Driver's Door	Live Data	-	
-	-	IDEA VAN	1.4 16V	Single Bitron Driver's Door	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch replacement	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Electropump replacement	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch bleed	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Pump replacement	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Deletion of statistical data relating to errors	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	IDEA VAN	1.4 16V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	New actuators	
-	-	IDEA VAN	1.4 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 ABS	Live Data	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 ABS	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	IDEA VAN	1.4 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Boot	Live Data	-	
-	-	IDEA VAN	1.4 16V	G.E. Procond Boot	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW 1 Power Steering	Live Data	-	
-	-	IDEA VAN	1.4 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	IDEA VAN	1.4 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	Special Functions	Memory mode write	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Live Data	-	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Special Functions	Key programming	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Special Functions	Siren serial line check	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Special Functions	Ultrasound sensor check	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Special Functions	Tilt sensor check (if present)	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Special Functions	Dusk and rain sensors check	
-	-	IDEA VAN	1.4 16V	Marelli Body Computer 1	Special Functions	Window wash system check	
-	-	IDEA VAN	1.4 16V	Denso Climate Control 1 (Two-zone)	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Denso Climate Control 1 (Two-zone)	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Denso Climate Control 1 (Two-zone)	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Denso Climate Control 1 (Two-zone)	Live Data	-	
-	-	IDEA VAN	1.4 16V	Denso Climate Control 1 (Two-zone)	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Denso Climate Control 1 (Two-zone)	Special Functions	Flap actuators learning test	
-	-	IDEA VAN	1.4 16V	Denso Climate Control 1 (Two-zone)	Special Functions	Pollution sensor test	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Live Data	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	Special Functions	Memory mode write	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Live Data	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	Special Functions	Memory mode write	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Live Data	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Headlamp pos. correct.	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Inputs status	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Reset odometer	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm exclusion	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Seat belts alarm enable	
-	-	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	Special Functions	Instrument panel replacement	
-	-	IDEA VAN	1.4 16V	Single Driver's Door G.E. Procond	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Single Driver's Door G.E. Procond	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Single Driver's Door G.E. Procond	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Single Driver's Door G.E. Procond	Live Data	-	
-	-	IDEA VAN	1.4 16V	Single Driver's Door G.E. Procond	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Schrader Tyre Pressure Check	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Schrader Tyre Pressure Check	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Schrader Tyre Pressure Check	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Schrader Tyre Pressure Check	Live Data	-	
-	-	IDEA VAN	1.4 16V	Schrader Tyre Pressure Check	Special Functions	Wheel transmitters learning	
-	-	IDEA VAN	1.4 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	IDEA VAN	1.4 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	IDEA VAN	1.4 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	IDEA VAN	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Live Data	-	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Clutch replacement	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	ECO switch replacement	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Electropump replacement	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Clutch bleed	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	Special Functions	New actuators	
-	-	IDEA VAN	1.4 16V	Marelli 7 Body Computer	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Marelli 7 Body Computer	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli 7 Body Computer	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Marelli 7 Body Computer	Live Data	-	
-	-	IDEA VAN	1.4 16V	Marelli 7 Body Computer	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Marelli 7 Body Computer	Special Functions	Key programming	
-	-	IDEA VAN	1.4 16V	Marelli 7 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	IDEA VAN	1.4 16V	Marelli 7 Body Computer	Special Functions	Indicators command enable/disable	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Live Data	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Startup with code card	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Knock counter reset	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Overboost counter reset	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Neutral signal learn	
-	-	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	IDEA VAN	1.4 16V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	IDEA VAN	1.4 16V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	IDEA VAN	1.4 16V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	IDEA VAN	1.4 16V	Convergence Lauberhorn C1	Live Data	-	
-	-	IDEA VAN	1.4 16V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	IDEA VAN	1.4 16V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	IDEA VAN	1.4 16V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	LINEA	1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	LINEA	1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	LINEA	1.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	LINEA	1.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Live Data	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Actuation Test	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 E0BD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	LINEA	1.3 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.3 JTD	Marelli/Microsoft Convergence	Live Data	-	
-	-	LINEA	1.3 JTD	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	LINEA	1.3 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	LINEA	1.3 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	LINEA	1.3 JTD	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Bosch Parking Control Unit (1)	Live Data	-	
-	-	LINEA	1.3 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	LINEA	1.3 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	LINEA	1.3 JTD	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	LINEA	1.3 JTD	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	LINEA	1.3 JTD	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.3 JTD	Denso 4 Climate Control (Two-zone)	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Denso 4 Climate Control (Two-zone)	Read fault code	-	
-	-	LINEA	1.3 JTD	Denso 4 Climate Control (Two-zone)	Erase fault code	-	
-	-	LINEA	1.3 JTD	Denso 4 Climate Control (Two-zone)	Read data stream	-	
-	-	LINEA	1.3 JTD	Denso 4 Climate Control (Two-zone)	Actuation Test	-	
-	-	LINEA	1.3 JTD	Denso 4 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Live Data	-	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Actuation Test	-	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	ECO/SPORT switch replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Electropump replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch bleed	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	LINEA	1.3 JTD	Marelli Selespeed CFC300 Automatic Gearbox	Special Functions	New actuators	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Live Data	-	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Actuation Test	-	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Read fault code	-	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Erase fault code	-	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Read data stream	-	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Special Functions	Instrument panel replacement	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Special Functions	Reset odometer	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.3 JTD	Marelli 4 Cluster	Special Functions	Servicing information delete	
-	-	LINEA	1.3 JTD	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	LINEA	1.3 JTD	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	LINEA	1.3 JTD	Marelli Body Computer 9	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Marelli Body Computer 9	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Body Computer 9	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Body Computer 9	Live Data	-	
-	-	LINEA	1.3 JTD	Marelli Body Computer 9	Actuation Test	-	
-	-	LINEA	1.3 JTD	Marelli Body Computer 9	Special Functions	Key programming	
-	-	LINEA	1.3 JTD	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	LINEA	1.3 JTD	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Convergence Lauberhorn C1	Live Data	-	
-	-	LINEA	1.3 JTD	Convergence Lauberhorn C1	Actuation Test	-	
-	-	LINEA	1.3 JTD	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	LINEA	1.3 JTD	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Read Data Stream	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Control unit replacement	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Oil change	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EObD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EObD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EObD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EObD (eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EObD (eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EObD (eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	LINEA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EObD (eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	LINEA	1.4 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	LINEA	1.4 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	LINEA	1.4 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Bosch 8 ABS	Live Data	-	
-	-	LINEA	1.4 16V	Bosch 8 ABS	Actuation Test	-	
-	-	LINEA	1.4 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	LINEA	1.4 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	LINEA	1.4 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	LINEA	1.4 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	LINEA	1.4 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	LINEA	1.4 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	LINEA	1.4 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	LINEA	1.4 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	LINEA	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	LINEA	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	LINEA	1.4 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	LINEA	1.4 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	LINEA	1.4 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	LINEA	1.4 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	LINEA	1.4 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	LINEA	1.4 16V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	LINEA	1.4 16V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	LINEA	1.4 16V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	LINEA	1.4 16V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	LINEA	1.4 16V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.4 16V	Denso 4 Climate Control (Two-zone)	Read ECU Information	-	
-	-	LINEA	1.4 16V	Denso 4 Climate Control (Two-zone)	Read fault code	-	
-	-	LINEA	1.4 16V	Denso 4 Climate Control (Two-zone)	Erase fault code	-	
-	-	LINEA	1.4 16V	Denso 4 Climate Control (Two-zone)	Read data stream	-	
-	-	LINEA	1.4 16V	Denso 4 Climate Control (Two-zone)	Actuation Test	-	
-	-	LINEA	1.4 16V	Denso 4 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.4 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Read ECU Information	-	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Read fault code	-	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Erase fault code	-	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Read data stream	-	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Special Functions	Instrument panel replacement	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Special Functions	Reset odometer	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.4 16V	Marelli 4 Cluster	Special Functions	Servicing information delete	
-	-	LINEA	1.4 16V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	LINEA	1.4 16V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	LINEA	1.4 16V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	LINEA	1.4 16V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	LINEA	1.4 16V	Marelli Body Computer 9	Read ECU Information	-	
-	-	LINEA	1.4 16V	Marelli Body Computer 9	Read Fault Code	-	
-	-	LINEA	1.4 16V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Marelli Body Computer 9	Live Data	-	
-	-	LINEA	1.4 16V	Marelli Body Computer 9	Actuation Test	-	
-	-	LINEA	1.4 16V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	LINEA	1.4 16V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	LINEA	1.4 16V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	LINEA	1.4 16V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	LINEA	1.4 16V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Convergence Lauberhorn Cl	Live Data	-	
-	-	LINEA	1.4 16V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	LINEA	1.4 16V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	LINEA	1.4 16V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Read ECU Information	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Read Fault Code	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Live Data	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Actuation Test	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Read ECU Information	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Read Fault Code	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Erase Fault Code	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Live Data	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Actuation Test	-	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Special Functions	Startup with code card	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Special Functions	Knock counter reset	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Special Functions	Overboost counter reset	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Special Functions	Neutral signal learn	
-	-	LINEA	1.4 16V	Bosch injection Motronic Me7.9.10 PDA (eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	LINEA	1.4 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	LINEA	1.4 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	LINEA	1.4 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Bosch 8 ABS	Live Data	-	
-	-	LINEA	1.4 8V	Bosch 8 ABS	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.4 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	LINEA	1.4 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	LINEA	1.4 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	LINEA	1.4 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read ECU Information	-	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read Fault Code	-	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Live Data	-	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Actuation Test	-	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Startup with code card	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phonic wheel learn reset	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Throttle learn storage	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Vehicle configuration deletion	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Cruise control learn	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Air conditioner learn	
-	-	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phase sensor learn zeroing	
-	-	LINEA	1.4 8V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	LINEA	1.4 8V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	LINEA	1.4 8V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Marelli/Microsoft Convergence	Live Data	-	
-	-	LINEA	1.4 8V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	LINEA	1.4 8V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	LINEA	1.4 8V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	LINEA	1.4 8V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	LINEA	1.4 8V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	LINEA	1.4 8V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	LINEA	1.4 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	LINEA	1.4 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	LINEA	1.4 8V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	LINEA	1.4 8V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	LINEA	1.4 8V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	LINEA	1.4 8V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	LINEA	1.4 8V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.4 8V	Denso 4 Climate Control (Two-zone)	Read ECU Information	-	
-	-	LINEA	1.4 8V	Denso 4 Climate Control (Two-zone)	Read fault code	-	
-	-	LINEA	1.4 8V	Denso 4 Climate Control (Two-zone)	Erase fault code	-	
-	-	LINEA	1.4 8V	Denso 4 Climate Control (Two-zone)	Read data stream	-	
-	-	LINEA	1.4 8V	Denso 4 Climate Control (Two-zone)	Actuation Test	-	
-	-	LINEA	1.4 8V	Denso 4 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Live Data	-	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.4 8V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Read ECU Information	-	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Read fault code	-	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Erase fault code	-	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Read data stream	-	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Special Functions	Instrument panel replacement	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Special Functions	Reset odometer	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.4 8V	Marelli 4 Cluster	Special Functions	Servicing information delete	
-	-	LINEA	1.4 8V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	LINEA	1.4 8V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	LINEA	1.4 8V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	LINEA	1.4 8V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	LINEA	1.4 8V	Marelli Body Computer 9	Read ECU Information	-	
-	-	LINEA	1.4 8V	Marelli Body Computer 9	Read Fault Code	-	
-	-	LINEA	1.4 8V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Marelli Body Computer 9	Live Data	-	
-	-	LINEA	1.4 8V	Marelli Body Computer 9	Actuation Test	-	
-	-	LINEA	1.4 8V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	LINEA	1.4 8V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	LINEA	1.4 8V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	LINEA	1.4 8V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	LINEA	1.4 8V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	LINEA	1.4 8V	Convergence Lauberhorn C1	Live Data	-	
-	-	LINEA	1.4 8V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	LINEA	1.4 8V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	LINEA	1.4 8V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 ABS	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 ABS	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Marelli/Microsoft Convergence	Read ECU Information	-	



**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.4 TURBO 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	LINEA	1.4 TURBO 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	LINEA	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	LINEA	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	LINEA	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.4 TURBO 16V	Denso 4 Climate Control (Two-zone)	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Denso 4 Climate Control (Two-zone)	Read fault code	-	
-	-	LINEA	1.4 TURBO 16V	Denso 4 Climate Control (Two-zone)	Erase fault code	-	
-	-	LINEA	1.4 TURBO 16V	Denso 4 Climate Control (Two-zone)	Read data stream	-	
-	-	LINEA	1.4 TURBO 16V	Denso 4 Climate Control (Two-zone)	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Denso 4 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Read fault code	-	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Erase fault code	-	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Read data stream	-	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Special Functions	Instrument panel replacement	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Special Functions	Reset odometer	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.4 TURBO 16V	Marelli 4 Cluster	Special Functions	Servicing information delete	
-	-	LINEA	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Startup with code card	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Knock counter reset	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Overboost counter reset	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Self-learnt functions reset	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Neutral signal learn	
-	-	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	LINEA	1.4 TURBO 16V	Marelli Body Computer 9	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Body Computer 9	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Body Computer 9	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Body Computer 9	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	LINEA	1.4 TURBO 16V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	LINEA	1.4 TURBO 16V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	LINEA	1.4 TURBO 16V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	LINEA	1.4 TURBO 16V	Convergence Lauberhorn C1	Live Data	-	
-	-	LINEA	1.4 TURBO 16V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	LINEA	1.4 TURBO 16V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	LINEA	1.4 TURBO 16V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read ECU Information	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read Fault Code	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Live Data	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Actuation Test	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read ECU Information	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read Fault Code	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Live Data	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Actuation Test	-	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Startup with code card	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Phonic wheel learn reset	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Throttle learn storage	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Vehicle configuration deletion	
-	-	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Air conditioner learn	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Read ECU Information	-	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Live Data	-	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Actuation Test	-	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Levers on steering wheel learn	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Statistical data deletion	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Tunnel lever replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Steering wheel levers replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Gearbox oil accumulator replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	ECO/SPORT switch replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Electropump replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	End of line / service self-calibration	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Gearbox replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch bleed	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Accumulator depressurisation	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch self-calibration enable	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Pump relay replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	KIT/Gearbox replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	AUTO switch replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	New actuators	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Hydraulic kit replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Sensor replacement	
-	-	LINEA	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	LINEA	1.6 16V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	LINEA	1.6 16V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	LINEA	1.6 16V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	LINEA	1.6 16V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	LINEA	1.6 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	LINEA	1.6 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	LINEA	1.6 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Bosch 8 ABS	Live Data	-	
-	-	LINEA	1.6 16V	Bosch 8 ABS	Actuation Test	-	
-	-	LINEA	1.6 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	LINEA	1.6 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	LINEA	1.6 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	LINEA	1.6 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	LINEA	1.6 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	LINEA	1.6 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	LINEA	1.6 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	LINEA	1.6 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	LINEA	1.6 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	LINEA	1.6 16V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	LINEA	1.6 16V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	LINEA	1.6 16V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	LINEA	1.6 16V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	LINEA	1.6 16V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.6 16V	Denso 4 Climate Control (Two-zone)	Read ECU Information	-	
-	-	LINEA	1.6 16V	Denso 4 Climate Control (Two-zone)	Read fault code	-	
-	-	LINEA	1.6 16V	Denso 4 Climate Control (Two-zone)	Erase fault code	-	
-	-	LINEA	1.6 16V	Denso 4 Climate Control (Two-zone)	Read data stream	-	
-	-	LINEA	1.6 16V	Denso 4 Climate Control (Two-zone)	Actuation Test	-	
-	-	LINEA	1.6 16V	Denso 4 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.6 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	LINEA	1.6 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	LINEA	1.6 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	LINEA	1.6 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	LINEA	1.6 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	LINEA	1.6 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.6 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Read ECU Information	-	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Read fault code	-	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Erase fault code	-	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Read data stream	-	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Special Functions	Instrument panel replacement	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Special Functions	Reset odometer	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.6 16V	Marelli 4 Cluster	Special Functions	Servicing information delete	
-	-	LINEA	1.6 16V	Marelli Body Computer 9	Read ECU Information	-	
-	-	LINEA	1.6 16V	Marelli Body Computer 9	Read Fault Code	-	
-	-	LINEA	1.6 16V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Marelli Body Computer 9	Live Data	-	
-	-	LINEA	1.6 16V	Marelli Body Computer 9	Actuation Test	-	
-	-	LINEA	1.6 16V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	LINEA	1.6 16V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	LINEA	1.6 16V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	LINEA	1.6 16V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	LINEA	1.6 16V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	LINEA	1.6 16V	Convergence Lauberhorn C1	Live Data	-	
-	-	LINEA	1.6 16V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	LINEA	1.6 16V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	LINEA	1.6 16V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	LINEA	1.6 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Bosch 8 ABS	Live Data	-	
-	-	LINEA	1.6 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	LINEA	1.6 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.6 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	LINEA	1.6 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	LINEA	1.6 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Marelli/Microsoft Convergence	Live Data	-	
-	-	LINEA	1.6 JTD	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	LINEA	1.6 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	LINEA	1.6 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	LINEA	1.6 JTD	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Bosch Parking Control Unit (1)	Live Data	-	
-	-	LINEA	1.6 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	LINEA	1.6 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	LINEA	1.6 JTD	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	LINEA	1.6 JTD	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	LINEA	1.6 JTD	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.6 JTD	Denso 4 Climate Control (Two-zone)	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Denso 4 Climate Control (Two-zone)	Read fault code	-	
-	-	LINEA	1.6 JTD	Denso 4 Climate Control (Two-zone)	Erase fault code	-	
-	-	LINEA	1.6 JTD	Denso 4 Climate Control (Two-zone)	Read data stream	-	
-	-	LINEA	1.6 JTD	Denso 4 Climate Control (Two-zone)	Actuation Test	-	
-	-	LINEA	1.6 JTD	Denso 4 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Live Data	-	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Actuation Test	-	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.6 JTD	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Read fault code	-	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Erase fault code	-	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Read data stream	-	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Special Functions	Instrument panel replacement	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Special Functions	Reset odometer	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.6 JTD	Marelli 4 Cluster	Special Functions	Servicing information delete	
-	-	LINEA	1.6 JTD	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	LINEA	1.6 JTD	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	LINEA	1.6 JTD	Marelli Body Computer 9	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Marelli Body Computer 9	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Marelli Body Computer 9	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Marelli Body Computer 9	Live Data	-	
-	-	LINEA	1.6 JTD	Marelli Body Computer 9	Actuation Test	-	
-	-	LINEA	1.6 JTD	Marelli Body Computer 9	Special Functions	Key programming	
-	-	LINEA	1.6 JTD	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Live Data	-	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Actuation Test	-	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Startup with code card	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector codes read	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Control unit replacement	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	LINEA	1.6 JTD	Bosch Diesel Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	LINEA	1.6 JTD	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	LINEA	1.6 JTD	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	LINEA	1.6 JTD	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	LINEA	1.6 JTD	Convergence Lauberhorn Cl	Live Data	-	
-	-	LINEA	1.6 JTD	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	LINEA	1.6 JTD	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	LINEA	1.6 JTD	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read ECU Information	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read Fault Code	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Live Data	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Actuation Test	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read ECU Information	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read Fault Code	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Live Data	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Actuation Test	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Actuation Test	-	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Startup with code card	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Phonic wheel learn reset	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Throttle learn storage	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Vehicle configuration deletion	
-	-	LINEA	1.8 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Air conditioner learn	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Read ECU Information	-	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Read Fault Code	-	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Live Data	-	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Actuation Test	-	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Levers on steering wheel learn	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Statistical data deletion	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Tunnel lever replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Steering wheel levers replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Gearbox oil accumulator replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	ECO/SPORT switch replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Electropump replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	End of line / service self-calibration	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Gearbox replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch bleed	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Accumulator depressurisation	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch self-calibration enable	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Pump relay replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	KIT/Gearbox replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	AUTO switch replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	New actuators	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Hydraulic kit replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Sensor replacement	
-	-	LINEA	1.8 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	LINEA	1.8 16V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	LINEA	1.8 16V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	LINEA	1.8 16V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	LINEA	1.8 16V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	LINEA	1.8 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	LINEA	1.8 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	LINEA	1.8 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Bosch 8 ABS	Live Data	-	
-	-	LINEA	1.8 16V	Bosch 8 ABS	Actuation Test	-	
-	-	LINEA	1.8 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	LINEA	1.8 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	LINEA	1.8 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	LINEA	1.8 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	LINEA	1.8 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	LINEA	1.8 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	LINEA	1.8 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	LINEA	1.8 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	LINEA	1.8 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	LINEA	1.8 16V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	LINEA	1.8 16V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	LINEA	1.8 16V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	LINEA	1.8 16V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	LINEA	1.8 16V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.8 16V	Denso 4 Climate Control (Two-zone)	Read ECU Information	-	
-	-	LINEA	1.8 16V	Denso 4 Climate Control (Two-zone)	Read fault code	-	
-	-	LINEA	1.8 16V	Denso 4 Climate Control (Two-zone)	Erase fault code	-	
-	-	LINEA	1.8 16V	Denso 4 Climate Control (Two-zone)	Read data stream	-	
-	-	LINEA	1.8 16V	Denso 4 Climate Control (Two-zone)	Actuation Test	-	
-	-	LINEA	1.8 16V	Denso 4 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.8 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	LINEA	1.8 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	LINEA	1.8 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	LINEA	1.8 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	LINEA	1.8 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	LINEA	1.8 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.8 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Read ECU Information	-	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Read fault code	-	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Erase fault code	-	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Read data stream	-	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Special Functions	Instrument panel replacement	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Special Functions	Reset odometer	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.8 16V	Marelli 4 Cluster	Special Functions	Servicing information delete	
-	-	LINEA	1.8 16V	Marelli Body Computer 9	Read ECU Information	-	
-	-	LINEA	1.8 16V	Marelli Body Computer 9	Read Fault Code	-	
-	-	LINEA	1.8 16V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Marelli Body Computer 9	Live Data	-	
-	-	LINEA	1.8 16V	Marelli Body Computer 9	Actuation Test	-	
-	-	LINEA	1.8 16V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	LINEA	1.8 16V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	LINEA	1.8 16V	Convergence Lauberhorn Cl	Read ECU Information	-	
-	-	LINEA	1.8 16V	Convergence Lauberhorn Cl	Read Fault Code	-	
-	-	LINEA	1.8 16V	Convergence Lauberhorn Cl	Erase Fault Code	-	
-	-	LINEA	1.8 16V	Convergence Lauberhorn Cl	Live Data	-	
-	-	LINEA	1.8 16V	Convergence Lauberhorn Cl	Actuation Test	-	
-	-	LINEA	1.8 16V	Convergence Lauberhorn Cl	Special Functions	Convergence system restart	
-	-	LINEA	1.8 16V	Convergence Lauberhorn Cl	Special Functions	Audio system test	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Read ECU Information	-	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Read Fault Code	-	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Live Data	-	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Actuation Test	-	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Levers on steering wheel learn	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Statistical data deletion	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Tunnel lever replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Steering wheel levers replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Gearbox oil accumulator replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	ECO/SPORT switch replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Electropump replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	End of line / service self-calibration	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Gearbox replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch bleed	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Accumulator depressurisation	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch self-calibration enable	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Pump relay replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	KIT/Gearbox replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	AUTO switch replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	New actuators	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Hydraulic kit replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Sensor replacement	
-	-	LINEA	1.9 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	LINEA	1.9 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	LINEA	1.9 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	LINEA	1.9 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Bosch 8 ABS	Live Data	-	
-	-	LINEA	1.9 16V	Bosch 8 ABS	Actuation Test	-	
-	-	LINEA	1.9 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	LINEA	1.9 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	LINEA	1.9 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	LINEA	1.9 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Read ECU Information	-	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Read Fault Code	-	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Live Data	-	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Actuation Test	-	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Special Functions	Startup with code card	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Special Functions	Phonic wheel learn reset	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Special Functions	Zeroing of self-adaption parameters	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Special Functions	Throttle learn storage	
-	-	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	Special Functions	Vehicle configuration deletion	
-	-	LINEA	1.9 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	LINEA	1.9 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	LINEA	1.9 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	LINEA	1.9 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	LINEA	1.9 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	LINEA	1.9 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	LINEA	1.9 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	LINEA	1.9 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	LINEA	1.9 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	LINEA	1.9 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	LINEA	1.9 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	LINEA	1.9 16V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	LINEA	1.9 16V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	LINEA	1.9 16V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	LINEA	1.9 16V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	LINEA	1.9 16V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.9 16V	Denso 4 Climate Control (Two-zone)	Read ECU Information	-	
-	-	LINEA	1.9 16V	Denso 4 Climate Control (Two-zone)	Read fault code	-	
-	-	LINEA	1.9 16V	Denso 4 Climate Control (Two-zone)	Erase fault code	-	
-	-	LINEA	1.9 16V	Denso 4 Climate Control (Two-zone)	Read data stream	-	
-	-	LINEA	1.9 16V	Denso 4 Climate Control (Two-zone)	Actuation Test	-	
-	-	LINEA	1.9 16V	Denso 4 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	LINEA	1.9 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Read ECU Information	-	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Read fault code	-	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Erase fault code	-	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Read data stream	-	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Special Functions	Headlamp pos. correct.	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Special Functions	Instrument panel replacement	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Special Functions	Reset odometer	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm exclusion	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Special Functions	Seat belts alarm enable	
-	-	LINEA	1.9 16V	Marelli 4 Cluster	Special Functions	Servicing information delete	
-	-	LINEA	1.9 16V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	LINEA	1.9 16V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	LINEA	1.9 16V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	LINEA	1.9 16V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	LINEA	1.9 16V	Marelli Body Computer 9	Read ECU Information	-	
-	-	LINEA	1.9 16V	Marelli Body Computer 9	Read Fault Code	-	
-	-	LINEA	1.9 16V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Marelli Body Computer 9	Live Data	-	
-	-	LINEA	1.9 16V	Marelli Body Computer 9	Actuation Test	-	
-	-	LINEA	1.9 16V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	LINEA	1.9 16V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	LINEA	1.9 16V	Convergence Lauberhorn C1	Read ECU Information	-	
-	-	LINEA	1.9 16V	Convergence Lauberhorn C1	Read Fault Code	-	
-	-	LINEA	1.9 16V	Convergence Lauberhorn C1	Erase Fault Code	-	
-	-	LINEA	1.9 16V	Convergence Lauberhorn C1	Live Data	-	
-	-	LINEA	1.9 16V	Convergence Lauberhorn C1	Actuation Test	-	
-	-	LINEA	1.9 16V	Convergence Lauberhorn C1	Special Functions	Convergence system restart	
-	-	LINEA	1.9 16V	Convergence Lauberhorn C1	Special Functions	Audio system test	
-	-	MAREA	'01 100 16V CF3	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'01 100 16V CF3	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'01 100 16V CF3	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'01 100 16V CF3	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'01 100 16V CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'01 100 16V CF3	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'01 100 16V CF3	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	'01 100 16V CF3	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'01 100 16V CF3	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	MAREA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	MAREA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	MAREA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	MAREA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	MAREA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	MAREA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	MAREA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	MAREA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	MAREA	'01 150 20V CF3	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'01 150 20V CF3	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	'01 150 20V CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'01 150 20V CF3	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'01 150 20V CF3	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'01 150 20V CF3	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'01 150 20V CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'01 150 20V CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'01 150 20V CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'01 150 20V CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'01 150 20V CF3	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'01 150 20V CF3	Lucas EBC 430 ABS	Erase fault code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MAREA	'01 150 20V CF3	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'01 150 20V CF3	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'01 150 20V CF3	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Read Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Erase Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Live Data	-	
-	-	MAREA	'01 150 20V CF3	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Actuation Test	-	
-	-	MAREA	'01 150 20V CF3	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Special Functions	Startup with code card	
-	-	MAREA	'01 150 20V CF3	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Read ECU Information	-	
-	-	MAREA	'01 150 20V CF3	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Read Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Erase Fault Code	-	
-	-	MAREA	'01 150 20V CF3	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Live Data	-	
-	-	MAREA	'01 150 20V CF3	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Actuation Test	-	
-	-	MAREA	'01 150 20V CF3	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Special Functions	Startup with code card	
-	-	MAREA	'01 JTD 110 CF3	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'01 JTD 110 CF3	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'01 JTD 110 CF3	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'01 JTD 110 CF3	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	'01 JTD 110 CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'01 JTD 110 CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'01 JTD 110 CF3	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'01 JTD 110 CF3	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'01 JTD 110 CF3	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'01 JTD 110 CF3	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'01 JTD 110 CF3	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'01 JTD 110 CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'01 JTD 110 CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'01 JTD 110 CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'01 JTD 110 CF3	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	'01 JTD 110 CF3	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'01 JTD 110 CF3	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	'01 JTD 110 CF3	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'01 JTD 110 CF3	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'01 JTD 110 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	MAREA	'01 JTD 110 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	MAREA	'01 JTD 110 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	MAREA	'01 JTD 110 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	MAREA	'01 JTD 110 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	MAREA	'01 JTD 110 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	MAREA	1.4 12V	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	1.4 12V	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	1.4 12V	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	1.4 12V	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	1.4 12V	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	1.4 12V	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	1.4 12V	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	1.4 12V	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	1.4 12V	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	1.4 12V	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	1.4 12V	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	1.4 12V	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Read ECU Information	-	
-	-	MAREA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Read Fault Code	-	
-	-	MAREA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Erase Fault Code	-	
-	-	MAREA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Live Data	-	
-	-	MAREA	1.4 12V	Bosch Monomotronic MA1.7.3 Injection	Actuation Test	-	
-	-	MAREA	1.4 12V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	1.4 12V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	1.4 12V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	1.4 12V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	1.4 12V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	1.4 12V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	1.4 12V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	1.4 12V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	1.4 12V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	1.4 12V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	1.4 12V	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	1.4 12V	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	1.4 12V	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	1.4 12V	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	1.4 12V	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	1.6 16V	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	1.6 16V	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	1.6 16V	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	1.6 16V	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	1.6 16V	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	1.6 16V	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	1.6 16V	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	1.6 16V	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	1.6 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	1.6 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	1.6 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	1.6 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	1.6 16V	Borletti MCC55F Climate Control	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MAREA	1.6 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	1.6 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	1.6 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	1.6 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	1.6 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	1.6 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	1.6 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	1.6 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	1.6 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	1.6 16V	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	1.6 16V	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	1.6 16V	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	1.6 16V	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	1.6 16V	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	1.6 16V	Magneti Marelli IAW 1AF/1AB Injection	Read ECU Information	-	
-	-	MAREA	1.6 16V	Magneti Marelli IAW 1AF/1AB Injection	Read fault code	-	
-	-	MAREA	1.6 16V	Magneti Marelli IAW 1AF/1AB Injection	Erase fault code	-	
-	-	MAREA	1.6 16V	Magneti Marelli IAW 1AF/1AB Injection	Read data stream	-	
-	-	MAREA	1.6 16V	Magneti Marelli IAW 1AF/1AB Injection	Actuation Test	-	
-	-	MAREA	1.6 16V GASOLINA	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	1.6 16V GASOLINA	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	1.6 16V GASOLINA	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	1.6 16V GASOLINA	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	1.6 16V GASOLINA	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	1.6 16V GASOLINA	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	1.6 16V GASOLINA	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	1.6 16V GASOLINA	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	1.6 16V GASOLINA	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	1.6 16V GASOLINA	Magneti Marelli IAW 1AB Injection	Read ECU Information	-	
-	-	MAREA	1.6 16V GASOLINA	Magneti Marelli IAW 1AB Injection	Read fault code	-	
-	-	MAREA	1.6 16V GASOLINA	Magneti Marelli IAW 1AB Injection	Erase fault code	-	
-	-	MAREA	1.6 16V GASOLINA	Magneti Marelli IAW 1AB Injection	Read data stream	-	
-	-	MAREA	1.6 16V GASOLINA	Magneti Marelli IAW 1AB Injection	Actuation Test	-	
-	-	MAREA	1.6 16V GASOLINA	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	1.6 16V GASOLINA	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	1.6 16V GASOLINA	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	1.6 16V GASOLINA	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	1.6 16V GASOLINA	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	1.6 16V GASOLINA	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	1.6 16V GASOLINA	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	1.6 16V GASOLINA	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	1.6 16V GASOLINA	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	1.8 16V	Hitachi MPI Injection	Read ECU Information	-	
-	-	MAREA	1.8 16V	Hitachi MPI Injection	Read Fault Code	-	
-	-	MAREA	1.8 16V	Hitachi MPI Injection	Erase Fault Code	-	
-	-	MAREA	1.8 16V	Hitachi MPI Injection	Live Data	-	
-	-	MAREA	1.8 16V	Hitachi MPI Injection	Actuation Test	-	
-	-	MAREA	1.8 16V	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	1.8 16V	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	1.8 16V	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	1.8 16V	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	1.8 16V	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	1.8 16V	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	1.8 16V	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	1.8 16V	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	1.8 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	1.8 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	1.8 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	1.8 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	1.8 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	1.8 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	1.8 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	1.8 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	1.8 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	1.8 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	1.8 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	1.8 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	1.8 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	1.8 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	1.8 16V	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	1.8 16V	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	1.8 16V	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	1.8 16V	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	1.8 16V	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	1.9 TD 100 CV	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	1.9 TD 100 CV	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	1.9 TD 100 CV	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	1.9 TD 100 CV	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	1.9 TD 100 CV	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	1.9 TD 100 CV	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	1.9 TD 100 CV	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	1.9 TD 100 CV	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	1.9 TD 100 CV	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	1.9 TD 100 CV	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	1.9 TD 100 CV	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	1.9 TD 100 CV	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	1.9 TD 100 CV	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	1.9 TD 100 CV	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	1.9 TD 100 CV	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	1.9 TD 100 CV	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	1.9 TD 100 CV	Lucas EBC 430 ABS	Read data stream	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MAREA	1.9 TD 100 CV	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	1.9 TD 100 CV	Lucas DPNC Diesel Injection	Read ECU Information	-	
-	-	MAREA	1.9 TD 100 CV	Lucas DPNC Diesel Injection	Read fault code	-	
-	-	MAREA	1.9 TD 100 CV	Lucas DPNC Diesel Injection	Erase fault code	-	
-	-	MAREA	1.9 TD 100 CV	Lucas DPNC Diesel Injection	Read data stream	-	
-	-	MAREA	1.9 TD 75 CV	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	1.9 TD 75 CV	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	1.9 TD 75 CV	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	1.9 TD 75 CV	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	1.9 TD 75 CV	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	1.9 TD 75 CV	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	1.9 TD 75 CV	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	1.9 TD 75 CV	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	1.9 TD 75 CV	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	1.9 TD 75 CV	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	1.9 TD 75 CV	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	1.9 TD 75 CV	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	1.9 TD 75 CV	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	1.9 TD 75 CV	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	1.9 TD 75 CV	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	1.9 TD 75 CV	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	1.9 TD 75 CV	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	1.9 TD 75 CV	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	2.0 20V	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	2.0 20V	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	2.0 20V	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	2.0 20V	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	2.0 20V	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	2.0 20V	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	2.0 20V	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	2.0 20V	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	2.0 20V	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	2.0 20V	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	2.0 20V	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	2.0 20V	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	2.0 20V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	2.0 20V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	2.0 20V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	2.0 20V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	2.0 20V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	2.0 20V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	2.0 20V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	2.0 20V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	2.0 20V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	2.0 20V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	2.0 20V	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	2.0 20V	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	2.0 20V	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	2.0 20V	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	2.0 20V	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Read ECU Information	-	
-	-	MAREA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Read Fault Code	-	
-	-	MAREA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Erase Fault Code	-	
-	-	MAREA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Live Data	-	
-	-	MAREA	2.0 20V	Bosch Motronic M2.10.4 Injection (2.0 20v eng.)	Actuation Test	-	
-	-	MAREA	2.4 TD	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	2.4 TD	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	2.4 TD	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	2.4 TD	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	2.4 TD	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	2.4 TD	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	2.4 TD	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	2.4 TD	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	2.4 TD	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	2.4 TD	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	2.4 TD	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	2.4 TD	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	2.4 TD	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	2.4 TD	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	2.4 TD	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	2.4 TD	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	2.4 TD	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	2.4 TD	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	2.4 TD	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	2.4 TD	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	2.4 TD	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	2.4 TD	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	2.4 TD	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	2.4 TD	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	2.4 TD	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	2.4 TD	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	2.4 TD	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	2.4 TD	Bosch MSA 11 Diesel Injection (2.4 eng. El. key)	Read Fault Code	-	
-	-	MAREA	2.4 TD	Bosch MSA 11 Diesel Injection (2.4 eng. El. key)	Erase Fault Code	-	
-	-	MAREA	2.4 TD	Bosch MSA 11 Diesel Injection (2.4 eng. El. key)	Live Data	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Read ECU Information	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Read Fault Code	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Erase Fault Code	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Live Data	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Actuation Test	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Special Functions	Startup with code card	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	MAREA	'99 100 16V	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'99 100 16V	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'99 100 16V	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'99 100 16V	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'99 100 16V	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'99 100 16V	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'99 100 16V	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'99 100 16V	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	

### Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MAREA	'99 100 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'99 100 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'99 100 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'99 100 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 4GF Injection (Blu-Power)	Read ECU Information	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 4GF Injection (Blu-Power)	Read Fault Code	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 4GF Injection (Blu-Power)	Erase Fault Code	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 4GF Injection (Blu-Power)	Live Data	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 4GF Injection (Blu-Power)	Actuation Test	-	
-	-	MAREA	'99 100 16V	Magneti Marelli IAW 4GF Injection (Blu-Power)	Special Functions	Startup with code card	
-	-	MAREA	'99 100 16V	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'99 100 16V	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'99 100 16V	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'99 100 16V	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'99 100 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'99 100 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'99 100 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'99 100 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'99 100 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'99 100 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'99 100 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'99 100 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'99 100 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'99 100 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'99 100 16V	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	'99 100 16V	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'99 100 16V	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	'99 100 16V	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'99 100 16V	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'99 115 16V	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'99 115 16V	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'99 115 16V	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'99 115 16V	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'99 115 16V	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'99 115 16V	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'99 115 16V	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'99 115 16V	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Read ECU Information	-	
-	-	MAREA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Read Fault Code	-	
-	-	MAREA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Erase Fault Code	-	
-	-	MAREA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Live Data	-	
-	-	MAREA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Actuation Test	-	
-	-	MAREA	'99 115 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Special Functions	Startup with code card	
-	-	MAREA	'99 115 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'99 115 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'99 115 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'99 115 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'99 115 16V	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'99 115 16V	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'99 115 16V	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'99 115 16V	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'99 115 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'99 115 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'99 115 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'99 115 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'99 115 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'99 115 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'99 115 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'99 115 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'99 115 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'99 115 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'99 115 16V	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	'99 115 16V	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'99 115 16V	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	'99 115 16V	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'99 115 16V	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'99 155 20V	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'99 155 20V	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'99 155 20V	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'99 155 20V	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'99 155 20V	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'99 155 20V	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'99 155 20V	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'99 155 20V	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Read ECU Information	-	
-	-	MAREA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Read Fault Code	-	
-	-	MAREA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Erase Fault Code	-	
-	-	MAREA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Live Data	-	
-	-	MAREA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Actuation Test	-	
-	-	MAREA	'99 155 20V	Bosch Motronic ME3.1 Injection (eng. 2.0 20V)	Special Functions	Startup with code card	
-	-	MAREA	'99 155 20V	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'99 155 20V	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'99 155 20V	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'99 155 20V	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'99 155 20V	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'99 155 20V	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'99 155 20V	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'99 155 20V	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'99 155 20V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'99 155 20V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'99 155 20V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'99 155 20V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'99 155 20V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'99 155 20V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'99 155 20V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'99 155 20V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'99 155 20V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'99 155 20V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'99 155 20V	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	'99 155 20V	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'99 155 20V	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	'99 155 20V	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'99 155 20V	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'99 155 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Read ECU Information	-	
-	-	MAREA	'99 155 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Read Fault Code	-	
-	-	MAREA	'99 155 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MAREA	'99 155 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Live Data	-	
-	-	MAREA	'99 155 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Actuation Test	-	
-	-	MAREA	'99 155 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Special Functions	Startup with code card	
-	-	MAREA	'99 80 16V	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'99 80 16V	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'99 80 16V	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'99 80 16V	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'99 80 16V	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'99 80 16V	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'99 80 16V	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'99 80 16V	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Read ECU Information	-	
-	-	MAREA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Read Fault Code	-	
-	-	MAREA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Erase Fault Code	-	
-	-	MAREA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Live Data	-	
-	-	MAREA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Actuation Test	-	
-	-	MAREA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Special Functions	Startup with code card	
-	-	MAREA	'99 80 16V	Bosch Motronic M1.5.5 Injection (eng. 1.2 16V)	Special Functions	Reset self-adapt. param. and idle act.	
-	-	MAREA	'99 80 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'99 80 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'99 80 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'99 80 16V	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'99 80 16V	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'99 80 16V	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'99 80 16V	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'99 80 16V	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'99 80 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'99 80 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'99 80 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'99 80 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'99 80 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'99 80 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'99 80 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'99 80 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'99 80 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'99 80 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'99 80 16V	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	'99 80 16V	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'99 80 16V	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	'99 80 16V	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'99 80 16V	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Read ECU Information	-	
-	-	MAREA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Read Fault Code	-	
-	-	MAREA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Live Data	-	
-	-	MAREA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Actuation Test	-	
-	-	MAREA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Special Functions	Electronic key release	
-	-	MAREA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Special Functions	EGR(Exhaust Gas Recycling)	
-	-	MAREA	'99 JTD 105	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'99 JTD 105	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'99 JTD 105	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 105	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'99 JTD 105	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'99 JTD 105	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'99 JTD 105	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 105	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	'99 JTD 105	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'99 JTD 105	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'99 JTD 105	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 105	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'99 JTD 105	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'99 JTD 105	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'99 JTD 105	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 105	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'99 JTD 105	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'99 JTD 105	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'99 JTD 105	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'99 JTD 105	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'99 JTD 105	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'99 JTD 105	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'99 JTD 105	Lucas EBC 430 ABS	Read ECU Information	-	
-	-	MAREA	'99 JTD 105	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'99 JTD 105	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	'99 JTD 105	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'99 JTD 105	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'99 JTD 130	Allied MY 97 Airbag (2F-2P)	Read ECU Information	-	
-	-	MAREA	'99 JTD 130	Allied MY 97 Airbag (2F-2P)	Read Fault Code	-	
-	-	MAREA	'99 JTD 130	Allied MY 97 Airbag (2F-2P)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 130	Allied MY 97 Airbag (2F-2P)	Live Data	-	
-	-	MAREA	'99 JTD 130	Allied MY 97 Air Bag (2F-2P-S)	Read ECU Information	-	
-	-	MAREA	'99 JTD 130	Allied MY 97 Air Bag (2F-2P-S)	Read Fault Code	-	
-	-	MAREA	'99 JTD 130	Allied MY 97 Air Bag (2F-2P-S)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 130	Allied MY 97 Air Bag (2F-2P-S)	Live Data	-	
-	-	MAREA	'99 JTD 130	Breed MY 97 Airbag (2F-2P-2L-S)	Read ECU Information	-	
-	-	MAREA	'99 JTD 130	Breed MY 97 Airbag (2F-2P-2L-S)	Read Fault Code	-	
-	-	MAREA	'99 JTD 130	Breed MY 97 Airbag (2F-2P-2L-S)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 130	Breed MY 97 Airbag (2F-2P-2L-S)	Live Data	-	
-	-	MAREA	'99 JTD 130	Breed MY 97 Airbag (2F-2P-2L)	Read ECU Information	-	
-	-	MAREA	'99 JTD 130	Breed MY 97 Airbag (2F-2P-2L)	Read Fault Code	-	
-	-	MAREA	'99 JTD 130	Breed MY 97 Airbag (2F-2P-2L)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 130	Breed MY 97 Airbag (2F-2P-2L)	Live Data	-	
-	-	MAREA	'99 JTD 130	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MAREA	'99 JTD 130	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MAREA	'99 JTD 130	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MAREA	'99 JTD 130	Borletti MCC55F Climate Control	Live Data	-	
-	-	MAREA	'99 JTD 130	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MAREA	'99 JTD 130	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	MAREA	'99 JTD 130	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	MAREA	'99 JTD 130	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	MAREA	'99 JTD 130	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	MAREA	'99 JTD 130	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	MAREA	'99 JTD 130	Lucas EBC 430 ABS	Read ECU Information	-	

Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MAREA	'99 JTD 130	Lucas EBC 430 ABS	Read fault code	-	
-	-	MAREA	'99 JTD 130	Lucas EBC 430 ABS	Erase fault code	-	
-	-	MAREA	'99 JTD 130	Lucas EBC 430 ABS	Read data stream	-	
-	-	MAREA	'99 JTD 130	Lucas EBC 430 ABS	Actuation Test	-	
-	-	MAREA	'99 JTD 130	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	Read ECU Information	-	
-	-	MAREA	'99 JTD 130	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	Read Fault Code	-	
-	-	MAREA	'99 JTD 130	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	Erase Fault Code	-	
-	-	MAREA	'99 JTD 130	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	Live Data	-	
-	-	MAREA	'99 JTD 130	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	Actuation Test	-	
-	-	MAREA	'99 JTD 130	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	Special Functions	Electronic key release	
-	-	MAREA	'99 JTD 130	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	Special Functions	EGR(Exhaust Gas Recycling)	
-	-	MULTIPLA	'02 1.6 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA	'02 1.6 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA	'02 1.6 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-I)	Read ECU Information	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-I)	Read Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-I)	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-I)	Live Data	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-I)	Actuation Test	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-I)	Read ECU Information	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-I)	Read Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-I)	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-I)	Live Data	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-I)	Actuation Test	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Read ECU Information	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Read Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Live Data	-	
-	-	MULTIPLA	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Actuation Test	-	
-	-	MULTIPLA	'02 1.6 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA	'02 1.6 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA	'02 1.6 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	MULTIPLA	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	MULTIPLA	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	MULTIPLA	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	MULTIPLA	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	MULTIPLA	'02 1.6 16V	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA	'02 1.6 16V	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA	'02 1.6 16V	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA	'02 1.6 16V	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA	'02 1.6 16V	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA	'02 1.6 16V	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA	'02 1.6 16V	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA	'02 1.9 JTD	Bosch ABS 5.7 VDC	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch ABS 5.7 VDC	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch ABS 5.7 VDC	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch ABS 5.7 VDC	Live Data	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch ABS 5.7 VDC	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-I)	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-I)	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-I)	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-I)	Live Data	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-I)	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Live Data	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Live Data	-	
-	-	MULTIPLA	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA	'02 1.9 JTD	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	MULTIPLA	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Live Data	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	MULTIPLA	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	MULTIPLA	'02 1.9 JTD	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA	'02 1.9 JTD	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA	'02 1.9 JTD	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA	'02 1.9 JTD	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA	'02 1.9 JTD	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA	'02 1.9 JTD	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA	'02 1.9 JTD	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-1)	Read ECU Information	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-1)	Read Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-1)	Erase Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-1)	Live Data	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-1)	Actuation Test	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Read ECU Information	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Read Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Erase Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Live Data	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Actuation Test	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read ECU Information	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Erase Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Live Data	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Actuation Test	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Lambda sensor check	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Startup with code card	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Read ECU Information	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Read Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Erase Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Live Data	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Actuation Test	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Special Functions	Gas injector 1	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Special Functions	Gas injector 2	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Special Functions	Gas injector 3	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Special Functions	Gas injector 4	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Special Functions	Petrol pump relay	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Special Functions	Gas solenoid valve relay	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Special Functions	Gas injectors relay	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 E0BD	Special Functions	Zeroing of self-adaption parameters	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA	'02 BIPOWER-GPOWER	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA	'02 BLUPOWER	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA	'02 BLUPOWER	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA	'02 BLUPOWER	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-1)	Read ECU Information	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-1)	Read Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-1)	Erase Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-1)	Live Data	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-1)	Actuation Test	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Read ECU Information	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Read Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Erase Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Live Data	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens Airbag MY 99 (2F-2P-2L-1)	Actuation Test	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	MULTIPLA	'02 BLUPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	MULTIPLA	'02 BLUPOWER	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA	'02 BLUPOWER	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Borletti MCC55F Climate Control	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
1. ✓ : means that the system has this function  
2. - : means that the system does not have this function  
3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MULTIPLA	'02 BLUPOWER	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA	'02 BLUPOWER	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA	'02 BLUPOWER	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA	'02 BLUPOWER	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA	'02 BLUPOWER	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA	'02 BLUPOWER	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA	'02 BLUPOWER	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA	'02 BLUPOWER	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA	1.6 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA	1.6 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA	1.6 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA	1.6 16V	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA	1.6 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Read ECU Information	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Read Fault Code	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Erase Fault Code	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Live Data	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Actuation Test	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Special Functions	Startup with code card	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	MULTIPLA	1.6 16V	Breed MY 97 Airbag (3F-1)	Read ECU Information	-	
-	-	MULTIPLA	1.6 16V	Breed MY 97 Airbag (3F-1)	Read Fault Code	-	
-	-	MULTIPLA	1.6 16V	Breed MY 97 Airbag (3F-1)	Erase Fault Code	-	
-	-	MULTIPLA	1.6 16V	Breed MY 97 Airbag (3F-1)	Live Data	-	
-	-	MULTIPLA	1.6 16V	Breed MY 97 Airbag (3F-2L-1)	Read ECU Information	-	
-	-	MULTIPLA	1.6 16V	Breed MY 97 Airbag (3F-2L-1)	Read Fault Code	-	
-	-	MULTIPLA	1.6 16V	Breed MY 97 Airbag (3F-2L-1)	Erase Fault Code	-	
-	-	MULTIPLA	1.6 16V	Breed MY 97 Airbag (3F-2L-1)	Live Data	-	
-	-	MULTIPLA	1.6 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA	1.6 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA	1.6 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA	1.6 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA	1.6 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	MULTIPLA	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	MULTIPLA	1.6 16V	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA	1.6 16V	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA	1.6 16V	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA	1.6 16V	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA	1.6 16V	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA	1.6 16V	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA	1.6 16V	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA	1.6 16V	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA	1.9 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA	1.9 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA	1.9 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA	1.9 JTD	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Read ECU Information	-	
-	-	MULTIPLA	1.9 JTD	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Read Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Erase Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Live Data	-	
-	-	MULTIPLA	1.9 JTD	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Actuation Test	-	
-	-	MULTIPLA	1.9 JTD	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Special Functions	Electronic key release	
-	-	MULTIPLA	1.9 JTD	Bosch Diesel EDC15 Injection (1.9 TD d.i. engine)	Special Functions	EGR(Exhaust Gas Recycling)	
-	-	MULTIPLA	1.9 JTD	Breed MY 97 Airbag (3F-1)	Read ECU Information	-	
-	-	MULTIPLA	1.9 JTD	Breed MY 97 Airbag (3F-1)	Read Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Breed MY 97 Airbag (3F-1)	Erase Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Breed MY 97 Airbag (3F-1)	Live Data	-	
-	-	MULTIPLA	1.9 JTD	Breed MY 97 Airbag (3F-2L-1)	Read ECU Information	-	
-	-	MULTIPLA	1.9 JTD	Breed MY 97 Airbag (3F-2L-1)	Read Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Breed MY 97 Airbag (3F-2L-1)	Erase Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Breed MY 97 Airbag (3F-2L-1)	Live Data	-	
-	-	MULTIPLA	1.9 JTD	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA	1.9 JTD	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA	1.9 JTD	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	MULTIPLA	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	MULTIPLA	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	MULTIPLA	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	MULTIPLA	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	MULTIPLA	1.9 JTD	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA	1.9 JTD	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA	1.9 JTD	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA	1.9 JTD	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA	1.9 JTD	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA	1.9 JTD	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA	1.9 JTD	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA	BIPOWER	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA	BIPOWER	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA	BIPOWER	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA	BIPOWER	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA	BIPOWER	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA	BIPOWER	Breed MY 97 Airbag (3F-1)	Read ECU Information	-	
-	-	MULTIPLA	BIPOWER	Breed MY 97 Airbag (3F-1)	Read Fault Code	-	
-	-	MULTIPLA	BIPOWER	Breed MY 97 Airbag (3F-1)	Erase Fault Code	-	
-	-	MULTIPLA	BIPOWER	Breed MY 97 Airbag (3F-1)	Live Data	-	
-	-	MULTIPLA	BIPOWER	Breed MY 97 Airbag (3F-2L-1)	Read ECU Information	-	
-	-	MULTIPLA	BIPOWER	Breed MY 97 Airbag (3F-2L-1)	Read Fault Code	-	
-	-	MULTIPLA	BIPOWER	Breed MY 97 Airbag (3F-2L-1)	Erase Fault Code	-	
-	-	MULTIPLA	BIPOWER	Breed MY 97 Airbag (3F-2L-1)	Live Data	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4GF Injection (Bi-Power)	Read ECU Information	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4GF Injection (Bi-Power)	Read Fault Code	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4GF Injection (Bi-Power)	Erase Fault Code	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4GF Injection (Bi-Power)	Live Data	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4GF Injection (Bi-Power)	Actuation Test	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4GF Injection (Bi-Power)	Special Functions	Startup with code card	
-	-	MULTIPLA	BIPOWER	Borletti MCC55F Climate Control	Read ECU Information	-	

### Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MULTIPLA	BIPOWER	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA	BIPOWER	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA	BIPOWER	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA	BIPOWER	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read ECU Information	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read Fault Code	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Erase Fault Code	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Live Data	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Actuation Test	-	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Lambda sensor check	
-	-	MULTIPLA	BIPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Startup with code card	
-	-	MULTIPLA	BIPOWER	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA	BIPOWER	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA	BIPOWER	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA	BIPOWER	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA	BIPOWER	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA	BIPOWER	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA	BIPOWER	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA	BIPOWER	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA	BLUPOWER	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA	BLUPOWER	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA	BLUPOWER	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA	BLUPOWER	Breed MY 97 Airbag (3F-1)	Read ECU Information	-	
-	-	MULTIPLA	BLUPOWER	Breed MY 97 Airbag (3F-1)	Read Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Breed MY 97 Airbag (3F-1)	Erase Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Breed MY 97 Airbag (3F-1)	Live Data	-	
-	-	MULTIPLA	BLUPOWER	Breed MY 97 Airbag (3F-2L-1)	Read ECU Information	-	
-	-	MULTIPLA	BLUPOWER	Breed MY 97 Airbag (3F-2L-1)	Read Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Breed MY 97 Airbag (3F-2L-1)	Erase Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Breed MY 97 Airbag (3F-2L-1)	Live Data	-	
-	-	MULTIPLA	BLUPOWER	Magneti Marelli IAW 4GF Injection (Blu-Power)	Read ECU Information	-	
-	-	MULTIPLA	BLUPOWER	Magneti Marelli IAW 4GF Injection (Blu-Power)	Read Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Magneti Marelli IAW 4GF Injection (Blu-Power)	Erase Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Magneti Marelli IAW 4GF Injection (Blu-Power)	Live Data	-	
-	-	MULTIPLA	BLUPOWER	Magneti Marelli IAW 4GF Injection (Blu-Power)	Actuation Test	-	
-	-	MULTIPLA	BLUPOWER	Magneti Marelli IAW 4GF Injection (Blu-Power)	Special Functions	Startup with code card	
-	-	MULTIPLA	BLUPOWER	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA	BLUPOWER	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA	BLUPOWER	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA	BLUPOWER	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA	BLUPOWER	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA	BLUPOWER	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA	BLUPOWER	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA	BLUPOWER	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA	BLUPOWER	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA	BLUPOWER	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA VAN	'02 1.6 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-1)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-1)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-1)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-1)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-1)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-1)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-1)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-1)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-1)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens Airbag MY 99 (2F-2P-2L-1)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	MULTIPLA VAN	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	MULTIPLA VAN	'02 1.6 16V	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.6 16V	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA VAN	'02 1.6 16V	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA VAN	'02 1.6 16V	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch ABS 5.7 VDC	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch ABS 5.7 VDC	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch ABS 5.7 VDC	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch ABS 5.7 VDC	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch ABS 5.7 VDC	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-1)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-1)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-1)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-1)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-1)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-1)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens Airbag MY 99 (2F-2P-2L-I)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Live Data	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	MULTIPLA VAN	'02 1.9 JTD	Marelli code 2 electronic key	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Marelli code 2 electronic key	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Marelli code 2 electronic key	Clear Fault Code	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Marelli code 2 electronic key	Read Data Stream	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Marelli code 2 electronic key	Actuation Test	-	
-	-	MULTIPLA VAN	'02 1.9 JTD	Marelli code 2 electronic key	Special Functions	Key status	
-	-	MULTIPLA VAN	'02 1.9 JTD	Marelli code 2 electronic key	Special Functions	Stored keys deletion	
-	-	MULTIPLA VAN	'02 1.9 JTD	Marelli code 2 electronic key	Special Functions	Key storage	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Live Data	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	Actuation Test	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Live Data	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-I)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Live Data	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens Airbag MY 99 (2F-2P-2L-I)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Live Data	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Siemens MY 99 Airbag (2F-2P-2L-2T-I)	Actuation Test	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Live Data	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	Actuation Test	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Live Data	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Actuation Test	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Lambda sensor check	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	Special Functions	Startup with code card	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 EOBD	Read ECU Information	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 EOBD	Read Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 EOBD	Erase Fault Code	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 EOBD	Live Data	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 EOBD	Actuation Test	-	
-	-	MULTIPLA VAN	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 EOBD	Special Functions	Gas injector 1	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA (169)	'03 1.1 8V	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA (169)	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PANDA (169)	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.1 8V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'03 1.1 8V	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Delphi Electric Steering	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA (169)	'03 1.1 8V	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 ABS	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA (169)	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'03 1.1 8V	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Siemens Body Computer	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Siemens Body Computer	Actuation Test	-	
-	-	PANDA (169)	'03 1.1 8V	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA (169)	'03 1.1 8V	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA (169)	'03 1.1 8V	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA (169)	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA (169)	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng.8V)	Special Functions	Phonic wheel learn reset	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng.8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng.8V)	Special Functions	Throttle learn storage	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng.8V)	Special Functions	Vehicle configuration deletion	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng.8V)	Special Functions	Phase sensor learn zeroing	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng.8V)	Special Functions	Air conditioner learn	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng.8V)	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA (169)	'03 1.2 8V	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Throttle learn storage	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Throttle learn storage	
-	-	PANDA (169)	'03 1.2 8V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch replacement	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Electropump replacement	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch bleed	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Pump replacement	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Deletion of statistical data relating to errors	
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Calculation of clutch degradation index	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA (169)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	New actuators	
-	-	PANDA (169)	'03 1.2 8V	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Delphi Electric Steering	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA (169)	'03 1.2 8V	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ABS	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA (169)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'03 1.2 8V	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Siemens Body Computer	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Siemens Body Computer	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA (169)	'03 1.2 8V	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA (169)	'03 1.2 8V	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA (169)	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA (169)	'03 1.2 8V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Read ECU Information	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Read Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Read Data Stream	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Actuation Test	-	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Special Functions	Phonic wheel learn reset	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Special Functions	Self-adapting parameters zeroing	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Special Functions	Throttle learn storage	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Special Functions	Vehicle configuration deletion	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Special Functions	Air conditioner learn	
-	-	PANDA (169)	'03 1.2 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG	Special Functions	Phase sensor learn zeroing	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Oil change	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/E0BD(eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA (169)	'03 1.3 JTD	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 1 injector classification	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 2 injector classification	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 3 injector classification	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 4 injector classification	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector classification (4 cyl. bank)	
-	-	PANDA (169)	'03 1.3 JTD	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'03 1.3 JTD	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Delphi Electric Steering	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA (169)	'03 1.3 JTD	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'03 1.3 JTD	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Siemens Body Computer	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Siemens Body Computer	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA (169)	'03 1.3 JTD	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA (169)	'03 1.3 JTD	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	PANDA (169)	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA (169)	'06 1.4 16V	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'06 1.4 16V	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Delphi Electric Steering	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA (169)	'06 1.4 16V	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 ABS	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA (169)	'06 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'06 1.4 16V	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Siemens Body Computer	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Siemens Body Computer	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA (169)	'06 1.4 16V	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA (169)	'06 1.4 16V	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA (169)	'06 1.4 16V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Motronic Me7.6.3 CF4/EOBD Injection (eng. 16v)	Read ECU Information	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Motronic Me7.6.3 CF4/EOBD Injection (eng. 16v)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA (169)	'06 1.4 16V	Bosch Motronic Me7.6.3 CF4/EOBD Injection (eng. 16v)	Erase Fault Code	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Motronic Me7.6.3 CF4/EOBD Injection (eng. 16v)	Live Data	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Motronic Me7.6.3 CF4/EOBD Injection (eng. 16v)	Actuation Test	-	
-	-	PANDA (169)	'06 1.4 16V	Bosch Motronic Me7.6.3 CF4/EOBD Injection (eng. 16v)	Special Functions	Startup with code card	
-	-	PANDA (169)	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA (169)	'07 BIPOWER	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PANDA (169)	'07 BIPOWER	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Lambda sensor check	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Startup with code card	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	PANDA (169)	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Phonic wheel learn reset	
-	-	PANDA (169)	'07 BIPOWER	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Delphi Electric Steering	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA (169)	'07 BIPOWER	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 ABS	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA (169)	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'07 BIPOWER	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Siemens Body Computer	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Siemens Body Computer	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA (169)	'07 BIPOWER	Siemens Body Computer	Special Functions	Indicators command enable/disable	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA (169)	'07 BIPOWER	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Actuation Test	-	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injector 1	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injector 2	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injector 3	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injector 4	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Petrol pump relay	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas solenoid valve relay	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Gas injectors relay	
-	-	PANDA (169)	'07 BIPOWER	Gas Injection Metatron 6DO EOBD	Special Functions	Zeroing of self-adaption parameters	
-	-	PANDA (169)	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA (169)	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Startup with code card	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Throttle learn storage	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Phase sensor learn zeroing	
-	-	PANDA (169)	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Air conditioner learn	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA (169)	'10 NATURAL POWER	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'10 NATURAL POWER	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Delphi Electric Steering	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA (169)	'10 NATURAL POWER	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ABS	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA (169)	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA (169)	'10 NATURAL POWER	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Siemens Body Computer	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Siemens Body Computer	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA (169)	'10 NATURAL POWER	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA (169)	'10 NATURAL POWER	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA (169)	'10 NATURAL POWER	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA VAN	'03 1.1 8V	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA VAN	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PANDA VAN	'03 1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.1 8V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'03 1.1 8V	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Delphi Electric Steering	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA VAN	'03 1.1 8V	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 ABS	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA VAN	'03 1.1 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'03 1.1 8V	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Siemens Body Computer	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Siemens Body Computer	Actuation Test	-	
-	-	PANDA VAN	'03 1.1 8V	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA VAN	'03 1.1 8V	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA VAN	'03 1.1 8V	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA VAN	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA VAN	'03 1.1 8V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Special Functions	Throttle learn storage	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Special Functions	Phase sensor learn zeroing	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Special Functions	Air conditioner learn	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli Injection IAW 5SF8 CF5/EOBD(eng. 8V)	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA VAN	'03 1.2 8V	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Throttle learn storage	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Throttle learn storage	
-	-	PANDA VAN	'03 1.2 8V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch Parking Control Unit	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA VAN	'03 1.2 8V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch replacement	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Electropump replacement	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch bleed	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Pump replacement	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Deletion of statistical data relating to errors	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	PANDA VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	New actuators	
-	-	PANDA VAN	'03 1.2 8V	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Delphi Electric Steering	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA VAN	'03 1.2 8V	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ABS	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'03 1.2 8V	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Siemens Body Computer	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Siemens Body Computer	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA VAN	'03 1.2 8V	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA VAN	'03 1.2 8V	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA VAN	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA VAN	'03 1.2 8V	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Oil change	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD(eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA VAN	'03 1.3 JTD	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 1 injector classification	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 2 injector classification	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 3 injector classification	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 4 injector classification	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector classification (4 cyl. bank)	
-	-	PANDA VAN	'03 1.3 JTD	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'03 1.3 JTD	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Delphi Electric Steering	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA VAN	'03 1.3 JTD	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'03 1.3 JTD	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Siemens Body Computer	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Siemens Body Computer	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA VAN	'03 1.3 JTD	Siemens Body Computer	Special Functions	Indicators command enable/disable	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA VAN	'03 1.3 JTD	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	PANDA VAN	'03 1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	PANDA VAN	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Injection Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Injection Landi Renzo LC02 Gas	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-1)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	TRW MY 99 Airbag (2F-2P-2L-2T-1)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA VAN	'07 BIPOWER	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PANDA VAN	'07 BIPOWER	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Lambda sensor check	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Startup with code card	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	PANDA VAN	'07 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Phonic wheel learn reset	
-	-	PANDA VAN	'07 BIPOWER	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Delphi Electric Steering	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA VAN	'07 BIPOWER	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ABS	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA VAN	'07 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'07 BIPOWER	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Siemens Body Computer	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Siemens Body Computer	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA VAN	'07 BIPOWER	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA VAN	'07 BIPOWER	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 1	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 2	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 3	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 4	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Petrol pump relay	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas solenoid valve relay	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injectors relay	
-	-	PANDA VAN	'07 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Zeroing of self-adaption parameters	
-	-	PANDA VAN	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA VAN	'07 BIPOWER	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Startup with code card	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Throttle learn storage	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Phase sensor learn zeroing	
-	-	PANDA VAN	'10 NATURAL POWER	Magneti Marelli Injection IAW 5SF8 Natural Power (eng. 8V)	Special Functions	Air conditioner learn	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (1F-2P)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2P)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-1)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-I)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-I)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-I)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-I)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-2T-I)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-2T-I)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-2T-I)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW MY 99 Airbag (2F-2P-2L-2T-I)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW Airbag (EP-Proxy) 3	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW Airbag (EP-Proxy) 3	Read fault code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW Airbag (EP-Proxy) 3	Erase fault code	-	
-	-	PANDA VAN	'10 NATURAL POWER	TRW Airbag (EP-Proxy) 3	Read data stream	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch Parking Control Unit	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch Parking Control Unit	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'10 NATURAL POWER	Delphi Electric Steering	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Delphi Electric Steering	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Delphi Electric Steering	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Delphi Electric Steering	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Delphi Electric Steering	Special Functions	Servo mechanism group replacement	
-	-	PANDA VAN	'10 NATURAL POWER	Delphi Electric Steering	Special Functions	Engine - control unit group replacement	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ABS	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ABS	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ABS	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ABS	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ABS	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 VDC ABS	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Denso Climate Control 1 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PANDA VAN	'10 NATURAL POWER	Siemens Body Computer	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Siemens Body Computer	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Siemens Body Computer	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Siemens Body Computer	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Siemens Body Computer	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Siemens Body Computer	Special Functions	Key programming	
-	-	PANDA VAN	'10 NATURAL POWER	Siemens Body Computer	Special Functions	Indicators command enable/disable	
-	-	PANDA VAN	'10 NATURAL POWER	Siemens Body Computer	Special Functions	Dusk and rain sensors check	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Marelli 3 Connect (Multi-Model)	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Read ECU Information	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Read Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Erase Fault Code	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Live Data	-	
-	-	PANDA VAN	'10 NATURAL POWER	Bosch 8 ASR ABS	Actuation Test	-	
-	-	PERLA	1.7 8V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PERLA	1.7 8V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PERLA	1.7 8V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PERLA	1.7 8V	Bosch 5.3 ABS	Live Data	-	
-	-	PERLA	1.7 8V	Bosch 5.3 ABS	Actuation Test	-	
-	-	PERLA	1.7 8V	Siemens Airbag MY 99 (2F-I)	Read ECU Information	-	
-	-	PERLA	1.7 8V	Siemens Airbag MY 99 (2F-I)	Read Fault Code	-	
-	-	PERLA	1.7 8V	Siemens Airbag MY 99 (2F-I)	Erase Fault Code	-	
-	-	PERLA	1.7 8V	Siemens Airbag MY 99 (2F-I)	Live Data	-	
-	-	PERLA	1.7 8V	Siemens Airbag MY 99 (2F-I)	Actuation Test	-	
-	-	PERLA	1.7 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PERLA	1.7 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PERLA	1.7 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PERLA	1.7 8V	Bosch 8 ABS	Live Data	-	
-	-	PERLA	1.7 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Statistical data deletion	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Tunnel lever replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	SPORT switch replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Steering wheel levers replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Electropump replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	End of line / service self-calibration	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch bleed	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Accumulator depressurisation	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch self-calibration enable	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Pump relay replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Gearbox replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Pump replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	CITY switch replacement	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Deletion of statistical data relating to errors	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Calculation of clutch degradation index	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Engagement lever pin securing screw diagnosis	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	New actuators	
-	-	PERLA	1.7 8V	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Selection lever return diagnosis	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Read ECU Information	-	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Read Fault Code	-	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Erase Fault Code	-	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Live Data	-	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Actuation Test	-	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Headlamp pos. correct.	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Servicing information delete	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Inputs status	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Oil change servicing information delete	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Reset odometer	
-	-	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Instrument panel replacement	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Read ECU Information	-	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Read Fault Code	-	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Erase Fault Code	-	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Live Data	-	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Actuation Test	-	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Special Functions	Key programming	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Special Functions	Dusk and rain sensors check	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Special Functions	Window wash system check	
-	-	PERLA	1.7 8V	Marelli Body Computer 2	Special Functions	Indicators command enable/disable	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Read ECU Information	-	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Read Fault Code	-	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Erase Fault Code	-	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Live Data	-	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Actuation Test	-	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Special Functions	Phonic wheel learn reset	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Special Functions	Throttle learn storage	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Special Functions	Vehicle configuration deletion	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Special Functions	Air conditioner learn	
-	-	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	Special Functions	Startup with code card	
-	-	PREMIO	1497 ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Read ECU Information	-	
-	-	PREMIO	1497 ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Erase Fault Code	-	
-	-	PREMIO	1497 ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Live Data	-	
-	-	PREMIO	1497 ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Actuation Test	-	
-	-	PREMIO	1497 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	PREMIO	1497 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	PREMIO	1497 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	PREMIO	1497 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Live Data	-	
-	-	PREMIO	1497 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	PREMIO	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	PREMIO	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	PREMIO	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	PREMIO	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Live Data	-	
-	-	PREMIO	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	PUNTO (176)	55	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	55	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	55	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	55	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	55	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	PUNTO (176)	55	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	55	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	55	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	55	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 06F Enhanced Injection	Read ECU Information	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 06F Enhanced Injection	Read Fault Code	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 06F Enhanced Injection	Erase Fault Code	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 06F Enhanced Injection	Live Data	-	
-	-	PUNTO (176)	55	Magneti Marelli IAW 06F Enhanced Injection	Actuation Test	-	
-	-	PUNTO (176)	55	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	55	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	55	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	55	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	55	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	55	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	55	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	55	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	55	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	55	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (176)	60	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	60	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	60	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	60	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	60	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	PUNTO (176)	60	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	60	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	60	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	60	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 06F Enhanced Injection	Read ECU Information	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 06F Enhanced Injection	Read Fault Code	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (176)	60	Magneti Marelli IAW 06F Enhanced Injection	Erase Fault Code	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 06F Enhanced Injection	Live Data	-	
-	-	PUNTO (176)	60	Magneti Marelli IAW 06F Enhanced Injection	Actuation Test	-	
-	-	PUNTO (176)	60	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	60	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	60	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	60	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	60	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	60	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	60	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	60	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	60	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	60	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (176)	75	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	75	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	75	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	75	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	75	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	75	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	75	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	75	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	75	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 18F Injection	Read ECU Information	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 18F Injection	Read Fault Code	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 18F Injection	Erase Fault Code	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 18F Injection	Live Data	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 18F Injection	Actuation Test	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 08F Injection	Read ECU Information	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 08F Injection	Read Fault Code	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 08F Injection	Erase Fault Code	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 08F Injection	Live Data	-	
-	-	PUNTO (176)	75	Magneti Marelli IAW 08F Injection	Actuation Test	-	
-	-	PUNTO (176)	75	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	75	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	75	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	75	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	75	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	75	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	75	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	75	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	75	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	75	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (176)	75 '98	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	75 '98	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	75 '98	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	75 '98	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	75 '98	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	75 '98	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	75 '98	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	75 '98	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	75 '98	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	75 '98	Magneti Marelli IAW 49F Injection (eng. 1.2)	Read ECU Information	-	
-	-	PUNTO (176)	75 '98	Magneti Marelli IAW 49F Injection (eng. 1.2)	Read Fault Code	-	
-	-	PUNTO (176)	75 '98	Magneti Marelli IAW 49F Injection (eng. 1.2)	Erase Fault Code	-	
-	-	PUNTO (176)	75 '98	Magneti Marelli IAW 49F Injection (eng. 1.2)	Live Data	-	
-	-	PUNTO (176)	75 '98	Magneti Marelli IAW 49F Injection (eng. 1.2)	Actuation Test	-	
-	-	PUNTO (176)	75 '98	Magneti Marelli IAW 49F Injection (eng. 1.2)	Special Functions	Startup with code card	
-	-	PUNTO (176)	75 '98	Magneti Marelli IAW 49F Injection (eng. 1.2)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO (176)	75 '98	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	75 '98	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	75 '98	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	75 '98	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	75 '98	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	85 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	85 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	85 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	85 16V	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	85 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	85 16V	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	85 16V	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	85 16V	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	85 16V	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	85 16V	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	85 16V	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	85 16V	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	85 16V	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	85 16V	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	85 16V	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	85 16V	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	85 16V	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	85 16V	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	85 16V	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (176)	85 16V	Magneti Marelli IAW 18 FD Injection	Read ECU Information	-	
-	-	PUNTO (176)	85 16V	Magneti Marelli IAW 18 FD Injection	Read Fault Code	-	
-	-	PUNTO (176)	85 16V	Magneti Marelli IAW 18 FD Injection	Erase Fault Code	-	
-	-	PUNTO (176)	85 16V	Magneti Marelli IAW 18 FD Injection	Live Data	-	
-	-	PUNTO (176)	85 16V	Magneti Marelli IAW 18 FD Injection	Actuation Test	-	
-	-	PUNTO (176)	90	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	90	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	90	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	90	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	90	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	90	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	90	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	90	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	90	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	90	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	90	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	90	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	90	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	90	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	90	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	90	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	90	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	90	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	90	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (176)	D	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	D	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	D	Bosch 5.3 ABS	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (176)	D	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	D	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	D	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	D	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	D	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	D	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	D	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	D	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	D	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	D	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	D	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	D	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	D	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	D	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	D	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	D	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (176)	GT	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	GT	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	GT	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	GT	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	GT	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	GT	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	GT	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	GT	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	GT	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	GT	Bosch Motronic M2.7 Injection	Read Fault Code	-	
-	-	PUNTO (176)	GT	Bosch Motronic M2.7 Injection	Erase Fault Code	-	
-	-	PUNTO (176)	GT	Bosch Motronic M2.7 Injection	Live Data	-	
-	-	PUNTO (176)	GT	Bosch Motronic M2.7 Injection	Actuation Test	-	
-	-	PUNTO (176)	GT	Bosch Motronic M2.7 Injection (El. key)	Read Fault Code	-	
-	-	PUNTO (176)	GT	Bosch Motronic M2.7 Injection (El. key)	Erase Fault Code	-	
-	-	PUNTO (176)	GT	Bosch Motronic M2.7 Injection (El. key)	Live Data	-	
-	-	PUNTO (176)	GT	Bosch Motronic M2.7 Injection (El. key)	Actuation Test	-	
-	-	PUNTO (176)	GT	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	GT	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	GT	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	GT	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	GT	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	GT	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	GT	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	GT	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	GT	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	GT	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (176)	SELECTA	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	SELECTA	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	SELECTA	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	SELECTA	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	SELECTA	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	PUNTO (176)	SELECTA	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	SELECTA	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	SELECTA	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	SELECTA	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 06F Enhanced Injection	Read ECU Information	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 06F Enhanced Injection	Read Fault Code	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 06F Enhanced Injection	Erase Fault Code	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 06F Enhanced Injection	Live Data	-	
-	-	PUNTO (176)	SELECTA	Magneti Marelli IAW 06F Enhanced Injection	Actuation Test	-	
-	-	PUNTO (176)	SELECTA	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	SELECTA	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	SELECTA	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	SELECTA	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	SELECTA	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	SELECTA	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	SELECTA	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	SELECTA	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	SELECTA	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	SELECTA	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (176)	TD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (176)	TD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (176)	TD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (176)	TD	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (176)	TD	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (176)	TD	TRW MY 97 Airbag (2F)	Read ECU Information	-	
-	-	PUNTO (176)	TD	TRW MY 97 Airbag (2F)	Read Fault Code	-	
-	-	PUNTO (176)	TD	TRW MY 97 Airbag (2F)	Erase Fault Code	-	
-	-	PUNTO (176)	TD	TRW MY 97 Airbag (2F)	Live Data	-	
-	-	PUNTO (176)	TD	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	PUNTO (176)	TD	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	PUNTO (176)	TD	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	PUNTO (176)	TD	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	PUNTO (176)	TD	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	PUNTO (176)	TD	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	PUNTO (176)	TD	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	PUNTO (176)	TD	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	PUNTO (176)	TD	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	PUNTO (176)	TD	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW MY 97 Airbag (2F-2L-I)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW MY 97 Airbag (2F-2L-I)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW MY 97 Airbag (2F-2L-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW MY 97 Airbag (2F-2L-I)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Fuji SG-CVT Automatic Transmission	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Fuji SG-CVT Automatic Transmission	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Fuji SG-CVT Automatic Transmission	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Fuji SG-CVT Automatic Transmission	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW Airbag MY 99 (2F-2T-I)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'03 1.2 16V	TRW Airbag MY 99 (2F-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW Airbag MY 99 (2F-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW Airbag MY 99 (2F-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	TRW Airbag MY 99 (2F-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.2 16V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.2 16V	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.2 16V	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO (188)	'03 1.2 16V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.2 8V	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.2 8V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.2 8V	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi Electric Steering	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'03 1.2 8V	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Throttle learn storage	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Throttle learn storage	
-	-	PUNTO (188)	'03 1.2 8V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch replacement	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Electropump replacement	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch bleed	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Pump replacement	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Deletion of statistical data relating to errors	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	New actuators	
-	-	PUNTO (188)	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Special Functions	Key programming	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO (188)	'03 1.2 8V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.3 JTD	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 1 injector classification	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 2 injector classification	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 3 injector classification	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 4 injector classification	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector classification (4 cyl. bank)	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Statistical data deletion	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Tunnel lever replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	SPORT switch replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Steering wheel levers replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Electropump replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	End of line / service self-calibration	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch bleed	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Accumulator depressurisation	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch self-calibration enable	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Pump relay replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Gearbox replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Pump replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	CITY switch replacement	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Deletion of statistical data relating to errors	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Calculation of clutch degradation index	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Engagement lever pin securing screw diagnosis	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	New actuators	
-	-	PUNTO (188)	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Selection lever return diagnosis	
-	-	PUNTO (188)	'03 1.4 16V	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW Airbag MY 99 (2F-2T-I)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW Airbag MY 99 (2F-2T-I)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW Airbag MY 99 (2F-2T-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW Airbag MY 99 (2F-2T-I)	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	TRW Airbag MY 99 (2F-2T-I)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.4 16V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.4 16V	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.4 16V	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO (188)	'03 1.4 16V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.4 16V	Injection - Bosch Motronic Me7.3H4M Outside EEC	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.4 16V	Injection - Bosch Motronic Me7.3H4M Outside EEC	Read Fault Code	-	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'03 1.4 16V	Injection - Bosch Motronic Me7.3H4M Outside EEC	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.4 16V	Injection - Bosch Motronic Me7.3H4M Outside EEC	Live Data	-	
-	-	PUNTO (188)	'03 1.4 16V	Injection - Bosch Motronic Me7.3H4M Outside EEC	Actuation Test	-	
-	-	PUNTO (188)	'03 1.4 16V	Injection - Bosch Motronic Me7.3H4M Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.8 16V	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW Airbag MY 99 (2F-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW Airbag MY 99 (2F-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW Airbag MY 99 (2F-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW Airbag MY 99 (2F-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	TRW Airbag MY 99 (2F-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.8 16V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.8 16V	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'03 1.8 16V	Hitachi EOBD Injection	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Hitachi EOBD Injection	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Hitachi EOBD Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Hitachi EOBD Injection	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Hitachi EOBD Injection	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Hitachi EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.8 16V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.8 16V	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO (188)	'03 1.8 16V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.9 JTD	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW Airbag MY 99 (2F-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW Airbag MY 99 (2F-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW Airbag MY 99 (2F-2T-1)	Erase Fault Code	-	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'03 1.9 JTD	TRW Airbag MY 99 (2F-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	TRW Airbag MY 99 (2F-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector codes read	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 1 injector classification	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 2 injector classification	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 3 injector classification	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 4 injector classification	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 5 injector classification	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector classification (4 cyl. bank)	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector classification (5 cyl. bank)	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.9 JTD	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO (188)	'03 1.9 JTD	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Airbag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Airbag TRW MY 99 (2F-2L-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Airbag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Airbag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Airbag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Erase Fault Code	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'03 BIPOWER	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 BIPOWER	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 BIPOWER	Metatron 6A0 Gas Injection	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Metatron 6A0 Gas Injection	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Metatron 6A0 Gas Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Metatron 6A0 Gas Injection	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Metatron 6A0 Gas Injection	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Lambda sensor check	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO (188)	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Phonic wheel learn reset	
-	-	PUNTO (188)	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 ABS	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO (188)	'03 BIPOWER	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Read ECU Information	-	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Read Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Erase Fault Code	-	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Live Data	-	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Actuation Test	-	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 1	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 2	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 3	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 4	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Petrol pump relay	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas solenoid valve relay	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injectors relay	
-	-	PUNTO (188)	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 16V	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'99 1.2 16V	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 TC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 TC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 TC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch 5.3 TC ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3 H4 Injection	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3 H4 Injection	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3 H4 Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3 H4 Injection	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3 H4 Injection	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3 H4 Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.2 16V	Fuji SG-CVT Automatic Transmission	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Fuji SG-CVT Automatic Transmission	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Fuji SG-CVT Automatic Transmission	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Fuji SG-CVT Automatic Transmission	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Airbag TRW MY 99 (2F-2L-2T-I)	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'99 1.2 16V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'99 1.2 16V	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 16V	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'99 1.2 16V	Marelli Cluster	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Marelli Cluster	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Marelli Cluster	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Marelli Cluster	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Marelli Cluster	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Live Data	-	
-	-	PUNTO (188)	'99 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 16V	Injection - Bosch Motronic Me7.3H4 Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 8V	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 TC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 TC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 TC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Bosch 5.3 TC ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 59F Injection	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 59F Injection	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 59F Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 59F Injection	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 59F Injection	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 59F Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.2 8V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-I)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-I)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-I)	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Airbag TRW MY 99 (2F-2L-2T-I)	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'99 1.2 8V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'99 1.2 8V	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 8V	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'99 1.2 8V	Marelli Cluster	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	Marelli Cluster	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Marelli Cluster	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Marelli Cluster	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Marelli Cluster	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PUNTO (188)	'99 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'99 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	PUNTO (188)	'99 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	PUNTO (188)	'99 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (188)	'99 1.8 16V	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Actuation Test	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi MPI Injection (eng. 1.8 16V '98)	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 TC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 TC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 TC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Bosch 5.3 TC ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Airbag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'99 1.8 16V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'99 1.8 16V	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'99 1.8 16V	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'99 1.8 16V	Marelli Cluster	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Marelli Cluster	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Marelli Cluster	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Marelli Cluster	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Marelli Cluster	Actuation Test	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi EOBD Injection	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi EOBD Injection	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi EOBD Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi EOBD Injection	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi EOBD Injection	Actuation Test	-	
-	-	PUNTO (188)	'99 1.8 16V	Hitachi EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.8 16V	Injection - Hitachi MPI Outside EEC	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.8 16V	Injection - Hitachi MPI Outside EEC	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Injection - Hitachi MPI Outside EEC	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.8 16V	Injection - Hitachi MPI Outside EEC	Live Data	-	
-	-	PUNTO (188)	'99 1.8 16V	Injection - Hitachi MPI Outside EEC	Actuation Test	-	
-	-	PUNTO (188)	'99 1.8 16V	Injection - Hitachi MPI Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 D	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 TC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 TC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 TC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Bosch 5.3 TC ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	Lucas Epic DCU3F Diesel Injection	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	Lucas Epic DCU3F Diesel Injection	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Lucas Epic DCU3F Diesel Injection	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Lucas Epic DCU3F Diesel Injection	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	Lucas Epic DCU3F Diesel Injection	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 D	Lucas Epic DCU3F Diesel Injection	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.9 D	Airbag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	Airbag TRW MY 99 (2F-2L-2T-1)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Airbag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Airbag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	Airbag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'99 1.9 D	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'99 1.9 D	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 D	Delphi Electric Steering	Special Functions	System calibration	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO (188)	'99 1.9 D	Marelli Cluster	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 D	Marelli Cluster	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Marelli Cluster	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 D	Marelli Cluster	Live Data	-	
-	-	PUNTO (188)	'99 1.9 D	Marelli Cluster	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 JTD	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 TC ABS	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 TC ABS	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 TC ABS	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch 5.3 TC ABS	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	TRW MY 97 Airbag (2F-2L-I)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	TRW MY 97 Airbag (2F-2L-I)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	TRW MY 97 Airbag (2F-2L-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	TRW MY 97 Airbag (2F-2L-I)	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-I)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-I)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-I)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-I)	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	Airbag TRW MY 99 (2F-2L-2T-I)	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi Electric Steering	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 JTD	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO (188)	'99 1.9 JTD	Marelli Cluster	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	Marelli Cluster	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Marelli Cluster	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Marelli Cluster	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	Marelli Cluster	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 Diesel Injection (1.9 TD '99 eng.)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 Diesel Injection (1.9 TD '99 eng.)	Read fault code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 Diesel Injection (1.9 TD '99 eng.)	Erase fault code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 Diesel Injection (1.9 TD '99 eng.)	Read data stream	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 Diesel Injection (1.9 TD '99 eng.)	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 Diesel Injection (1.9 TD '99 eng.)	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	PUNTO (188)	'99 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Read data stream	-	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	PUNTO EVO (199)	1.2 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO (199)	1.2 8V	Denso 2 Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso 2 Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso 2 Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso 2 Single-zone Climate Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso 2 Single-zone Climate Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso 2 Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO (199)	1.2 8V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.2 8V	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.2 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO EVO (199)	1.2 8V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO (199)	1.2 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP eng. 8V)	Special Functions	Cam edges zeroing (VVT)	
-	-	PUNTO EVO (199)	1.2 8V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO (199)	1.2 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO (199)	1.2 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	PUNTO EVO (199)	1.2 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO (199)	1.2 8V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.2 8V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.2 8V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.2 8V	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.2 8V	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.2 8V	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.2 8V	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read data stream	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	PUNTO EVO (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read fault code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read data stream	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector codes read	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 1	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 2	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 3	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 4	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector replacement (per bank)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Air flow meter sensor replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Differential pressure sensor replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Mechanical waste-gate valve replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Oil change	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Phonic wheel replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Rail pressure sensor replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement lambda sensor	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Speed limit setting	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter regeneration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Throttle test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	EGR valve test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Glow plug preheating circuit test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Automatic configuration read	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	ECO switch replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Electropump replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch bleed	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line self-calibration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	New actuators	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Hydraulic kit replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.3 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.3 MJET 16V	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.3 MJET 16V	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso 2 Single-zone Climate Control(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso 2 Single-zone Climate Control(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso 2 Single-zone Climate Control(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso 2 Single-zone Climate Control(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso 2 Single-zone Climate Control(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso 2 Single-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Phonic wheel replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Timing sensor and/or cam replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Supercharging system components replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Rpm sensor and/or distribution belt replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Downstream lambda sensor and/or catalyzer and/or injectors replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Upstream lambda sensor replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	MultiAir rolling finger replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	UniAir module replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Lauberhorn Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 16V M. AIR	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	PUNTO EVO (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Cam edges zeroing (VVT)	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox oil accumulator replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Control unit replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Gearbox replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Hydraulic kit replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Clutch replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Tunnel lever replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Steering wheel levers replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration signal learn	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	ECO/SPORT switch replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Pump relay replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	AUTO switch replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Electropump replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Sensor replacement	
-	-	PUNTO EVO (199)	1.4 8V	Automatic Gearbox Marelli Selespeed CFC328 2	Special Functions	Longitudinal acceleration sensor replacement	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	PUNTO EVO (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	PUNTO EVO (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP eng. 8v)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO (199)	1.4 8V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 8V	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 8V	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 8V	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 8V	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso 2 Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso 2 Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso 2 Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso 2 Single-zone Climate Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso 2 Single-zone Climate Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso 2 Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Read fault code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Read data stream	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Phonic wheel replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Timing sensor and/or cam replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Supercharging system components replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Performance limiting deactivation	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Rpm sensor and/or distribution belt replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Downstream lambda sensor and/or catalyzer and/or injectors replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	Upstream lambda sensor replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	MultiAir rolling finger replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	Special Functions	UniAir module replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M.AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Lauberhorn Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.4 TURBO 16V M. AIR	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read data stream	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	PUNTO EVO (199)	1.6 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso 2 Single-zone Climate Control(EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	1.6 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector codes read	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Speed limit setting	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 1	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 2	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 3	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of injector cyl. 4	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Injector replacement (per bank)	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Oil change (only for version with DPF)	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve replacement	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Air flow meter sensor replacement	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Rail pressure sensor replacement	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Replacement lambda sensor	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration read	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Automatic configuration write	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	EGR valve test	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	Special Functions	Glow plug preheating circuit test	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	1.6 MJET 16V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	1.6 MJET 16V	CONTINENTAL Airbag(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	CONTINENTAL Airbag(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	CONTINENTAL Airbag(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	CONTINENTAL Airbag(EP)	Live Data	-	
-	-	PUNTO EVO (199)	1.6 MJET 16V	CONTINENTAL Airbag(EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Read data stream	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Continental Airbag(EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Continental Airbag(EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Continental Airbag(EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Continental Airbag(EP)	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Continental Airbag(EP)	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso 2 Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso 2 Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso 2 Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso 2 Single-zone Climate Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso 2 Single-zone Climate Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso 2 Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Oil change	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Oil temperature sensor replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Timing sensor and/or cam replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	UniAir module replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Supercharging system components replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	MultiAir rolling finger replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Phonic wheel replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Performance limiting deactivation	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Rpm sensor and/or distribution belt replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Downstream lambda sensor and/or catalyzer and/or injectors replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Motorised throttle replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Replacement injectors	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Fuel supply system component replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Startup with code card	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Magneti Marelli IAW 8GSF CF5/E0BD Injection (EP 0.9 engine)	Special Functions	Rpm sensor and/or timing chain replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Service information delete	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO (199)	0.9 TURBO TWIN AIR	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Startup with code card	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Throttle learn storage	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Cruise control learn	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Air conditioner learn	
-	-	PUNTO INTERN. (118)	1.2 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	Special Functions	Phase sensor learn zeroing	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli/Microsoft Convergence	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	PUNTO INTERN. (118)	1.2 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	PUNTO INTERN. (118)	1.2 8V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Read ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	PUNTO INTERN. (118)	1.2 8V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Body Computer 9	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Body Computer 9	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Body Computer 9	Live Data	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Body Computer 9	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	PUNTO INTERN. (118)	1.2 8V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli/Microsoft Convergence	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch Parking Control Unit (1)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	PUNTO INTERN. (118)	1.3 JTD	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	PUNTO INTERN. (118)	1.3 JTD	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	PUNTO INTERN. (118)	1.3 JTD	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Body Computer 9	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Body Computer 9	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Body Computer 9	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Body Computer 9	Live Data	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Body Computer 9	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Body Computer 9	Special Functions	Key programming	
-	-	PUNTO INTERN. (118)	1.3 JTD	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Startup with code card	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Knock counter reset	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Overboost counter reset	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Self-learnt functions reset	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Neutral signal learn	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Performance limiting deactivation	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	PUNTO INTERN. (118)	1.4 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	PUNTO INTERN. (118)	1.4 16V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	PUNTO INTERN. (118)	1.4 16V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.4 16V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Body Computer 9	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Body Computer 9	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Body Computer 9	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Body Computer 9	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	PUNTO INTERN. (118)	1.4 16V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Special Functions	Startup with code card	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Special Functions	Phonic wheel learn reset	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Special Functions	Throttle learn storage	
-	-	PUNTO INTERN. (118)	1.4 8V	Magneti Marelli Injection IAW 4SF	Special Functions	Vehicle configuration deletion	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli/Microsoft Convergence	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	PUNTO INTERN. (118)	1.4 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	PUNTO INTERN. (118)	1.4 8V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	PUNTO INTERN. (118)	1.4 8V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Body Computer 9	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Body Computer 9	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Body Computer 9	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Body Computer 9	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	PUNTO INTERN. (118)	1.4 8V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Startup with code card	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Knock counter reset	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Overboost counter reset	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Self-learnt functions reset	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Neutral signal learn	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Injection Motronic Me7.9.10 PDA(eng.1.4)	Special Functions	Performance limiting deactivation	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Body Computer 9	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Body Computer 9	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Body Computer 9	Live Data	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Body Computer 9	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	PUNTO INTERN. (118)	1.4 TURBO 16V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Startup with code card	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Phonic wheel learn reset	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Throttle learn storage	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Vehicle configuration deletion	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	Special Functions	Air conditioner learn	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Levers on steering wheel learn	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Statistical data deletion	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Tunnel lever replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Steering wheel levers replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Gearbox oil accumulator replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	ECO/SPORT switch replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Electropump replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	End of line / service self-calibration	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Gearbox replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch bleed	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Accumulator depressurisation	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Clutch self-calibration enable	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Pump relay replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	KIT/Gearbox replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	AUTO switch replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	New actuators	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Hydraulic kit replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Sensor replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Automatic Gearbox Marelli Selespeed CFC319	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Phonic wheel learn reset	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Throttle learn storage	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Vehicle configuration deletion	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Air/Fuel learn setting	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Alcohol fuel setting	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Petrol fuel setting	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Air conditioner learn	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Startup with code card	
-	-	PUNTO INTERN. (118)	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Phase sensor learn zeroing	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli/Microsoft Convergence	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	PUNTO INTERN. (118)	1.6 16V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	PUNTO INTERN. (118)	1.6 16V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	PUNTO INTERN. (118)	1.6 16V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Body Computer 9	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Body Computer 9	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Body Computer 9	Live Data	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Body Computer 9	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	PUNTO INTERN. (118)	1.6 16V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli/Microsoft Convergence	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli/Microsoft Convergence	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli/Microsoft Convergence	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli/Microsoft Convergence	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli/Microsoft Convergence	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli/Microsoft Convergence	Special Functions	Convergence system restart	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli/Microsoft Convergence	Special Functions	Audio system test	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Startup with code card	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Self-adapting parameters zeroing (air)	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Self-adapting parameters zeroing (knock)	
-	-	PUNTO INTERN. (118)	1.8 8V	Delphi MT27E Injection (eng.1.8 8v)	Special Functions	Zeroing fan mode learn	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch Parking Control Unit (1)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch Parking Control Unit (1)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch Parking Control Unit (1)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch Parking Control Unit (1)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence disable	
-	-	PUNTO INTERN. (118)	1.8 8V	Bosch Parking Control Unit (1)	Special Functions	Tow hook presence enable	
-	-	PUNTO INTERN. (118)	1.8 8V	Climate Control Denso 2 (Single-zone)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Climate Control Denso 2 (Single-zone)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Climate Control Denso 2 (Single-zone)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Climate Control Denso 2 (Single-zone)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Climate Control Denso 2 (Single-zone)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Climate Control Denso 2 (Single-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Live Data	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Special Functions	Inputs status	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Special Functions	Servicing information delete	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Special Functions	Oil change servicing information delete	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Special Functions	Reset odometer	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Instrument Panel 3	Special Functions	Instrument panel replacement	
-	-	PUNTO INTERN. (118)	1.8 8V	Autoliv 1 Airbag (Proxi)	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Autoliv 1 Airbag (Proxi)	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Autoliv 1 Airbag (Proxi)	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Autoliv 1 Airbag (Proxi)	Live Data	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Autoliv 1 Airbag (Proxi)	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Body Computer 9	Read ECU Information	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Body Computer 9	Read Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Body Computer 9	Erase Fault Code	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Body Computer 9	Live Data	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Body Computer 9	Actuation Test	-	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Body Computer 9	Special Functions	Key programming	
-	-	PUNTO INTERN. (118)	1.8 8V	Marelli Body Computer 9	Special Functions	Dusk and rain sensors check	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Read data stream	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control (EP)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso 2 Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read fault code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Erase fault code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read data stream	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector codes read	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 1	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 2	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 3	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 4	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector replacement (per bank)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Air flow meter sensor replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Differential pressure sensor replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Mechanical waste-gate valve replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Oil change	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Phonic wheel replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Rail pressure sensor replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement lambda sensor	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Speed limit setting	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter regeneration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Startup with code card	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Throttle test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	EGR valve test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Glow plug preheating circuit test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Automatic configuration read	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	ECO switch replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Electropump replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch bleed	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line self-calibration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	New actuators	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Hydraulic kit replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO VAN (199)	1.3 MJET 16V	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Read fault code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Erase fault code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Read data stream	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Lateral and longitud. acceleration sensor calibration	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Longitudinal/lateral accel. sens. calibration reset	
-	-	PUNTO EVO VAN (199)	1.4 8V	ABS Bosch 9 ESP (EP) 2	Special Functions	Recognition of speed sensor type	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso 2 Single-zone Climate Control (EP)	Special Functions	Flap actuators learning test	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Key programming	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Inertia switch rearm (FIS)	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Indicators command enable/disable	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Country standards change	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Power mode gearbox	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Roof control unit initialisation	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi Body Computer (EP) 4	Special Functions	Exit shipping mode	
-	-	PUNTO EVO VAN (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Injection Landi Renzo LC02 Gas	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Startup with code card	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Injection IAW 5SF3 CF4/EOBD (EP eng. 8V)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Read fault code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Erase fault code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Read data stream	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Cam edges zeroing (VVT)	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Startup with code card	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso Heater (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso Heater (EP)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso Heater (EP)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso Heater (EP)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Denso Heater (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Antenna replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm deletion	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Wheel transmitters learning	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit activation	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit deactivation	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Alarm state check	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Manual system configuration	
-	-	PUNTO EVO VAN (199)	1.4 8V	TRW Tyre Pressure Control (EP)	Special Functions	Control unit replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Convergence system restart	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	Special Functions	Audio system test	
-	-	PUNTO EVO VAN (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence disable	
-	-	PUNTO EVO VAN (199)	1.4 8V	Valeo Parking Control Unit (EP) 2	Special Functions	Tow hook presence enable	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Gearbox oil accumulator replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Control unit replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Gearbox replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Hydraulic kit replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Clutch replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Tunnel lever replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Steering wheel levers replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Longitudinal acceleration signal learn	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	ECO/SPORT switch replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Pump relay replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	AUTO switch replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Electropump replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Sensor replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	Special Functions	Longitudinal acceleration sensor replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Startup with code card	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Delphi (EP) 3 Electric Steering	Special Functions	Position sensor calibration	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Longit. acc. sensor calibration	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Static test	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Steering angle calibration	
-	-	PUNTO EVO VAN (199)	1.4 8V	Bosch ABS 8 ESP (EP) 2	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Headlamp pos. correct.	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Servicing information delete	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Reset odometer	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Seat belts alarm enable	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Instrument Cluster (EP) 3	Special Functions	Instrument panel replacement	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Read Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Erase Fault Code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Live Data	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Actuation Test	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Startup with code card	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	PUNTO EVO VAN (199)	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8v)	Special Functions	Neutral signal learn	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Telematic Satellite Control Unit (EP)	Read ECU Information	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Telematic Satellite Control Unit (EP)	Read fault code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Telematic Satellite Control Unit (EP)	Erase fault code	-	
-	-	PUNTO EVO VAN (199)	1.4 8V	Marelli Telematic Satellite Control Unit (EP)	Read data stream	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW MY 97 Airbag (2F-2L-I)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW MY 97 Airbag (2F-2L-I)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW MY 97 Airbag (2F-2L-I)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW MY 97 Airbag (2F-2L-I)	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Air Bag TRW MY 99 (2F-2L-2T-I)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Air Bag TRW MY 99 (2F-2L-2T-I)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Air Bag TRW MY 99 (2F-2L-2T-I)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Air Bag TRW MY 99 (2F-2L-2T-I)	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Air Bag TRW MY 99 (2F-2L-2T-I)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-I)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-I)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-I)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-I)	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	TRW Airbag MY 99 (2F-2T-I)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO VAN	'03 1.2 8V	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO VAN	'03 1.2 8V	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi Electric Steering	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Startup with code card	
-	-	PUNTO VAN	'03 1.2 8V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Throttle learn storage	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Startup with code card	
-	-	PUNTO VAN	'03 1.2 8V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Throttle learn storage	
-	-	PUNTO VAN	'03 1.2 8V	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch replacement	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Electropump replacement	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch bleed	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Gearbox replacement	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	KIT/Pump replacement	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Deletion of statistical data relating to errors	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Selespeed CFC228F Automatic Gearbox	Special Functions	New actuators	
-	-	PUNTO VAN	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 ABS	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO VAN	'03 1.2 8V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO VAN	'03 1.3 JTD	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Air Bag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Air Bag TRW MY 99 (2F-2L-2T-1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Air Bag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Air Bag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Air Bag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	TRW Airbag MY 99 (2F-2T-1)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi Electric Steering	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 1 injector classification	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 2 injector classification	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 3 injector classification	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Cyl. 4 injector classification	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli 6JF EOBD Diesel Injection (eng. 1.3 JTD)	Special Functions	Injector classification (4 cyl. bank)	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Live Data	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Actuation Test	-	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Statistical data deletion	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Tunnel lever replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	SPORT switch replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Steering wheel levers replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Electropump replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	End of line / service self-calibration	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch bleed	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Accumulator depressurisation	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Clutch self-calibration enable	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Pump relay replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Gearbox replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	KIT/Pump replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	CITY switch replacement	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Deletion of statistical data relating to errors	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Calculation of clutch degradation index	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Engagement lever pin securing screw diagnosis	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	New actuators	
-	-	PUNTO VAN	'03 1.3 JTD	Marelli Automatic Gearbox Selespeed CFC208F (1)	Special Functions	Selection lever return diagnosis	
-	-	PUNTO VAN	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Injection Landi Renzo LC02 Gas	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Air Bag TRW MY 99 (2F-2L-2T-1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Air Bag TRW MY 99 (2F-2L-2T-1)	Air Bag Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Air Bag TRW MY 99 (2F-2L-2T-1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Air Bag TRW MY 99 (2F-2L-2T-1)	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Air Bag TRW MY 99 (2F-2L-2T-1)	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	TRW Airbag MY 99 (2F-2T-1)	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi/Marelli Body Computer	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi/Marelli Body Computer	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi/Marelli Body Computer	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi/Marelli Body Computer	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi/Marelli Body Computer	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi/Marelli Body Computer	Special Functions	Key programming	
-	-	PUNTO VAN	'03 BIPOWER	Delphi/Marelli Body Computer	Special Functions	Indicators command enable/disable	
-	-	PUNTO VAN	'03 BIPOWER	Delphi Electric Steering	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi Electric Steering	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi Electric Steering	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi Electric Steering	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi Electric Steering	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Delphi Electric Steering	Special Functions	System calibration	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	PUNTO VAN	'03 BIPOWER	Metatron 6A0 Gas Injection	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Metatron 6A0 Gas Injection	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Metatron 6A0 Gas Injection	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Metatron 6A0 Gas Injection	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Metatron 6A0 Gas Injection	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch Parking Control Unit	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch Parking Control Unit	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch Parking Control Unit	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch Parking Control Unit	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch Parking Control Unit	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch Parking Control Unit	Special Functions	Sensor vibration time too long	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Inputs status	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Servicing information delete	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Reset odometer	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm exclusion	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Seat belts alarm enable	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Comfort)	Special Functions	Instrument panel replacement	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Lambda sensor check	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Startup with code card	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	PUNTO VAN	'03 BIPOWER	Magneti Marelli IAW 5AF Gas Injection	Special Functions	Phonic wheel learn reset	
-	-	PUNTO VAN	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Denso 2 Climate Control (Two-zone)	Special Functions	Flap actuators learning test	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 ABS	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 ABS	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 ABS	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 ABS	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 ABS	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 VDC ABS	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 VDC ABS	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Bosch 8 VDC ABS	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Headlamp pos. correct.	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Inputs status	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Reset odometer	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Instrument Panel (Strip/Modale)	Special Functions	Instrument panel replacement	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	PUNTO VAN	'03 BIPOWER	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Read ECU Information	-	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Read Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Erase Fault Code	-	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Live Data	-	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Actuation Test	-	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 1	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 2	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 3	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injector 4	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Petrol pump relay	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas solenoid valve relay	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Gas injectors relay	
-	-	PUNTO VAN	'03 BIPOWER	Gas Injection Metatron 6D0 EOBD	Special Functions	Zeroing of self-adaption parameters	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Live Data	-	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Actuation Test	-	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Gearbox oil accumulator replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Control unit replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Gearbox replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Hydraulic kit replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Clutch replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Tunnel lever replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Steering wheel levers replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Longitudinal acceleration signal learn	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	ECO/SPORT switch replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Pump relay replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Electropump replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Selection and/or engagement clutch electrovalve replacement	
-	-	QUBO	1.3 JTD	Automatic Gearbox Marelli Selespeed CFC308 (EP)	Special Functions	Sensor replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Live Data	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Actuation Test	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Oil change	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Mechanical waste-gate valve replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Neutral signal learn	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Manual system configuration	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration read	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Automatic configuration write	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	Special Functions	Glow plug preheating circuit test	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read fault code	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Erase fault code	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Read data stream	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Actuation Test	-	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector codes read	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 1	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 2	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 3	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of injector cyl. 4	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Injector replacement (per bank)	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Neutral signal learn	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Air flow meter sensor replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Differential pressure sensor replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Intelligent alternator (IAM) replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Mechanical waste-gate valve replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Oil change	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Phonic wheel replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Rail pressure sensor replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement lambda sensor	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Replacement of potentiometer and/or clutch group	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Speed limit setting	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Particulate filter regeneration	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Startup with code card	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Throttle test	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	EGR valve test	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Glow plug preheating circuit test	
-	-	QUBO	1.3 JTD	Marelli Diesel Injection 8F3 CF5/5+ EOBD (EP 1.3 JTD engine)	Special Functions	Automatic configuration read	
-	-	QUBO	1.3 JTD	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	QUBO	1.3 JTD	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	QUBO	1.3 JTD	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	QUBO	1.3 JTD	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Live Data	-	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Actuation Test	-	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	QUBO	1.3 JTD	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	QUBO	1.3 JTD	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Live Data	-	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Actuation Test	-	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox oil accumulator replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Longitudinal acceleration signal learn	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	ECO switch replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Statistical data deletion	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Tunnel lever replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Electropump replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line / service self-calibration	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Gearbox replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch bleed	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Accumulator depressurisation	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Clutch self-calibration enable	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Pump relay replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	End of line self-calibration	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	New actuators	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Hydraulic kit replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Steering wheel levers replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	AUTO switch replacement	
-	-	QUBO	1.3 JTD	Marelli Selespeed CFC300 (EP) Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Live Data	-	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Actuation Test	-	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Key programming	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Inertia switch rearm (FIS)	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Indicators command enable/disable	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Country standards change	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Power mode gearbox	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Roof control unit initialisation	
-	-	QUBO	1.3 JTD	Delphi Body Computer (EP) 2	Special Functions	Exit shipping mode	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Live Data	-	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Actuation Test	-	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector codes read	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Speed limit setting	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 1	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 2	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 3	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Replacement of injector cyl. 4	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Injector replacement (per bank)	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Oil change (only for version with DPF)	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Phonic wheel replacement	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Rail pressure sensor replacement	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Manual system configuration	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration read	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Automatic configuration write	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Startup with code card	
-	-	QUBO	1.3 JTD	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	Special Functions	Self-learnt functions reset	
-	-	QUBO	1.3 JTD	Autoliv 2 Airbag (Proxi)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Autoliv 2 Airbag (Proxi)	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Autoliv 2 Airbag (Proxi)	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Autoliv 2 Airbag (Proxi)	Live Data	-	
-	-	QUBO	1.3 JTD	Autoliv 2 Airbag (Proxi)	Actuation Test	-	
-	-	QUBO	1.3 JTD	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	QUBO	1.3 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	QUBO	1.3 JTD	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	QUBO	1.3 JTD	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	QUBO	1.3 JTD	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	QUBO	1.3 JTD	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	QUBO	1.3 JTD	Lauberhorn Convergence (EP)	Live Data	-	
-	-	QUBO	1.3 JTD	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	QUBO	1.3 JTD	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	QUBO	1.3 JTD	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Live Data	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Actuation Test	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Special Functions	Startup with code card	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA CF5/EOBD(1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	QUBO	1.4 8V	Marelli/Microsoft Convergence (EP)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Marelli/Microsoft Convergence (EP)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Marelli/Microsoft Convergence (EP)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Marelli/Microsoft Convergence (EP)	Live Data	-	
-	-	QUBO	1.4 8V	Marelli/Microsoft Convergence (EP)	Actuation Test	-	
-	-	QUBO	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Convergence system restart	
-	-	QUBO	1.4 8V	Marelli/Microsoft Convergence (EP)	Special Functions	Audio system test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Live Data	-	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Actuation Test	-	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Special Functions	Headlamp pos. correct.	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Special Functions	Servicing information delete	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Special Functions	Reset odometer	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm exclusion	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Special Functions	Seat belts alarm enable	
-	-	QUBO	1.4 8V	Marelli Cluster (EP)	Special Functions	Instrument panel replacement	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Live Data	-	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Actuation Test	-	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Longit. acc. sensor calibration	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Static test	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Steering angle calibration	
-	-	QUBO	1.4 8V	Bosch ABS 8 ESP (EP)	Special Functions	Tyre Pressure Monitoring System (TPMS) control unit configuration reset	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Read ECU Information	-	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Read Fault Code	-	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Live Data	-	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Actuation Test	-	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Special Functions	Key programming	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Special Functions	Inertia switch rearm (FIS)	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Special Functions	Indicators command enable/disable	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Special Functions	Country standards change	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Special Functions	Power mode gearbox	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Special Functions	Roof control unit initialisation	
-	-	QUBO	1.4 8V	Delphi Body Computer (EP) 2	Special Functions	Exit shipping mode	
-	-	QUBO	1.4 8V	Autoliv 2 Airbag (Proxi)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Autoliv 2 Airbag (Proxi)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Autoliv 2 Airbag (Proxi)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Autoliv 2 Airbag (Proxi)	Live Data	-	
-	-	QUBO	1.4 8V	Autoliv 2 Airbag (Proxi)	Actuation Test	-	
-	-	QUBO	1.4 8V	Bosch Parking Control Unit (EP)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Bosch Parking Control Unit (EP)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Bosch Parking Control Unit (EP)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Bosch Parking Control Unit (EP)	Live Data	-	
-	-	QUBO	1.4 8V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence disable	
-	-	QUBO	1.4 8V	Bosch Parking Control Unit (EP)	Special Functions	Tow hook presence enable	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Live Data	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Actuation Test	-	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Special Functions	Startup with code card	
-	-	QUBO	1.4 8V	Injection, Valeo TU3 PSA (1.4 eng.)	Special Functions	Zeroing of self-adaption parameters	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Live Data	-	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Actuation Test	-	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Startup with code card	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Throttle learn storage	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Vehicle configuration deletion	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Phonic wheel learn reset	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Zeroing of self-adaption parameters	
-	-	QUBO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP eng. 8v)	Special Functions	Cam edges zeroing (VVT)	
-	-	QUBO	1.4 8V	Lauberhorn Convergence (EP)	Read ECU Information	-	
-	-	QUBO	1.4 8V	Lauberhorn Convergence (EP)	Read Fault Code	-	
-	-	QUBO	1.4 8V	Lauberhorn Convergence (EP)	Erase Fault Code	-	
-	-	QUBO	1.4 8V	Lauberhorn Convergence (EP)	Live Data	-	
-	-	QUBO	1.4 8V	Lauberhorn Convergence (EP)	Actuation Test	-	
-	-	QUBO	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Convergence system restart	
-	-	QUBO	1.4 8V	Lauberhorn Convergence (EP)	Special Functions	Audio system test	
-	-	SCUDO (222)	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Read Fault Code	-	
-	-	SCUDO (222)	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Erase Fault Code	-	
-	-	SCUDO (222)	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Live Data	-	
-	-	SCUDO (222)	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Actuation Test	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Read fault code	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Erase fault code	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Read data stream	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Read fault code	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Erase fault code	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Read data stream	-	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Special Functions	System configuration write	
-	-	SCUDO (222)	'00 2.0 16V	Autoliv ACU Airbag	Special Functions	Control unit unlock	
-	-	SCUDO (222)	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Read fault code	-	
-	-	SCUDO (222)	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Erase fault code	-	
-	-	SCUDO (222)	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Read data stream	-	
-	-	SCUDO (222)	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Self-adaptive parameters	
-	-	SCUDO (222)	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Acceler. pedal posit. learn.	
-	-	SCUDO (222)	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Oil counter write	
-	-	SCUDO (222)	'00 2.0 JTD	Webasto Heater (PSA)	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 JTD	Webasto Heater (PSA)	Read Fault Code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Webasto Heater (PSA)	Erase Fault Code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Webasto Heater (PSA)	Read Data Stream	-	
-	-	SCUDO (222)	'00 2.0 JTD	Webasto Heater (PSA)	Actuation Test	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Erase Fault Code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Live Data	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Actuation Test	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Special Functions	Particulate filter regeneration	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Read Fault Code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Live Data	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Actuation Test	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Read fault code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Erase fault code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Read data stream	-	
-	-	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Actuation Test	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Read fault code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Erase fault code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Read data stream	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Read fault code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Erase fault code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Read data stream	-	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Special Functions	System configuration write	
-	-	SCUDO (222)	'00 2.0 JTD	Autoliv ACU Airbag	Special Functions	Control unit unlock	
-	-	SCUDO (222)	'00 2.0 JTD	Siemens AL4 TA2000 PSA Automatic Gearbox	Read ECU Information	-	
-	-	SCUDO (222)	'00 2.0 JTD	Siemens AL4 TA2000 PSA Automatic Gearbox	Read fault code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Siemens AL4 TA2000 PSA Automatic Gearbox	Erase fault code	-	
-	-	SCUDO (222)	'00 2.0 JTD	Siemens AL4 TA2000 PSA Automatic Gearbox	Read data stream	-	
-	-	SCUDO (222)	'00 2.0 JTD	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Self-adaptive parameters	
-	-	SCUDO (222)	'00 2.0 JTD	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Acceler. pedal posit. learn.	
-	-	SCUDO (222)	'00 2.0 JTD	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Oil counter write	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Read ECU Information	-	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Read fault code	-	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Erase fault code	-	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Read data stream	-	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Read ECU Information	-	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Read fault code	-	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Erase fault code	-	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Read data stream	-	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Special Functions	System configuration write	
-	-	SCUDO (222)	'01 1.9 D	Autoliv ACU Airbag	Special Functions	Control unit unlock	
-	-	SCUDO (222)	'01 1.9 D	Lucas DCN2 Diesel Injection	Read ECU Information	-	
-	-	SCUDO (222)	'01 1.9 D	Lucas DCN2 Diesel Injection	Read fault code	-	
-	-	SCUDO (222)	'01 1.9 D	Lucas DCN2 Diesel Injection	Erase fault code	-	
-	-	SCUDO (222)	'01 1.9 D	Lucas DCN2 Diesel Injection	Read data stream	-	
-	-	SCUDO (222)	1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Read Fault Code	-	
-	-	SCUDO (222)	1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Erase Fault Code	-	
-	-	SCUDO (222)	1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Live Data	-	
-	-	SCUDO (222)	1.9 D	Bosch AS3 Diesel Injection	Read Fault Code	-	
-	-	SCUDO (222)	1.9 D	Bosch AS3 Diesel Injection	Erase Fault Code	-	
-	-	SCUDO (222)	1.9 D	Bosch AS3 Diesel Injection	Live Data	-	
-	-	SCUDO (222)	1.9 TD	Bosch AS3 Diesel Injection	Read Fault Code	-	
-	-	SCUDO (222)	1.9 TD	Bosch AS3 Diesel Injection	Erase Fault Code	-	
-	-	SCUDO (222)	1.9 TD	Bosch AS3 Diesel Injection	Live Data	-	
-	-	SCUDO (222)	2.0 16V	Bosch Motronic MP7.3 injection	Read ECU Information	-	
-	-	SCUDO (222)	2.0 16V	Bosch Motronic MP7.3 injection	Read Fault Code	-	
-	-	SCUDO (222)	2.0 16V	Bosch Motronic MP7.3 injection	Erase Fault Code	-	
-	-	SCUDO (222)	2.0 16V	Bosch Motronic MP7.3 injection	Live Data	-	
-	-	SCUDO (222)	2.0 16V	Bosch Motronic MP7.3 injection	Actuation Test	-	
-	-	SCUDO (222)	'97 1.6 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Read Fault Code	-	
-	-	SCUDO (222)	'97 1.6 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Erase Fault Code	-	
-	-	SCUDO (222)	'97 1.6 I.E.	Bosch Monomotronic MA 1.7 Injection (El. Key)	Live Data	-	
-	-	SCUDO (222)	'97 1.9 TD	Bosch AS3 Diesel Injection	Read Fault Code	-	
-	-	SCUDO (222)	'97 1.9 TD	Bosch AS3 Diesel Injection	Erase Fault Code	-	
-	-	SCUDO (222)	'97 1.9 TD	Bosch AS3 Diesel Injection	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Special Functions	System configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration rea	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Special Functions	United kingdom (Thatcham std)	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	Special Functions	Volumetric sensors automatic diagnosis	
-	-	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	Special Functions	System configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration rea	
-	-	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Clarion CD Magazine (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Clarion CD Magazine (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Clarion CD Magazine (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Clarion CD Magazine (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Clarion CD Magazine (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	System configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	LED colours configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Screen configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Options configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Sound system and telephone configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Function block/speed configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Advanced customisation	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Personal data deletion	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	VIN Code configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Call buttons configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Luminosity/Rain Sensor	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Luminosity/Rain Sensor	Read Fault Code	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Luminosity/Rain Sensor	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Luminosity/Rain Sensor	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	BOSCH/Temic Airbag (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	BOSCH/Temic Airbag (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	BOSCH/Temic Airbag (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	BOSCH/Temic Airbag (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Control unit unlock	
-	-	SCUDO (272)	1.6 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Cooling fans test	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Manual system configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration rea	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Deletion stored buttons	
-	-	SCUDO (272)	1.6 JTD 16V	HPI Power Steering	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	HPI Power Steering	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	HPI Power Steering	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	HPI Power Steering	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	HPI Power Steering	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration rea	
-	-	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Wabco Air Springs	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Wabco Air Springs	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Wabco Air Springs	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Wabco Air Springs	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Wabco Air Springs	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Wabco Air Springs	Special Functions	Vehicle geometry height setting	
-	-	SCUDO (272)	1.6 JTD 16V	Wabco Air Springs	Special Functions	Pneumatic circuit filling	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 PSA (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 PSA (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 PSA (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 PSA (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 PSA (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 PSA (CAN)	Special Functions	Brake bleed	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Special Functions	Brake bleed	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Special Functions	Steering angle calibration	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Special Functions	Steering angle reset	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	Flap actuators learning test	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	Recirculation flap learn	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	Distribution flap learn	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	LH mixing flap learn	
-	-	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	RH mixing flap learn	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	Special Functions	System configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Multi-Function Switch (COM2005)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Multi-Function Switch (COM2005)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Multi-Function Switch (COM2005)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Multi-Function Switch (COM2005)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Delphi Multi-Function Switch (COM2005)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Special Functions	EGR throttle learn	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Special Functions	EGR valve learn	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Special Functions	Injector codes read	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Special Functions	Injector replacement (per bank)	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (eng. 1.6)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Denso PSA Climate Control (Rear)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso PSA Climate Control (Rear)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso PSA Climate Control (Rear)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso PSA Climate Control (Rear)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso PSA Climate Control (Rear)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Denso PSA Climate Control (Rear)	Special Functions	Flap actuators learning test	
-	-	SCUDO (272)	1.6 JTD 16V	Valeo Body Computer 2 (BSI CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Valeo Body Computer 2 (BSI CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Valeo Body Computer 2 (BSI CAN)	Clear Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Special Functions	Brake bleed	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Brake bleed	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle calibration	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle reset	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Longit. acc. sensor calibration	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson EV Body Computer (BSI CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson EV Body Computer (BSI CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Johnson EV Body Computer (BSI CAN)	Clear Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Screen configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Options configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Jukebox function	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Advanced customisation	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Personal data deletion	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Call buttons configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	JukeBox data deletion	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	VIN Code configuration	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens USB Box Control Unit	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens USB Box Control Unit	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens USB Box Control Unit	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens USB Box Control Unit	Live Data	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens USB Box Control Unit	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	1.6 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Read fault code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Erase fault code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Read data stream	-	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Special Functions	System configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	Continental RD45 Radio	Special Functions	VIN Code write	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read ECU Information	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read Data Stream	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Additional diesel circuit filling	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	pump or pipe replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Air metering unit replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR exchanger replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR valve learn	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR valve replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine head replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Exhaust manifold replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	FAP Replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	High pressure pump replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Air flow meter replacement	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine group replacement with flow meter	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine group replacement without flow meter	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Homologation number	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Immobiliser code check	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Part. Filter regeneration	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Replacement injectors	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Replacement of lambda sensor	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Self-learnt functions reset	
-	-	SCUDO (272)	1.6 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator auto radio	Read Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator auto radio	Erase Fault Code	-	
-	-	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator auto radio	Actuation Test	-	
-	-	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Personal data deletion	
-	-	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	VIN Code configuration	
-	-	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Manual system configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Part. Filter regeneration	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Replacement of particulate filter and interventions on diesel additive circuit.	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	EGR valve learn	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Replacement injectors	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Differential pressure sensor replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Self-learnt functions reset	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Supercharg. air cooling SV replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Air flow meter replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Air metering unit replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	High pressure pump replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Replacement of lambda sensor	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection(2.0 eng.)	Special Functions	Homologation number	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Special Functions	System configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Special Functions	United kingdom (Thatcham std)	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	Special Functions	Volumetric sensors automatic diagnosis	
-	-	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	Special Functions	System configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration rea	
-	-	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	System configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	LED colours configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Screen configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Options configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Sound system and telephone configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Function block/speed configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Advanced customisation	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Personal data deletion	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	VIN Code configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Call buttons configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Control unit unlock	
-	-	SCUDO (272)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Cooling fans test	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Manual system configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration rea	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Deletion stored buttons	
-	-	SCUDO (272)	2.0 JTD 16V	HPI Power Steering	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	HPI Power Steering	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	HPI Power Steering	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	HPI Power Steering	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	HPI Power Steering	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration rea	
-	-	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Part. Filter regeneration	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	EGR valve learn	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Replacement injectors	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Replacement of particulate filter and interventions on diesel additive circuit.	
-	-	SCUDO (272)	2.0 JTD 16V	Wabco Air Springs	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Wabco Air Springs	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Wabco Air Springs	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Wabco Air Springs	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Wabco Air Springs	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Wabco Air Springs	Special Functions	Vehicle geometry height setting	
-	-	SCUDO (272)	2.0 JTD 16V	Wabco Air Springs	Special Functions	Pneumatic circuit filling	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 PSA (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 PSA (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 PSA (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 PSA (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 PSA (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 PSA (CAN)	Special Functions	Brake bleed	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Special Functions	Brake bleed	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Special Functions	Steering angle calibration	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	Special Functions	Steering angle reset	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	Flap actuators learning test	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	Recirculation flap learn	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	Distribution flap learn	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	LH mixing flap learn	
-	-	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	Special Functions	RH mixing flap learn	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	Special Functions	System configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso PSA Climate Control (Rear)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso PSA Climate Control (Rear)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso PSA Climate Control (Rear)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso PSA Climate Control (Rear)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso PSA Climate Control (Rear)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Denso PSA Climate Control (Rear)	Special Functions	Flap actuators learning test	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson EV CF5 Body Computer (BSI CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson EV CF5 Body Computer (BSI CAN)	Read fault code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson EV CF5 Body Computer (BSI CAN)	Erase fault code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Valeo Body Computer 2 (BSI CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Valeo Body Computer 2 (BSI CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Valeo Body Computer 2 (BSI CAN)	Clear Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	ABS Bosch 8.1 PSA (CAN)	Special Functions	Brake bleed	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Brake bleed	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle calibration	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle reset	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Longit. acc. sensor calibration	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN)	Clear Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Screen configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Options configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Jukebox function	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Advanced customisation	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Personal data deletion	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Call buttons configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	JukeBox data deletion	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Manual system configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	VIN Code configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens USB Box Control Unit	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens USB Box Control Unit	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens USB Box Control Unit	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens USB Box Control Unit	Live Data	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens USB Box Control Unit	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Read fault code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Erase fault code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Read data stream	-	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Special Functions	System configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Continental RD45 Radio	Special Functions	VIN Code write	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read Data Stream	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Additional diesel circuit filling	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	pump or pipe replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Air metering unit replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR exchanger replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR valve learn	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR valve replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine head replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Exhaust manifold replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	FAP Replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	High pressure pump replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Air flow meter replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine group replacement with flow meter	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine group replacement without flow meter	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Homologation number	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Immobiliser code check	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Part. Filter regeneration	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Replacement injectors	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Replacement of lambda sensor	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Self-learnt functions reset	
-	-	SCUDO (272)	2.0 JTD 16V	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Personal data deletion	
-	-	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	VIN Code configuration	
-	-	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Manual system configuration	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Read ECU Information	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Read Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Erase Fault Code	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Read Data Stream	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Actuation Test	-	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Replacement of particulate filter and interventions on diesel additive circuit.	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Air flow meter replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Air metering unit replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Diesel high pressure rail replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Differential pressure sensor replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	EGR exchanger replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	EGR valve learn	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Engine head replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Exhaust manifold replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Replacement of lambda sensor	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Supercharg. air cooling SV replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Automatic configuration read	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Automatic configuration write	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Engine group replacement with flow meter	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Engine group replacement without flow meter	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	High pressure pump replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Replacement injectors	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Self-learned functions reset	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Homologation number	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Immobiliser code check	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Injector classification	
-	-	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 BR2 CF5 diesel injection (2.0 eng.)	Special Functions	Part. Filter regeneration	
-	-	SEDICI	1.6 16V	Bosch ABS SZK	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Bosch ABS SZK	Read fault code	-	
-	-	SEDICI	1.6 16V	Bosch ABS SZK	Erase fault code	-	
-	-	SEDICI	1.6 16V	Bosch ABS SZK	Read data stream	-	
-	-	SEDICI	1.6 16V	Bosch ABS SZK	Special Functions	Mounting check	
-	-	SEDICI	1.6 16V	Diamond Active Control unit 4WD SZK	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Diamond Active Control unit 4WD SZK	Read fault code	-	
-	-	SEDICI	1.6 16V	Diamond Active Control unit 4WD SZK	Erase fault code	-	
-	-	SEDICI	1.6 16V	Diamond Active Control unit 4WD SZK	Read data stream	-	
-	-	SEDICI	1.6 16V	Mitsubishi SZK Electric Steering	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Mitsubishi SZK Electric Steering	Read fault code	-	
-	-	SEDICI	1.6 16V	Mitsubishi SZK Electric Steering	Erase fault code	-	
-	-	SEDICI	1.6 16V	Mitsubishi SZK Electric Steering	Read data stream	-	
-	-	SEDICI	1.6 16V	Denso SZK Climate Control	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Denso SZK Climate Control	Read fault code	-	
-	-	SEDICI	1.6 16V	Denso SZK Climate Control	Erase fault code	-	
-	-	SEDICI	1.6 16V	Denso SZK Climate Control	Read data stream	-	
-	-	SEDICI	1.6 16V	Denso SZK Petrol Injection (eng. 1.6)	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Denso SZK Petrol Injection (eng. 1.6)	Read Fault Code	-	
-	-	SEDICI	1.6 16V	Denso SZK Petrol Injection (eng. 1.6)	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	Denso SZK Petrol Injection (eng. 1.6)	Live Data	-	
-	-	SEDICI	1.6 16V	Denso SZK Petrol Injection (eng. 1.6)	Actuation Test	-	
-	-	SEDICI	1.6 16V	Denso SZK Petrol Injection (eng. 1.6)	Special Functions	Zeroing of self-adaption parameters	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK	Read Fault Code	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK	Live Data	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK	Actuation Test	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK	Special Functions	Deletion of air temperature sensor data	
-	-	SEDICI	1.6 16V	Siemens Air Bag SZK	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Siemens Air Bag SZK	Read fault code	-	
-	-	SEDICI	1.6 16V	Siemens Air Bag SZK	Erase fault code	-	
-	-	SEDICI	1.6 16V	Siemens Air Bag SZK	Read data stream	-	
-	-	SEDICI	1.6 16V	Bosch ABS ESP SZK	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Bosch ABS ESP SZK	Read fault code	-	
-	-	SEDICI	1.6 16V	Bosch ABS ESP SZK	Erase fault code	-	
-	-	SEDICI	1.6 16V	Bosch ABS ESP SZK	Read data stream	-	
-	-	SEDICI	1.6 16V	Bosch ABS ESP SZK	Special Functions	Mounting check	
-	-	SEDICI	1.6 16V	SZK Automatic Gearbox	Read ECU Information	-	
-	-	SEDICI	1.6 16V	SZK Automatic Gearbox	Read Fault Code	-	
-	-	SEDICI	1.6 16V	SZK Automatic Gearbox	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	SZK Automatic Gearbox	Read Data Stream	-	
-	-	SEDICI	1.6 16V	SZK Automatic Gearbox	Actuation Test	-	
-	-	SEDICI	1.6 16V	Electric Steering Mitsubishi SZK 2	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Electric Steering Mitsubishi SZK 2	Read Fault Code	-	
-	-	SEDICI	1.6 16V	Electric Steering Mitsubishi SZK 2	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	Electric Steering Mitsubishi SZK 2	Read Data Stream	-	
-	-	SEDICI	1.6 16V	Automatic Gearbox SZK 2	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Automatic Gearbox SZK 2	Read Fault Code	-	
-	-	SEDICI	1.6 16V	Automatic Gearbox SZK 2	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	Automatic Gearbox SZK 2	Read Data Stream	-	
-	-	SEDICI	1.6 16V	Petrol Injection Denso SZK (eng. 1.6) 2	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Petrol Injection Denso SZK (eng. 1.6) 2	Read Fault Code	-	
-	-	SEDICI	1.6 16V	Petrol Injection Denso SZK (eng. 1.6) 2	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	Petrol Injection Denso SZK (eng. 1.6) 2	Read Data Stream	-	
-	-	SEDICI	1.6 16V	Petrol Injection Denso SZK (eng. 1.6) 2	Special Functions	Zeroing of self-adaption parameters	
-	-	SEDICI	1.6 16V	Bosch Petrol Injection SZK CF5/EOBD eng. 1.6)	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Bosch Petrol Injection SZK CF5/EOBD eng. 1.6)	Read Fault Code	-	
-	-	SEDICI	1.6 16V	Bosch Petrol Injection SZK CF5/EOBD eng. 1.6)	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	Bosch Petrol Injection SZK CF5/EOBD eng. 1.6)	Read Data Stream	-	
-	-	SEDICI	1.6 16V	Bosch Petrol Injection SZK CF5/EOBD eng. 1.6)	Special Functions	Zeroing of self-adaption parameters	
-	-	SEDICI	1.6 16V	Bosch Petrol Injection SZK CF5/EOBD eng. 1.6)	Special Functions	Conditioner learn zeroing	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Read Fault Code	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Actuation Test	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Read ECU Information	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Read Fault Code	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Erase Fault Code	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Actuation Test	-	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Special Functions	Deletion of air temperature sensor data	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Special Functions	'Parking brake alarm' function enable	
-	-	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	Special Functions	'Parking brake alarm' function disable	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS SZK	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS SZK	Read fault code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SEDICI	1.9 MJET 8V	Bosch ABS SZK	Erase fault code	-	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS SZK	Read data stream	-	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS SZK	Special Functions	Mounting check	
-	-	SEDICI	1.9 MJET 8V	Diamond Active Control unit 4WD SZK	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	Diamond Active Control unit 4WD SZK	Read fault code	-	
-	-	SEDICI	1.9 MJET 8V	Diamond Active Control unit 4WD SZK	Erase fault code	-	
-	-	SEDICI	1.9 MJET 8V	Diamond Active Control unit 4WD SZK	Read data stream	-	
-	-	SEDICI	1.9 MJET 8V	Mitsubishi SZK Electric Steering	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	Mitsubishi SZK Electric Steering	Read fault code	-	
-	-	SEDICI	1.9 MJET 8V	Mitsubishi SZK Electric Steering	Erase fault code	-	
-	-	SEDICI	1.9 MJET 8V	Mitsubishi SZK Electric Steering	Read data stream	-	
-	-	SEDICI	1.9 MJET 8V	Denso SZK Climate Control	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	Denso SZK Climate Control	Read fault code	-	
-	-	SEDICI	1.9 MJET 8V	Denso SZK Climate Control	Erase fault code	-	
-	-	SEDICI	1.9 MJET 8V	Denso SZK Climate Control	Read data stream	-	
-	-	SEDICI	1.9 MJET 8V	Calsonic-Kansei Body Computer SZK	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	Calsonic-Kansei Body Computer SZK	Read Fault Code	-	
-	-	SEDICI	1.9 MJET 8V	Calsonic-Kansei Body Computer SZK	Erase Fault Code	-	
-	-	SEDICI	1.9 MJET 8V	Calsonic-Kansei Body Computer SZK	Live Data	-	
-	-	SEDICI	1.9 MJET 8V	Calsonic-Kansei Body Computer SZK	Actuation Test	-	
-	-	SEDICI	1.9 MJET 8V	Calsonic-Kansei Body Computer SZK	Special Functions	Deletion of air temperature sensor data	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Read Fault Code	-	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Erase Fault Code	-	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Live Data	-	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Actuation Test	-	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Injector codes read	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Replacement of injector cyl. 1	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Replacement of injector cyl. 2	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Replacement of injector cyl. 3	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Replacement of injector cyl. 4	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Injector replacement (per bank)	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Oil change (only for version with DPF)	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Rail pressure sensor replacement	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Manual system configuration	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Automatic configuration read	
-	-	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (eng. 1.9)	Special Functions	Automatic configuration write	
-	-	SEDICI	1.9 MJET 8V	Siemens Air Bag SZK	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	Siemens Air Bag SZK	Read fault code	-	
-	-	SEDICI	1.9 MJET 8V	Siemens Air Bag SZK	Erase fault code	-	
-	-	SEDICI	1.9 MJET 8V	Siemens Air Bag SZK	Read data stream	-	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS ESP SZK	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS ESP SZK	Read fault code	-	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS ESP SZK	Erase fault code	-	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS ESP SZK	Read data stream	-	
-	-	SEDICI	1.9 MJET 8V	Bosch ABS ESP SZK	Special Functions	Mounting check	
-	-	SEDICI	1.9 MJET 8V	SZK Electronic Key	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	SZK Electronic Key	Read fault code	-	
-	-	SEDICI	1.9 MJET 8V	SZK Electronic Key	Erase fault code	-	
-	-	SEDICI	1.9 MJET 8V	SZK Electronic Key	Read data stream	-	
-	-	SEDICI	1.9 MJET 8V	DENSO SZK heater	Read ECU Information	-	
-	-	SEDICI	1.9 MJET 8V	DENSO SZK heater	Read fault code	-	
-	-	SEDICI	1.9 MJET 8V	DENSO SZK heater	Erase fault code	-	
-	-	SEDICI	1.9 MJET 8V	DENSO SZK heater	Read data stream	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS SZK	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS SZK	Read fault code	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS SZK	Erase fault code	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS SZK	Read data stream	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS SZK	Special Functions	Mounting check	
-	-	SEDICI	2.0 MJET 16V	Diamond Active Control unit 4WD SZK	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Diamond Active Control unit 4WD SZK	Read fault code	-	
-	-	SEDICI	2.0 MJET 16V	Diamond Active Control unit 4WD SZK	Erase fault code	-	
-	-	SEDICI	2.0 MJET 16V	Diamond Active Control unit 4WD SZK	Read data stream	-	
-	-	SEDICI	2.0 MJET 16V	Mitsubishi SZK Electric Steering	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Mitsubishi SZK Electric Steering	Read fault code	-	
-	-	SEDICI	2.0 MJET 16V	Mitsubishi SZK Electric Steering	Erase fault code	-	
-	-	SEDICI	2.0 MJET 16V	Mitsubishi SZK Electric Steering	Read data stream	-	
-	-	SEDICI	2.0 MJET 16V	Denso SZK Climate Control	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Denso SZK Climate Control	Read fault code	-	
-	-	SEDICI	2.0 MJET 16V	Denso SZK Climate Control	Erase fault code	-	
-	-	SEDICI	2.0 MJET 16V	Denso SZK Climate Control	Read data stream	-	
-	-	SEDICI	2.0 MJET 16V	Siemens Air Bag SZK	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Siemens Air Bag SZK	Read fault code	-	
-	-	SEDICI	2.0 MJET 16V	Siemens Air Bag SZK	Erase fault code	-	
-	-	SEDICI	2.0 MJET 16V	Siemens Air Bag SZK	Read data stream	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS ESP SZK	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS ESP SZK	Read fault code	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS ESP SZK	Erase fault code	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS ESP SZK	Read data stream	-	
-	-	SEDICI	2.0 MJET 16V	Bosch ABS ESP SZK	Special Functions	Mounting check	
-	-	SEDICI	2.0 MJET 16V	SZK Electronic Key	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	SZK Electronic Key	Read fault code	-	
-	-	SEDICI	2.0 MJET 16V	SZK Electronic Key	Erase fault code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SEDICI	2.0 MJET 16V	SZK Electronic Key	Read data stream	-	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Read Fault Code	-	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Erase Fault Code	-	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Live Data	-	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Actuation Test	-	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Injector codes read	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Replacement of injector cyl. 1	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Replacement of injector cyl. 2	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Replacement of injector cyl. 3	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Replacement of injector cyl. 4	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Injector replacement (per bank)	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Oil change	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	EGR valve replacement	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Particulate filter with integrated pre-cat replacement	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Particulate filter regeneration	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Rail pressure sensor replacement	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Replacement lambda sensor	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Air flow meter sensor replacement	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Differential pressure sensor replacement	
-	-	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/E0BD SZK (eng. 2.0)	Special Functions	Control unit replacement	
-	-	SEDICI	2.0 MJET 16V	Asti SZK Heater	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Asti SZK Heater	Read Fault Code	-	
-	-	SEDICI	2.0 MJET 16V	Asti SZK Heater	Erase Fault Code	-	
-	-	SEDICI	2.0 MJET 16V	Asti SZK Heater	Read Data Stream	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Read Fault Code	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Erase Fault Code	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Actuation Test	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Read ECU Information	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Read Fault Code	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Erase Fault Code	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Actuation Test	-	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Special Functions	Deletion of air temperature sensor data	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Special Functions	'Parking brake alarm' function enable	
-	-	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	Special Functions	'Parking brake alarm' function disable	
-	-	SEICENTO	1108	Bosch 5.3 ABS	Read ECU Information	-	
-	-	SEICENTO	1108	Bosch 5.3 ABS	Read Fault Code	-	
-	-	SEICENTO	1108	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	SEICENTO	1108	Bosch 5.3 ABS	Live Data	-	
-	-	SEICENTO	1108	Bosch 5.3 ABS	Actuation Test	-	
-	-	SEICENTO	1108	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	SEICENTO	1108	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	SEICENTO	1108	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	SEICENTO	1108	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	SEICENTO	1108	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	SEICENTO	1108	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	SEICENTO	1108	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	SEICENTO	1108	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	SEICENTO	1108	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	SEICENTO	1108	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	SEICENTO	1108	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	SEICENTO	1108	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	SEICENTO	1108	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	SEICENTO	1108	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	SEICENTO	1108	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	SEICENTO	1108	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	SEICENTO	1108	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	SEICENTO	1108	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Special Functions	Key status	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	SEICENTO	1108	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	SEICENTO	1108	NSK Electric steering (intern. comb. engine)	Read ECU Information	-	
-	-	SEICENTO	1108	NSK Electric steering (intern. comb. engine)	Read Fault Code	-	
-	-	SEICENTO	1108	NSK Electric steering (intern. comb. engine)	Erase Fault Code	-	
-	-	SEICENTO	1108	NSK Electric steering (intern. comb. engine)	Read Data Stream	-	
-	-	SEICENTO	1108 CF3	Bosch 5.3 ABS	Read ECU Information	-	
-	-	SEICENTO	1108 CF3	Bosch 5.3 ABS	Read Fault Code	-	
-	-	SEICENTO	1108 CF3	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	Bosch 5.3 ABS	Live Data	-	
-	-	SEICENTO	1108 CF3	Bosch 5.3 ABS	Actuation Test	-	
-	-	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	SEICENTO	1108 CF3	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	SEICENTO	1108 CF3	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	SEICENTO	1108 CF3	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	SEICENTO	1108 CF3	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	SEICENTO	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	SEICENTO	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	SEICENTO	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	SEICENTO	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	SEICENTO	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	SEICENTO	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	SEICENTO	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	SEICENTO	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	SEICENTO	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	SEICENTO	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	SEICENTO	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Special Functions	Key status	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	SEICENTO	1108 CF3	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	SEICENTO	1108 CF3	NSK Electric steering (intern. comb. engine)	Read ECU Information	-	
-	-	SEICENTO	1108 CF3	NSK Electric steering (intern. comb. engine)	Read Fault Code	-	
-	-	SEICENTO	1108 CF3	NSK Electric steering (intern. comb. engine)	Erase Fault Code	-	
-	-	SEICENTO	1108 CF3	NSK Electric steering (intern. comb. engine)	Read Data Stream	-	
-	-	SEICENTO	899	Bosch 5.3 ABS	Read ECU Information	-	
-	-	SEICENTO	899	Bosch 5.3 ABS	Read Fault Code	-	
-	-	SEICENTO	899	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	SEICENTO	899	Bosch 5.3 ABS	Live Data	-	
-	-	SEICENTO	899	Bosch 5.3 ABS	Actuation Test	-	
-	-	SEICENTO	899	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	SEICENTO	899	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	SEICENTO	899	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	SEICENTO	899	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	SEICENTO	899	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	SEICENTO	899	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	SEICENTO	899	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	SEICENTO	899	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	SEICENTO	899	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	SEICENTO	899	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	SEICENTO	899	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	SEICENTO	899	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	SEICENTO	899	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	SEICENTO	899	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	SEICENTO	899	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	SEICENTO	899	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	SEICENTO	899	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	SEICENTO	899	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	899	Delphi code 2 electronic key	Special Functions	Key status	
-	-	SEICENTO	899	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	SEICENTO	899	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	SEICENTO	899	NSK Electric steering (intern. comb. engine)	Read ECU Information	-	
-	-	SEICENTO	899	NSK Electric steering (intern. comb. engine)	Read Fault Code	-	
-	-	SEICENTO	899	NSK Electric steering (intern. comb. engine)	Erase Fault Code	-	
-	-	SEICENTO	899	NSK Electric steering (intern. comb. engine)	Read Data Stream	-	
-	-	SEICENTO	CITYMATIC	Bosch 5.3 ABS	Read ECU Information	-	
-	-	SEICENTO	CITYMATIC	Bosch 5.3 ABS	Read Fault Code	-	
-	-	SEICENTO	CITYMATIC	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	SEICENTO	CITYMATIC	Bosch 5.3 ABS	Live Data	-	
-	-	SEICENTO	CITYMATIC	Bosch 5.3 ABS	Actuation Test	-	
-	-	SEICENTO	CITYMATIC	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	SEICENTO	CITYMATIC	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	SEICENTO	CITYMATIC	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	SEICENTO	CITYMATIC	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	SEICENTO	CITYMATIC	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	SEICENTO	CITYMATIC	ICIT/TRW VAS95 Alarm	Read ECU Information	-	
-	-	SEICENTO	CITYMATIC	ICIT/TRW VAS95 Alarm	Read Fault Code	-	
-	-	SEICENTO	CITYMATIC	ICIT/TRW VAS95 Alarm	Erase Fault Code	-	
-	-	SEICENTO	CITYMATIC	ICIT/TRW VAS95 Alarm	Live Data	-	
-	-	SEICENTO	CITYMATIC	ICIT/TRW VAS95 Alarm	Actuation Test	-	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Read Data Stream	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Special Functions	Key status	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	SEICENTO	CITYMATIC	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	SEICENTO	CITYMATIC	NSK Electric steering (intern. comb. engine)	Read ECU Information	-	
-	-	SEICENTO	CITYMATIC	NSK Electric steering (intern. comb. engine)	Read Fault Code	-	
-	-	SEICENTO	CITYMATIC	NSK Electric steering (intern. comb. engine)	Erase Fault Code	-	
-	-	SEICENTO	CITYMATIC	NSK Electric steering (intern. comb. engine)	Read Data Stream	-	
-	-	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	SEICENTO	ELETTRA	Procond Battery Monitor	Read ECU Information	-	
-	-	SEICENTO	ELETTRA	Procond Battery Monitor	Read Fault Code	-	
-	-	SEICENTO	ELETTRA	Procond Battery Monitor	Erase Fault Code	-	
-	-	SEICENTO	ELETTRA	Procond Battery Monitor	Live Data	-	
-	-	SEICENTO	ELETTRA	Procond Battery Monitor	Actuation Test	-	
-	-	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Special Functions	Key status	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	SEICENTO	ELETTRA	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	SEICENTO VAN	1108 CF3	Bosch 5.3 ABS	Read ECU Information	-	
-	-	SEICENTO VAN	1108 CF3	Bosch 5.3 ABS	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Bosch 5.3 ABS	Live Data	-	
-	-	SEICENTO VAN	1108 CF3	Bosch 5.3 ABS	Actuation Test	-	
-	-	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	SEICENTO VAN	1108 CF3	ICIT/TRW VAS95 alarm	Read ECU Information	-	
-	-	SEICENTO VAN	1108 CF3	ICIT/TRW VAS95 alarm	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	ICIT/TRW VAS95 alarm	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	ICIT/TRW VAS95 alarm	Live Data	-	
-	-	SEICENTO VAN	1108 CF3	ICIT/TRW VAS95 alarm	Actuation Test	-	
-	-	SEICENTO VAN	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	SEICENTO VAN	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	SEICENTO VAN	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	SEICENTO VAN	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	SEICENTO VAN	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	SEICENTO VAN	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	SEICENTO VAN	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	SEICENTO VAN	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	SEICENTO VAN	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read ECU Information	-	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Read Data Stream	-	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Actuation Test	-	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Additional diesel circuit filling	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	pump or pipe replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Air metering unit replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR exchanger replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR valve learn	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	EGR valve replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine head replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Exhaust manifold replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	FAP Replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	High pressure pump replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Air flow meter replacement	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine group replacement with flow meter	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Engine group replacement without flow meter	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Automatic configuration read	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Homologation number	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Immobiliser code check	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Part. Filter regeneration	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Replacement injectors	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Replacement of lambda sensor	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Self-learned functions reset	
-	-	SEICENTO VAN	1108 CF3	Bosch EDC17C10 CF5 diesel injection (1.6 eng.)	Special Functions	Variable geometry turbo replacement	
-	-	SEICENTO VAN	1108 CF3	HERMAN BECKER Navigator auto radio	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	HERMAN BECKER Navigator auto radio	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	HERMAN BECKER Navigator auto radio	Actuation Test	-	
-	-	SEICENTO VAN	1108 CF3	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration read	
-	-	SEICENTO VAN	1108 CF3	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration write	
-	-	SEICENTO VAN	1108 CF3	HERMAN BECKER Navigator auto radio	Special Functions	Personal data deletion	
-	-	SEICENTO VAN	1108 CF3	HERMAN BECKER Navigator auto radio	Special Functions	VIN Code configuration	
-	-	SEICENTO VAN	1108 CF3	HERMAN BECKER Navigator auto radio	Special Functions	Manual system configuration	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Read Data Stream	-	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Actuation Test	-	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Special Functions	Key status	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Special Functions	Stored keys deletion	
-	-	SEICENTO VAN	1108 CF3	Delphi code 2 electronic key	Special Functions	Key storage	
-	-	SEICENTO VAN	1108 CF3	NSK Electric steering (intern. comb. engine)	Read ECU Information	-	
-	-	SEICENTO VAN	1108 CF3	NSK Electric steering (intern. comb. engine)	Read Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	NSK Electric steering (intern. comb. engine)	Erase Fault Code	-	
-	-	SEICENTO VAN	1108 CF3	NSK Electric steering (intern. comb. engine)	Read Data Stream	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 VDC	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 VDC	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 VDC	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 VDC	Live Data	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 VDC	Actuation Test	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read ECU Information	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Live Data	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Actuation Test	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read ECU Information	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Erase Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Live Data	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Actuation Test	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO	1.2 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7	Live Data	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO	1.2 16V	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO	1.2 16V	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO	1.2 16V	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bitron Driver's Door	Live Data	-	
-	-	STILO	1.2 16V	Bitron Driver's Door	Actuation Test	-	
-	-	STILO	1.2 16V	Bitron Boot	Read ECU Information	-	
-	-	STILO	1.2 16V	Bitron Boot	Read Fault Code	-	
-	-	STILO	1.2 16V	Bitron Boot	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bitron Boot	Live Data	-	
-	-	STILO	1.2 16V	Bitron Boot	Actuation Test	-	
-	-	STILO	1.2 16V	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	1.2 16V	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	1.2 16V	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	1.2 16V	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	1.2 16V	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	1.2 16V	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO	1.2 16V	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO	1.2 16V	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bitron Passenger Door	Live Data	-	
-	-	STILO	1.2 16V	Bitron Passenger Door	Actuation Test	-	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Live Data	-	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.2 16V	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	1.2 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	1.2 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO	1.2 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	1.2 16V	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	1.2 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	1.2 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	1.2 16V	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	1.2 16V	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	1.2 16V	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	1.2 16V	Visteon instrument panel	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.2 16V	Visteon instrument panel	Actuation Test	-	
-	-	STILO	1.2 16V	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	1.2 16V	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO	1.2 16V	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	1.2 16V	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	1.2 16V	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	1.2 16V	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	1.2 16V	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	1.2 16V	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	1.2 16V	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	1.2 16V	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	1.2 16V	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	1.2 16V	Lear Driving Seat	Live Data	-	
-	-	STILO	1.2 16V	Lear Driving Seat	Actuation Test	-	
-	-	STILO	1.2 16V	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	1.2 16V	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	1.2 16V	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	1.2 16V	Lear Passenger Seat	Live Data	-	
-	-	STILO	1.2 16V	Lear Passenger Seat	Actuation Test	-	
-	-	STILO	1.2 16V	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	1.2 16V	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	1.2 16V	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	1.2 16V	TRW Steering Lock	Live Data	-	
-	-	STILO	1.2 16V	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	1.2 16V	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	1.2 16V	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	1.2 16V	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	1.2 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	1.2 16V	Marelli Climate Control	Live Data	-	
-	-	STILO	1.2 16V	Marelli Climate Control	Actuation Test	-	
-	-	STILO	1.2 16V	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	1.2 16V	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	1.2 16V	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	1.2 16V	Marelli Connect 2	Live Data	-	
-	-	STILO	1.2 16V	Marelli Connect 2	Actuation Test	-	
-	-	STILO	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Live Data	-	
-	-	STILO	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Actuation Test	-	
-	-	STILO	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	Special Functions	Startup with code card	
-	-	STILO	1.2 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch 8 ABS	Live Data	-	
-	-	STILO	1.2 16V	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	1.2 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO	1.2 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	1.2 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	1.2 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	1.2 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	1.2 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	1.2 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	1.2 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	1.2 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	1.2 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	1.2 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	1.2 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	1.2 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	1.2 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	1.2 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	1.2 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	1.2 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	1.2 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	1.2 16V	G.E. Procond Boot	Live Data	-	
-	-	STILO	1.2 16V	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	1.2 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	1.2 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	1.2 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	1.2 16V	TRW 1 Power Steering	Live Data	-	
-	-	STILO	1.2 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.2 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	1.2 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.2 16V	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO	1.2 16V	TRW Electric Drive	Special Functions	Mounting check	
-	-	STILO	1.4 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	STILO	1.4 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	STILO	1.4 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	STILO	1.4 16V	TRW 3 Electric Steering	Live Data	-	
-	-	STILO	1.4 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.4 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read ECU Information	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Live Data	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Actuation Test	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read ECU Information	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Erase Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Live Data	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Actuation Test	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO	1.4 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO	1.4 16V	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO	1.4 16V	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO	1.4 16V	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bosch ABS 5.7	Live Data	-	
-	-	STILO	1.4 16V	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO	1.4 16V	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO	1.4 16V	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO	1.4 16V	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bitron Driver's Door	Live Data	-	
-	-	STILO	1.4 16V	Bitron Driver's Door	Actuation Test	-	
-	-	STILO	1.4 16V	Bitron Boot	Read ECU Information	-	
-	-	STILO	1.4 16V	Bitron Boot	Read Fault Code	-	
-	-	STILO	1.4 16V	Bitron Boot	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bitron Boot	Live Data	-	
-	-	STILO	1.4 16V	Bitron Boot	Actuation Test	-	
-	-	STILO	1.4 16V	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	1.4 16V	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	1.4 16V	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	1.4 16V	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	1.4 16V	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	1.4 16V	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO	1.4 16V	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO	1.4 16V	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bitron Passenger Door	Live Data	-	
-	-	STILO	1.4 16V	Bitron Passenger Door	Actuation Test	-	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Live Data	-	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.4 16V	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	1.4 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	1.4 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO	1.4 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	1.4 16V	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	1.4 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	1.4 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	1.4 16V	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	1.4 16V	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	1.4 16V	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	1.4 16V	Visteon instrument panel	Live Data	-	
-	-	STILO	1.4 16V	Visteon instrument panel	Actuation Test	-	
-	-	STILO	1.4 16V	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	1.4 16V	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO	1.4 16V	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	1.4 16V	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	1.4 16V	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	1.4 16V	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	1.4 16V	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	1.4 16V	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	1.4 16V	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	1.4 16V	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	1.4 16V	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	1.4 16V	Lear Driving Seat	Live Data	-	
-	-	STILO	1.4 16V	Lear Driving Seat	Actuation Test	-	
-	-	STILO	1.4 16V	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	1.4 16V	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	1.4 16V	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	1.4 16V	Lear Passenger Seat	Live Data	-	
-	-	STILO	1.4 16V	Lear Passenger Seat	Actuation Test	-	
-	-	STILO	1.4 16V	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	1.4 16V	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	1.4 16V	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	1.4 16V	TRW Steering Lock	Live Data	-	
-	-	STILO	1.4 16V	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	1.4 16V	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	1.4 16V	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	1.4 16V	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	1.4 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	1.4 16V	Marelli Climate Control	Live Data	-	
-	-	STILO	1.4 16V	Marelli Climate Control	Actuation Test	-	
-	-	STILO	1.4 16V	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	1.4 16V	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	1.4 16V	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	1.4 16V	Marelli Connect 2	Live Data	-	
-	-	STILO	1.4 16V	Marelli Connect 2	Actuation Test	-	
-	-	STILO	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read ECU Information	-	
-	-	STILO	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Read Fault Code	-	
-	-	STILO	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Live Data	-	
-	-	STILO	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Actuation Test	-	
-	-	STILO	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	Special Functions	Startup with code card	
-	-	STILO	1.4 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	1.4 16V	Bosch 8 ABS	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.4 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bosch 8 ABS	Live Data	-	
-	-	STILO	1.4 16V	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	1.4 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO	1.4 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	1.4 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	1.4 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	1.4 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	1.4 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	1.4 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	1.4 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	1.4 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	1.4 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	1.4 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	1.4 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	1.4 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	1.4 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	1.4 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	1.4 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	1.4 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	1.4 16V	G.E. Procond Boot	Live Data	-	
-	-	STILO	1.4 16V	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	1.4 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	1.4 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	1.4 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	1.4 16V	TRW 1 Power Steering	Live Data	-	
-	-	STILO	1.4 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.4 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	1.4 16V	Bitron Doors Control	Read ECU Information	-	
-	-	STILO	1.4 16V	Bitron Doors Control	Read Fault Code	-	
-	-	STILO	1.4 16V	Bitron Doors Control	Erase Fault Code	-	
-	-	STILO	1.4 16V	Bitron Doors Control	Live Data	-	
-	-	STILO	1.4 16V	Bitron Doors Control	Actuation Test	-	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Read ECU Information	-	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Read Fault Code	-	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Erase Fault Code	-	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Live Data	-	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Actuation Test	-	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Special Functions	Key programming	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Special Functions	Country standards change	
-	-	STILO	1.4 16V	Marelli 5 Body Computer	Special Functions	Indicators command enable/disable	
-	-	STILO	1.4 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.4 16V	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO	1.4 16V	TRW Electric Drive	Special Functions	Mounting check	
-	-	STILO	1.6 16V	Bosch ABS 5.7 VDC	Read ECU Information	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 VDC	Read Fault Code	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 VDC	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 VDC	Live Data	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 VDC	Actuation Test	-	
-	-	STILO	1.6 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	STILO	1.6 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	STILO	1.6 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	STILO	1.6 16V	TRW 3 Electric Steering	Live Data	-	
-	-	STILO	1.6 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.6 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read ECU Information	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Live Data	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Actuation Test	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO	1.6 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7	Live Data	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO	1.6 16V	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO	1.6 16V	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO	1.6 16V	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bitron Driver's Door	Live Data	-	
-	-	STILO	1.6 16V	Bitron Driver's Door	Actuation Test	-	
-	-	STILO	1.6 16V	Bitron Boot	Read ECU Information	-	
-	-	STILO	1.6 16V	Bitron Boot	Read Fault Code	-	
-	-	STILO	1.6 16V	Bitron Boot	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bitron Boot	Live Data	-	
-	-	STILO	1.6 16V	Bitron Boot	Actuation Test	-	
-	-	STILO	1.6 16V	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	1.6 16V	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	1.6 16V	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	1.6 16V	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	1.6 16V	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	1.6 16V	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO	1.6 16V	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO	1.6 16V	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bitron Passenger Door	Live Data	-	
-	-	STILO	1.6 16V	Bitron Passenger Door	Actuation Test	-	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Live Data	-	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.6 16V	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	1.6 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	1.6 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO	1.6 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	1.6 16V	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	1.6 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	1.6 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	1.6 16V	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	1.6 16V	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	1.6 16V	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	1.6 16V	Visteon instrument panel	Live Data	-	
-	-	STILO	1.6 16V	Visteon instrument panel	Actuation Test	-	
-	-	STILO	1.6 16V	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	1.6 16V	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO	1.6 16V	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	1.6 16V	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	1.6 16V	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	1.6 16V	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	1.6 16V	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	1.6 16V	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	1.6 16V	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	1.6 16V	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	1.6 16V	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	1.6 16V	Lear Driving Seat	Live Data	-	
-	-	STILO	1.6 16V	Lear Driving Seat	Actuation Test	-	
-	-	STILO	1.6 16V	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	1.6 16V	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	1.6 16V	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	1.6 16V	Lear Passenger Seat	Live Data	-	
-	-	STILO	1.6 16V	Lear Passenger Seat	Actuation Test	-	
-	-	STILO	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Read ECU Information	-	
-	-	STILO	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Read Fault Code	-	
-	-	STILO	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Erase Fault Code	-	
-	-	STILO	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Live Data	-	
-	-	STILO	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Actuation Test	-	
-	-	STILO	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Startup with code card	
-	-	STILO	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	Special Functions	Throttle learn storage	
-	-	STILO	1.6 16V	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	1.6 16V	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	1.6 16V	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	1.6 16V	TRW Steering Lock	Live Data	-	
-	-	STILO	1.6 16V	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	1.6 16V	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	1.6 16V	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	1.6 16V	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	1.6 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	1.6 16V	Marelli Climate Control	Live Data	-	
-	-	STILO	1.6 16V	Marelli Climate Control	Actuation Test	-	
-	-	STILO	1.6 16V	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	1.6 16V	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	1.6 16V	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	1.6 16V	Marelli Connect 2	Live Data	-	
-	-	STILO	1.6 16V	Marelli Connect 2	Actuation Test	-	
-	-	STILO	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Read ECU Information	-	
-	-	STILO	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Read Fault Code	-	
-	-	STILO	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Erase Fault Code	-	
-	-	STILO	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Live Data	-	
-	-	STILO	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Actuation Test	-	
-	-	STILO	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Startup with code card	
-	-	STILO	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	Special Functions	Throttle learn storage	
-	-	STILO	1.6 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	1.6 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO	1.6 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bosch 8 ABS	Live Data	-	
-	-	STILO	1.6 16V	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	1.6 16V	Bosch 8 VDC ABS	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.6 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	1.6 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	1.6 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	1.6 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	1.6 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	1.6 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	1.6 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	1.6 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	1.6 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	1.6 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	1.6 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	1.6 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	1.6 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	1.6 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	1.6 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	1.6 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	1.6 16V	G.E. Procond Boot	Live Data	-	
-	-	STILO	1.6 16V	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	1.6 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	1.6 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	1.6 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	1.6 16V	TRW 1 Power Steering	Live Data	-	
-	-	STILO	1.6 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.6 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Read ECU Information	-	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Read Fault Code	-	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Erase Fault Code	-	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Live Data	-	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Actuation Test	-	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	Startup with code card	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	Phonic wheel learn reset	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	Zeroing of self-adaption parameters	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	Throttle learn storage	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	Vehicle configuration deletion	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	Cruise control learn	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	Air conditioner learn	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	Phase sensor learn zeroing	
-	-	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.6 16v)	Special Functions	EGR valve learn	
-	-	STILO	1.6 16V	Bitron Doors Control	Read ECU Information	-	
-	-	STILO	1.6 16V	Bitron Doors Control	Read Fault Code	-	
-	-	STILO	1.6 16V	Bitron Doors Control	Erase Fault Code	-	
-	-	STILO	1.6 16V	Bitron Doors Control	Live Data	-	
-	-	STILO	1.6 16V	Bitron Doors Control	Actuation Test	-	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Read ECU Information	-	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Read Fault Code	-	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Erase Fault Code	-	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Live Data	-	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Actuation Test	-	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Special Functions	Key programming	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Special Functions	Country standards change	
-	-	STILO	1.6 16V	Marelli 5 Body Computer	Special Functions	Indicators command enable/disable	
-	-	STILO	1.6 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.6 16V	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO	1.6 16V	TRW Electric Drive	Special Functions	Mounting check	
-	-	STILO	1.8 16V	Bosch ABS 5.7 VDC	Read ECU Information	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 VDC	Read Fault Code	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 VDC	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 VDC	Live Data	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 VDC	Actuation Test	-	
-	-	STILO	1.8 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	STILO	1.8 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	STILO	1.8 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	STILO	1.8 16V	TRW 3 Electric Steering	Live Data	-	
-	-	STILO	1.8 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.8 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read ECU Information	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Live Data	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Actuation Test	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read ECU Information	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Live Data	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Actuation Test	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO	1.8 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7	Live Data	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	1.8 16V	Hitachi EOBD Injection	Read ECU Information	-	
-	-	STILO	1.8 16V	Hitachi EOBD Injection	Read Fault Code	-	
-	-	STILO	1.8 16V	Hitachi EOBD Injection	Erase Fault Code	-	
-	-	STILO	1.8 16V	Hitachi EOBD Injection	Live Data	-	
-	-	STILO	1.8 16V	Hitachi EOBD Injection	Actuation Test	-	
-	-	STILO	1.8 16V	Hitachi EOBD Injection	Special Functions	Startup with code card	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO	1.8 16V	Injection - Hitachi MPI Outside EEC	Read ECU Information	-	
-	-	STILO	1.8 16V	Injection - Hitachi MPI Outside EEC	Read Fault Code	-	
-	-	STILO	1.8 16V	Injection - Hitachi MPI Outside EEC	Erase Fault Code	-	
-	-	STILO	1.8 16V	Injection - Hitachi MPI Outside EEC	Live Data	-	
-	-	STILO	1.8 16V	Injection - Hitachi MPI Outside EEC	Actuation Test	-	
-	-	STILO	1.8 16V	Injection - Hitachi MPI Outside EEC	Special Functions	Startup with code card	
-	-	STILO	1.8 16V	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO	1.8 16V	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO	1.8 16V	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bitron Driver's Door	Live Data	-	
-	-	STILO	1.8 16V	Bitron Driver's Door	Actuation Test	-	
-	-	STILO	1.8 16V	Bitron Boot	Read ECU Information	-	
-	-	STILO	1.8 16V	Bitron Boot	Read Fault Code	-	
-	-	STILO	1.8 16V	Bitron Boot	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bitron Boot	Live Data	-	
-	-	STILO	1.8 16V	Bitron Boot	Actuation Test	-	
-	-	STILO	1.8 16V	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	1.8 16V	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	1.8 16V	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	1.8 16V	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	1.8 16V	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	1.8 16V	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO	1.8 16V	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO	1.8 16V	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bitron Passenger Door	Live Data	-	
-	-	STILO	1.8 16V	Bitron Passenger Door	Actuation Test	-	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Live Data	-	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.8 16V	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	1.8 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	1.8 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO	1.8 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	1.8 16V	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	1.8 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	1.8 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	1.8 16V	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	1.8 16V	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	1.8 16V	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	1.8 16V	Visteon instrument panel	Live Data	-	
-	-	STILO	1.8 16V	Visteon instrument panel	Actuation Test	-	
-	-	STILO	1.8 16V	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	1.8 16V	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO	1.8 16V	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	1.8 16V	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	1.8 16V	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	1.8 16V	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	1.8 16V	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	1.8 16V	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	1.8 16V	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	1.8 16V	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	1.8 16V	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	1.8 16V	Lear Driving Seat	Live Data	-	
-	-	STILO	1.8 16V	Lear Driving Seat	Actuation Test	-	
-	-	STILO	1.8 16V	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	1.8 16V	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	1.8 16V	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	1.8 16V	Lear Passenger Seat	Live Data	-	
-	-	STILO	1.8 16V	Lear Passenger Seat	Actuation Test	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.8 16V	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	1.8 16V	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	1.8 16V	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	1.8 16V	TRW Steering Lock	Live Data	-	
-	-	STILO	1.8 16V	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	1.8 16V	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	1.8 16V	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	1.8 16V	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	1.8 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	1.8 16V	Marelli Climate Control	Live Data	-	
-	-	STILO	1.8 16V	Marelli Climate Control	Actuation Test	-	
-	-	STILO	1.8 16V	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	1.8 16V	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	1.8 16V	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	1.8 16V	Marelli Connect 2	Live Data	-	
-	-	STILO	1.8 16V	Marelli Connect 2	Actuation Test	-	
-	-	STILO	1.8 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	1.8 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO	1.8 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bosch 8 ABS	Live Data	-	
-	-	STILO	1.8 16V	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	1.8 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO	1.8 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	1.8 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	1.8 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	1.8 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	1.8 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	1.8 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	1.8 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	1.8 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	1.8 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	1.8 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	1.8 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	1.8 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	1.8 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	1.8 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	1.8 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	1.8 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	1.8 16V	G.E. Procond Boot	Live Data	-	
-	-	STILO	1.8 16V	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	1.8 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	1.8 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	1.8 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	1.8 16V	TRW 1 Power Steering	Live Data	-	
-	-	STILO	1.8 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.8 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Read ECU Information	-	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Read Fault Code	-	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Erase Fault Code	-	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Live Data	-	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Actuation Test	-	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Startup with code card	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Zeroing of self-adaption parameters	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Self-adapting parameters zeroing (air)	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Self-adapting parameters zeroing (knock)	
-	-	STILO	1.8 16V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Zeroing fan mode learn	
-	-	STILO	1.8 16V	Bitron Doors Control	Read ECU Information	-	
-	-	STILO	1.8 16V	Bitron Doors Control	Read Fault Code	-	
-	-	STILO	1.8 16V	Bitron Doors Control	Erase Fault Code	-	
-	-	STILO	1.8 16V	Bitron Doors Control	Live Data	-	
-	-	STILO	1.8 16V	Bitron Doors Control	Actuation Test	-	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Read ECU Information	-	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Read Fault Code	-	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Erase Fault Code	-	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Live Data	-	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Actuation Test	-	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Special Functions	Key programming	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Special Functions	Country standards change	
-	-	STILO	1.8 16V	Marelli 5 Body Computer	Special Functions	Indicators command enable/disable	
-	-	STILO	1.8 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.8 16V	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO	1.8 16V	TRW Electric Drive	Special Functions	Mounting check	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read ECU Information	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read Fault Code	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Erase Fault Code	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Live Data	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Actuation Test	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO	1.8 8V	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	1.8 8V	Bosch Discharge Headlamp (right)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.8 8V	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	1.8 8V	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	1.8 8V	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	1.8 8V	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	1.8 8V	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Live Data	-	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.8 8V	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	1.8 8V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	1.8 8V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO	1.8 8V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	1.8 8V	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	1.8 8V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	1.8 8V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	1.8 8V	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	1.8 8V	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	1.8 8V	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	1.8 8V	Visteon instrument panel	Live Data	-	
-	-	STILO	1.8 8V	Visteon instrument panel	Actuation Test	-	
-	-	STILO	1.8 8V	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	1.8 8V	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO	1.8 8V	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	1.8 8V	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	1.8 8V	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	1.8 8V	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	1.8 8V	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	1.8 8V	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	1.8 8V	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	1.8 8V	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	1.8 8V	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	1.8 8V	Lear Driving Seat	Live Data	-	
-	-	STILO	1.8 8V	Lear Driving Seat	Actuation Test	-	
-	-	STILO	1.8 8V	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	1.8 8V	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	1.8 8V	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	1.8 8V	Lear Passenger Seat	Live Data	-	
-	-	STILO	1.8 8V	Lear Passenger Seat	Actuation Test	-	
-	-	STILO	1.8 8V	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	1.8 8V	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	1.8 8V	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	1.8 8V	TRW Steering Lock	Live Data	-	
-	-	STILO	1.8 8V	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	1.8 8V	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	1.8 8V	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	1.8 8V	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	1.8 8V	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	1.8 8V	Marelli Climate Control	Live Data	-	
-	-	STILO	1.8 8V	Marelli Climate Control	Actuation Test	-	
-	-	STILO	1.8 8V	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	1.8 8V	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	1.8 8V	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	1.8 8V	Marelli Connect 2	Live Data	-	
-	-	STILO	1.8 8V	Marelli Connect 2	Actuation Test	-	
-	-	STILO	1.8 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	1.8 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO	1.8 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	1.8 8V	Bosch 8 ABS	Live Data	-	
-	-	STILO	1.8 8V	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	1.8 8V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO	1.8 8V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	1.8 8V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	1.8 8V	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	1.8 8V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	1.8 8V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	1.8 8V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	1.8 8V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	1.8 8V	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	1.8 8V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	1.8 8V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	1.8 8V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	1.8 8V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	1.8 8V	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	1.8 8V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	1.8 8V	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	1.8 8V	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	1.8 8V	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	1.8 8V	G.E. Procond Boot	Live Data	-	
-	-	STILO	1.8 8V	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	1.8 8V	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	1.8 8V	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	1.8 8V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	1.8 8V	TRW 1 Power Steering	Live Data	-	
-	-	STILO	1.8 8V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.8 8V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Read ECU Information	-	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Read Fault Code	-	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Erase Fault Code	-	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Live Data	-	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Actuation Test	-	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Startup with code card	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Zeroing of self-adaption parameters	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Self-adapting parameters zeroing (air)	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Self-adapting parameters zeroing (knock)	
-	-	STILO	1.8 8V	Delphi MT25E Injection (eng. 1.8)	Special Functions	Zeroing fan mode learn	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 VDC	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 VDC	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 VDC	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 VDC	Live Data	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 VDC	Actuation Test	-	
-	-	STILO	1.9 JTD	TRW 3 Electric Steering	Read ECU Information	-	
-	-	STILO	1.9 JTD	TRW 3 Electric Steering	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.9 JTD	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	STILO	1.9 JTD	TRW 3 Electric Steering	Live Data	-	
-	-	STILO	1.9 JTD	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.9 JTD	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-S-C)	Live Data	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-S-C)	Actuation Test	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Live Data	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Actuation Test	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO	1.9 JTD	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7	Live Data	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Live Data	-	
-	-	STILO	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	STILO	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	Special Functions	Injector classification	
-	-	STILO	1.9 JTD	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bitron Driver's Door	Live Data	-	
-	-	STILO	1.9 JTD	Bitron Driver's Door	Actuation Test	-	
-	-	STILO	1.9 JTD	Bitron Boot	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bitron Boot	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bitron Boot	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bitron Boot	Live Data	-	
-	-	STILO	1.9 JTD	Bitron Boot	Actuation Test	-	
-	-	STILO	1.9 JTD	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	1.9 JTD	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	1.9 JTD	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	1.9 JTD	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	1.9 JTD	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bitron Passenger Door	Live Data	-	
-	-	STILO	1.9 JTD	Bitron Passenger Door	Actuation Test	-	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Live Data	-	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.9 JTD	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	1.9 JTD	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	1.9 JTD	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO	1.9 JTD	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	1.9 JTD	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	1.9 JTD	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	1.9 JTD	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	1.9 JTD	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	1.9 JTD	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Visteon instrument panel	Live Data	-	
-	-	STILO	1.9 JTD	Visteon instrument panel	Actuation Test	-	
-	-	STILO	1.9 JTD	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	1.9 JTD	Visteon instrument panel	Special Functions	Instrument panel lighting	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.9 JTD	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	1.9 JTD	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	1.9 JTD	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	1.9 JTD	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	1.9 JTD	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	1.9 JTD	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	1.9 JTD	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	1.9 JTD	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	1.9 JTD	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Lear Driving Seat	Live Data	-	
-	-	STILO	1.9 JTD	Lear Driving Seat	Actuation Test	-	
-	-	STILO	1.9 JTD	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	1.9 JTD	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	1.9 JTD	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Lear Passenger Seat	Live Data	-	
-	-	STILO	1.9 JTD	Lear Passenger Seat	Actuation Test	-	
-	-	STILO	1.9 JTD	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	1.9 JTD	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	1.9 JTD	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	1.9 JTD	TRW Steering Lock	Live Data	-	
-	-	STILO	1.9 JTD	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	1.9 JTD	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	1.9 JTD	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	1.9 JTD	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	1.9 JTD	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Marelli Climate Control	Live Data	-	
-	-	STILO	1.9 JTD	Marelli Climate Control	Actuation Test	-	
-	-	STILO	1.9 JTD	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	1.9 JTD	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	1.9 JTD	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Marelli Connect 2	Live Data	-	
-	-	STILO	1.9 JTD	Marelli Connect 2	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch 8 ABS	Live Data	-	
-	-	STILO	1.9 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	1.9 JTD	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	1.9 JTD	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	1.9 JTD	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	1.9 JTD	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	1.9 JTD	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	1.9 JTD	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	1.9 JTD	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	1.9 JTD	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	1.9 JTD	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	1.9 JTD	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	1.9 JTD	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	1.9 JTD	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	1.9 JTD	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	1.9 JTD	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	1.9 JTD	G.E. Procond Boot	Live Data	-	
-	-	STILO	1.9 JTD	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	1.9 JTD	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	1.9 JTD	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	1.9 JTD	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	1.9 JTD	TRW 1 Power Steering	Live Data	-	
-	-	STILO	1.9 JTD	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.9 JTD	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Live Data	-	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Actuation Test	-	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	STILO	1.9 JTD	Bitron Doors Control	Read ECU Information	-	
-	-	STILO	1.9 JTD	Bitron Doors Control	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.9 JTD	Bitron Doors Control	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Bitron Doors Control	Live Data	-	
-	-	STILO	1.9 JTD	Bitron Doors Control	Actuation Test	-	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Read ECU Information	-	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Read Fault Code	-	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Erase Fault Code	-	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Live Data	-	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Actuation Test	-	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Special Functions	Key programming	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Special Functions	Country standards change	
-	-	STILO	1.9 JTD	Marelli 5 Body Computer	Special Functions	Indicators command enable/disable	
-	-	STILO	1.9 JTD	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Live Data	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Live Data	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.9 JTD	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO	1.9 JTD	TRW Electric Drive	Special Functions	Mounting check	
-	-	STILO	1.9 JTD 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW 3 Electric Steering	Live Data	-	
-	-	STILO	1.9 JTD 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.9 JTD 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch ABS 5.7	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bitron Driver's Door	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bitron Driver's Door	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bitron Boot	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bitron Boot	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bitron Boot	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bitron Boot	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bitron Boot	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	1.9 JTD 16V	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bitron Passenger Door	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bitron Passenger Door	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Live Data	-	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	1.9 JTD 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Valeo Parking Control Unit	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.9 JTD 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	1.9 JTD 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	1.9 JTD 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Live Data	-	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	1.9 JTD 16V	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	1.9 JTD 16V	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Lear Driving Seat	Live Data	-	
-	-	STILO	1.9 JTD 16V	Lear Driving Seat	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Lear Passenger Seat	Live Data	-	
-	-	STILO	1.9 JTD 16V	Lear Passenger Seat	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW Steering Lock	Live Data	-	
-	-	STILO	1.9 JTD 16V	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	1.9 JTD 16V	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	1.9 JTD 16V	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Marelli Climate Control	Live Data	-	
-	-	STILO	1.9 JTD 16V	Marelli Climate Control	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Marelli Connect 2	Live Data	-	
-	-	STILO	1.9 JTD 16V	Marelli Connect 2	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Startup with code card	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector codes read	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 1 injector classification	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 2 injector classification	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 3 injector classification	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 4 injector classification	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 5 injector classification	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector classification (4 cyl. bank)	
-	-	STILO	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector classification (5 cyl. bank)	
-	-	STILO	1.9 JTD 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 ABS	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Boot	Live Data	-	
-	-	STILO	1.9 JTD 16V	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW 1 Power Steering	Live Data	-	
-	-	STILO	1.9 JTD 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	1.9 JTD 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	STILO	1.9 JTD 16V	Bitron Doors Control	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Bitron Doors Control	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bitron Doors Control	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Bitron Doors Control	Live Data	-	
-	-	STILO	1.9 JTD 16V	Bitron Doors Control	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Live Data	-	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Key programming	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Siren serial line check	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Country standards change	
-	-	STILO	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Indicators command enable/disable	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Live Data	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO	1.9 JTD 16V	TRW Electric Drive	Special Functions	Mounting check	
-	-	STILO	2.4 20V	Bosch ABS 5.7 VDC	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 VDC	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 VDC	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 VDC	Live Data	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 VDC	Actuation Test	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	2.4 20V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7	Live Data	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	2.4 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Live Data	-	
-	-	STILO	2.4 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Special Functions	Startup with code card	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO	2.4 20V	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Read ECU Information	-	
-	-	STILO	2.4 20V	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Read Fault Code	-	
-	-	STILO	2.4 20V	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Erase Fault Code	-	
-	-	STILO	2.4 20V	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Live Data	-	
-	-	STILO	2.4 20V	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Actuation Test	-	
-	-	STILO	2.4 20V	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	Special Functions	Startup with code card	
-	-	STILO	2.4 20V	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO	2.4 20V	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO	2.4 20V	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bitron Driver's Door	Live Data	-	
-	-	STILO	2.4 20V	Bitron Driver's Door	Actuation Test	-	
-	-	STILO	2.4 20V	Bitron Boot	Read ECU Information	-	
-	-	STILO	2.4 20V	Bitron Boot	Read Fault Code	-	
-	-	STILO	2.4 20V	Bitron Boot	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bitron Boot	Live Data	-	
-	-	STILO	2.4 20V	Bitron Boot	Actuation Test	-	
-	-	STILO	2.4 20V	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	2.4 20V	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	2.4 20V	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	2.4 20V	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	2.4 20V	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	2.4 20V	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO	2.4 20V	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO	2.4 20V	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bitron Passenger Door	Live Data	-	
-	-	STILO	2.4 20V	Bitron Passenger Door	Actuation Test	-	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Live Data	-	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	2.4 20V	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	2.4 20V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	2.4 20V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO	2.4 20V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	2.4 20V	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	2.4 20V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	2.4 20V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	2.4 20V	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	2.4 20V	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	2.4 20V	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	2.4 20V	Visteon instrument panel	Live Data	-	
-	-	STILO	2.4 20V	Visteon instrument panel	Actuation Test	-	
-	-	STILO	2.4 20V	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	2.4 20V	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO	2.4 20V	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	2.4 20V	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	2.4 20V	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	2.4 20V	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	2.4 20V	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	2.4 20V	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	2.4 20V	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	2.4 20V	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	2.4 20V	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	2.4 20V	Lear Driving Seat	Live Data	-	
-	-	STILO	2.4 20V	Lear Driving Seat	Actuation Test	-	
-	-	STILO	2.4 20V	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	2.4 20V	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	2.4 20V	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	2.4 20V	Lear Passenger Seat	Live Data	-	
-	-	STILO	2.4 20V	Lear Passenger Seat	Actuation Test	-	
-	-	STILO	2.4 20V	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	2.4 20V	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	2.4 20V	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	2.4 20V	TRW Steering Lock	Live Data	-	
-	-	STILO	2.4 20V	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	2.4 20V	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	2.4 20V	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	2.4 20V	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	2.4 20V	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	2.4 20V	Marelli Climate Control	Live Data	-	
-	-	STILO	2.4 20V	Marelli Climate Control	Actuation Test	-	
-	-	STILO	2.4 20V	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	2.4 20V	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	2.4 20V	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	2.4 20V	Marelli Connect 2	Live Data	-	
-	-	STILO	2.4 20V	Marelli Connect 2	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Read fault code	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Erase fault code	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Read data stream	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Read ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Read fault code	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Erase fault code	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Read data stream	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Special Functions	Accept configuration	
-	-	STILO	2.4 20V	Bosch Adaptive Cruise Control	Special Functions	Self-adaptation parameter erasure	
-	-	STILO	2.4 20V	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bosch 8 ABS	Live Data	-	
-	-	STILO	2.4 20V	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	2.4 20V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO	2.4 20V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	2.4 20V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	2.4 20V	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	2.4 20V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	2.4 20V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	2.4 20V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	2.4 20V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	2.4 20V	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	2.4 20V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	2.4 20V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	2.4 20V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	2.4 20V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	2.4 20V	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	2.4 20V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	2.4 20V	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	2.4 20V	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	2.4 20V	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	2.4 20V	G.E. Procond Boot	Live Data	-	
-	-	STILO	2.4 20V	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	2.4 20V	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	2.4 20V	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	2.4 20V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	2.4 20V	TRW 1 Power Steering	Live Data	-	
-	-	STILO	2.4 20V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	2.4 20V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	2.4 20V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Live Data	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Live Data	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Actuation Test	-	
-	-	STILO	2.4 20V	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO	2.4 20V	TRW Electric Drive	Special Functions	Mounting check	
-	-	STILO	SELESPEED	Bosch ABS 5.7 VDC	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 VDC	Read Fault Code	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 VDC	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 VDC	Live Data	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 VDC	Actuation Test	-	
-	-	STILO	SELESPEED	Marelli Selespeed CFC209F Automatic Gearbox	Read ECU Information	-	
-	-	STILO	SELESPEED	Marelli Selespeed CFC209F Automatic Gearbox	Read Fault Code	-	
-	-	STILO	SELESPEED	Marelli Selespeed CFC209F Automatic Gearbox	Erase Fault Code	-	
-	-	STILO	SELESPEED	Marelli Selespeed CFC209F Automatic Gearbox	Live Data	-	
-	-	STILO	SELESPEED	Marelli Selespeed CFC209F Automatic Gearbox	Actuation Test	-	
-	-	STILO	SELESPEED	Marelli Selespeed CFC209F Automatic Gearbox	Special Functions	Calculation of clutch degradation index	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read ECU Information	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-S-C)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-S-C)	Live Data	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-S-C)	Actuation Test	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read ECU Information	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Live Data	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Actuation Test	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO	SELESPEED	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7	Live Data	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Read Fault Code	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Live Data	-	
-	-	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	SELESPEED	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Live Data	-	
-	-	STILO	SELESPEED	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch Motronic Me3.1 EOBD Injection (eng. 2.0/2.4 20V)	Special Functions	Startup with code card	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO	SELESPEED	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO	SELESPEED	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO	SELESPEED	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bitron Driver's Door	Live Data	-	
-	-	STILO	SELESPEED	Bitron Driver's Door	Actuation Test	-	
-	-	STILO	SELESPEED	Bitron Boot	Read ECU Information	-	
-	-	STILO	SELESPEED	Bitron Boot	Read Fault Code	-	
-	-	STILO	SELESPEED	Bitron Boot	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bitron Boot	Live Data	-	
-	-	STILO	SELESPEED	Bitron Boot	Actuation Test	-	
-	-	STILO	SELESPEED	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO	SELESPEED	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO	SELESPEED	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO	SELESPEED	Delphi MF Passive Entry	Live Data	-	
-	-	STILO	SELESPEED	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO	SELESPEED	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO	SELESPEED	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO	SELESPEED	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bitron Passenger Door	Live Data	-	
-	-	STILO	SELESPEED	Bitron Passenger Door	Actuation Test	-	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Live Data	-	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO	SELESPEED	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO	SELESPEED	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO	SELESPEED	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO	SELESPEED	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO	SELESPEED	Valeo Parking Control Unit	Live Data	-	
-	-	STILO	SELESPEED	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO	SELESPEED	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO	SELESPEED	Visteon instrument panel	Read ECU Information	-	
-	-	STILO	SELESPEED	Visteon instrument panel	Read Fault Code	-	
-	-	STILO	SELESPEED	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO	SELESPEED	Visteon instrument panel	Live Data	-	
-	-	STILO	SELESPEED	Visteon instrument panel	Actuation Test	-	
-	-	STILO	SELESPEED	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO	SELESPEED	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO	SELESPEED	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO	SELESPEED	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO	SELESPEED	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO	SELESPEED	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO	SELESPEED	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO	SELESPEED	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO	SELESPEED	Lear Driving Seat	Read ECU Information	-	
-	-	STILO	SELESPEED	Lear Driving Seat	Read Fault Code	-	
-	-	STILO	SELESPEED	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO	SELESPEED	Lear Driving Seat	Live Data	-	
-	-	STILO	SELESPEED	Lear Driving Seat	Actuation Test	-	
-	-	STILO	SELESPEED	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO	SELESPEED	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO	SELESPEED	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO	SELESPEED	Lear Passenger Seat	Live Data	-	
-	-	STILO	SELESPEED	Lear Passenger Seat	Actuation Test	-	
-	-	STILO	SELESPEED	TRW Steering Lock	Read ECU Information	-	
-	-	STILO	SELESPEED	TRW Steering Lock	Read Fault Code	-	
-	-	STILO	SELESPEED	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO	SELESPEED	TRW Steering Lock	Live Data	-	
-	-	STILO	SELESPEED	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO	SELESPEED	TRW Steering Lock	Special Functions	Key command	
-	-	STILO	SELESPEED	Marelli Climate Control	Read ECU Information	-	
-	-	STILO	SELESPEED	Marelli Climate Control	Read Fault Code	-	
-	-	STILO	SELESPEED	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO	SELESPEED	Marelli Climate Control	Live Data	-	
-	-	STILO	SELESPEED	Marelli Climate Control	Actuation Test	-	
-	-	STILO	SELESPEED	Marelli Connect 2	Read ECU Information	-	
-	-	STILO	SELESPEED	Marelli Connect 2	Read Fault Code	-	
-	-	STILO	SELESPEED	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO	SELESPEED	Marelli Connect 2	Live Data	-	
-	-	STILO	SELESPEED	Marelli Connect 2	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Read fault code	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Erase fault code	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Read data stream	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Read fault code	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Erase fault code	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Read data stream	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Special Functions	Accept configuration	
-	-	STILO	SELESPEED	Bosch Adaptive Cruise Control	Special Functions	Self-adaptation parameter erasure	
-	-	STILO	SELESPEED	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO	SELESPEED	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch 8 ABS	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO	SELESPEED	Bosch 8 ABS	Actuation Test	-	
-	-	STILO	SELESPEED	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO	SELESPEED	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO	SELESPEED	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO	SELESPEED	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO	SELESPEED	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO	SELESPEED	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO	SELESPEED	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO	SELESPEED	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO	SELESPEED	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO	SELESPEED	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO	SELESPEED	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO	SELESPEED	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO	SELESPEED	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO	SELESPEED	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO	SELESPEED	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO	SELESPEED	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO	SELESPEED	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO	SELESPEED	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO	SELESPEED	G.E. Procond Boot	Live Data	-	
-	-	STILO	SELESPEED	G.E. Procond Boot	Actuation Test	-	
-	-	STILO	SELESPEED	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO	SELESPEED	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO	SELESPEED	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO	SELESPEED	TRW 1 Power Steering	Live Data	-	
-	-	STILO	SELESPEED	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO	SELESPEED	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO	SELESPEED	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Live Data	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Actuation Test	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Read ECU Information	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Read Fault Code	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Live Data	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Actuation Test	-	
-	-	STILO	SELESPEED	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO	SELESPEED	TRW Electric Drive	Special Functions	Mounting check	
-	-	STILO VAN	1.9 JTD 16V	TRW 3 Electric Steering	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 3 Electric Steering	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 3 Electric Steering	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 3 Electric Steering	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 3 Electric Steering	Special Functions	Steering angle calibration	
-	-	STILO VAN	1.9 JTD 16V	TRW 3 Electric Steering	Special Functions	Mounting check	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-4P-4L-2T-I-S-C)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-S-C)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-S-C)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-2T-I-C)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-2L-I-C)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Siemens MY 99 Airbag (2F-2P-I-C)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch ABS 5.7	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch ABS 5.7	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch ABS 5.7	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch ABS 5.7	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch ABS 5.7	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (left)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (right)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (right)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (right)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (right)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Driver's Door	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Driver's Door	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Driver's Door	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Driver's Door	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Driver's Door	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Boot	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Boot	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Boot	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Boot	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Boot	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Delphi MF Passive Entry	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Delphi MF Passive Entry	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Delphi MF Passive Entry	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Delphi MF Passive Entry	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Delphi MF Passive Entry	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Passenger Door	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Passenger Door	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Passenger Door	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Passenger Door	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Passenger Door	Actuation Test	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Key programming	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Siren serial line check	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Ultrasound sensor check	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	Special Functions	Window wash system check	
-	-	STILO VAN	1.9 JTD 16V	Valeo Parking Control Unit	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Valeo Parking Control Unit	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Valeo Parking Control Unit	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Valeo Parking Control Unit	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence disable	
-	-	STILO VAN	1.9 JTD 16V	Valeo Parking Control Unit	Special Functions	Tow hook presence enable	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Special Functions	LCD display illumination	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Special Functions	Instrument panel lighting	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Special Functions	Headlamp actuators	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Special Functions	Keyboard lighting	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Special Functions	Reset distance till next servicing	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Special Functions	Deactivation of alarm for unbuckled seat belt	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Special Functions	Instrument panel replacement	
-	-	STILO VAN	1.9 JTD 16V	Visteon instrument panel	Special Functions	Oil change servicing information delete	
-	-	STILO VAN	1.9 JTD 16V	Lear Driving Seat	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Driving Seat	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Driving Seat	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Driving Seat	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Driving Seat	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Passenger Seat	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Passenger Seat	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Passenger Seat	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Passenger Seat	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Lear Passenger Seat	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Steering Lock	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Steering Lock	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Steering Lock	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Steering Lock	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Steering Lock	Special Functions	Steering lock/unlock	
-	-	STILO VAN	1.9 JTD 16V	TRW Steering Lock	Special Functions	Key command	
-	-	STILO VAN	1.9 JTD 16V	Marelli Climate Control	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Climate Control	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Climate Control	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Climate Control	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Climate Control	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Connect 2	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Connect 2	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Connect 2	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Connect 2	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli Connect 2	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Startup with code card	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector codes read	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 1 injector classification	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 2 injector classification	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 3 injector classification	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 4 injector classification	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Cyl. 5 injector classification	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector classification (4 cyl. bank)	
-	-	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	Special Functions	Injector classification (5 cyl. bank)	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 ABS	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 ABS	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 VDC ABS	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 VDC ABS	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 VDC ABS	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 VDC ABS	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch 8 VDC ABS	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Passenger Door	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Passenger Door	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Passenger Door	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Passenger Door	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Passenger Door	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Driver's Door	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Driver's Door	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Driver's Door	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Driver's Door	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Driver's Door	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Boot	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Boot	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Boot	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Boot	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	G.E. Procond Boot	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 1 Power Steering	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 1 Power Steering	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 1 Power Steering	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 1 Power Steering	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	TRW 1 Power Steering	Special Functions	Steering angle calibration	
-	-	STILO VAN	1.9 JTD 16V	TRW 1 Power Steering	Special Functions	Vehicle type learn reset	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Startup with code card	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector codes read	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 1	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 2	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 3	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 4	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Replacement of injector cyl. 5	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Injector replacement (per bank)	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Oil change (only for version with DPF)	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor replacement	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	STILO VAN	1.9 JTD 16V	Bitron Doors Control	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Doors Control	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Doors Control	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Doors Control	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Bitron Doors Control	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Key programming	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Siren serial line check	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Tilt sensor check (if present)	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Dusk and rain sensors check	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Country standards change	
-	-	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	Special Functions	Indicators command enable/disable	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Read ECU Information	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Read Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Erase Fault Code	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Live Data	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Actuation Test	-	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Special Functions	Vehicle type learn reset	
-	-	STILO VAN	1.9 JTD 16V	TRW Electric Drive	Special Functions	Mounting check	
-	-	STRADA	1.3 JTD	Bosch 5.3 ABS	Read ECU Information	-	
-	-	STRADA	1.3 JTD	Bosch 5.3 ABS	Read Fault Code	-	
-	-	STRADA	1.3 JTD	Bosch 5.3 ABS	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	Bosch 5.3 ABS	Live Data	-	
-	-	STRADA	1.3 JTD	Bosch 5.3 ABS	Actuation Test	-	
-	-	STRADA	1.3 JTD	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	STRADA	1.3 JTD	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	STRADA	1.3 JTD	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	STRADA	1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	STRADA	1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	STRADA	1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	STRADA	1.3 JTD	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	STRADA	1.3 JTD	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	STRADA	1.3 JTD	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	STRADA	1.3 JTD	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	STRADA	1.3 JTD	Bosch 8 ABS	Read ECU Information	-	
-	-	STRADA	1.3 JTD	Bosch 8 ABS	Read Fault Code	-	
-	-	STRADA	1.3 JTD	Bosch 8 ABS	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	Bosch 8 ABS	Live Data	-	
-	-	STRADA	1.3 JTD	Bosch 8 ABS	Actuation Test	-	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Read ECU Information	-	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Read Fault Code	-	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Live Data	-	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Actuation Test	-	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Special Functions	Headlamp pos. correct.	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Special Functions	Servicing information delete	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Special Functions	Inputs status	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Special Functions	Oil change servicing information delete	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Special Functions	Reset odometer	
-	-	STRADA	1.3 JTD	Marelli Instrument Panel (Palio RST2)	Special Functions	Instrument panel replacement	
-	-	STRADA	1.3 JTD	Marelli Body Computer 2	Read ECU Information	-	
-	-	STRADA	1.3 JTD	Marelli Body Computer 2	Read Fault Code	-	
-	-	STRADA	1.3 JTD	Marelli Body Computer 2	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	Marelli Body Computer 2	Live Data	-	
-	-	STRADA	1.3 JTD	Marelli Body Computer 2	Actuation Test	-	
-	-	STRADA	1.3 JTD	Marelli Body Computer 2	Special Functions	Key programming	
-	-	STRADA	1.3 JTD	Marelli Body Computer 2	Special Functions	Dusk and rain sensors check	
-	-	STRADA	1.3 JTD	Marelli Body Computer 2	Special Functions	Window wash system check	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Indicators command enable/disable	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Live Data	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Oil change (only for version with DPF)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor and injectors replacement	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Lambda sensor replacement (only for version with lambda sensor)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter replacement (only for version with lambda sensor)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Pre-catalyser replacement (only for version with DPF)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter replacement (only for version with DPF)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration (only for version with DPF)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Read ECU Information	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Read Fault Code	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Erase Fault Code	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Read Data Stream	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Actuation Test	-	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	EGR valve test	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Startup with code card	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Control unit replacement	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Injector codes read	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Speed limit setting	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 1	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 2	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 3	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of injector cyl. 4	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Injector replacement (per bank)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Air flow meter sensor replacement	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Differential pressure sensor replacement (only for version with DPF)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Fuel pressure regulator replacement (high pressure pump input)	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Oil change	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Particulate filter regeneration	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Phonic wheel replacement	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Rail pressure sensor replacement	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement lambda sensor	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Replacement of variable geometry turbo and/or turbo posit. sensor	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water temp. w. lamp ON	
-	-	STRADA	1.3 JTD	Marelli Diesel Injection 8F3 CF5/EOBD (eng. 1.3 JTD)	Special Functions	Resetting distance travelled with water in diesel w. lamp ON	
-	-	STRADA	1.4 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	STRADA	1.4 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	STRADA	1.4 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STRADA	1.4 8V	Bosch 8 ABS	Live Data	-	
-	-	STRADA	1.4 8V	Bosch 8 ABS	Actuation Test	-	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Read ECU Information	-	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Read Fault Code	-	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Erase Fault Code	-	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Live Data	-	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Actuation Test	-	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Special Functions	Startup with code card	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Special Functions	Phonic wheel learn reset	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Special Functions	Zeroing of self-adaption parameters	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Special Functions	Throttle learn storage	
-	-	STRADA	1.4 8V	Magneti Marelli injection IAW 4SF	Special Functions	Vehicle configuration deletion	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Read ECU Information	-	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Read Fault Code	-	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Erase Fault Code	-	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Live Data	-	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Actuation Test	-	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Special Functions	Key programming	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Special Functions	Dusk and rain sensors check	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Special Functions	Window wash system check	
-	-	STRADA	1.4 8V	Marelli Body Computer 2	Special Functions	Indicators command enable/disable	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Read ECU Information	-	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Read Fault Code	-	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Erase Fault Code	-	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Live Data	-	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Actuation Test	-	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Headlamp pos. correct.	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Servicing information delete	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Inputs status	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Oil change servicing information delete	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Reset odometer	
-	-	STRADA	1.4 8V	Marelli Instrument Panel (Palio RST2)	Special Functions	Instrument panel replacement	
-	-	STRADA	1.4 8V	TRW MY 97 Airbag (2F-1)	Read ECU Information	-	
-	-	STRADA	1.4 8V	TRW MY 97 Airbag (2F-1)	Read Fault Code	-	
-	-	STRADA	1.4 8V	TRW MY 97 Airbag (2F-1)	Erase Fault Code	-	
-	-	STRADA	1.4 8V	TRW MY 97 Airbag (2F-1)	Live Data	-	
-	-	STRADA	1.4 8V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	STRADA	1.4 8V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	STRADA	1.4 8V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	STRADA	1.4 8V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	STRADA	1.4 8V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	STRADA	1.4 8V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	STRADA	1.4 8V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	STRADA	1.4 8V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	STRADA	1.4 8V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Read ECU Information	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Erase Fault Code	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Live Data	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Actuation Test	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Read ECU Information	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Read Fault Code	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Erase Fault Code	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Live Data	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Actuation Test	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Actuation Test	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Special Functions	Startup with code card	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Special Functions	Phonic wheel learn reset	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Special Functions	Zeroing of self-adaption parameters	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Special Functions	Throttle learn storage	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Special Functions	Vehicle configuration deletion	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec injection	Special Functions	Air conditioner learn	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Read ECU Information	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Read Fault Code	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Erase Fault Code	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Live Data	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Actuation Test	-	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Phonic wheel learn reset	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Throttle learn storage	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Vehicle configuration deletion	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Air/Fuel learn setting	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Alcohol fuel setting	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Petrol fuel setting	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Air conditioner learn	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Startup with code card	
-	-	STRADA	1.6 16V	Magneti Marelli IAW 7GF Injection	Special Functions	Phase sensor learn zeroing	
-	-	STRADA	1.6 16V	TRW MY 97 Airbag (2F-I)	Read ECU Information	-	
-	-	STRADA	1.6 16V	TRW MY 97 Airbag (2F-I)	Read Fault Code	-	
-	-	STRADA	1.6 16V	TRW MY 97 Airbag (2F-I)	Erase Fault Code	-	
-	-	STRADA	1.6 16V	TRW MY 97 Airbag (2F-I)	Live Data	-	
-	-	STRADA	1.6 16V	TRW MY 97 Airbag (2F-2L-1)	Read ECU Information	-	
-	-	STRADA	1.6 16V	TRW MY 97 Airbag (2F-2L-1)	Read Fault Code	-	
-	-	STRADA	1.6 16V	TRW MY 97 Airbag (2F-2L-1)	Erase Fault Code	-	
-	-	STRADA	1.6 16V	TRW MY 97 Airbag (2F-2L-1)	Live Data	-	
-	-	STRADA	1.6 16V	Bosch 8 ABS	Read ECU Information	-	
-	-	STRADA	1.6 16V	Bosch 8 ABS	Read Fault Code	-	
-	-	STRADA	1.6 16V	Bosch 8 ABS	Erase Fault Code	-	
-	-	STRADA	1.6 16V	Bosch 8 ABS	Live Data	-	
-	-	STRADA	1.6 16V	Bosch 8 ABS	Actuation Test	-	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Read ECU Information	-	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Read Fault Code	-	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Erase Fault Code	-	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Live Data	-	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Actuation Test	-	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Headlamp pos. correct.	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Servicing information delete	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Inputs status	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Oil change servicing information delete	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Reset odometer	
-	-	STRADA	1.6 16V	Marelli Instrument Panel (Palio RST2)	Special Functions	Instrument panel replacement	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Read ECU Information	-	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Read Fault Code	-	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Erase Fault Code	-	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Live Data	-	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Actuation Test	-	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Special Functions	Key programming	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Special Functions	Dusk and rain sensors check	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Special Functions	Window wash system check	
-	-	STRADA	1.6 16V	Marelli Body Computer 2	Special Functions	Indicators command enable/disable	
-	-	STRADA	1.6 16V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	STRADA	1.6 16V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	STRADA	1.6 16V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	STRADA	1.6 16V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	STRADA	1.6 16V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	TEMPRA	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TEMPRA	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TEMPRA	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TEMPRA	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	TEMPRA	2.0 16V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	TEMPRA	2.0 16V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	TEMPRA	2.0 16V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	TEMPRA	2.0 16V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Live Data	-	
-	-	TEMPRA	2.0 16V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	TEMPRA	2.0 8V ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Read ECU Information	-	
-	-	TEMPRA	2.0 8V ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Erase Fault Code	-	
-	-	TEMPRA	2.0 8V ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Live Data	-	
-	-	TEMPRA	2.0 8V ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Actuation Test	-	
-	-	TEMPRA	2.0 8V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	TEMPRA	2.0 8V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	TEMPRA	2.0 8V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	TEMPRA	2.0 8V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Live Data	-	
-	-	TEMPRA	2.0 8V GASOLINA	Magnetic Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	TEMPRA	2.0 TURBO GASOLINA	Bosch Motronic M1.5.2 Injection	Read Fault Code	-	
-	-	TEMPRA	2.0 TURBO GASOLINA	Bosch Motronic M1.5.2 Injection	Erase Fault Code	-	
-	-	TEMPRA	2.0 TURBO GASOLINA	Bosch Motronic M1.5.2 Injection	Live Data	-	
-	-	TEMPRA	2.0 TURBO GASOLINA	Bosch Motronic M1.5.2 Injection	Actuation Test	-	
-	-	TEMPRA	'93 1.4 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Read Fault Code	-	
-	-	TEMPRA	'93 1.4 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Erase Fault Code	-	
-	-	TEMPRA	'93 1.4 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Live Data	-	
-	-	TEMPRA	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TEMPRA	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TEMPRA	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TEMPRA	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	TEMPRA	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA	'93 1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Read Fault Code	-	
-	-	TEMPRA	'93 1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Erase Fault Code	-	
-	-	TEMPRA	'93 1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Live Data	-	
-	-	TEMPRA	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TEMPRA	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TEMPRA	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TEMPRA	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	TEMPRA	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Read ECU Information	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Read Fault Code	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Erase Fault Code	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Live Data	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Actuation Test	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Read ECU Information	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Read Fault Code	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Erase Fault Code	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Live Data	-	
-	-	TEMPRA	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Actuation Test	-	
-	-	TEMPRA	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA	'93 1.9 D	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA	'93 1.9 D	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA	'93 1.9 D	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA	'93 1.9 D	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA	'93 1.9 D	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA SW	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TEMPRA SW	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TEMPRA SW	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TEMPRA SW	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	TEMPRA SW	'93 1.4 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Read Fault Code	-	
-	-	TEMPRA SW	'93 1.4 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Erase Fault Code	-	
-	-	TEMPRA SW	'93 1.4 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Live Data	-	
-	-	TEMPRA SW	'93 1.4 I.E	Bosch Monomotronic MA 1.7 Injection	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TEMPRA SW	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TEMPRA SW	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	TEMPRA SW	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA SW	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA SW	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA SW	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA SW	'93 1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Read Fault Code	-	
-	-	TEMPRA SW	'93 1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Erase Fault Code	-	
-	-	TEMPRA SW	'93 1.6 I.E	Bosch Monomotronic MA 1.7 Injection (El. Key)	Live Data	-	
-	-	TEMPRA SW	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TEMPRA SW	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TEMPRA SW	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	TEMPRA SW	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA SW	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA SW	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA SW	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Read Fault Code	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Erase Fault Code	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Live Data	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 18F Injection	Actuation Test	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Read Fault Code	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Erase Fault Code	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Live Data	-	
-	-	TEMPRA SW	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Actuation Test	-	
-	-	TEMPRA SW	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA SW	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA SW	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA SW	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA SW	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA SW	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA SW	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA SW	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA SW	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA SW	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA SW	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA SW	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA SW	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA SW	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA SW	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA SW	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA SW	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA SW	'93 2.0 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TEMPRA SW	'93 4X4	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TEMPRA SW	'93 4X4	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TEMPRA SW	'93 4X4	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TEMPRA SW	'93 4X4	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TEMPRA SW	'93 4X4	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TIPO	1.6 I.E GASOLINA	Bosch Motronic M1.5.4 Injection	Read Fault Code	-	
-	-	TIPO	1.6 I.E GASOLINA	Bosch Motronic M1.5.4 Injection	Erase Fault Code	-	
-	-	TIPO	1.6 I.E GASOLINA	Bosch Motronic M1.5.4 Injection	Live Data	-	
-	-	TIPO	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TIPO	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TIPO	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TIPO	1.6 SELECTA ECO	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	TIPO	'93 1.1 I.E	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TIPO	'93 1.1 I.E	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TIPO	'93 1.1 I.E	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TIPO	'93 1.1 I.E	Bosch Monomotronic MA1.7 Injection	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	TIPO	'93 1.1 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TIPO	'93 1.1 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TIPO	'93 1.1 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TIPO	'93 1.1 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TIPO	'93 1.1 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TIPO	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TIPO	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TIPO	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TIPO	'93 1.4 I.E	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	TIPO	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TIPO	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TIPO	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TIPO	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TIPO	'93 1.4 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TIPO	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	TIPO	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	TIPO	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	
-	-	TIPO	'93 1.6 I.E	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	TIPO	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TIPO	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TIPO	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TIPO	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TIPO	'93 1.6 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TIPO	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TIPO	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TIPO	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TIPO	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TIPO	'93 1.8 I.E	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TIPO	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Read ECU Information	-	
-	-	TIPO	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Read Fault Code	-	
-	-	TIPO	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Erase Fault Code	-	
-	-	TIPO	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Live Data	-	
-	-	TIPO	'93 1.8 I.E	Magneti Marelli IAW 08F Injection	Actuation Test	-	
-	-	TIPO	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TIPO	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TIPO	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TIPO	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TIPO	'93 1.9 DS	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TIPO	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TIPO	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TIPO	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TIPO	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TIPO	'93 1.9 TURBO DS	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TIPO	'93 2.0 16V	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TIPO	'93 2.0 16V	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TIPO	'93 2.0 16V	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TIPO	'93 2.0 16V	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TIPO	'93 2.0 16V	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	TIPO	'93 2.0 I.E.	ICIT VAS 93 Anti-Theft Device	Read ECU Information	-	
-	-	TIPO	'93 2.0 I.E.	ICIT VAS 93 Anti-Theft Device	Read fault code	-	
-	-	TIPO	'93 2.0 I.E.	ICIT VAS 93 Anti-Theft Device	Erase fault code	-	
-	-	TIPO	'93 2.0 I.E.	ICIT VAS 93 Anti-Theft Device	Read data stream	-	
-	-	TIPO	'93 2.0 I.E.	ICIT VAS 93 Anti-Theft Device	Actuation Test	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Read fault code	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Erase fault code	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Read data stream	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Read fault code	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Erase fault code	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Read data stream	-	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Special Functions	System configuration write	
-	-	ULYSSE	'00 2.0 16V	Autoliv ACU Airbag	Special Functions	Control unit unlock	
-	-	ULYSSE	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Read Fault Code	-	
-	-	ULYSSE	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Erase Fault Code	-	
-	-	ULYSSE	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Live Data	-	
-	-	ULYSSE	'00 2.0 16V	Magneti Marelli MM4.8P PSA injection	Actuation Test	-	
-	-	ULYSSE	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Read fault code	-	
-	-	ULYSSE	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Erase fault code	-	
-	-	ULYSSE	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Read data stream	-	
-	-	ULYSSE	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Self-adaptive parameters	
-	-	ULYSSE	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Acceler. pedal posit. learn.	
-	-	ULYSSE	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	Special Functions	Oil counter write	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Read fault code	-	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Erase fault code	-	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Read data stream	-	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Read fault code	-	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Erase fault code	-	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Read data stream	-	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Special Functions	System configuration write	
-	-	ULYSSE	'00 2.0 JTD	Autoliv ACU Airbag	Special Functions	Control unit unlock	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read Fault Code	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Erase Fault Code	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Live Data	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Actuation Test	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Special Functions	Particulate filter regeneration	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Read Fault Code	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Live Data	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Actuation Test	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Read fault code	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Erase fault code	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Read data stream	-	
-	-	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	Actuation Test	-	
-	-	ULYSSE	'00 2.0 JTD	WEBASTO Heater (PSA)	Read ECU Information	-	
-	-	ULYSSE	'00 2.0 JTD	WEBASTO Heater (PSA)	Read Fault Code	-	
-	-	ULYSSE	'00 2.0 JTD	WEBASTO Heater (PSA)	Erase Fault Code	-	
-	-	ULYSSE	'00 2.0 JTD	WEBASTO Heater (PSA)	Read Data Stream	-	
-	-	ULYSSE	'00 2.0 JTD	WEBASTO Heater (PSA)	Actuation Test	-	
-	-	ULYSSE	1.9 TD	Bosch AS3 Diesel Injection	Read Fault Code	-	
-	-	ULYSSE	1.9 TD	Bosch AS3 Diesel Injection	Erase Fault Code	-	
-	-	ULYSSE	1.9 TD	Bosch AS3 Diesel Injection	Live Data	-	
-	-	ULYSSE	'97 1.9 TD	Bosch AS3 Diesel Injection	Read Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE	'97 1.9 TD	Bosch AS3 Diesel Injection	Erase Fault Code	-	
-	-	ULYSSE	'97 1.9 TD	Bosch AS3 Diesel Injection	Live Data	-	
-	-	ULYSSE	'97 TURBO	Bosch Motronic MP3.2 injection (9600 Baud)	Read Fault Code	-	
-	-	ULYSSE	'97 TURBO	Bosch Motronic MP3.2 injection (9600 Baud)	Erase Fault Code	-	
-	-	ULYSSE	'97 TURBO	Bosch Motronic MP3.2 injection (9600 Baud)	Live Data	-	
-	-	ULYSSE	'98 2.0 16V	Bosch Motronic MP7.3 injection	Read ECU Information	-	
-	-	ULYSSE	'98 2.0 16V	Bosch Motronic MP7.3 injection	Read Fault Code	-	
-	-	ULYSSE	'98 2.0 16V	Bosch Motronic MP7.3 injection	Erase Fault Code	-	
-	-	ULYSSE	'98 2.0 16V	Bosch Motronic MP7.3 injection	Live Data	-	
-	-	ULYSSE	'98 2.0 16V	Bosch Motronic MP7.3 injection	Actuation Test	-	
-	-	ULYSSE	TURBO	Bosch Motronic MP 3.2 Injection	Read Fault Code	-	
-	-	ULYSSE	TURBO	Bosch Motronic MP 3.2 Injection	Erase Fault Code	-	
-	-	ULYSSE	TURBO	Bosch Motronic MP 3.2 Injection	Live Data	-	
-	-	ULYSSE	2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Read ECU Information	-	
-	-	ULYSSE	2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Read Fault Code	-	
-	-	ULYSSE	2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Live Data	-	
-	-	ULYSSE	2.0 JTD	Bosch EDC15 PSA Diesel Injection (eng. 2.0 8v)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Special Functions	Particulate filter regeneration	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Special Functions	System configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Special Functions	System configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration rea	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Special Functions	United kingdom (Thatcham std)	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Alarm	Special Functions	Volumetric sensors automatic diagnosis	
-	-	ULYSSE (179)	2.0 JTD 16V	Blaupunkt Radio	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Blaupunkt Radio	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Blaupunkt Radio	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Blaupunkt Radio	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Blaupunkt Radio	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Blaupunkt Radio	Special Functions	System configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration rea	
-	-	ULYSSE (179)	2.0 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Passenger Door	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Passenger Door	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Passenger Door	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Passenger Door	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Passenger Door	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	System configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	LED colours configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Driver's Door	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Driver's Door	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Driver's Door	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Driver's Door	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Brose Driver's Door	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Screen configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Options configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Sound system and telephone configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Function block/speed configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Advanced customisation	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Personal data deletion	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	VIN Code configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Call buttons configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Tyre Pressure Control	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Tyre Pressure Control	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Tyre Pressure Control	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Tyre Pressure Control	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Wheel identification check	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Control unit deactivation	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Control unit activation	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Secondary wheel identification deletion	
-	-	ULYSSE (179)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Control unit unlock	
-	-	ULYSSE (179)	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Cooling fans test	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration rea	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Deletion stored buttons	
-	-	ULYSSE (179)	2.0 JTD 16V	HPI Power Steering	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	HPI Power Steering	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	HPI Power Steering	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	HPI Power Steering	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	HPI Power Steering	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Automatic configuration rea	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Texton Sliding Doors (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Texton Sliding Doors (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Texton Sliding Doors (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Texton Sliding Doors (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Texton Sliding Doors (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Automatic configuration rea	
-	-	ULYSSE (179)	2.0 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Brake bleed	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Steering angle calibration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Steering angle reset	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA DAV Connect Command (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA DAV Connect Command (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA DAV Connect Command (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration rea	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	FAP Replacement	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	Control unit replacement	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	Engine type configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo Body Computer (BSI CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo Body Computer (BSI CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo Body Computer (BSI CAN)	Clear Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read fault code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Erase fault code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read data stream	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Oil counter write	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Borg warner sol. valves compatibility	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	System configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Self-adaptive parameters	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 1	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 2	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 3	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 4	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 5	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 6	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Heat exchang. flow EV.	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Part. Filter regeneration	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	EGR valve learn	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Replacement injectors	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Replacement of particulate filter and interventions on diesel additive circuit.	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Brake bleed	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle calibration	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle reset	
-	-	ULYSSE (179)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Longit. acc. sensor calibration	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Clear Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Screen configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Options configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Jukebox function	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Advanced customisation	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Personal data deletion	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Call buttons configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	JukeBox data deletion	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	ULYSSE (179)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	VIN Code configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens USB Box Control Unit	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens USB Box Control Unit	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens USB Box Control Unit	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens USB Box Control Unit	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens USB Box Control Unit	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.0 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Personal data deletion	
-	-	ULYSSE (179)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	VIN Code configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Live Data	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Special Functions	System calibration	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Actuation Test	-	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	System calibration	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - high	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - low	
-	-	ULYSSE (179)	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - intermediate	
-	-	ULYSSE (179)	2.0 JTD 16V	WEBASTO Heater (PSA)	Read ECU Information	-	
-	-	ULYSSE (179)	2.0 JTD 16V	WEBASTO Heater (PSA)	Read Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	WEBASTO Heater (PSA)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.0 JTD 16V	WEBASTO Heater (PSA)	Read Data Stream	-	
-	-	ULYSSE (179)	2.0 JTD 16V	WEBASTO Heater (PSA)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Special Functions	Particulate filter regeneration	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Multi-Switch (COM2003)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Multi-Switch (COM2003)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Multi-Switch (COM2003)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Multi-Switch (COM2003)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Multi-Switch (COM2003)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bitron Driver's Seat (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bitron Driver's Seat (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bitron Driver's Seat (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bitron Driver's Seat (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bitron Driver's Seat (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bitron Driver's Seat (CAN)	Special Functions	System configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Special Functions	System configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Special Functions	United kingdom (Thatcham std)	
-	-	ULYSSE (179)	2.2 JTD 16V	Delphi Alarm	Special Functions	Volumetric sensors automatic diagnosis	
-	-	ULYSSE (179)	2.2 JTD 16V	Blaupunkt Radio	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Blaupunkt Radio	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Blaupunkt Radio	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Blaupunkt Radio	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Blaupunkt Radio	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Blaupunkt Radio	Special Functions	System configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Passenger Door	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Passenger Door	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Passenger Door	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Passenger Door	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Passenger Door	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Clarion CD Magazine (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Clarion CD Magazine (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Clarion CD Magazine (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Clarion CD Magazine (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Clarion CD Magazine (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	System configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	LED colours configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Driver's Door	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Driver's Door	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Driver's Door	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Driver's Door	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Brose Driver's Door	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Screen configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Options configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Sound system and telephone configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Function block/speed configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Advanced customisation	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Personal data deletion	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	VIN Code configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Call buttons configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Luminosity/Rain Sensor	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Luminosity/Rain Sensor	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Luminosity/Rain Sensor	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Luminosity/Rain Sensor	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens Tyre Pressure Control	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens Tyre Pressure Control	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens Tyre Pressure Control	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens Tyre Pressure Control	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Wheel identification check	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Control unit deactivation	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Control unit activation	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Secondary wheel identification deletion	
-	-	ULYSSE (179)	2.2 JTD 16V	BOSCH/Temic Airbag (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	BOSCH/Temic Airbag (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	BOSCH/Temic Airbag (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	BOSCH/Temic Airbag (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Control unit unlock	
-	-	ULYSSE (179)	2.2 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Cooling fans test	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Deletion stored buttons	
-	-	ULYSSE (179)	2.2 JTD 16V	HPI Power Steering	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	HPI Power Steering	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	HPI Power Steering	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	HPI Power Steering	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	HPI Power Steering	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Front Sunroof (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Front Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Front Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Front Sunroof (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Front Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Centre Sunroof (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Centre Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Centre Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Centre Sunroof (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Centre Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Rear Sunroof (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Rear Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Rear Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Rear Sunroof (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Inalfa Rear Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Cluster (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Cluster (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Cluster (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Cluster (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Marelli Cluster (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Texton Sliding Doors (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Texton Sliding Doors (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Texton Sliding Doors (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Texton Sliding Doors (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Texton Sliding Doors (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Brake bleed	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Steering angle calibration	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Steering angle reset	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA DAV Connect Command (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA DAV Connect Command (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA DAV Connect Command (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration rea	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Diesel additive control (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Diesel additive control (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Diesel additive control (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Diesel additive control (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Diesel additive control (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	FAP Replacement	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	Control unit replacement	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	Engine type configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Denso Climate Control (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Denso Climate Control (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Denso Climate Control (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Denso Climate Control (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	PSA Denso Climate Control (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo Body Computer (BSI CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo Body Computer (BSI CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo Body Computer (BSI CAN)	Clear Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Brake bleed	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle calibration	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle reset	
-	-	ULYSSE (179)	2.2 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Longit. acc. sensor calibration	
-	-	ULYSSE (179)	2.2 JTD 16V	AISIN AM6 Automatic Gearbox	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	AISIN AM6 Automatic Gearbox	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	AISIN AM6 Automatic Gearbox	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	AISIN AM6 Automatic Gearbox	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Clear Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Screen configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Options configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Jukebox function	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Advanced customisation	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Personal data deletion	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Call buttons configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	JukeBox data deletion	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	ULYSSE (179)	2.2 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	VIN Code configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens USB Box Control Unit	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens USB Box Control Unit	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens USB Box Control Unit	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens USB Box Control Unit	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens USB Box Control Unit	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	HERMAN BECKER Navigator auto radio	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	HERMAN BECKER Navigator auto radio	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	HERMAN BECKER Navigator auto radio	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration read	
-	-	ULYSSE (179)	2.2 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration write	
-	-	ULYSSE (179)	2.2 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Personal data deletion	
-	-	ULYSSE (179)	2.2 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	VIN Code configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Manual system configuration	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Live Data	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (RH)	Special Functions	System calibration	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (LH)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (LH)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (LH)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (LH)	Actuation Test	-	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	System calibration	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - high	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - low	
-	-	ULYSSE (179)	2.2 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - intermediate	
-	-	ULYSSE (179)	2.2 JTD 16V	WEBASTO Heater (PSA)	Read ECU Information	-	
-	-	ULYSSE (179)	2.2 JTD 16V	WEBASTO Heater (PSA)	Read Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	WEBASTO Heater (PSA)	Erase Fault Code	-	
-	-	ULYSSE (179)	2.2 JTD 16V	WEBASTO Heater (PSA)	Read Data Stream	-	
-	-	ULYSSE (179)	2.2 JTD 16V	WEBASTO Heater (PSA)	Actuation Test	-	
-	-	UNO	1000 I.E. ECO	Bosch Monomotronic MA1.7 Injection	Read ECU Information	-	
-	-	UNO	1000 I.E. ECO	Bosch Monomotronic MA1.7 Injection	Read Fault Code	-	
-	-	UNO	1000 I.E. ECO	Bosch Monomotronic MA1.7 Injection	Erase Fault Code	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	UNO	1000 I.E. ECO	Bosch Monomotronic MA1.7 Injection	Live Data	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 16F Injection	Read ECU Information	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 16F Injection	Read Fault Code	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 16F Injection	Erase Fault Code	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 16F Injection	Live Data	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 16F Injection	Actuation Test	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read ECU Information	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Read Fault Code	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Erase Fault Code	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Live Data	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Actuation Test	-	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Lambda sensor check	
-	-	UNO	1242 BENZINA	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	Special Functions	Startup with code card	
-	-	UNO	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read ECU Information	-	
-	-	UNO	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Read Fault Code	-	
-	-	UNO	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Erase Fault Code	-	
-	-	UNO	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Live Data	-	
-	-	UNO	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Actuation Test	-	
-	-	UNO	1242 BENZINA	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	Special Functions	Startup with code card	
-	-	UNO	1497 ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Read ECU Information	-	
-	-	UNO	1497 ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Erase Fault Code	-	
-	-	UNO	1497 ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Live Data	-	
-	-	UNO	1497 ALCOOL	Magneti Marelli IAW G7.XX Alcohol Injection	Actuation Test	-	
-	-	UNO	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	UNO	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	UNO	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	UNO	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Live Data	-	
-	-	UNO	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	UNO	1580 GASOLINA	Bosch Motronic M1.5.4 Injection	Read Fault Code	-	
-	-	UNO	1580 GASOLINA	Bosch Motronic M1.5.4 Injection	Erase Fault Code	-	
-	-	UNO	1580 GASOLINA	Bosch Motronic M1.5.4 Injection	Live Data	-	
-	-	UNO	1580 GASOLINA	Magneti Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	UNO	1580 GASOLINA	Magneti Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	UNO	1580 GASOLINA	Magneti Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	UNO	1580 GASOLINA	Magneti Marelli IAW G7.XX Injection	Live Data	-	
-	-	UNO	1580 GASOLINA	Magneti Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.XX Injection	Live Data	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.11 LC Injection	Read ECU Information	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.11 LC Injection	Read Fault Code	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.11 LC Injection	Erase Fault Code	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.11 LC Injection	Live Data	-	
-	-	UNO	994 GASOLINA	Magneti Marelli IAW G7.11 LC Injection	Actuation Test	-	
-	-	UNO	994 I.E. START	Magneti Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	UNO	994 I.E. START	Magneti Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	UNO	994 I.E. START	Magneti Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	UNO	994 I.E. START	Magneti Marelli IAW G7.XX Injection	Live Data	-	
-	-	UNO	994 I.E. START	Magneti Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Read ECU Information	-	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Read Fault Code	-	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Erase Fault Code	-	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Live Data	-	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Actuation Test	-	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Special Functions	Servicing information delete	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Special Functions	Oil change servicing information delete	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Special Functions	Instrument panel replacement	
-	-	UNO (195)	1.4 8V	Continental Body/Instrument Panel	Special Functions	Reset odometer	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Read ECU Information	-	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Read Fault Code	-	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Erase Fault Code	-	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Live Data	-	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Actuation Test	-	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Phonic wheel learn reset	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Zeroing of self-adaption parameters	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Throttle learn storage	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Vehicle configuration deletion	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Air/Fuel learn setting	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Alcohol fuel setting	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Petrol fuel setting	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Air conditioner learn	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Startup with code card	
-	-	UNO (195)	1.4 8V	Magneti Marelli IAW 7GF Injection	Special Functions	Phase sensor learn zeroing	
-	-	UNO (195)	1.4 8V	Bosch 8 ABS	Read ECU Information	-	
-	-	UNO (195)	1.4 8V	Bosch 8 ABS	Read Fault Code	-	
-	-	UNO (195)	1.4 8V	Bosch 8 ABS	Erase Fault Code	-	
-	-	UNO (195)	1.4 8V	Bosch 8 ABS	Live Data	-	
-	-	UNO (195)	1.4 8V	Bosch 8 ABS	Actuation Test	-	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Read ECU Information	-	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Read Fault Code	-	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Erase Fault Code	-	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Live Data	-	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Actuation Test	-	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Key programming	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Siren serial line check	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Ultrasound sensor check	
-	-	UNO (195)	1.4 8V	Marelli Body Computer MY 03	Special Functions	Indicators command enable/disable	
-	-	UNO (195)	1.4 8V	Siemens Airbag 1 (Proxi)	Read ECU Information	-	
-	-	UNO (195)	1.4 8V	Siemens Airbag 1 (Proxi)	Read Fault Code	-	
-	-	UNO (195)	1.4 8V	Siemens Airbag 1 (Proxi)	Erase Fault Code	-	
-	-	UNO (195)	1.4 8V	Siemens Airbag 1 (Proxi)	Live Data	-	
-	-	UNO (195)	1.4 8V	Siemens Airbag 1 (Proxi)	Actuation Test	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Read ECU Information	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Read Fault Code	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Erase Fault Code	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Live Data	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW 1G7 Gasoline Injection	Actuation Test	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	UNO PICK-UP	1497 GASOLINA	Magneti Marelli IAW G7.XX Injection	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	UNO PICK-UP	1497 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	UNO PICK-UP	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read ECU Information	-	
-	-	UNO PICK-UP	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Read Fault Code	-	
-	-	UNO PICK-UP	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Erase Fault Code	-	
-	-	UNO PICK-UP	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Live Data	-	
-	-	UNO PICK-UP	1580 GASOLINA	Magnetic Marelli IAW G7.XX Injection	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Special Functions	Particulate filter regeneration	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Switch (COM2003)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bitron Driver's Seat (CAN)	Special Functions	System configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Special Functions	System configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration rea	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Special Functions	United kingdom (Thatcham std)	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Alarm	Special Functions	Volumetric sensors automatic diagnosis	
-	-	ULYSSE VAN	2.0 JTD 16V	Blaupunkt Radio	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Blaupunkt Radio	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Blaupunkt Radio	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Blaupunkt Radio	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Blaupunkt Radio	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Blaupunkt Radio	Special Functions	System configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration rea	
-	-	ULYSSE VAN	2.0 JTD 16V	Blaupunkt Radio	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Passenger Door	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Passenger Door	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Passenger Door	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Passenger Door	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Passenger Door	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Clarion CD Magazine (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Clarion CD Magazine (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Clarion CD Magazine (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Clarion CD Magazine (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Clarion CD Magazine (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	System configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Clarion CD Magazine (CAN)	Special Functions	LED colours configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Driver's Door	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Driver's Door	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Driver's Door	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Driver's Door	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Brose Driver's Door	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Screen configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Options configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Sound system and telephone configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Function block/speed configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Advanced customisation	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Personal data deletion	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	VIN Code configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration read	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Call buttons configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Connect (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Tyre Pressure Control	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Tyre Pressure Control	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Tyre Pressure Control	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Tyre Pressure Control	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Wheel identification check	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Control unit deactivation	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Control unit activation	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Tyre Pressure Control	Special Functions	Secondary wheel identification deletion	
-	-	ULYSSE VAN	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Control unit unlock	
-	-	ULYSSE VAN	2.0 JTD 16V	BOSCH/Temic Airbag (CAN)	Special Functions	Cooling fans test	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Manual system configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration rea	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson / Borg Multi-Function Screen	Special Functions	Deletion stored buttons	
-	-	ULYSSE VAN	2.0 JTD 16V	HPI Power Steering	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	HPI Power Steering	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	HPI Power Steering	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	HPI Power Steering	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	HPI Power Steering	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Read ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Front Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Centre Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Inalfa Rear Sunroof (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Marelli Cluster (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Automatic configuration rea	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Odometer Warning Lamps (BTO CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Texton Sliding Doors (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Texton Sliding Doors (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Texton Sliding Doors (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Texton Sliding Doors (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Texton Sliding Doors (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Automatic configuration rea	
-	-	ULYSSE VAN	2.0 JTD 16V	Texton Sliding Doors (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Brake bleed	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Steering angle calibration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Bosch ABS 8 ESP (CAN)	Special Functions	Steering angle reset	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA DAV Connect Command (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA DAV Connect Command (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA DAV Connect Command (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration rea	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	FAP Replacement	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	Control unit replacement	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Diesel additive control (CAN)	Special Functions	Engine type configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	PSA Denso Climate Control (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo Body Computer (BSI CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo Body Computer (BSI CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo Body Computer (BSI CAN)	Clear Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read fault code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Erase fault code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read data stream	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Oil counter write	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Borg warner sol. valves compatibility	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	System configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Self-adaptive parameters	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 1	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 2	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 3	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 4	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 5	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 6	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Heat exchang. flow EV.	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Part. Filter regeneration	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Automatic configuration read	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	EGR valve learn	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Replacement injectors	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/EOBD (eng.16v)	Special Functions	Replacement of particulate filter and interventions on diesel additive circuit.	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Brake bleed	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle calibration	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Steering angle reset	
-	-	ULYSSE VAN	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	Special Functions	Longit. acc. sensor calibration	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Johnson EV Body Computer (BSI CAN) 2	Clear Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Screen configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Options configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Jukebox function	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Advanced customisation	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Personal data deletion	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration read	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Call buttons configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	JukeBox data deletion	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Manual system configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	ULYSSE VAN	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	Special Functions	VIN Code configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens USB Box Control Unit	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens USB Box Control Unit	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens USB Box Control Unit	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens USB Box Control Unit	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens USB Box Control Unit	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration read	
-	-	ULYSSE VAN	2.0 JTD 16V	Siemens USB Box Control Unit	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration read	
-	-	ULYSSE VAN	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Automatic configuration write	
-	-	ULYSSE VAN	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Personal data deletion	
-	-	ULYSSE VAN	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	VIN Code configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	HERMAN BECKER Navigator auto radio	Special Functions	Manual system configuration	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Live Data	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (RH)	Special Functions	System calibration	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Actuation Test	-	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	System calibration	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - high	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - low	
-	-	ULYSSE VAN	2.0 JTD 16V	Valeo PSA discharge headlamp (LH)	Special Functions	Headlight actuators - intermediate	
-	-	ULYSSE VAN	2.0 JTD 16V	WEBASTO Heater (PSA)	Read ECU Information	-	
-	-	ULYSSE VAN	2.0 JTD 16V	WEBASTO Heater (PSA)	Read Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	WEBASTO Heater (PSA)	Erase Fault Code	-	
-	-	ULYSSE VAN	2.0 JTD 16V	WEBASTO Heater (PSA)	Read Data Stream	-	
-	-	ULYSSE VAN	2.0 JTD 16V	WEBASTO Heater (PSA)	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Test limit speed disable	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Test limit speed restore	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Brake bleed	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Steering angle calibration	
-	-	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Manual system configuration	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Texton Sliding Doors	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli mm4mp2 Psa Injection	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli mm4mp2 Psa Injection	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli mm4mp2 Psa Injection	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli mm4mp2 Psa Injection	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli mm4mp2 Psa Injection	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli Mm6Lp Psa Injection	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli Mm6Lp Psa Injection	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli Mm6Lp Psa Injection	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli Mm6Lp Psa Injection	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli Mm6Lp Psa Injection	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli Mm6Lp Psa Injection	Special Functions	Reset self-adapt. param. and idle act.	
-	-	ULYSSE '02	2.0 16V	Magneti Marelli Mm6Lp Psa Injection	Special Functions	System configuration	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Voice synthesis test	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Cooling fans test	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Automatic emergency call activation	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Manual emergency call activation	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Assistance call activation	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Optical fibre test	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Backup battery replacement	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Call buttons configuration	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Personal data deletion	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	VIN Code configuration	
-	-	ULYSSE '02	2.0 16V	Marelli PSA Connect	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Marelli Odometer w. lamps (bto)	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Sagem Body Computer	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Sagem Body Computer	Erase fault code	-	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read fault code	-	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Erase fault code	-	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read data stream	-	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Oil counter write	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Borg warner sol. valves compatibility	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	System configuration	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Self-adaptive parameters	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 1	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 2	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 3	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 4	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 5	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 6	
-	-	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Heat exchang. flow EV.	
-	-	ULYSSE '02	2.0 16V	Texton Alarm 2	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Texton Alarm 2	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Texton Alarm 2	Clear Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Texton Alarm 2	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Texton Alarm 2	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Texton Alarm 2	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Texton Alarm 2	Clear Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Texton Alarm 2	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Temic Airbag	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Temic Airbag	Read fault code	-	
-	-	ULYSSE '02	2.0 16V	Temic Airbag	Erase fault code	-	
-	-	ULYSSE '02	2.0 16V	Temic Airbag	Read data stream	-	
-	-	ULYSSE '02	2.0 16V	Temic Airbag	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Temic Airbag	Read fault code	-	
-	-	ULYSSE '02	2.0 16V	Temic Airbag	Erase fault code	-	
-	-	ULYSSE '02	2.0 16V	Temic Airbag	Read data stream	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read fault code	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Erase fault code	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read data stream	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read fault code	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Erase fault code	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read data stream	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read fault code	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Erase fault code	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read data stream	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Read fault code	-	
-	-	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	Erase fault code	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Live Data	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (RH)	Special Functions	System calibration	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (LH)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (LH)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (LH)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (LH)	Actuation Test	-	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (LH)	Special Functions	System calibration	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (LH)	Special Functions	Headlight actuators - high	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (LH)	Special Functions	Headlight actuators - low	
-	-	ULYSSE '02	2.0 16V	Valeo Psa Discharge Headlamp (LH)	Special Functions	Headlight actuators - intermediate	
-	-	ULYSSE '02	2.0 16V	WEBASTO Heater (PSA)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 16V	WEBASTO Heater (PSA)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 16V	WEBASTO Heater (PSA)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 16V	WEBASTO Heater (PSA)	Read Data Stream	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE '02	2.0 16V	WEBASTO Heater (PSA)	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Webasto Heater (PSA)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Webasto Heater (PSA)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Webasto Heater (PSA)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Webasto Heater (PSA)	Read Data Stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Webasto Heater (PSA)	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Oil counter write	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Borg warner sol. valves compatibility	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	System configuration	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Self-adaptive parameters	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 1	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 2	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 3	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 4	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 5	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Sequence EV. 6	
-	-	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	Special Functions	Heat exchang. flow EV.	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion CD Changer	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Body Computer	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Sagem Body Computer	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli Psa Instrument Panel	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Clarion/Philips Sound System	Special Functions	Chassis number	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Special Functions	System calibration	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Read fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Read fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Special Functions	Control unit replacement	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Special Functions	Additive type configuration	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Special Functions	FAP Temperature probe presence configuration	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli diesel additive check	Special Functions	FAP Replacement	
-	-	ULYSSE '02	2.0 JTD 16V	Texton Alarm 2	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Texton Alarm 2	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Texton Alarm 2	Clear Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Texton Alarm 2	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Texton Alarm 2	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Texton Alarm 2	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Texton Alarm 2	Clear Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Texton Alarm 2	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Special Functions	Voice synthesis test	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Special Functions	Cooling fans test	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Special Functions	Automatic emergency call activation	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Special Functions	Manual emergency call activation	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Special Functions	Assistance call activation	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Connect	Special Functions	Optical fibre test	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE '02	2.0 JTD 16V	Inalfa Rear Sunroof	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Inalfa Rear Sunroof	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Inalfa Rear Sunroof	Read fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Inalfa Rear Sunroof	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Inalfa Rear Sunroof	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Temic Airbag	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Temic Airbag	Read fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Temic Airbag	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Temic Airbag	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Temic Airbag	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Temic Airbag	Read fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Temic Airbag	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Temic Airbag	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Driver's Door	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Driver's Door	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Driver's Door	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Driver's Door	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Driver's Door	Erase fault code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Driver's Door	Read data stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Passenger's Door	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Passenger's Door	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Passenger's Door	Read Data Stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Passenger's Door	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Passenger's Door	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Passenger's Door	Read Data Stream	-	
-	-	ULYSSE '02	2.0 JTD 16V	Marelli PSA Passenger's Door	Special Functions	Stored status deletion	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Test limit speed disable	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Test limit speed restore	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Brake bleed	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Steering angle calibration	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch 5.7 ESP PSA ABS	Special Functions	Manual system configuration	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (LH)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (LH)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (LH)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (LH)	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (LH)	Special Functions	System calibration	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (LH)	Special Functions	Headlight actuators - high	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (LH)	Special Functions	Headlight actuators - low	
-	-	ULYSSE '02	2.0 JTD 16V	Valeo Psa Discharge Headlamp (LH)	Special Functions	Headlight actuators - intermediate	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read ECU Information	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Read Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Erase Fault Code	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Live Data	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Actuation Test	-	
-	-	ULYSSE '02	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (eng. 16v)	Special Functions	Particulate filter regeneration	
-	-	ULYSSE '02	2.2 JTD 16V	Webasto Heater (PSA)	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Webasto Heater (PSA)	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Webasto Heater (PSA)	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Webasto Heater (PSA)	Read Data Stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Webasto Heater (PSA)	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion CD Changer	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Multi-Function Screen	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Body Computer	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Sagem Body Computer	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Psa Instrument Panel	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Clarion/Philips Sound System	Special Functions	Chassis number	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Read ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo Psa Discharge Headlamp (RH)	Special Functions	System calibration	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Read data stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Read data stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Special Functions	Control unit replacement	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Special Functions	Additive type configuration	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Special Functions	FAP Temperature probe presence configuration	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli diesel additive check	Special Functions	FAP Replacement	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Alarm 2	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Alarm 2	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Alarm 2	Clear Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Alarm 2	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Alarm 2	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Alarm 2	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Alarm 2	Clear Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Alarm 2	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Voice synthesis test	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Cooling fans test	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Automatic emergency call activation	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Manual emergency call activation	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Assistance call activation	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Optical fibre test	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Backup battery replacement	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Call buttons configuration	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Personal data deletion	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	VIN Code configuration	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Connect	Special Functions	Activation/Deactivation 'Auxiliary video input' procedure	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli Odometer w. lamps (bto)	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Texton Sliding Doors	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read data stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read data stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read data stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Inalfa Front Sunroof	Read data stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Erase Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Marelli PSA Climate Control	Actuation Test	-	
-	-	ULYSSE '02	2.2 JTD 16V	Eaton Multi-Switch Stalk Unit (COM2000)	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Eaton Multi-Switch Stalk Unit (COM2000)	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Eaton Multi-Switch Stalk Unit (COM2000)	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Eaton Multi-Switch Stalk Unit (COM2000)	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Eaton Multi-Switch Stalk Unit (COM2000)	Read Fault Code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Eaton Multi-Switch Stalk Unit (COM2000)	Live Data	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read data stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read data stream	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read ECU Information	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Erase fault code	-	
-	-	ULYSSE '02	2.2 JTD 16V	Valeo PSA Parking Control Unit	Read data stream	-	





















## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Erase codes	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Live Data	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	ECU Information	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Read Codes	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Erase codes	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Live Data	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	ECU Information	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Read Codes	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Erase codes	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Live Data	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	ECU Information	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Read Codes	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Erase codes	-	
2007	CC	CC-Cinquecento	-	EPS -- Electric Power Steering	Live Data	-	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	ECU Information	-	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	Read Codes	-	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	Erase codes	-	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	Live Data	-	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	Actuators	-	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	ECU Configure Information	-	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	Special Functions	Audio video signal detection	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	Special Functions	Power on and disable user inputs	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	Special Functions	Reset Parameters to Default	
2007	CC	CC-Cinquecento	-	RADIO -- Radio	System Tests	Power Down	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2007	CC	CC-Cinquecento	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Live Data	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Actuators	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Audio Test	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Live Data	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Actuators	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2007	CC	CC-Cinquecento	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	ECU Information	-	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	Read Codes	-	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	Erase codes	-	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	Live Data	-	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	ECU Information	-	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	Read Codes	-	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	Erase codes	-	
2007	CC	CC-Cinquecento	-	PAM -- Park Assist Module	Live Data	-	
2007	CC	CC-Cinquecento	-	AHM -- Additional Heater Module	ECU Information	-	
2007	CC	CC-Cinquecento	-	AHM -- Additional Heater Module	Read Codes	-	
2007	CC	CC-Cinquecento	-	AHM -- Additional Heater Module	Erase codes	-	
2007	CC	CC-Cinquecento	-	AHM -- Additional Heater Module	Live Data	-	
2007	CC	CC-Cinquecento	-	AHM -- Additional Heater Module	Actuators	-	
2007	CC	CC-Cinquecento	-	AHM -- Additional Heater Module	Special Functions	Self-Learning Working Mode	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	ECU Information	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Read Codes	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Erase codes	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Live Data	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Actuators	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	ECU Information	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Read Codes	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Erase codes	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Live Data	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Actuators	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	ECU Information	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Read Codes	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Erase codes	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Live Data	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Actuators	-	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2007	CC	CC-Cinquecento	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	











## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail overpressure waste gate valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Megaknock counter reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Over boost counter reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2008	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Instrument Panel Cluster Replacement	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Live Data	-	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Actuators	-	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	ECU SERIAL NUMBER Management	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Rolls Test	
2008	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Write Front and Rear axle nominal tire pressure	
2008	DB	DB-Doblo	-	BCM -- Body Controller	ECU Information	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Read Codes	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Erase codes	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Live Data	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Actuators	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	ECU Configure Information	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	DB	DB-Doblo	-	BCM -- Body Controller	ECU Information	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Read Codes	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Erase codes	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Live Data	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Actuators	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	ECU Configure Information	-	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2008	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2008	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2008	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2008	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2008	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Flap actuators learning test	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	ECU Information	-	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Read Codes	-	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Erase codes	-	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Live Data	-	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trail ECU absence	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trail ECU presence	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	ECU Information	-	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Read Codes	-	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Erase codes	-	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Live Data	-	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2008	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2008	DB	DB-Doblo	-	AHM -- Additional Heater Module	ECU Information	-	
2008	DB	DB-Doblo	-	AHM -- Additional Heater Module	Read Codes	-	
2008	DB	DB-Doblo	-	AHM -- Additional Heater Module	Erase codes	-	
2008	DB	DB-Doblo	-	AHM -- Additional Heater Module	Live Data	-	
2008	DB	DB-Doblo	-	AHM -- Additional Heater Module	Actuators	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	DB	DB-Doblo	-	AHM -- Additional Heater Module	Special Functions	Self-Learning Working Mode	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Live Data	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Actuators	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Live Data	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Actuators	-	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2008	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Rail overpressure waste gate valve replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Read / Write reprogramming ECU data	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Adaptive parameters reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Phases front reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Reset Learned Adaptive	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Reset vehicle configuration	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	

















## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	FQ	FQ-Fiorino Qubo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electro valve replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	ECO function switch Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	ECO function switch Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electro valve replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	ECO function switch Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Longitudinal acceleration sensor replacemen	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Accumulator Oil replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Clutch bleed	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Clutch group replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Clutch self-calibration enable	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	ECO function switch Replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic pressure depressurization	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Kit replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Levers at wheel replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Longitudinal acceleration sensor replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	New actuator	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacementnt	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Pump replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Reset statistical data	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Switch AUTO replacement	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacementt	
2008	FQ	FQ-Fiorino Qubo	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor decalibration	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Steering angle sensor calibration	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Steering angle sensor calibration	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor decalibration	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	Steering angle sensor calibration	
2008	FQ	FQ-Fiorino Qubo	-	ABS -- Anti Lock Brakes	Special Functions	TPMS calibration	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Instrument Panel Cluster Replacement	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	FQ	FQ-Fiorino Qubo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Siren check request	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	ECU Configure Information	-	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	FQ	FQ-Fiorino Qubo	-	BCM -- Body Controller	Special Functions	Siren check request	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Special Functions	Trail ECU absence	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Special Functions	Trail ECU presence	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2008	FQ	FQ-Fiorino Qubo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2008	FQ	FQ-Fiorino Qubo	-	AHM -- Additional Heater Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	AHM -- Additional Heater Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	AHM -- Additional Heater Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	AHM -- Additional Heater Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	AHM -- Additional Heater Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	AHM -- Additional Heater Module	Special Functions	Self-Learning Working Mode	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Live Data	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Actuators	-	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2008	FQ	FQ-Fiorino Qubo	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral Signal learning with engine off	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Reset phases front	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learned functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learned functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learned functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Control unit Replacement/Reprogramming	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learned functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Megaknock counter reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Over boost counter reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Control unit Replacement/Reprogramming	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learned functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Adaptative parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Megaknock sensor or spark plugs replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Control unit Replacement/Reprogramming	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Megaknock counter reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Pre - catalyzer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail overpressure waste gate valve replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Read / Write reprogramming ECU data	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Megaknock counter reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Over boost counter reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Control unit Replacement/Reprogramming	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Oil change	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Live Data	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Actuators	-	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Control unit Replacement/Reprogramming	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2008	MT	MT-Mito	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	ECU Information	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Read Codes	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Erase codes	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Live Data	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Actuators	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Hydraulic circuit depressurization	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Gearbox Replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Longitudinal acceleration sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K1) control solenoid valve command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Range selection electro valve command (PPVS)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	ECU Information	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Read Codes	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Erase codes	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Live Data	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Gearbox Replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Longitudinal acceleration sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Reversing lights command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K1) control solenoid valve command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Range selection electro valve command (PPVS)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	ECU Information	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Erase codes	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Live Data	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Actuators	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Hydraulic circuit depressurization	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Gearbox Replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Longitudinal acceleration sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K1) control solenoid valve command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Range selection electro valve command (PPVS)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	ECU Information	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Read Codes	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Erase codes	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Live Data	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Actuators	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Hydraulic circuit depressurization	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Gearbox Replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Longitudinal acceleration sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K1) control solenoid valve command	
2008	MT	MT-Mito	-	TCM -- Transmission Control Module	System Tests	Range selection electro valve command (PPVS)	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	ECU Information	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Read Codes	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Erase codes	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Live Data	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Actuators	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	System Tests	Longitudinal G-Sensor Calibration Test	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	ECU Information	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Read Codes	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Erase codes	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Live Data	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Actuators	-	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2008	MT	MT-Mito	-	ABS -- Anti Lock Brakes	System Tests	Longitudinal G-Sensor Calibration Test	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2008	MT	MT-Mito	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Live Data	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Actuators	-	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2008	MT	MT-Mito	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Live Data	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Actuators	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Write Front and Rear axle nominal tire pressure	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Live Data	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Actuators	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Alarms deletion	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Antenna replacement	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Control unit activation	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Control unit deactivation	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Manual System Configuration	
2008	MT	MT-Mito	-	TPM -- Tire Pressure Monitor	Special Functions	Wheel transmitters learning	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Read Codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Erase codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Live Data	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Actuators	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Configure Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Siren check request	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Read Codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Erase codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Live Data	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Actuators	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Configure Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Siren check request	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	BCM -- Body Controller	Erase codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Live Data	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Actuators	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Configure Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Siren check request	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Read Codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Erase codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Live Data	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Actuators	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Configure Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Siren check request	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Read Codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Erase codes	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Live Data	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Actuators	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	ECU Configure Information	-	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Modify longitudinal anti-tilt sensor	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Program Keys	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2008	MT	MT-Mito	-	BCM -- Body Controller	Special Functions	Siren check request	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	ECU Information	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Read Codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Erase codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Live Data	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	ECU Information	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Read Codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Erase codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Live Data	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	ECU Information	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Read Codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Erase codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Live Data	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	ECU Information	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Read Codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Erase codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Live Data	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	ECU Information	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Read Codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Erase codes	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Live Data	-	
2008	MT	MT-Mito	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2008	MT	MT-Mito	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2008	MT	MT-Mito	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2008	MT	MT-Mito	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2008	MT	MT-Mito	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2008	MT	MT-Mito	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2008	MT	MT-Mito	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2008	MT	MT-Mito	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Flap actuators learning test	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Live Data	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Actuators	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Actuators	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2008	MT	MT-Mito	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2008	MT	MT-Mito	-	PAM -- Park Assist Module	ECU Information	-	
2008	MT	MT-Mito	-	PAM -- Park Assist Module	Read Codes	-	
2008	MT	MT-Mito	-	PAM -- Park Assist Module	Erase codes	-	
2008	MT	MT-Mito	-	PAM -- Park Assist Module	Live Data	-	
2008	MT	MT-Mito	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2008	MT	MT-Mito	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2008	MT	MT-Mito	-	ADCM -- Active Damping Control Module	ECU Information	-	
2008	MT	MT-Mito	-	ADCM -- Active Damping Control Module	Read Codes	-	
2008	MT	MT-Mito	-	ADCM -- Active Damping Control Module	Erase codes	-	
2008	MT	MT-Mito	-	ADCM -- Active Damping Control Module	Live Data	-	
2008	MT	MT-Mito	-	ADCM -- Active Damping Control Module	Actuators	-	
2008	MT	MT-Mito	-	ADCM -- Active Damping Control Module	Special Functions	Accelerometers calibration	
2008	MT	MT-Mito	-	AHM -- Additional Heater Module	ECU Information	-	
2008	MT	MT-Mito	-	AHM -- Additional Heater Module	Read Codes	-	
2008	MT	MT-Mito	-	AHM -- Additional Heater Module	Erase codes	-	
2008	MT	MT-Mito	-	AHM -- Additional Heater Module	Live Data	-	
2008	MT	MT-Mito	-	AHM -- Additional Heater Module	Actuators	-	
2008	MT	MT-Mito	-	AHM -- Additional Heater Module	Special Functions	Self-Learning Working Mode	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	ECU Information	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Read Codes	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Erase codes	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Live Data	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Actuators	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	ECU Information	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Read Codes	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Erase codes	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Live Data	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Actuators	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	ECU Information	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Read Codes	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Erase codes	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Live Data	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Actuators	-	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2008	MT	MT-Mito	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	ECU Information	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Read Codes	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Erase codes	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Live Data	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Actuators	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Special Functions	Audiobox activation	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	ECU Information	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Read Codes	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Erase codes	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Live Data	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Actuators	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	ECU Configure Information	-	
2008	MT	MT-Mito	-	RMN -- Steering Column Control Module	Special Functions	Audiobox activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learned functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Pre - catalyzer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Motorized throttle learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Reset phases front	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail overpressure waste gate valve replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Read / Write reprogramming ECU data	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Motorized throttle learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Reset adaptive parameters	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phases front reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail overpressure waste gate valve replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Read / Write reprogramming ECU data	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Phases front reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Adaptive parameters reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Differential pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Accumulator Oil replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Clutch bleed	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Clutch group replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Clutch self-calibration enable	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	ECO function switch Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Hydraulic pressure depressurization	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Kit replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Levers at wheel replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Longitudinal acceleration sensor replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	New actuator	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Pump replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Reset statistical data	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Switch AUTO replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	ECO function switch Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Levers at wheel replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Longitudinal acceleration sensor replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electro valve replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Switch AUTO replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	ECO function switch Replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2009	PE	PE-Punto EVO	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	

















## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2011	GU	GU-Giulietta	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2011	GU	GU-Giulietta	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2011	GU	GU-Giulietta	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2011	GU	GU-Giulietta	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2011	GU	GU-Giulietta	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2011	GU	GU-Giulietta	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	ECU Configure Information	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	Actuators	-	
2011	GU	GU-Giulietta	-	AFLS -- Adaptive Front Lighting System	ECU Configure Information	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	ECU Information	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Read Codes	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Erase codes	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Live Data	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	ECU Information	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Read Codes	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Erase codes	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Live Data	-	
2011	GU	GU-Giulietta	-	PAM -- Park Assist Module	Actuators	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	ECU Information	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Read Codes	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Erase codes	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Live Data	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Actuators	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	ECU Information	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Read Codes	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Erase codes	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Live Data	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Actuators	-	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2011	GU	GU-Giulietta	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2011	GU	GU-Giulietta	-	DSTM -- On Board Charging Module	ECU Information	-	
2011	GU	GU-Giulietta	-	DSTM -- On Board Charging Module	Read Codes	-	
2011	GU	GU-Giulietta	-	DSTM -- On Board Charging Module	Erase codes	-	
2011	GU	GU-Giulietta	-	DSTM -- On Board Charging Module	Live Data	-	
2011	GU	GU-Giulietta	-	DSTM -- On Board Charging Module	Actuators	-	
2011	GU	GU-Giulietta	-	PSTM -- Radio Frequency Hub	ECU Information	-	
2011	GU	GU-Giulietta	-	PSTM -- Radio Frequency Hub	Read Codes	-	
2011	GU	GU-Giulietta	-	PSTM -- Radio Frequency Hub	Erase codes	-	
2011	GU	GU-Giulietta	-	PSTM -- Radio Frequency Hub	Live Data	-	
2011	GU	GU-Giulietta	-	PSTM -- Radio Frequency Hub	Actuators	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	ECU Information	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Read Codes	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Erase codes	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Live Data	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Actuators	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	ECU Configure Information	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Special Functions	Audiobox activation	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	ECU Information	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Read Codes	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Erase codes	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Live Data	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Actuators	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	ECU Configure Information	-	
2011	GU	GU-Giulietta	-	RMN -- Steering Column Control Module	Special Functions	Audiobox activation	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Option	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cooled EGR H-Bridge Valve System Test	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test(Non-RFE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test(Non-RFE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2011	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2011	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Information	-	
2011	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Read Codes	-	
2011	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Erase codes	-	
2011	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Live Data	-	
2011	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Actuators	-	
2011	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Configure Information	-	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Information	-	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Read Codes	-	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Erase codes	-	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Live Data	-	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Actuators	-	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2011	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2011	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2011	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2011	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2011	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2011	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2011	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2011	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Rollover Detection	
2011	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2011	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2011	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2011	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2011	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Live Data	-	
2011	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Actuators	-	
2011	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Live Data	-	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Activate TPM High Gain Mode	
2011	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2011	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2011	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Change country code	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size	
2011	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2011	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2011	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2011	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2011	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2011	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2011	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2011	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Information	-	
2011	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Read Codes	-	
2011	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Erase codes	-	
2011	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Live Data	-	
2011	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Configure Information	-	
2011	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	Enable/Disable Front Seat Video	
2011	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	TGW Tone Test	
2011	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	System Tests	Anti-theft Override Test	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2011	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	











## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	CL	CL-500L	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	CL	CL-500L	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	CL	CL-500L	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Live Data	-	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Actuators	-	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Special Functions	TPM FGA PROXI Configuration	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	Special Functions	Update Front and Rear Axle Nominal Tire Pressure Values	
2012	CL	CL-500L	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2012	CL	CL-500L	-	BCM -- Body Controller	ECU Information	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Read Codes	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Erase codes	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Live Data	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Actuators	-	
2012	CL	CL-500L	-	BCM -- Body Controller	ECU Configure Information	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Rain and Automatic Lights Sensors check	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Enable Front Fog Lamp Dropout	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Configure Door Locks	
2012	CL	CL-500L	-	BCM -- Body Controller	ECU Information	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Read Codes	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Erase codes	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Live Data	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Actuators	-	
2012	CL	CL-500L	-	BCM -- Body Controller	ECU Configure Information	-	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Rain and Automatic Lights Sensors check	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Enable Front Fog Lamp Dropout	
2012	CL	CL-500L	-	BCM -- Body Controller	Special Functions	Configure Door Locks	
2012	CL	CL-500L	-	EPS -- Electric Power Steering	ECU Information	-	
2012	CL	CL-500L	-	EPS -- Electric Power Steering	Read Codes	-	
2012	CL	CL-500L	-	EPS -- Electric Power Steering	Erase codes	-	
2012	CL	CL-500L	-	EPS -- Electric Power Steering	Live Data	-	
2012	CL	CL-500L	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	CL	CL-500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Live Data	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Actuators	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Live Data	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Actuators	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Audio Test	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Live Data	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Actuators	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Live Data	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Actuators	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Audio Test	
2012	CL	CL-500L	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2012	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2012	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2012	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2012	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	ECU Information	-	
2012	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Read Codes	-	
2012	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Erase codes	-	
2012	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Live Data	-	
2012	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Actuators	-	
2012	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2012	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2012	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2012	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	ECU Information	-	
2012	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Read Codes	-	
2012	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Erase codes	-	
2012	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Live Data	-	
2012	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Actuators	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2012	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2012	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	ECU Information	-	
2012	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Read Codes	-	
2012	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Erase codes	-	
2012	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Live Data	-	
2012	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Actuators	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2012	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2012	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2012	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	ECU Information	-	
2012	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Read Codes	-	
2012	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Erase codes	-	
2012	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Live Data	-	
2012	CM	CM-Viaggio	-	PAM -- Park Assist Module	ECU Information	-	
2012	CM	CM-Viaggio	-	PAM -- Park Assist Module	Read Codes	-	
2012	CM	CM-Viaggio	-	PAM -- Park Assist Module	Erase codes	-	
2012	CM	CM-Viaggio	-	PAM -- Park Assist Module	Live Data	-	
2012	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2012	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2012	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Information	-	
2012	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Read Codes	-	
2012	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Erase codes	-	
2012	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Live Data	-	
2012	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2012	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	ECU Information	-	
2012	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2012	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2012	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Live Data	-	
2012	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2012	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2012	CM	CM-Viaggio	-	EDM -- External Disc Module	ECU Information	-	
2012	CM	CM-Viaggio	-	EDM -- External Disc Module	Read Codes	-	
2012	CM	CM-Viaggio	-	EDM -- External Disc Module	Erase codes	-	
2012	CM	CM-Viaggio	-	EDM -- External Disc Module	Actuators	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Actuators	-	
2012	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2012	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	FF	FF-500	-	TCM -- Transmission Control Module	Live Data	-	
2012	FF	FF-500	-	TCM -- Transmission Control Module	Actuators	-	
2012	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2012	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2012	FF	FF-500	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	FF	FF-500	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	FF	FF-500	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	FF	FF-500	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	FF	FF-500	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	FF	FF-500	-	ABS -- Anti Lock Brakes	Special Functions	ABS Static Test	
2012	FF	FF-500	-	ABS -- Anti Lock Brakes	System Tests	Longitudinal G-Sensor Calibration Test	
2012	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2012	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Enable Seatbelt Minder Chime	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	Proxi Configuration	
2012	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Live Data	-	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Actuators	-	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	TPM FGA PROXI Configuration	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Update Front and Rear Axle Nominal Tire Pressure Values	
2012	FF	FF-500	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2012	FF	FF-500	-	BCM -- Body Controller	ECU Information	-	
2012	FF	FF-500	-	BCM -- Body Controller	Read Codes	-	
2012	FF	FF-500	-	BCM -- Body Controller	Erase codes	-	
2012	FF	FF-500	-	BCM -- Body Controller	Live Data	-	
2012	FF	FF-500	-	BCM -- Body Controller	Actuators	-	
2012	FF	FF-500	-	BCM -- Body Controller	ECU Configure Information	-	
2012	FF	FF-500	-	BCM -- Body Controller	Special Functions	Erase and Program Keys	
2012	FF	FF-500	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2012	FF	FF-500	-	BCM -- Body Controller	Special Functions	Initialize Power Top	
2012	FF	FF-500	-	EPS -- Electric Power Steering	ECU Information	-	
2012	FF	FF-500	-	EPS -- Electric Power Steering	Read Codes	-	
2012	FF	FF-500	-	EPS -- Electric Power Steering	Erase codes	-	
2012	FF	FF-500	-	EPS -- Electric Power Steering	Live Data	-	
2012	FF	FF-500	-	EPS -- Electric Power Steering	Special Functions	Clear Steering Pull Compensation	
2012	FF	FF-500	-	EPS -- Electric Power Steering	Special Functions	Initialize EPS	
2012	FF	FF-500	-	PTS -- Parktronics	ECU Information	-	
2012	FF	FF-500	-	PTS -- Parktronics	Read Codes	-	
2012	FF	FF-500	-	PTS -- Parktronics	Erase codes	-	
2012	FF	FF-500	-	PTS -- Parktronics	Live Data	-	
2012	FF	FF-500	-	RADIO -- Radio	ECU Information	-	
2012	FF	FF-500	-	RADIO -- Radio	Read Codes	-	
2012	FF	FF-500	-	RADIO -- Radio	Erase codes	-	
2012	FF	FF-500	-	RADIO -- Radio	Live Data	-	
2012	FF	FF-500	-	RADIO -- Radio	Special Functions	RADIO PROXI Configuration	
2012	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2012	FF	FF-500	-	CTM -- Convergence Telematic Module	ECU Information	-	
2012	FF	FF-500	-	CTM -- Convergence Telematic Module	Read Codes	-	
2012	FF	FF-500	-	CTM -- Convergence Telematic Module	Erase codes	-	
2012	FF	FF-500	-	CTM -- Convergence Telematic Module	Live Data	-	
2012	FF	FF-500	-	CTM -- Convergence Telematic Module	Actuators	-	
2012	FF	FF-500	-	CTM -- Convergence Telematic Module	Special Functions	CTM Proxi Configuration	
2012	FF	FF-500	-	CTM -- Convergence Telematic Module	System Tests	Audio System Test	
2012	FF	FF-500	-	VTM -- Vehicle Tracking Module	ECU Information	-	
2012	FF	FF-500	-	VTM -- Vehicle Tracking Module	Read Codes	-	
2012	FF	FF-500	-	VTM -- Vehicle Tracking Module	Erase codes	-	
2012	FF	FF-500	-	VTM -- Vehicle Tracking Module	Live Data	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cooled EGR H-Bridge Valve System Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test(Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test(Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test(Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test(Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Option	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2012	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Information	-	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Read Codes	-	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Erase codes	-	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Live Data	-	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Actuators	-	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Event Data	-	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2012	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Information	-	
2012	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Read Codes	-	
2012	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Erase codes	-	
2012	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Live Data	-	
2012	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Actuators	-	
2012	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2012	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2012	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2012	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2012	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Rollover Detection	
2012	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2012	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2012	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2012	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Live Data	-	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Activate TPM High Gain Mode	
2012	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2012	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Change country code	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size (JF)	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size (LX)	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2012	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Change country code	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size	
2012	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2012	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2012	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Information	-	
2012	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Read Codes	-	
2012	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Erase codes	-	
2012	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Live Data	-	
2012	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Configure Information	-	
2012	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	Enable/Disable Front Seat Video	
2012	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	TGW Tone Test	
2012	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	System Tests	Anti-theft Override Test	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	View Recent Multi-Module VIN handshake Immobilizer Failures	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2012	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2012	JF	JF-Freemont	-	PTS -- Parktronics	ECU Information	-	
2012	JF	JF-Freemont	-	PTS -- Parktronics	Read Codes	-	
2012	JF	JF-Freemont	-	PTS -- Parktronics	Erase codes	-	
2012	JF	JF-Freemont	-	PTS -- Parktronics	Live Data	-	
2012	JF	JF-Freemont	-	PTS -- Parktronics	Actuators	-	
2012	JF	JF-Freemont	-	PTS -- Parktronics	ECU Configure Information	-	
2012	JF	JF-Freemont	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2012	JF	JF-Freemont	-	PTS -- Parktronics	System Tests	System Wiring Test	
2012	JF	JF-Freemont	-	ICS -- Integrated Center Stack	ECU Information	-	
2012	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Read Codes	-	
2012	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Erase codes	-	
2012	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Live Data	-	
2012	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Actuators	-	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2012	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2012	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	ECU Information	-	
2012	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Read Codes	-	
2012	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Erase codes	-	
2012	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Live Data	-	
2012	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Information	-	
2012	JF	JF-Freemont	-	DDM -- Driver Door Module	Read Codes	-	
2012	JF	JF-Freemont	-	DDM -- Driver Door Module	Erase codes	-	
2012	JF	JF-Freemont	-	DDM -- Driver Door Module	Live Data	-	
2012	JF	JF-Freemont	-	DDM -- Driver Door Module	Actuators	-	
2012	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Information	-	
2012	JF	JF-Freemont	-	PDM -- Passenger Door Module	Read Codes	-	
2012	JF	JF-Freemont	-	PDM -- Passenger Door Module	Erase codes	-	
2012	JF	JF-Freemont	-	PDM -- Passenger Door Module	Live Data	-	
2012	JF	JF-Freemont	-	PDM -- Passenger Door Module	Actuators	-	
2012	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize Siren	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Self Test	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM and Siren Communication Test	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Siren Test	
2012	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	Ultrasonic Motion Detection Test	
2012	JF	JF-Freemont	-	AMP -- Amplifier	ECU Information	-	
2012	JF	JF-Freemont	-	AMP -- Amplifier	Read Codes	-	
2012	JF	JF-Freemont	-	AMP -- Amplifier	Erase codes	-	
2012	JF	JF-Freemont	-	AMP -- Amplifier	Live Data	-	
2012	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Input Test	
2012	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Microphone Tone Test	
2012	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Microphone Output Short Test	
2012	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Output Short Test	
2012	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Software Test	
2012	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Tone Test	
2012	JF	JF-Freemont	-	HFM -- Hands Free Module	ECU Information	-	
2012	JF	JF-Freemont	-	HFM -- Hands Free Module	Read Codes	-	
2012	JF	JF-Freemont	-	HFM -- Hands Free Module	Erase codes	-	
2012	JF	JF-Freemont	-	HFM -- Hands Free Module	Live Data	-	
2012	JF	JF-Freemont	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2012	JF	JF-Freemont	-	VES3 -- Last Row Screen	ECU Information	-	
2012	JF	JF-Freemont	-	VES3 -- Last Row Screen	Read Codes	-	
2012	JF	JF-Freemont	-	VES3 -- Last Row Screen	Erase codes	-	
2012	JF	JF-Freemont	-	VES3 -- Last Row Screen	Live Data	-	
2012	JF	JF-Freemont	-	VES3 -- Last Row Screen	Actuators	-	
2012	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Information	-	
2012	JF	JF-Freemont	-	HSM -- Heated Seat Module	Read Codes	-	
2012	JF	JF-Freemont	-	HSM -- Heated Seat Module	Erase codes	-	
2012	JF	JF-Freemont	-	HSM -- Heated Seat Module	Live Data	-	
2012	JF	JF-Freemont	-	HSM -- Heated Seat Module	Actuators	-	
2012	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2012	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2012	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2012	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2012	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2012	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Live Data	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Actuators	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Event Data	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Cooled EGR H-Bridge Valve System Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Live Data	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Actuators	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Event Data	-	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2012	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2012	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Information	-	
2012	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	Read Codes	-	
2012	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	Erase codes	-	
2012	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	Live Data	-	
2012	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	Actuators	-	
2012	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Configure Information	-	
2012	JS	JS-Flavia	-	CGW -- Central Gateway	ECU Information	-	
2012	JS	JS-Flavia	-	CGW -- Central Gateway	Read Codes	-	
2012	JS	JS-Flavia	-	CGW -- Central Gateway	Erase codes	-	
2012	JS	JS-Flavia	-	CGW -- Central Gateway	Live Data	-	
2012	JS	JS-Flavia	-	CGW -- Central Gateway	Actuators	-	
2012	JS	JS-Flavia	-	CGW -- Central Gateway	ECU Configure Information	-	
2012	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2012	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2012	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2012	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	Live Data	-	
2012	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2012	JS	JS-Flavia	-	SAS -- Steering Angle Sensor	ECU Information	-	
2012	JS	JS-Flavia	-	SAS -- Steering Angle Sensor	Read Codes	-	
2012	JS	JS-Flavia	-	SAS -- Steering Angle Sensor	Erase codes	-	
2012	JS	JS-Flavia	-	SAS -- Steering Angle Sensor	Live Data	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	ECU Information	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	Read Codes	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	Erase codes	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	Live Data	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	Actuators	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	ECU Information	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	Read Codes	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	Erase codes	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	Live Data	-	
2012	JS	JS-Flavia	-	RADIO -- Radio	ECU Configure Information	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	ECU Information	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	Read Codes	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	Erase codes	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	Live Data	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	Actuators	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	ECU Information	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	Read Codes	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	Erase codes	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	Live Data	-	
2012	JS	JS-Flavia	-	DDM -- Driver Door Module	Actuators	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	ECU Information	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	Read Codes	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	Erase codes	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	Live Data	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	Actuators	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	ECU Information	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	Read Codes	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	Erase codes	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	Live Data	-	
2012	JS	JS-Flavia	-	PDM -- Passenger Door Module	Actuators	-	
2012	JS	JS-Flavia	-	PTCM -- Power Top Control Module	ECU Information	-	
2012	JS	JS-Flavia	-	PTCM -- Power Top Control Module	Read Codes	-	
2012	JS	JS-Flavia	-	PTCM -- Power Top Control Module	Erase codes	-	
2012	JS	JS-Flavia	-	PTCM -- Power Top Control Module	Live Data	-	
2012	JS	JS-Flavia	-	PTCM -- Power Top Control Module	ECU Configure Information	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	ECU Information	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	Read Codes	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	Erase codes	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	Live Data	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	ECU Configure Information	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	System Tests	AMP Input Test	
2012	JS	JS-Flavia	-	AMP -- Amplifier	System Tests	AMP Software Test	
2012	JS	JS-Flavia	-	AMP -- Amplifier	ECU Information	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	Read Codes	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	Erase codes	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	Live Data	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	ECU Configure Information	-	
2012	JS	JS-Flavia	-	AMP -- Amplifier	System Tests	AMP Input Test	
2012	JS	JS-Flavia	-	AMP -- Amplifier	System Tests	AMP Software Test	
2012	JS	JS-Flavia	-	HFM -- Hands Free Module	ECU Information	-	
2012	JS	JS-Flavia	-	HFM -- Hands Free Module	Read Codes	-	
2012	JS	JS-Flavia	-	HFM -- Hands Free Module	Erase codes	-	
2012	JS	JS-Flavia	-	HFM -- Hands Free Module	Live Data	-	
2012	JS	JS-Flavia	-	HFM -- Hands Free Module	Actuators	-	
2012	JS	JS-Flavia	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2012	LX	LX-Thema	-	EPS -- Electric Power Steering	ECU Information	-	
2012	LX	LX-Thema	-	EPS -- Electric Power Steering	Read Codes	-	
2012	LX	LX-Thema	-	EPS -- Electric Power Steering	Erase codes	-	
2012	LX	LX-Thema	-	EPS -- Electric Power Steering	Live Data	-	
2012	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2012	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2012	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2012	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2012	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Actuators	-	
2012	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Special Functions	AFLS Calibration	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Information	-	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Read Codes	-	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Erase codes	-	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Live Data	-	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Actuators	-	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	View Recent Multi-Module VIN handshake Immobilizer Failures	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2012	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2012	LX	LX-Thema	-	BCM -- Body Controller	ECU Information	-	
2012	LX	LX-Thema	-	BCM -- Body Controller	Read Codes	-	
2012	LX	LX-Thema	-	BCM -- Body Controller	Erase codes	-	
2012	LX	LX-Thema	-	BCM -- Body Controller	Live Data	-	
2012	LX	LX-Thema	-	BCM -- Body Controller	Actuators	-	
2012	LX	LX-Thema	-	BCM -- Body Controller	ECU Configure Information	-	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Change country code	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size (JF)	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size (LX)	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2012	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2012	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2012	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2012	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2012	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2012	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2012	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2012	LX	LX-Thema	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2012	LX	LX-Thema	-	AMP -- Amplifier	ECU Information	-	
2012	LX	LX-Thema	-	AMP -- Amplifier	Read Codes	-	
2012	LX	LX-Thema	-	AMP -- Amplifier	Erase codes	-	
2012	LX	LX-Thema	-	AMP -- Amplifier	Live Data	-	
2012	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Input Test	
2012	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Microphone Tone Test	
2012	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Microphone Output Short Test	
2012	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Output Short Test	
2012	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Software Test	
2012	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Tone Test	
2012	LX	LX-Thema	-	DDM -- Driver Door Module	ECU Information	-	
2012	LX	LX-Thema	-	DDM -- Driver Door Module	Read Codes	-	
2012	LX	LX-Thema	-	DDM -- Driver Door Module	Erase codes	-	
2012	LX	LX-Thema	-	DDM -- Driver Door Module	Live Data	-	
2012	LX	LX-Thema	-	DDM -- Driver Door Module	Actuators	-	
2012	LX	LX-Thema	-	DDM -- Driver Door Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	PTS -- Parktronics	ECU Information	-	
2012	LX	LX-Thema	-	PTS -- Parktronics	Read Codes	-	
2012	LX	LX-Thema	-	PTS -- Parktronics	Erase codes	-	
2012	LX	LX-Thema	-	PTS -- Parktronics	Live Data	-	
2012	LX	LX-Thema	-	PTS -- Parktronics	Actuators	-	
2012	LX	LX-Thema	-	PTS -- Parktronics	ECU Configure Information	-	
2012	LX	LX-Thema	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2012	LX	LX-Thema	-	PTS -- Parktronics	System Tests	System Wiring Test	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2012	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2012	LX	LX-Thema	-	DTCM -- Drive Train Control Module	ECU Information	-	
2012	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Read Codes	-	
2012	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Erase codes	-	
2012	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Live Data	-	
2012	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Actuators	-	
2012	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Special Functions	Read Digital Encoder Channels	
2012	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	ECU Information	-	
2012	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Read Codes	-	
2012	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Erase codes	-	
2012	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Live Data	-	
2012	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	ECU Configure Information	-	
2012	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Special Functions	Enable/Disable Front Seat Video	
2012	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Special Functions	TGW Tone Test	
2012	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	System Tests	Anti-theft Override Test	
2012	LX	LX-Thema	-	BSM -- Blind Spot Module	ECU Information	-	
2012	LX	LX-Thema	-	BSM -- Blind Spot Module	Read Codes	-	
2012	LX	LX-Thema	-	BSM -- Blind Spot Module	Erase codes	-	
2012	LX	LX-Thema	-	BSM -- Blind Spot Module	Live Data	-	
2012	LX	LX-Thema	-	BSM -- Blind Spot Module	Special Functions	Sensor Connectivity and HMI Test	
2012	LX	LX-Thema	-	PDM -- Passenger Door Module	ECU Information	-	
2012	LX	LX-Thema	-	PDM -- Passenger Door Module	Read Codes	-	
2012	LX	LX-Thema	-	PDM -- Passenger Door Module	Erase codes	-	
2012	LX	LX-Thema	-	PDM -- Passenger Door Module	Live Data	-	
2012	LX	LX-Thema	-	PDM -- Passenger Door Module	Actuators	-	
2012	LX	LX-Thema	-	PDM -- Passenger Door Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	ICS -- Integrated Center Stack	ECU Information	-	
2012	LX	LX-Thema	-	ICS -- Integrated Center Stack	Read Codes	-	
2012	LX	LX-Thema	-	ICS -- Integrated Center Stack	Erase codes	-	
2012	LX	LX-Thema	-	ICS -- Integrated Center Stack	Live Data	-	
2012	LX	LX-Thema	-	ICS -- Integrated Center Stack	Actuators	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2012	LX	LX-Thema	-	ESM -- Electronic Shifter	Actuators	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Event Data	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Cooled EGR H-Bridge Valve System Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Event Data	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Option	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2012	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2012	LX	LX-Thema	-	SCCM -- Steering Column Control Module	ECU Information	-	
2012	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Read Codes	-	
2012	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Erase codes	-	
2012	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Live Data	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Initialize EGS-52	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Store Learned Adaptives	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Learned Adaptives	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Event Data	-	
2012	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2012	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2012	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2012	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2012	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Live Data	-	
2012	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Special Functions	ACC Aim Mode - Auto Alignment	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	MSMD Self Test	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Standardization	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	
2012	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2012	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Live Data	-	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Activate TPM High Gain Mode	
2012	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2012	LX	LX-Thema	-	ADCM -- Active Damping Control Module	ECU Information	-	
2012	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Read Codes	-	
2012	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Erase codes	-	
2012	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Live Data	-	
2012	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2012	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2012	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2012	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2012	LX	LX-Thema	-	HSM -- Heated Seat Module	ECU Information	-	
2012	LX	LX-Thema	-	HSM -- Heated Seat Module	Read Codes	-	
2012	LX	LX-Thema	-	HSM -- Heated Seat Module	Erase codes	-	
2012	LX	LX-Thema	-	HSM -- Heated Seat Module	Live Data	-	
2012	LX	LX-Thema	-	HSM -- Heated Seat Module	Actuators	-	
2012	LX	LX-Thema	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	HFM -- Hands Free Module	ECU Information	-	
2012	LX	LX-Thema	-	HFM -- Hands Free Module	Read Codes	-	
2012	LX	LX-Thema	-	HFM -- Hands Free Module	Erase codes	-	
2012	LX	LX-Thema	-	HFM -- Hands Free Module	Live Data	-	
2012	LX	LX-Thema	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize Siren	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Self Test	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM and Siren Communication Test	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Siren Test	
2012	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	Ultrasonic Motion Detection Test	
2012	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2012	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Control unit Replacement/Reprogramming	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neutral signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Supercharging system components replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Control unit Replacement/Reprogramming	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neutral signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Downstream lambda probe replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	EGR low pressure valve replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	NOx replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	EGR low pressure valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Read second level micro safety reset event	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neutral signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Supercharging system components replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Read second level micro safety reset event	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neutral signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Self-adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel Reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	ECU Information	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Read Codes	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Erase codes	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Live Data	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Actuators	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electro valve replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	ECU Information	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Read Codes	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Erase codes	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Live Data	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Actuators	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electro valve replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2012	NP	NP-Panda	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor decalibration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Reset gear configuration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor decalibration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Reset gear configuration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	TPMS calibration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor decalibration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	Reset gear configuration	
2012	NP	NP-Panda	-	ABS -- Anti Lock Brakes	Special Functions	TPMS calibration	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	NP	NP-Panda	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	ECU replacement	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2012	NP	NP-Panda	-	BCM -- Body Controller	ECU Information	-	
2012	NP	NP-Panda	-	BCM -- Body Controller	Read Codes	-	
2012	NP	NP-Panda	-	BCM -- Body Controller	Erase codes	-	
2012	NP	NP-Panda	-	BCM -- Body Controller	Live Data	-	
2012	NP	NP-Panda	-	BCM -- Body Controller	Actuators	-	
2012	NP	NP-Panda	-	BCM -- Body Controller	Special Functions	Blinking Lights Configuration	
2012	NP	NP-Panda	-	BCM -- Body Controller	Special Functions	Column switch module substitution	
2012	NP	NP-Panda	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2012	NP	NP-Panda	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2012	NP	NP-Panda	-	BCM -- Body Controller	Special Functions	Program Keys	
2012	NP	NP-Panda	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	ECU Information	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	Read Codes	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	Erase codes	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	Live Data	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	ECU Information	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	Read Codes	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	Erase codes	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	Live Data	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2012	NP	NP-Panda	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2012	NP	NP-Panda	-	PTS -- Parktronics	ECU Information	-	
2012	NP	NP-Panda	-	PTS -- Parktronics	Read Codes	-	
2012	NP	NP-Panda	-	PTS -- Parktronics	Erase codes	-	
2012	NP	NP-Panda	-	PTS -- Parktronics	Live Data	-	
2012	NP	NP-Panda	-	PTS -- Parktronics	Special Functions	Disable tow hook presence	
2012	NP	NP-Panda	-	PTS -- Parktronics	Special Functions	Enable tow hook presence	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Flap actuators learning test	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	NP	NP-Panda	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Flap actuators learning test	
2012	NP	NP-Panda	-	AHM -- Additional Heater Module	ECU Information	-	
2012	NP	NP-Panda	-	AHM -- Additional Heater Module	Read Codes	-	
2012	NP	NP-Panda	-	AHM -- Additional Heater Module	Erase codes	-	
2012	NP	NP-Panda	-	AHM -- Additional Heater Module	Live Data	-	
2012	NP	NP-Panda	-	AHM -- Additional Heater Module	Actuators	-	
2012	NP	NP-Panda	-	AHM -- Additional Heater Module	Special Functions	Self-Learning Working Mode	
2012	NP	NP-Panda	-	CTM -- Convergence Telematic Module	ECU Information	-	
2012	NP	NP-Panda	-	CTM -- Convergence Telematic Module	Read Codes	-	
2012	NP	NP-Panda	-	CTM -- Convergence Telematic Module	Erase codes	-	
2012	NP	NP-Panda	-	CTM -- Convergence Telematic Module	Live Data	-	
2012	NP	NP-Panda	-	CTM -- Convergence Telematic Module	Actuators	-	
2012	NP	NP-Panda	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2012	NP	NP-Panda	-	CCM -- Controlled Coupling Module	ECU Information	-	
2012	NP	NP-Panda	-	CCM -- Controlled Coupling Module	Read Codes	-	
2012	NP	NP-Panda	-	CCM -- Controlled Coupling Module	Erase codes	-	
2012	NP	NP-Panda	-	CCM -- Controlled Coupling Module	Live Data	-	
2012	NP	NP-Panda	-	CCM -- Controlled Coupling Module	Actuators	-	
2012	NP	NP-Panda	-	CCM -- Controlled Coupling Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	CMM -- Instrument Panel Cluster	ECU Information	-	
2012	NP	NP-Panda	-	CMM -- Instrument Panel Cluster	Read Codes	-	
2012	NP	NP-Panda	-	CMM -- Instrument Panel Cluster	Erase codes	-	
2012	NP	NP-Panda	-	CMM -- Instrument Panel Cluster	Live Data	-	
2012	NP	NP-Panda	-	CMM -- Instrument Panel Cluster	ECU Configure Information	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Event Data	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Cooled EGR H-Bridge Valve System Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Event Data	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Diesel Particulate Filter replacement	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Fuel mean value adaption initialization	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	IMA quick calibration	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor 1 initialization	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Oxidation catalyst initialization	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Request anti-slugging for Air Condition Compressor	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	program variant coding	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure control switchover	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TIPM Enable Emissions Rolls Test mode	
2012	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Compression Test	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Information	-	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Read Codes	-	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Erase codes	-	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Live Data	-	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Actuators	-	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Event Data	-	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2012	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2012	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Special Functions	Rollover Detection	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Special Functions	Reset ECU	
2012	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2012	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Information	-	
2012	RT	RT-Voyager	-	CGW -- Central Gateway	Read Codes	-	
2012	RT	RT-Voyager	-	CGW -- Central Gateway	Erase codes	-	
2012	RT	RT-Voyager	-	CGW -- Central Gateway	Live Data	-	
2012	RT	RT-Voyager	-	CGW -- Central Gateway	Actuators	-	
2012	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Configure Information	-	
2012	RT	RT-Voyager	-	DMFR -- Door Module Front Right	ECU Information	-	
2012	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Read Codes	-	
2012	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Erase codes	-	
2012	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Live Data	-	
2012	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Actuators	-	
2012	RT	RT-Voyager	-	VES3 -- Last Row Screen	ECU Information	-	
2012	RT	RT-Voyager	-	VES3 -- Last Row Screen	Read Codes	-	
2012	RT	RT-Voyager	-	VES3 -- Last Row Screen	Erase codes	-	
2012	RT	RT-Voyager	-	VES3 -- Last Row Screen	Live Data	-	
2012	RT	RT-Voyager	-	VES3 -- Last Row Screen	Actuators	-	
2012	RT	RT-Voyager	-	VES3 -- Last Row Screen	ECU Configure Information	-	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Information	-	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Read Codes	-	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Erase codes	-	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Live Data	-	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Actuators	-	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Configure Information	-	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Special Functions	Learn Latch Sector Home	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Cinch Test	
2012	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Release Test	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Cool Down Test	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Front Blower State	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Rear Blower State	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Cool Down Test	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Front Blower State	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Rear Blower State	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2012	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2012	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Information	-	
2012	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Read Codes	-	
2012	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Erase codes	-	
2012	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Live Data	-	
2012	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Actuators	-	
2012	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Configure Information	-	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	ECU Information	-	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Read Codes	-	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Erase codes	-	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Live Data	-	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Learn Side Test	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Ramp Van Configuration	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Close Test	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Open Test	
2012	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Actuate Drive Clutch Engage	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	ECU Information	-	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Read Codes	-	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Erase codes	-	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Live Data	-	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Learn Side Test	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Ramp Van Configuration	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Close Test	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Open Test	
2012	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Actuate Drive Clutch Engage	
2012	RT	RT-Voyager	-	SUNR -- Sunroof	ECU Information	-	
2012	RT	RT-Voyager	-	SUNR -- Sunroof	Read Codes	-	
2012	RT	RT-Voyager	-	SUNR -- Sunroof	Erase codes	-	
2012	RT	RT-Voyager	-	SUNR -- Sunroof	Live Data	-	
2012	RT	RT-Voyager	-	SUNR -- Sunroof	Actuators	-	
2012	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Information	-	
2012	RT	RT-Voyager	-	HSM -- Heated Seat Module	Read Codes	-	
2012	RT	RT-Voyager	-	HSM -- Heated Seat Module	Erase codes	-	
2012	RT	RT-Voyager	-	HSM -- Heated Seat Module	Live Data	-	
2012	RT	RT-Voyager	-	HSM -- Heated Seat Module	Actuators	-	
2012	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	HSM -- Heated Seat Module	Special Functions	Heated Steering Wheel Configuration	
2012	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	ECU Information	-	
2012	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Read Codes	-	
2012	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Erase codes	-	
2012	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Live Data	-	
2012	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Actuators	-	
2012	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Special Functions	HIDT Calibration	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2012	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM and Siren Communication Test	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Ultrasonic Motion Detection Test	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize ITM	
2012	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	System Tests	Siren Test	
2012	RT	RT-Voyager	-	PTS -- Parktronics	ECU Information	-	
2012	RT	RT-Voyager	-	PTS -- Parktronics	Read Codes	-	
2012	RT	RT-Voyager	-	PTS -- Parktronics	Erase codes	-	
2012	RT	RT-Voyager	-	PTS -- Parktronics	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	RT	RT-Voyager	-	PTS -- Parktronics	Actuators	-	
2012	RT	RT-Voyager	-	PTS -- Parktronics	ECU Configure Information	-	
2012	RT	RT-Voyager	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2012	RT	RT-Voyager	-	PTS -- Parktronics	System Tests	System Wiring Test	
2012	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2012	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2012	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2012	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2012	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2012	RT	RT-Voyager	-	DVD -- DVD Changer	ECU Information	-	
2012	RT	RT-Voyager	-	DVD -- DVD Changer	Read Codes	-	
2012	RT	RT-Voyager	-	DVD -- DVD Changer	Erase codes	-	
2012	RT	RT-Voyager	-	DVD -- DVD Changer	Live Data	-	
2012	RT	RT-Voyager	-	AHBM -- Automatic High Beam	ECU Information	-	
2012	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Read Codes	-	
2012	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Erase codes	-	
2012	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Live Data	-	
2012	RT	RT-Voyager	-	AHBM -- Automatic High Beam	System Tests	AHBM Self Test	
2012	RT	RT-Voyager	-	AHBM -- Automatic High Beam	System Tests	Aim Test	
2012	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Information	-	
2012	RT	RT-Voyager	-	VES2 -- Second Row Screen	Read Codes	-	
2012	RT	RT-Voyager	-	VES2 -- Second Row Screen	Erase codes	-	
2012	RT	RT-Voyager	-	VES2 -- Second Row Screen	Live Data	-	
2012	RT	RT-Voyager	-	VES2 -- Second Row Screen	Actuators	-	
2012	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Configure Information	-	
2012	RT	RT-Voyager	-	VES2 -- Second Row Screen	Special Functions	Headphone Test	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Live Data	-	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Tire Sensor ID with TPM Tool	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2012	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Information	-	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Read Codes	-	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Erase codes	-	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Live Data	-	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Actuators	-	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Configure Information	-	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Special Functions	Learn Latch Sector Home	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Cinch Test	
2012	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Release Test	
2012	RT	RT-Voyager	-	BSM -- Blind Spot Module	ECU Information	-	
2012	RT	RT-Voyager	-	BSM -- Blind Spot Module	Read Codes	-	
2012	RT	RT-Voyager	-	BSM -- Blind Spot Module	Erase codes	-	
2012	RT	RT-Voyager	-	BSM -- Blind Spot Module	Live Data	-	
2012	RT	RT-Voyager	-	BSM -- Blind Spot Module	Special Functions	Sensor Connectivity and HMI Test	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Standardization	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2012	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	
2012	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2012	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2012	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2012	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2012	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Information	-	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	Read Codes	-	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	Erase codes	-	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	Live Data	-	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	Special Functions	PEM Replace	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Locate Learned Keys	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Door Handle Verification Test	
2012	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	LF Antenna Verification Test	
2012	RT	RT-Voyager	-	FSM -- Fold Stow Module	ECU Information	-	
2012	RT	RT-Voyager	-	FSM -- Fold Stow Module	Read Codes	-	
2012	RT	RT-Voyager	-	FSM -- Fold Stow Module	Erase codes	-	
2012	RT	RT-Voyager	-	FSM -- Fold Stow Module	Live Data	-	
2012	RT	RT-Voyager	-	FSM -- Fold Stow Module	Actuators	-	
2012	RT	RT-Voyager	-	HFM -- Hands Free Module	ECU Information	-	
2012	RT	RT-Voyager	-	HFM -- Hands Free Module	Read Codes	-	
2012	RT	RT-Voyager	-	HFM -- Hands Free Module	Erase codes	-	
2012	RT	RT-Voyager	-	HFM -- Hands Free Module	Live Data	-	
2012	RT	RT-Voyager	-	HFM -- Hands Free Module	Actuators	-	
2012	RT	RT-Voyager	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2012	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	Actuators	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2012	RT	RT-Voyager	-	RADIO -- Radio	ECU Configure Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Information	-	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Read Codes	-	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Erase codes	-	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Live Data	-	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Actuators	-	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Configure Information	-	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Language Preference	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Update Measurement Unit	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert Minder	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Program Dealer Contact Information	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Measurement Units	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Language Preference	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert System	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	Self Test	
2012	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	CCN Self Test	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Information	-	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Read Codes	-	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Erase codes	-	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Live Data	-	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Actuators	-	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Configure Information	-	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Close Position	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Open Position	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Ramp Van Configuration	
2012	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	System Tests	Latch Home Sector Test	
2012	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	ECU Information	-	
2012	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Read Codes	-	
2012	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Erase codes	-	
2012	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Live Data	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Information	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Read Codes	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Erase codes	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Live Data	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Actuators	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Information	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Read Codes	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Erase codes	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Live Data	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Actuators	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2013	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2013	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2013	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2013	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2013	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2013	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2013	CM	CM-Viaggio	-	PAM -- Park Assist Module	ECU Information	-	
2013	CM	CM-Viaggio	-	PAM -- Park Assist Module	Read Codes	-	
2013	CM	CM-Viaggio	-	PAM -- Park Assist Module	Erase codes	-	
2013	CM	CM-Viaggio	-	PAM -- Park Assist Module	Live Data	-	
2013	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2013	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2013	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	ECU Information	-	
2013	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2013	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2013	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Live Data	-	
2013	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2013	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2013	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2013	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2013	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	ECU Information	-	
2013	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Read Codes	-	
2013	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Erase codes	-	
2013	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Live Data	-	
2013	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	ECU Information	-	
2013	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Read Codes	-	
2013	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Erase codes	-	
2013	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Live Data	-	
2013	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Actuators	-	
2013	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	ECU Information	-	
2013	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Read Codes	-	
2013	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Erase codes	-	
2013	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Live Data	-	
2013	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Actuators	-	
2013	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2013	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2013	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Actuators	-	
2013	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2013	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Information	-	
2013	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Read Codes	-	
2013	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Erase codes	-	
2013	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Live Data	-	
2013	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2013	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	ECU Information	-	
2013	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Read Codes	-	
2013	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Erase codes	-	
2013	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Live Data	-	
2013	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Actuators	-	
2013	CM	CM-Viaggio	-	EDM -- External Disc Module	ECU Information	-	
2013	CM	CM-Viaggio	-	EDM -- External Disc Module	Read Codes	-	
2013	CM	CM-Viaggio	-	EDM -- External Disc Module	Erase codes	-	
2013	CM	CM-Viaggio	-	EDM -- External Disc Module	Actuators	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2013	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Live Data	-	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Actuators	-	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Enable Seatbelt Minder Chime	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	Proxi Configuration	
2013	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Live Data	-	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Actuators	-	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	TPM FGA PROXI Configuration	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Update Front and Rear Axle Nominal Tire Pressure Values	
2013	FF	FF-500	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2013	FF	FF-500	-	BCM -- Body Controller	ECU Information	-	
2013	FF	FF-500	-	BCM -- Body Controller	Read Codes	-	
2013	FF	FF-500	-	BCM -- Body Controller	Erase codes	-	
2013	FF	FF-500	-	BCM -- Body Controller	Live Data	-	
2013	FF	FF-500	-	BCM -- Body Controller	Actuators	-	
2013	FF	FF-500	-	BCM -- Body Controller	ECU Configure Information	-	
2013	FF	FF-500	-	BCM -- Body Controller	Special Functions	Erase and Program Keys	
2013	FF	FF-500	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2013	FF	FF-500	-	BCM -- Body Controller	Special Functions	Initialize Power Top	
2013	FF	FF-500	-	EPS -- Electric Power Steering	ECU Information	-	
2013	FF	FF-500	-	EPS -- Electric Power Steering	Read Codes	-	
2013	FF	FF-500	-	EPS -- Electric Power Steering	Erase codes	-	
2013	FF	FF-500	-	EPS -- Electric Power Steering	Live Data	-	
2013	FF	FF-500	-	EPS -- Electric Power Steering	Special Functions	Clear Steering Pull Compensation	
2013	FF	FF-500	-	EPS -- Electric Power Steering	Special Functions	Initialize EPS	
2013	FF	FF-500	-	PTS -- Parktronics	ECU Information	-	
2013	FF	FF-500	-	PTS -- Parktronics	Read Codes	-	
2013	FF	FF-500	-	PTS -- Parktronics	Erase codes	-	
2013	FF	FF-500	-	PTS -- Parktronics	Live Data	-	
2013	FF	FF-500	-	RADIO -- Radio	ECU Information	-	
2013	FF	FF-500	-	RADIO -- Radio	Read Codes	-	
2013	FF	FF-500	-	RADIO -- Radio	Erase codes	-	
2013	FF	FF-500	-	RADIO -- Radio	Live Data	-	
2013	FF	FF-500	-	RADIO -- Radio	Special Functions	RADIO PROXI Configuration	
2013	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2013	FF	FF-500	-	CTM -- Convergence Telematic Module	ECU Information	-	
2013	FF	FF-500	-	CTM -- Convergence Telematic Module	Read Codes	-	
2013	FF	FF-500	-	CTM -- Convergence Telematic Module	Erase codes	-	
2013	FF	FF-500	-	CTM -- Convergence Telematic Module	Live Data	-	
2013	FF	FF-500	-	CTM -- Convergence Telematic Module	Actuators	-	
2013	FF	FF-500	-	CTM -- Convergence Telematic Module	Special Functions	CTM Proxi Configuration	
2013	FF	FF-500	-	CTM -- Convergence Telematic Module	System Tests	Audio System Test	
2013	FF	FF-500	-	VTM -- Vehicle Tracking Module	ECU Information	-	
2013	FF	FF-500	-	VTM -- Vehicle Tracking Module	Read Codes	-	
2013	FF	FF-500	-	VTM -- Vehicle Tracking Module	Erase codes	-	
2013	FF	FF-500	-	VTM -- Vehicle Tracking Module	Live Data	-	
2013	FF	FF-500	-	VTM -- Vehicle Tracking Module	Special Functions	VTM transport mode status	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Optiont	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2013	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Information	-	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Read Codes	-	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Erase codes	-	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Live Data	-	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Actuators	-	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Event Data	-	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2013	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2013	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Information	-	
2013	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Read Codes	-	
2013	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Erase codes	-	
2013	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Live Data	-	
2013	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Actuators	-	
2013	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2013	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2013	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2013	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2013	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2013	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2013	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2013	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2013	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Rollover Detection	
2013	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2013	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2013	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2013	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2013	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Live Data	-	
2013	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Actuators	-	
2013	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Live Data	-	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Activate TPM High Gain Mode	
2013	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2013	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2013	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Change country code	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size(JF)	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size(LX)	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2013	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2013	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2013	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2013	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2013	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2013	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2013	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2013	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2013	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Information	-	
2013	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Read Codes	-	
2013	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Erase codes	-	
2013	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Live Data	-	
2013	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Configure Information	-	
2013	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	Enable/Disable Front Seat Video	
2013	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	TGW Tone Test	
2013	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	System Tests	Anti-theft Override Test	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	View Recent Multi-Module VIN handshake Immobilizer Failures	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2013	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2013	JF	JF-Freemont	-	PTS -- Parktronics	ECU Information	-	
2013	JF	JF-Freemont	-	PTS -- Parktronics	Read Codes	-	
2013	JF	JF-Freemont	-	PTS -- Parktronics	Erase codes	-	
2013	JF	JF-Freemont	-	PTS -- Parktronics	Live Data	-	
2013	JF	JF-Freemont	-	PTS -- Parktronics	Actuators	-	
2013	JF	JF-Freemont	-	PTS -- Parktronics	ECU Configure Information	-	
2013	JF	JF-Freemont	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2013	JF	JF-Freemont	-	PTS -- Parktronics	System Tests	System Wiring Test	
2013	JF	JF-Freemont	-	ICS -- Integrated Center Stack	ECU Information	-	
2013	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Read Codes	-	
2013	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Erase codes	-	
2013	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Live Data	-	
2013	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Actuators	-	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2013	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2013	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	ECU Information	-	
2013	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Read Codes	-	
2013	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Erase codes	-	
2013	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Live Data	-	
2013	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Information	-	
2013	JF	JF-Freemont	-	DDM -- Driver Door Module	Read Codes	-	
2013	JF	JF-Freemont	-	DDM -- Driver Door Module	Erase codes	-	
2013	JF	JF-Freemont	-	DDM -- Driver Door Module	Live Data	-	
2013	JF	JF-Freemont	-	DDM -- Driver Door Module	Actuators	-	
2013	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Information	-	
2013	JF	JF-Freemont	-	PDM -- Passenger Door Module	Read Codes	-	
2013	JF	JF-Freemont	-	PDM -- Passenger Door Module	Erase codes	-	
2013	JF	JF-Freemont	-	PDM -- Passenger Door Module	Live Data	-	
2013	JF	JF-Freemont	-	PDM -- Passenger Door Module	Actuators	-	
2013	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize Siren	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Self Test	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM and Siren Communication Test	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Siren Test	
2013	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	Ultrasonic Motion Detection Test	
2013	JF	JF-Freemont	-	AMP -- Amplifier	ECU Information	-	
2013	JF	JF-Freemont	-	AMP -- Amplifier	Read Codes	-	
2013	JF	JF-Freemont	-	AMP -- Amplifier	Erase codes	-	
2013	JF	JF-Freemont	-	AMP -- Amplifier	Live Data	-	
2013	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Input Test	
2013	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Microphone Tone Test	
2013	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Microphone Output Short Test	
2013	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Output Short Test	
2013	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Software Test	
2013	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Tone Test	
2013	JF	JF-Freemont	-	HFM -- Hands Free Module	ECU Information	-	
2013	JF	JF-Freemont	-	HFM -- Hands Free Module	Read Codes	-	
2013	JF	JF-Freemont	-	HFM -- Hands Free Module	Erase codes	-	
2013	JF	JF-Freemont	-	HFM -- Hands Free Module	Live Data	-	
2013	JF	JF-Freemont	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2013	JF	JF-Freemont	-	VES3 -- Last Row Screen	ECU Information	-	
2013	JF	JF-Freemont	-	VES3 -- Last Row Screen	Read Codes	-	
2013	JF	JF-Freemont	-	VES3 -- Last Row Screen	Erase codes	-	
2013	JF	JF-Freemont	-	VES3 -- Last Row Screen	Live Data	-	
2013	JF	JF-Freemont	-	VES3 -- Last Row Screen	Actuators	-	
2013	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Information	-	
2013	JF	JF-Freemont	-	HSM -- Heated Seat Module	Read Codes	-	
2013	JF	JF-Freemont	-	HSM -- Heated Seat Module	Erase codes	-	
2013	JF	JF-Freemont	-	HSM -- Heated Seat Module	Live Data	-	
2013	JF	JF-Freemont	-	HSM -- Heated Seat Module	Actuators	-	
2013	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2013	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2013	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2013	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2013	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2013	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2013	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test(Non-RFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test(Non-RFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2013	JS	JS-Flavia	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	JS	JS-Flavia	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2013	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2013	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2013	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2013	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2013	JS	JS-Flavia	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2013	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Information	-	
2013	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	Read Codes	-	
2013	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	Erase codes	-	
2013	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	Live Data	-	
2013	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	Actuators	-	
2013	JS	JS-Flavia	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Configure Information	-	
2013	JS	JS-Flavia	-	CGW -- Central Gateway	ECU Information	-	
2013	JS	JS-Flavia	-	CGW -- Central Gateway	Read Codes	-	
2013	JS	JS-Flavia	-	CGW -- Central Gateway	Erase codes	-	
2013	JS	JS-Flavia	-	CGW -- Central Gateway	Live Data	-	
2013	JS	JS-Flavia	-	CGW -- Central Gateway	Actuators	-	
2013	JS	JS-Flavia	-	CGW -- Central Gateway	ECU Configure Information	-	
2013	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2013	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2013	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2013	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	Live Data	-	
2013	JS	JS-Flavia	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2013	JS	JS-Flavia	-	SAS -- Steering Angle Sensor	ECU Information	-	
2013	JS	JS-Flavia	-	SAS -- Steering Angle Sensor	Read Codes	-	
2013	JS	JS-Flavia	-	SAS -- Steering Angle Sensor	Erase codes	-	
2013	JS	JS-Flavia	-	SAS -- Steering Angle Sensor	Live Data	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	ECU Information	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	Read Codes	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	Erase codes	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	Live Data	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	Actuators	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	ECU Information	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	Read Codes	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	Erase codes	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	Live Data	-	
2013	JS	JS-Flavia	-	RADIO -- Radio	ECU Configure Information	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	JS	JS-Flavia	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	ECU Information	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	Read Codes	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	Erase codes	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	Live Data	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	Actuators	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	ECU Information	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	Read Codes	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	Erase codes	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	Live Data	-	
2013	JS	JS-Flavia	-	DDM -- Driver Door Module	Actuators	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	ECU Information	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	Read Codes	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	Erase codes	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	Live Data	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	Actuators	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	ECU Information	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	Read Codes	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	Erase codes	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	Live Data	-	
2013	JS	JS-Flavia	-	PDM -- Passenger Door Module	Actuators	-	
2013	JS	JS-Flavia	-	PTCM -- Power Top Control Module	ECU Information	-	
2013	JS	JS-Flavia	-	PTCM -- Power Top Control Module	Read Codes	-	
2013	JS	JS-Flavia	-	PTCM -- Power Top Control Module	Erase codes	-	
2013	JS	JS-Flavia	-	PTCM -- Power Top Control Module	Live Data	-	
2013	JS	JS-Flavia	-	PTCM -- Power Top Control Module	ECU Configure Information	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	ECU Information	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	Read Codes	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	Erase codes	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	Live Data	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	ECU Configure Information	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	System Tests	AMP Input Test	
2013	JS	JS-Flavia	-	AMP -- Amplifier	System Tests	AMP Software Test	
2013	JS	JS-Flavia	-	AMP -- Amplifier	ECU Information	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	Read Codes	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	Erase codes	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	Live Data	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	ECU Configure Information	-	
2013	JS	JS-Flavia	-	AMP -- Amplifier	System Tests	AMP Input Test	
2013	JS	JS-Flavia	-	AMP -- Amplifier	System Tests	AMP Software Test	
2013	JS	JS-Flavia	-	HFM -- Hands Free Module	ECU Information	-	
2013	JS	JS-Flavia	-	HFM -- Hands Free Module	Read Codes	-	
2013	JS	JS-Flavia	-	HFM -- Hands Free Module	Erase codes	-	
2013	JS	JS-Flavia	-	HFM -- Hands Free Module	Live Data	-	
2013	JS	JS-Flavia	-	HFM -- Hands Free Module	Actuators	-	
2013	JS	JS-Flavia	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Event Data	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	02 System Heater Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Event Data	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Event Data	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Optiont	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2013	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Initialize EGS-52	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Store Learned Adaptives	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Learned Adaptives	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Event Data	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Event Data	-	
2013	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2013	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2013	LX	LX-Thema	-	HSM -- Heated Seat Module	ECU Information	-	
2013	LX	LX-Thema	-	HSM -- Heated Seat Module	Read Codes	-	
2013	LX	LX-Thema	-	HSM -- Heated Seat Module	Erase codes	-	
2013	LX	LX-Thema	-	HSM -- Heated Seat Module	Live Data	-	
2013	LX	LX-Thema	-	HSM -- Heated Seat Module	Actuators	-	
2013	LX	LX-Thema	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	ADCM -- Active Damping Control Module	ECU Information	-	
2013	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Read Codes	-	
2013	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Erase codes	-	
2013	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Live Data	-	
2013	LX	LX-Thema	-	DTCM -- Drive Train Control Module	ECU Information	-	
2013	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Read Codes	-	
2013	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Erase codes	-	
2013	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Live Data	-	
2013	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Actuators	-	
2013	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Special Functions	Read Digital Encoder Channels	
2013	LX	LX-Thema	-	PTS -- Parktronics	ECU Information	-	
2013	LX	LX-Thema	-	PTS -- Parktronics	Read Codes	-	
2013	LX	LX-Thema	-	PTS -- Parktronics	Erase codes	-	
2013	LX	LX-Thema	-	PTS -- Parktronics	Live Data	-	
2013	LX	LX-Thema	-	PTS -- Parktronics	Actuators	-	
2013	LX	LX-Thema	-	PTS -- Parktronics	ECU Configure Information	-	
2013	LX	LX-Thema	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2013	LX	LX-Thema	-	PTS -- Parktronics	System Tests	System Wiring Test	
2013	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2013	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2013	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2013	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2013	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2013	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2013	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2013	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2013	LX	LX-Thema	-	SCCM -- Steering Column Control Module	ECU Information	-	
2013	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Read Codes	-	
2013	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Erase codes	-	
2013	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Live Data	-	
2013	LX	LX-Thema	-	PDM -- Passenger Door Module	ECU Information	-	
2013	LX	LX-Thema	-	PDM -- Passenger Door Module	Read Codes	-	
2013	LX	LX-Thema	-	PDM -- Passenger Door Module	Erase codes	-	
2013	LX	LX-Thema	-	PDM -- Passenger Door Module	Live Data	-	
2013	LX	LX-Thema	-	PDM -- Passenger Door Module	Actuators	-	
2013	LX	LX-Thema	-	PDM -- Passenger Door Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	AMP -- Amplifier	ECU Information	-	
2013	LX	LX-Thema	-	AMP -- Amplifier	Read Codes	-	
2013	LX	LX-Thema	-	AMP -- Amplifier	Erase codes	-	
2013	LX	LX-Thema	-	AMP -- Amplifier	Live Data	-	
2013	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Input Test	
2013	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Microphone Tone Test	
2013	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Microphone Output Short Test	
2013	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Output Short Test	
2013	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Software Test	
2013	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Tone Test	
2013	LX	LX-Thema	-	EPS -- Electric Power Steering	ECU Information	-	
2013	LX	LX-Thema	-	EPS -- Electric Power Steering	Read Codes	-	
2013	LX	LX-Thema	-	EPS -- Electric Power Steering	Erase codes	-	
2013	LX	LX-Thema	-	EPS -- Electric Power Steering	Live Data	-	
2013	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2013	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2013	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2013	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2013	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Actuators	-	
2013	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Special Functions	AFLS Calibration	
2013	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	ECU Information	-	
2013	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Read Codes	-	
2013	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Erase codes	-	
2013	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Live Data	-	
2013	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	ECU Configure Information	-	
2013	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Special Functions	Enable/Disable Front Seat Video	
2013	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Special Functions	TGW Tone Test	
2013	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	System Tests	Anti-theft Override Test	
2013	LX	LX-Thema	-	DDM -- Driver Door Module	ECU Information	-	
2013	LX	LX-Thema	-	DDM -- Driver Door Module	Read Codes	-	
2013	LX	LX-Thema	-	DDM -- Driver Door Module	Erase codes	-	
2013	LX	LX-Thema	-	DDM -- Driver Door Module	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	LX	LX-Thema	-	DDM -- Driver Door Module	Actuators	-	
2013	LX	LX-Thema	-	DDM -- Driver Door Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Live Data	-	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Activate TPM High Gain Mode	
2013	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2013	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2013	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2013	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2013	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2013	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2013	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2013	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2013	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	MSMD Self Test	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Standardization	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	
2013	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize Siren	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Self Test	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM and Siren Communication Test	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Siren Test	
2013	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	Ultrasonic Motion Detection Test	
2013	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2013	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2013	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2013	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Live Data	-	
2013	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Actuators	-	
2013	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2013	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2013	LX	LX-Thema	-	ESM -- Electronic Shifter	Actuators	-	
2013	LX	LX-Thema	-	HFM -- Hands Free Module	ECU Information	-	
2013	LX	LX-Thema	-	HFM -- Hands Free Module	Read Codes	-	
2013	LX	LX-Thema	-	HFM -- Hands Free Module	Erase codes	-	
2013	LX	LX-Thema	-	HFM -- Hands Free Module	Live Data	-	
2013	LX	LX-Thema	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2013	LX	LX-Thema	-	BCM -- Body Controller	ECU Information	-	
2013	LX	LX-Thema	-	BCM -- Body Controller	Read Codes	-	
2013	LX	LX-Thema	-	BCM -- Body Controller	Erase codes	-	
2013	LX	LX-Thema	-	BCM -- Body Controller	Live Data	-	
2013	LX	LX-Thema	-	BCM -- Body Controller	Actuators	-	
2013	LX	LX-Thema	-	BCM -- Body Controller	ECU Configure Information	-	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Change country code	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size(JF)	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size(LX)	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2013	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2013	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2013	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2013	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2013	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2013	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2013	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2013	LX	LX-Thema	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Information	-	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Read Codes	-	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Erase codes	-	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Live Data	-	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Actuators	-	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	View Recent Multi-Module VIN handshake Immobilizer Failures	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2013	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2013	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2013	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2013	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2013	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Live Data	-	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Diesel Particulate Filter replacement	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Fuel mean value adaption initialization	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	IMA quick calibration	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor 1 initialization	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Oxidation catalyst initialization	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Request anti-slugging for Air Condition Compressor	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	program variant coding	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure control switchover	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TIPM Enable Emissions Rolls Test mode	
2013	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Compression Test	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ESP Sensor	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Initialize ABS Non ESP	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	Bleed Brakes	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2013	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Information	-	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Read Codes	-	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Erase codes	-	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Live Data	-	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Actuators	-	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Event Data	-	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2013	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2013	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2013	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2013	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2013	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2013	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2013	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2013	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Information	-	
2013	RT	RT-Voyager	-	CGW -- Central Gateway	Read Codes	-	
2013	RT	RT-Voyager	-	CGW -- Central Gateway	Erase codes	-	
2013	RT	RT-Voyager	-	CGW -- Central Gateway	Live Data	-	
2013	RT	RT-Voyager	-	CGW -- Central Gateway	Actuators	-	
2013	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Configure Information	-	
2013	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Information	-	
2013	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Read Codes	-	
2013	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Erase codes	-	
2013	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Live Data	-	
2013	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Actuators	-	
2013	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Configure Information	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2013	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2013	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2013	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2013	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2013	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2013	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2013	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Information	-	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Read Codes	-	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Erase codes	-	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Live Data	-	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Actuators	-	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Configure Information	-	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Close Position	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Open Position	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Ramp Van Configuration	
2013	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	System Tests	Latch Home Sector Test	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Information	-	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Read Codes	-	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Erase codes	-	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Live Data	-	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Actuators	-	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Configure Information	-	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Special Functions	Learn Latch Sector Home	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Cinch Test	
2013	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Release Test	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	ECU Information	-	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Read Codes	-	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Erase codes	-	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Live Data	-	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Learn Side Test	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Ramp Van Configuration	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Close Test	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Open Test	
2013	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Actuate Drive Clutch Engage	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Information	-	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Read Codes	-	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Erase codes	-	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Live Data	-	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Actuators	-	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Configure Information	-	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Language Preference	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Update Measurement Unit	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert Minder	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Program Dealer Contact Information	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Measurement Units	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Language Preference	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert System	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	Self Test	
2013	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	CCN Self Test	
2013	RT	RT-Voyager	-	PTS -- Parktronics	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	RT	RT-Voyager	-	PTS -- Parktronics	Read Codes	-	
2013	RT	RT-Voyager	-	PTS -- Parktronics	Erase codes	-	
2013	RT	RT-Voyager	-	PTS -- Parktronics	Live Data	-	
2013	RT	RT-Voyager	-	PTS -- Parktronics	Actuators	-	
2013	RT	RT-Voyager	-	PTS -- Parktronics	ECU Configure Information	-	
2013	RT	RT-Voyager	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2013	RT	RT-Voyager	-	PTS -- Parktronics	System Tests	System Wiring Test	
2013	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	ECU Information	-	
2013	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Read Codes	-	
2013	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Erase codes	-	
2013	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Live Data	-	
2013	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Actuators	-	
2013	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Special Functions	HIDT Calibration	
2013	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2013	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2013	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2013	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2013	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Live Data	-	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Tire Sensor ID with TPM Tool	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2013	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM and Siren Communication Test	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Ultrasonic Motion Detection Test	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize ITM	
2013	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	System Tests	Siren Test	
2013	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2013	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2013	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2013	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2013	RT	RT-Voyager	-	DVD -- DVD Changer	ECU Information	-	
2013	RT	RT-Voyager	-	DVD -- DVD Changer	Read Codes	-	
2013	RT	RT-Voyager	-	DVD -- DVD Changer	Erase codes	-	
2013	RT	RT-Voyager	-	DVD -- DVD Changer	Live Data	-	
2013	RT	RT-Voyager	-	HFM -- Hands Free Module	ECU Information	-	
2013	RT	RT-Voyager	-	HFM -- Hands Free Module	Read Codes	-	
2013	RT	RT-Voyager	-	HFM -- Hands Free Module	Erase codes	-	
2013	RT	RT-Voyager	-	HFM -- Hands Free Module	Live Data	-	
2013	RT	RT-Voyager	-	HFM -- Hands Free Module	Actuators	-	
2013	RT	RT-Voyager	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2013	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	ECU Information	-	
2013	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Read Codes	-	
2013	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Erase codes	-	
2013	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Live Data	-	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Information	-	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Read Codes	-	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Erase codes	-	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Live Data	-	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Actuators	-	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Configure Information	-	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Special Functions	Learn Latch Sector Home	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Cinch Test	
2013	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Release Test	
2013	RT	RT-Voyager	-	VES3 -- Last Row Screen	ECU Information	-	
2013	RT	RT-Voyager	-	VES3 -- Last Row Screen	Read Codes	-	
2013	RT	RT-Voyager	-	VES3 -- Last Row Screen	Erase codes	-	
2013	RT	RT-Voyager	-	VES3 -- Last Row Screen	Live Data	-	
2013	RT	RT-Voyager	-	VES3 -- Last Row Screen	Actuators	-	
2013	RT	RT-Voyager	-	VES3 -- Last Row Screen	ECU Configure Information	-	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Information	-	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	Read Codes	-	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	Erase codes	-	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	Live Data	-	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Configure Information	-	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	Special Functions	PEM Replace	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Locate Learned Keys	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Door Handle Verification Test	
2013	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	LF Antenna Verification Test	
2013	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Information	-	
2013	RT	RT-Voyager	-	HSM -- Heated Seat Module	Read Codes	-	
2013	RT	RT-Voyager	-	HSM -- Heated Seat Module	Erase codes	-	
2013	RT	RT-Voyager	-	HSM -- Heated Seat Module	Live Data	-	
2013	RT	RT-Voyager	-	HSM -- Heated Seat Module	Actuators	-	
2013	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2013	RT	RT-Voyager	-	HSM -- Heated Seat Module	Special Functions	Heated Steering Wheel Configuration	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Standardization	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2013	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	
2013	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	Actuators	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2013	RT	RT-Voyager	-	RADIO -- Radio	ECU Configure Information	-	
2013	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Information	-	
2013	RT	RT-Voyager	-	VES2 -- Second Row Screen	Read Codes	-	
2013	RT	RT-Voyager	-	VES2 -- Second Row Screen	Erase codes	-	
2013	RT	RT-Voyager	-	VES2 -- Second Row Screen	Live Data	-	
2013	RT	RT-Voyager	-	VES2 -- Second Row Screen	Actuators	-	
2013	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Configure Information	-	
2013	RT	RT-Voyager	-	VES2 -- Second Row Screen	Special Functions	Headphone Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Self Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Cool Down Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Cool Down Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Front Blower State	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Rear Blower State	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Cool Down Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Front Blower State	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Rear Blower State	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2013	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2013	RT	RT-Voyager	-	FSM -- Fold Stow Module	ECU Information	-	
2013	RT	RT-Voyager	-	FSM -- Fold Stow Module	Read Codes	-	
2013	RT	RT-Voyager	-	FSM -- Fold Stow Module	Erase codes	-	
2013	RT	RT-Voyager	-	FSM -- Fold Stow Module	Live Data	-	
2013	RT	RT-Voyager	-	FSM -- Fold Stow Module	Actuators	-	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	ECU Information	-	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Read Codes	-	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Erase codes	-	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Live Data	-	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Learn Side Test	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Ramp Van Configuration	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Close Test	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Open Test	
2013	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Actuate Drive Clutch Engage	
2013	RT	RT-Voyager	-	SUNR -- Sunroof	ECU Information	-	
2013	RT	RT-Voyager	-	SUNR -- Sunroof	Read Codes	-	
2013	RT	RT-Voyager	-	SUNR -- Sunroof	Erase codes	-	
2013	RT	RT-Voyager	-	SUNR -- Sunroof	Live Data	-	
2013	RT	RT-Voyager	-	SUNR -- Sunroof	Actuators	-	
2013	RT	RT-Voyager	-	AHBM -- Automatic High Beam	ECU Information	-	
2013	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Read Codes	-	
2013	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Erase codes	-	
2013	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Live Data	-	
2013	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Actuators	-	
2013	RT	RT-Voyager	-	AHBM -- Automatic High Beam	System Tests	Aim Test	
2013	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2013	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2013	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2013	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2013	RT	RT-Voyager	-	DMFR -- Door Module Front Right	ECU Information	-	
2013	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Read Codes	-	
2013	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Erase codes	-	
2013	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Live Data	-	
2013	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Actuators	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC FGA Enable Seatbelt Minder Chime	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Actuators	-	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	TPM FGA PROXI Configuration	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Update Front and Rear Axle Nominal Tire Pressure Values	
2014	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Information	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Read Codes	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Erase codes	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Live Data	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Actuators	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Configure Information	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Rain and Automatic Lights Sensors check	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Enable Front Fog Lamp Dropout	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Configure Door Locks	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Information	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Read Codes	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Erase codes	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Live Data	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Actuators	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Configure Information	-	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Rain and Automatic Lights Sensors check	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Enable Front Fog Lamp Dropout	
2014	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Configure Door Locks	
2014	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	ECU Information	-	
2014	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Read Codes	-	
2014	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Erase codes	-	
2014	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Live Data	-	
2014	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Live Data	-	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Actuators	-	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Special Functions	Audio Test	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2014	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2014	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	ECU Information	-	
2014	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Read Codes	-	
2014	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Erase codes	-	
2014	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Live Data	-	
2014	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	ECU Information	-	
2014	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Read Codes	-	
2014	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Erase codes	-	
2014	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Live Data	-	
2014	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Actuators	-	
2014	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Live Data	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Actuators	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Event Data	-	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2014	BU	BU-Renegade	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	









## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BU	BU-Renegade	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2014	BU	BU-Renegade	-	AMP -- Amplifier	ECU Information	-	
2014	BU	BU-Renegade	-	AMP -- Amplifier	Read Codes	-	
2014	BU	BU-Renegade	-	AMP -- Amplifier	Erase codes	-	
2014	BU	BU-Renegade	-	AMP -- Amplifier	Live Data	-	
2014	BU	BU-Renegade	-	AMP -- Amplifier	Actuators	-	
2014	BU	BU-Renegade	-	AMP -- Amplifier	ECU Configure Information	-	
2014	BU	BU-Renegade	-	AMP -- Amplifier	System Tests	Audio Measure AC+DC	
2014	BU	BU-Renegade	-	AMP -- Amplifier	System Tests	Output Short Test	
2014	BU	BU-Renegade	-	AMP -- Amplifier	System Tests	Tone Test	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	ECU Information	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Read Codes	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Erase codes	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Live Data	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Actuators	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Special Functions	Audio signal detection	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Special Functions	Power Down	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Special Functions	Power on and Disable User Input	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Live Data	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Actuators	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Live Data	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Actuators	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Live Data	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	Actuators	-	
2014	BU	BU-Renegade	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2014	BU	BU-Renegade	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2014	BU	BU-Renegade	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2014	BU	BU-Renegade	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2014	BU	BU-Renegade	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2014	BU	BU-Renegade	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2014	BU	BU-Renegade	-	CSWM -- Comfort Seat Wheel Module	ECU Information	-	
2014	BU	BU-Renegade	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2014	BU	BU-Renegade	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2014	BU	BU-Renegade	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2014	BU	BU-Renegade	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2014	BU	BU-Renegade	-	EPS -- Electric Power Steering	ECU Information	-	
2014	BU	BU-Renegade	-	EPS -- Electric Power Steering	Read Codes	-	
2014	BU	BU-Renegade	-	EPS -- Electric Power Steering	Erase codes	-	
2014	BU	BU-Renegade	-	EPS -- Electric Power Steering	Live Data	-	
2014	BU	BU-Renegade	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2014	BU	BU-Renegade	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2014	BU	BU-Renegade	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2014	BU	BU-Renegade	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2014	BU	BU-Renegade	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2014	BU	BU-Renegade	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2014	BU	BU-Renegade	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	ECU Information	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Read Codes	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Erase codes	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Live Data	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	ECU Information	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Read Codes	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Erase codes	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Live Data	-	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2014	BU	BU-Renegade	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2014	BU	BU-Renegade	-	DTCM -- Drive Train Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	DTCM -- Drive Train Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	DTCM -- Drive Train Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	DTCM -- Drive Train Control Module	Live Data	-	
2014	BU	BU-Renegade	-	DTCM -- Drive Train Control Module	Special Functions	2WD Dyno Mode	
2014	BU	BU-Renegade	-	DTCM -- Drive Train Control Module	Special Functions	On Demand Self Test	
2014	BU	BU-Renegade	-	DTCM -- Drive Train Control Module	Special Functions	PTU Replacement	
2014	BU	BU-Renegade	-	DTCM -- Drive Train Control Module	Special Functions	RDU Replacement	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	ECU Information	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Read Codes	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Erase codes	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Live Data	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Actuators	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH immobilizer antenna test	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH locate learned keys	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM sensor rolls tests	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM Update FF FR Axle Nom Tire Press Val	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left front tire sensor Id	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left rear tire sensor Id	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right front tire sensor Id	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right rear tire sensor Id	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	ECU Information	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Read Codes	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Erase codes	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Live Data	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Actuators	-	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH immobilizer antenna test	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH locate learned keys	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM sensor rolls tests	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM Update FF FR Axle Nom Tire Press Val	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left front tire sensor Id	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left rear tire sensor Id	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right front tire sensor Id	
2014	BU	BU-Renegade	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right rear tire sensor Id	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	BU	BU-Renegade	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	BU	BU-Renegade	-	TTM -- Trailer tow module	ECU Information	-	
2014	BU	BU-Renegade	-	TTM -- Trailer tow module	Read Codes	-	
2014	BU	BU-Renegade	-	TTM -- Trailer tow module	Erase codes	-	
2014	BU	BU-Renegade	-	TTM -- Trailer tow module	Live Data	-	
2014	BU	BU-Renegade	-	TTM -- Trailer tow module	Actuators	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Information	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Read Codes	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Erase codes	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Live Data	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Actuators	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Information	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Read Codes	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Erase codes	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Live Data	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Actuators	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2014	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command(1st, 4th, 5th, 6th)	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2014	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2014	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2014	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2014	CM	CM-Viaggio	-	PAM -- Park Assist Module	ECU Information	-	
2014	CM	CM-Viaggio	-	PAM -- Park Assist Module	Read Codes	-	
2014	CM	CM-Viaggio	-	PAM -- Park Assist Module	Erase codes	-	
2014	CM	CM-Viaggio	-	PAM -- Park Assist Module	Live Data	-	
2014	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2014	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2014	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	ECU Information	-	
2014	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2014	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2014	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Live Data	-	
2014	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2014	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2014	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2014	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2014	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	ECU Information	-	
2014	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Read Codes	-	
2014	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Erase codes	-	
2014	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Live Data	-	
2014	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	ECU Information	-	
2014	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Read Codes	-	
2014	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Erase codes	-	
2014	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Live Data	-	
2014	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Actuators	-	
2014	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	ECU Information	-	
2014	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Read Codes	-	
2014	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Erase codes	-	
2014	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Live Data	-	
2014	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Actuators	-	
2014	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2014	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2014	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Actuators	-	
2014	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2014	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Information	-	
2014	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Read Codes	-	
2014	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Erase codes	-	
2014	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Live Data	-	
2014	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2014	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	ECU Information	-	
2014	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Read Codes	-	
2014	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Erase codes	-	
2014	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Live Data	-	
2014	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Actuators	-	
2014	CM	CM-Viaggio	-	EDM -- External Disc Module	ECU Information	-	
2014	CM	CM-Viaggio	-	EDM -- External Disc Module	Read Codes	-	
2014	CM	CM-Viaggio	-	EDM -- External Disc Module	Erase codes	-	
2014	CM	CM-Viaggio	-	EDM -- External Disc Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Dosing valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	NOx temperature sensor replacement (downstream SCR catalyst)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	SCR dosing module replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Selective Catalyst Reduction (SCR) replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Temperature sensor replacement (inlet SCR catalyst)	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Mechanical hydraulic test (SCR system)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	SCR dosing module test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	UREA dosing valve release test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	UREA emptying test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Adaptive Parameters reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Dosing valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	NOx temperature sensor replacement (downstream SCR catalyst)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	SCR dosing module replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Selective Catalyst Reduction (SCR) replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Temperature sensor replacement (inlet SCR catalyst)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Mechanical hydraulic test (SCR system)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	SCR dosing module test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	UREA dosing valve release test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	UREA emptying test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Adaptive Parameters reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Live Data	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Actuators	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	'UP Function' switch replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electro valve replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Live Data	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Actuators	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	'UP Function' switch replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electro valve replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2014	DC	DC-Ducato	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor decalibration	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Special Functions	Steering angle sensor calibration	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	DC	DC-Ducato	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	DC	DC-Ducato	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Actuators	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	ECU SERIAL NUMBER Management	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Rear Type Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Rear Type Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Rolls Test	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Actuators	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	ECU SERIAL NUMBER Management	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Rolls Test	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Actuators	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	ECU SERIAL NUMBER Management	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	DC	DC-Ducato	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Rolls Test	
2014	DC	DC-Ducato	-	BCM -- Body Controller	ECU Information	-	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Read Codes	-	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Erase codes	-	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Live Data	-	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Actuators	-	
2014	DC	DC-Ducato	-	BCM -- Body Controller	ECU Configure Information	-	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Special Functions	Key Learning procedure	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Special Functions	LIN Siren Check	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2014	DC	DC-Ducato	-	BCM -- Body Controller	Special Functions	Rain and Automatic Lights Sensors check	
2014	DC	DC-Ducato	-	EPS -- Electric Power Steering	ECU Information	-	
2014	DC	DC-Ducato	-	EPS -- Electric Power Steering	Read Codes	-	
2014	DC	DC-Ducato	-	EPS -- Electric Power Steering	Erase codes	-	
2014	DC	DC-Ducato	-	EPS -- Electric Power Steering	Live Data	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	ECU Information	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Read Codes	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Erase codes	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Live Data	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Actuators	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	ECU Configure Information	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Special Functions	Audio test for subwoofer specific	
2014	DC	DC-Ducato	-	RADIO -- Radio	Special Functions	Power on and disable user inputs	
2014	DC	DC-Ducato	-	RADIO -- Radio	Special Functions	Reset Parameters to Default	
2014	DC	DC-Ducato	-	RADIO -- Radio	System Tests	Power Down	
2014	DC	DC-Ducato	-	RADIO -- Radio	ECU Information	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Read Codes	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Erase codes	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Live Data	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Actuators	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	ECU Configure Information	-	
2014	DC	DC-Ducato	-	RADIO -- Radio	Special Functions	Audio video signal detection	
2014	DC	DC-Ducato	-	RADIO -- Radio	Special Functions	Power on and disable user inputs	
2014	DC	DC-Ducato	-	RADIO -- Radio	Special Functions	Reset Parameters to Default	
2014	DC	DC-Ducato	-	RADIO -- Radio	System Tests	Power Down	
2014	DC	DC-Ducato	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	DC	DC-Ducato	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	DC	DC-Ducato	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	DC	DC-Ducato	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	DC	DC-Ducato	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	DC	DC-Ducato	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	DC	DC-Ducato	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self learning motors test	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Live Data	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Actuators	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Live Data	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Actuators	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2014	DC	DC-Ducato	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	ECU Information	-	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Read Codes	-	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Erase codes	-	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Live Data	-	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Special Functions	Trail ECU absence	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Special Functions	Trail ECU presence	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	ECU Information	-	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Read Codes	-	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Erase codes	-	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Live Data	-	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2014	DC	DC-Ducato	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2014	DC	DC-Ducato	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2014	DC	DC-Ducato	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2014	DC	DC-Ducato	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2014	DC	DC-Ducato	-	HALF -- Haptical Lane Feedback	Live Data	-	
2014	DC	DC-Ducato	-	HALF -- Haptical Lane Feedback	Special Functions	Service Single Pole Calibration	
2014	DC	DC-Ducato	-	TTM -- Trailer tow module	ECU Information	-	
2014	DC	DC-Ducato	-	TTM -- Trailer tow module	Read Codes	-	
2014	DC	DC-Ducato	-	TTM -- Trailer tow module	Erase codes	-	
2014	DC	DC-Ducato	-	TTM -- Trailer tow module	Live Data	-	
2014	DC	DC-Ducato	-	TTM -- Trailer tow module	Actuators	-	
2014	DC	DC-Ducato	-	TTM -- Trailer tow module	ECU Configure Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2014	FF	FF-500	-	TCM -- Transmission Control Module	ECU Information	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Read Codes	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Erase codes	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Live Data	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Actuators	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2014	FF	FF-500	-	TCM -- Transmission Control Module	ECU Information	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Read Codes	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Erase codes	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Live Data	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Actuators	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Bleed Hydraulic Circuit	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	ECU Replacement With Value Transfer	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit depressurization	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Learn Clutches Contact Point	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Learn long acceleration Signal	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	New Actuators	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Quick Learn	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Reset of Data group	
2014	FF	FF-500	-	TCM -- Transmission Control Module	ECU Information	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Read Codes	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Erase codes	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Live Data	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Actuators	-	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2014	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2014	FF	FF-500	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	FF	FF-500	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	FF	FF-500	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	FF	FF-500	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	FF	FF-500	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	FF	FF-500	-	ABS -- Anti Lock Brakes	Special Functions	ABS Static Test	
2014	FF	FF-500	-	ABS -- Anti Lock Brakes	System Tests	Longitudinal G-Sensor Calibration Test	
2014	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Enable Seatbelt Minder Chime	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	Proxi Configuration	
2014	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Actuators	-	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	TPM FGA PROXI Configuration	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Update Front and Rear Axle Nominal Tire Pressure Values	
2014	FF	FF-500	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2014	FF	FF-500	-	BCM -- Body Controller	ECU Information	-	
2014	FF	FF-500	-	BCM -- Body Controller	Read Codes	-	
2014	FF	FF-500	-	BCM -- Body Controller	Erase codes	-	
2014	FF	FF-500	-	BCM -- Body Controller	Live Data	-	
2014	FF	FF-500	-	BCM -- Body Controller	Actuators	-	
2014	FF	FF-500	-	BCM -- Body Controller	ECU Configure Information	-	
2014	FF	FF-500	-	BCM -- Body Controller	Special Functions	Erase and Program Keys	
2014	FF	FF-500	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2014	FF	FF-500	-	BCM -- Body Controller	Special Functions	Initialize Power Top	
2014	FF	FF-500	-	EPS -- Electric Power Steering	ECU Information	-	
2014	FF	FF-500	-	EPS -- Electric Power Steering	Read Codes	-	
2014	FF	FF-500	-	EPS -- Electric Power Steering	Erase codes	-	
2014	FF	FF-500	-	EPS -- Electric Power Steering	Live Data	-	
2014	FF	FF-500	-	EPS -- Electric Power Steering	Special Functions	Clear Steering Pull Compensation	
2014	FF	FF-500	-	EPS -- Electric Power Steering	Special Functions	Initialize EPS	
2014	FF	FF-500	-	PTS -- Parktronics	ECU Information	-	
2014	FF	FF-500	-	PTS -- Parktronics	Read Codes	-	
2014	FF	FF-500	-	PTS -- Parktronics	Erase codes	-	
2014	FF	FF-500	-	PTS -- Parktronics	Live Data	-	
2014	FF	FF-500	-	RADIO -- Radio	ECU Information	-	
2014	FF	FF-500	-	RADIO -- Radio	Read Codes	-	
2014	FF	FF-500	-	RADIO -- Radio	Erase codes	-	
2014	FF	FF-500	-	RADIO -- Radio	Live Data	-	
2014	FF	FF-500	-	RADIO -- Radio	Special Functions	RADIO PROXI Configuration	
2014	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	FF	FF-500	-	CTM -- Convergence Telematic Module	ECU Information	-	
2014	FF	FF-500	-	CTM -- Convergence Telematic Module	Read Codes	-	
2014	FF	FF-500	-	CTM -- Convergence Telematic Module	Erase codes	-	
2014	FF	FF-500	-	CTM -- Convergence Telematic Module	Live Data	-	
2014	FF	FF-500	-	CTM -- Convergence Telematic Module	Actuators	-	
2014	FF	FF-500	-	CTM -- Convergence Telematic Module	Special Functions	CTM Proxi Configuration	
2014	FF	FF-500	-	CTM -- Convergence Telematic Module	System Tests	Audio System Test	
2014	FF	FF-500	-	VTM -- Vehicle Tracking Module	ECU Information	-	
2014	FF	FF-500	-	VTM -- Vehicle Tracking Module	Read Codes	-	
2014	FF	FF-500	-	VTM -- Vehicle Tracking Module	Erase codes	-	
2014	FF	FF-500	-	VTM -- Vehicle Tracking Module	Live Data	-	
2014	FF	FF-500	-	VTM -- Vehicle Tracking Module	Special Functions	VTM transport mode status	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test(Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test(Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	









## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test(Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test(Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Optiont	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2014	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Information	-	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Read Codes	-	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Erase codes	-	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Live Data	-	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Actuators	-	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Event Data	-	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2014	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2014	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Information	-	
2014	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Read Codes	-	
2014	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Erase codes	-	
2014	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Live Data	-	
2014	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Actuators	-	
2014	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2014	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2014	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2014	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Rollover Detection	
2014	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Activate TPM High Gain Mode	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2014	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2014	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2014	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Change country code	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Calibration	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size (JF)	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size (LX)	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2014	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2014	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2014	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2014	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2014	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2014	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2014	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2014	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2014	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Information	-	
2014	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Read Codes	-	
2014	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Erase codes	-	
2014	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Live Data	-	
2014	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Configure Information	-	
2014	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	Enable/Disable Front Seat Video	
2014	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	TGW Tone Test	
2014	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	System Tests	Anti-theft Override Test	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2014	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2014	JF	JF-Freemont	-	PTS -- Parktronics	ECU Information	-	
2014	JF	JF-Freemont	-	PTS -- Parktronics	Read Codes	-	
2014	JF	JF-Freemont	-	PTS -- Parktronics	Erase codes	-	
2014	JF	JF-Freemont	-	PTS -- Parktronics	Live Data	-	
2014	JF	JF-Freemont	-	PTS -- Parktronics	Actuators	-	
2014	JF	JF-Freemont	-	PTS -- Parktronics	ECU Configure Information	-	
2014	JF	JF-Freemont	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2014	JF	JF-Freemont	-	PTS -- Parktronics	System Tests	System Wiring Test	
2014	JF	JF-Freemont	-	ICS -- Integrated Center Stack	ECU Information	-	
2014	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Read Codes	-	
2014	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Erase codes	-	
2014	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Live Data	-	
2014	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Actuators	-	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2014	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2014	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	ECU Information	-	
2014	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Erase codes	-	
2014	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Live Data	-	
2014	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Information	-	
2014	JF	JF-Freemont	-	DDM -- Driver Door Module	Read Codes	-	
2014	JF	JF-Freemont	-	DDM -- Driver Door Module	Erase codes	-	
2014	JF	JF-Freemont	-	DDM -- Driver Door Module	Live Data	-	
2014	JF	JF-Freemont	-	DDM -- Driver Door Module	Actuators	-	
2014	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Information	-	
2014	JF	JF-Freemont	-	PDM -- Passenger Door Module	Read Codes	-	
2014	JF	JF-Freemont	-	PDM -- Passenger Door Module	Erase codes	-	
2014	JF	JF-Freemont	-	PDM -- Passenger Door Module	Live Data	-	
2014	JF	JF-Freemont	-	PDM -- Passenger Door Module	Actuators	-	
2014	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize Siren	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Self Test	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM and Siren Communication Test	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Siren Test	
2014	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	Ultrasonic Motion Detection Test	
2014	JF	JF-Freemont	-	AMP -- Amplifier	ECU Information	-	
2014	JF	JF-Freemont	-	AMP -- Amplifier	Read Codes	-	
2014	JF	JF-Freemont	-	AMP -- Amplifier	Erase codes	-	
2014	JF	JF-Freemont	-	AMP -- Amplifier	Live Data	-	
2014	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Input Test	
2014	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Microphone Tone Test	
2014	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Microphone Output Short Test	
2014	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Output Short Test	
2014	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Software Test	
2014	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Tone Test	
2014	JF	JF-Freemont	-	HFM -- Hands Free Module	ECU Information	-	
2014	JF	JF-Freemont	-	HFM -- Hands Free Module	Read Codes	-	
2014	JF	JF-Freemont	-	HFM -- Hands Free Module	Erase codes	-	
2014	JF	JF-Freemont	-	HFM -- Hands Free Module	Live Data	-	
2014	JF	JF-Freemont	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2014	JF	JF-Freemont	-	VES3 -- Last Row Screen	ECU Information	-	
2014	JF	JF-Freemont	-	VES3 -- Last Row Screen	Read Codes	-	
2014	JF	JF-Freemont	-	VES3 -- Last Row Screen	Erase codes	-	
2014	JF	JF-Freemont	-	VES3 -- Last Row Screen	Live Data	-	
2014	JF	JF-Freemont	-	VES3 -- Last Row Screen	Actuators	-	
2014	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Information	-	
2014	JF	JF-Freemont	-	HSM -- Heated Seat Module	Read Codes	-	
2014	JF	JF-Freemont	-	HSM -- Heated Seat Module	Erase codes	-	
2014	JF	JF-Freemont	-	HSM -- Heated Seat Module	Live Data	-	
2014	JF	JF-Freemont	-	HSM -- Heated Seat Module	Actuators	-	
2014	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2014	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2014	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2014	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2014	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2014	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2014	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	ECU Information	-	
2014	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	Read Codes	-	
2014	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	Erase codes	-	
2014	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	Live Data	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Event Data	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	









## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test (Non-EFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Option	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2014	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Event Data	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	QuickLearn	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Initialize EGS-52	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Store Learned Adaptives	
2014	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Learned Adaptives	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2014	LX	LX-Thema	-	ESM -- Electronic Shifter	Actuators	-	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2014	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2014	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2014	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2014	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2014	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Live Data	-	
2014	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Special Functions	ACC Aim Mode - Auto Alignment	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Information	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Read Codes	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Erase codes	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Live Data	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Actuators	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	View Recent Multi-Module VIN handshake Immobilizer Failures	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Information	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Read Codes	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Erase codes	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Live Data	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Actuators	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	View Recent Multi-Module VIN handshake Immobilizer Failures	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2014	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2014	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	ECU Information		
2014	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Read Codes		
2014	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Erase codes		
2014	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Live Data		
2014	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information		
2014	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2014	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	ECU Information		
2014	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Read Codes		
2014	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Erase codes		
2014	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Live Data		
2014	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	ECU Information		
2014	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Read Codes		
2014	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Erase codes		
2014	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Live Data		
2014	LX	LX-Thema	-	SCCM -- Steering Column Control Module	ECU Information		
2014	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Read Codes		
2014	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Erase codes		
2014	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Live Data		
2014	LX	LX-Thema	-	HSM -- Heated Seat Module	ECU Information		
2014	LX	LX-Thema	-	HSM -- Heated Seat Module	Read Codes		
2014	LX	LX-Thema	-	HSM -- Heated Seat Module	Erase codes		
2014	LX	LX-Thema	-	HSM -- Heated Seat Module	Live Data		
2014	LX	LX-Thema	-	HSM -- Heated Seat Module	Actuators		
2014	LX	LX-Thema	-	HSM -- Heated Seat Module	ECU Configure Information		
2014	LX	LX-Thema	-	EPS -- Electric Power Steering	ECU Information		
2014	LX	LX-Thema	-	EPS -- Electric Power Steering	Read Codes		
2014	LX	LX-Thema	-	EPS -- Electric Power Steering	Erase codes		
2014	LX	LX-Thema	-	EPS -- Electric Power Steering	Live Data		
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	ECU Information		
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Read Codes		
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Erase codes		
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Live Data		
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Actuators		
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	ECU Configure Information		
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize Siren	
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Self Test	
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM and Siren Communication Test	
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Siren Test	
2014	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	Ultrasonic Motion Detection Test	
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	ECU Information		
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Read Codes		
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Erase codes		
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Live Data		
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Actuators		
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information		
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2014	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2014	LX	LX-Thema	-	ADCM -- Active Damping Control Module	ECU Information		
2014	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Read Codes		
2014	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Erase codes		
2014	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Live Data		
2014	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	ECU Information		
2014	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Read Codes		
2014	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Erase codes		
2014	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Live Data		
2014	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	ECU Information		
2014	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Read Codes		
2014	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Erase codes		
2014	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Live Data		
2014	LX	LX-Thema	-	DTCM -- Drive Train Control Module	ECU Information		
2014	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Read Codes		
2014	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Erase codes		
2014	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Live Data		
2014	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Actuators		
2014	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Special Functions	Read Digital Encoder Channels	
2014	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	ECU Information		
2014	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Read Codes		
2014	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Erase codes		
2014	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Live Data		
2014	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	ECU Configure Information		
2014	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Special Functions	Enable/Disable Front Seat Video	
2014	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	Special Functions	TGW Tone Test	
2014	LX	LX-Thema	-	TGW -- Telematic Gateway Radio	System Tests	Anti-theft Override Test	
2014	LX	LX-Thema	-	PDM -- Passenger Door Module	ECU Information		
2014	LX	LX-Thema	-	PDM -- Passenger Door Module	Read Codes		
2014	LX	LX-Thema	-	PDM -- Passenger Door Module	Erase codes		
2014	LX	LX-Thema	-	PDM -- Passenger Door Module	Live Data		
2014	LX	LX-Thema	-	PDM -- Passenger Door Module	Actuators		
2014	LX	LX-Thema	-	PDM -- Passenger Door Module	ECU Configure Information		
2014	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	ECU Information		
2014	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Read Codes		
2014	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Erase codes		
2014	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Live Data		
2014	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Actuators		
2014	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2014	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2014	LX	LX-Thema	-	BCM -- Body Controller	ECU Information		
2014	LX	LX-Thema	-	BCM -- Body Controller	Read Codes		
2014	LX	LX-Thema	-	BCM -- Body Controller	Erase codes		
2014	LX	LX-Thema	-	BCM -- Body Controller	Live Data		
2014	LX	LX-Thema	-	BCM -- Body Controller	Actuators		
2014	LX	LX-Thema	-	BCM -- Body Controller	ECU Configure Information		
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Change country code	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Calibration	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size(JF)	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size(LX)	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2014	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2014	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2014	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2014	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2014	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2014	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2014	LX	LX-Thema	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2014	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2014	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2014	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2014	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2014	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Actuators	-	
2014	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Special Functions	AFLS Calibration	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	MSMD Self Test	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Standardization	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	
2014	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2014	LX	LX-Thema	-	HFM -- Hands Free Module	ECU Information	-	
2014	LX	LX-Thema	-	HFM -- Hands Free Module	Read Codes	-	
2014	LX	LX-Thema	-	HFM -- Hands Free Module	Erase codes	-	
2014	LX	LX-Thema	-	HFM -- Hands Free Module	Live Data	-	
2014	LX	LX-Thema	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2014	LX	LX-Thema	-	PTS -- Parktronics	ECU Information	-	
2014	LX	LX-Thema	-	PTS -- Parktronics	Read Codes	-	
2014	LX	LX-Thema	-	PTS -- Parktronics	Erase codes	-	
2014	LX	LX-Thema	-	PTS -- Parktronics	Live Data	-	
2014	LX	LX-Thema	-	PTS -- Parktronics	Actuators	-	
2014	LX	LX-Thema	-	PTS -- Parktronics	ECU Configure Information	-	
2014	LX	LX-Thema	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2014	LX	LX-Thema	-	PTS -- Parktronics	System Tests	System Wiring Test	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Activate TPM High Gain Mode	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2014	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2014	LX	LX-Thema	-	AMP -- Amplifier	ECU Information	-	
2014	LX	LX-Thema	-	AMP -- Amplifier	Read Codes	-	
2014	LX	LX-Thema	-	AMP -- Amplifier	Erase codes	-	
2014	LX	LX-Thema	-	AMP -- Amplifier	Live Data	-	
2014	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Input Test	
2014	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Microphone Tone Test	
2014	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Microphone Output Short Test	
2014	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Output Short Test	
2014	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Software Test	
2014	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Tone Test	
2014	LX	LX-Thema	-	ICS -- Integrated Center Stack	ECU Information	-	
2014	LX	LX-Thema	-	ICS -- Integrated Center Stack	Read Codes	-	
2014	LX	LX-Thema	-	ICS -- Integrated Center Stack	Erase codes	-	
2014	LX	LX-Thema	-	ICS -- Integrated Center Stack	Live Data	-	
2014	LX	LX-Thema	-	ICS -- Integrated Center Stack	Actuators	-	
2014	LX	LX-Thema	-	DDM -- Driver Door Module	ECU Information	-	
2014	LX	LX-Thema	-	DDM -- Driver Door Module	Read Codes	-	
2014	LX	LX-Thema	-	DDM -- Driver Door Module	Erase codes	-	
2014	LX	LX-Thema	-	DDM -- Driver Door Module	Live Data	-	
2014	LX	LX-Thema	-	DDM -- Driver Door Module	Actuators	-	
2014	LX	LX-Thema	-	DDM -- Driver Door Module	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Information	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Read Codes	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Erase codes	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Live Data	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Actuators	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Information	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Read Codes	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Erase codes	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Live Data	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Actuators	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2014	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacemnet	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command(1st,4th,5th,6th)	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacemnet	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command(1st,4th,5th,6th)	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Longitudinal and Lateral sensor calibration	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Static test	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Actuators	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Longitudinal and Lateral sensor calibration	
2014	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Static test	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2014	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2014	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2014	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	ECU Information	-	
2014	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Read Codes	-	
2014	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Erase codes	-	
2014	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Live Data	-	
2014	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Actuators	-	
2014	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2014	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2014	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2014	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	ECU Information	-	
2014	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Read Codes	-	
2014	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Erase codes	-	
2014	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Live Data	-	
2014	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Actuators	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2014	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Information	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Read Codes	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Erase codes	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Live Data	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Actuators	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Information	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Read Codes	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Erase codes	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Live Data	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Actuators	-	
2014	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	ECU Information	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	Read Codes	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	Erase codes	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	Live Data	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	Actuators	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	ECU Information	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	Read Codes	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	Erase codes	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	Live Data	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	Actuators	-	
2014	OT	OT-Ottimo	-	RADIO -- Radio	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2014	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	ECU Information	-	
2014	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Read Codes	-	
2014	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Erase codes	-	
2014	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Live Data	-	
2014	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	PAM -- Park Assist Module	ECU Information	-	
2014	OT	OT-Ottimo	-	PAM -- Park Assist Module	Read Codes	-	
2014	OT	OT-Ottimo	-	PAM -- Park Assist Module	Erase codes	-	
2014	OT	OT-Ottimo	-	PAM -- Park Assist Module	Live Data	-	
2014	OT	OT-Ottimo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2014	OT	OT-Ottimo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2014	OT	OT-Ottimo	-	ESM -- Electronic Shifter	ECU Information	-	
2014	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Read Codes	-	
2014	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Erase codes	-	
2014	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Live Data	-	
2014	OT	OT-Ottimo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2014	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2014	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2014	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2014	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Live Data	-	
2014	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2014	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2014	OT	OT-Ottimo	-	EDM -- External Disc Module	ECU Information	-	
2014	OT	OT-Ottimo	-	EDM -- External Disc Module	Read Codes	-	
2014	OT	OT-Ottimo	-	EDM -- External Disc Module	Erase codes	-	
2014	OT	OT-Ottimo	-	EDM -- External Disc Module	Actuators	-	
2014	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2014	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2014	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2014	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Live Data	-	
2014	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Actuators	-	
2014	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	









## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Event Data	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test(Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test(Non-RFE)	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Diesel Particulate Filter replacement	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Fuel mean value adaption initialization	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	IMA quick calibration	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor 1 initialization	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Oxidation catalyst initialization	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Request anti-slugging for Air Condition Compressor	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	program variant coding	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure control switchover	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TIPM Enable Emissions Rolls Test mode	
2014	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Compression Test	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Information	-	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Read Codes	-	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Erase codes	-	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Live Data	-	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Actuators	-	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Event Data	-	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2014	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2014	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2014	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2014	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2014	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2014	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2014	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2014	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2014	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2014	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Information	-	
2014	RT	RT-Voyager	-	CGW -- Central Gateway	Read Codes	-	
2014	RT	RT-Voyager	-	CGW -- Central Gateway	Erase codes	-	
2014	RT	RT-Voyager	-	CGW -- Central Gateway	Live Data	-	
2014	RT	RT-Voyager	-	CGW -- Central Gateway	Actuators	-	
2014	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Configure Information	-	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Information	-	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Read Codes	-	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Erase codes	-	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Live Data	-	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Actuators	-	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Configure Information	-	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Special Functions	Learn Latch Sector Home	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Cinch Test	
2014	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Release Test	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Tire Sensor ID with TPM Tool	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Live Data	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Tire Sensor ID with TPM Tool	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Turn off Gain Mode Override	
2014	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2014	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	Actuators	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2014	RT	RT-Voyager	-	RADIO -- Radio	ECU Configure Information	-	
2014	RT	RT-Voyager	-	HFM -- Hands Free Module	ECU Information	-	
2014	RT	RT-Voyager	-	HFM -- Hands Free Module	Read Codes	-	
2014	RT	RT-Voyager	-	HFM -- Hands Free Module	Erase codes	-	
2014	RT	RT-Voyager	-	HFM -- Hands Free Module	Live Data	-	
2014	RT	RT-Voyager	-	HFM -- Hands Free Module	Actuators	-	
2014	RT	RT-Voyager	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2014	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	ECU Information	-	
2014	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Read Codes	-	
2014	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Erase codes	-	
2014	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Live Data	-	
2014	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2014	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2014	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2014	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2014	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2014	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Information	-	
2014	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Read Codes	-	
2014	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Erase codes	-	
2014	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Live Data	-	
2014	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Actuators	-	
2014	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Configure Information	-	
2014	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Information	-	
2014	RT	RT-Voyager	-	VES2 -- Second Row Screen	Read Codes	-	
2014	RT	RT-Voyager	-	VES2 -- Second Row Screen	Erase codes	-	
2014	RT	RT-Voyager	-	VES2 -- Second Row Screen	Live Data	-	
2014	RT	RT-Voyager	-	VES2 -- Second Row Screen	Actuators	-	
2014	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Configure Information	-	
2014	RT	RT-Voyager	-	VES2 -- Second Row Screen	Special Functions	Headphone Test	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Cool Down Test	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Front Blower State	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Rear Blower State	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2014	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2014	RT	RT-Voyager	-	DMFR -- Door Module Front Right	ECU Information	-	
2014	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Read Codes	-	
2014	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Erase codes	-	
2014	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Live Data	-	
2014	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Actuators	-	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM and Siren Communication Test	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Ultrasonic Motion Detection Test	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize ITM	
2014	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	System Tests	Siren Test	
2014	RT	RT-Voyager	-	FSM -- Fold Stow Module	ECU Information	-	
2014	RT	RT-Voyager	-	FSM -- Fold Stow Module	Read Codes	-	
2014	RT	RT-Voyager	-	FSM -- Fold Stow Module	Erase codes	-	
2014	RT	RT-Voyager	-	FSM -- Fold Stow Module	Live Data	-	
2014	RT	RT-Voyager	-	FSM -- Fold Stow Module	Actuators	-	
2014	RT	RT-Voyager	-	SUNR -- Sunroof	ECU Information	-	
2014	RT	RT-Voyager	-	SUNR -- Sunroof	Read Codes	-	
2014	RT	RT-Voyager	-	SUNR -- Sunroof	Erase codes	-	
2014	RT	RT-Voyager	-	SUNR -- Sunroof	Live Data	-	
2014	RT	RT-Voyager	-	SUNR -- Sunroof	Actuators	-	
2014	RT	RT-Voyager	-	AHBM -- Automatic High Beam	ECU Information	-	
2014	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Read Codes	-	
2014	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Erase codes	-	
2014	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Live Data	-	
2014	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Actuators	-	
2014	RT	RT-Voyager	-	AHBM -- Automatic High Beam	System Tests	Aim Test	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Information	-	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Read Codes	-	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Erase codes	-	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Live Data	-	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Actuators	-	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Configure Information	-	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Language Preference	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Update Measurement Unit	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert Minder	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Program Dealer Contact Information	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Measurement Units	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Language Preference	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert System	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	Self Test	
2014	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	CCN Self Test	
2014	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2014	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2014	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2014	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2014	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2014	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2014	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2014	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2014	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	ECU Information	-	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Read Codes	-	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Erase codes	-	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Live Data	-	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Learn Side Test	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Ramp Van Configuration	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Close Test	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Open Test	
2014	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Actuate Drive Clutch Engage	
2014	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	ECU Information	-	
2014	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Read Codes	-	
2014	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Erase codes	-	
2014	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Live Data	-	
2014	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Actuators	-	
2014	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Special Functions	HIDT Calibration	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2014	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Information	-	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Read Codes	-	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Erase codes	-	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Live Data	-	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Actuators	-	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Configure Information	-	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Special Functions	Learn Latch Sector Home	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Cinch Test	
2014	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Release Test	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Information	-	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	Read Codes	-	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	Erase codes	-	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	Live Data	-	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	Special Functions	PEM Replace	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Locate Learned Keys	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Door Handle Verification Test	
2014	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	LF Antenna Verification Test	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	ECU Information	-	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Read Codes	-	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Erase codes	-	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Live Data	-	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Learn Side Test	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Ramp Van Configuration	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Close Test	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Open Test	
2014	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Actuate Drive Clutch Engage	
2014	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2014	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2014	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2014	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Information	-	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Read Codes	-	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Erase codes	-	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Live Data	-	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Actuators	-	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Close Position	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Open Position	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Ramp Van Configuration	
2014	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	System Tests	Latch Home Sector Test	
2014	RT	RT-Voyager	-	DVD -- DVD Changer	ECU Information	-	
2014	RT	RT-Voyager	-	DVD -- DVD Changer	Read Codes	-	
2014	RT	RT-Voyager	-	DVD -- DVD Changer	Erase codes	-	
2014	RT	RT-Voyager	-	DVD -- DVD Changer	Live Data	-	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Standardization	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2014	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	
2014	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Information	-	
2014	RT	RT-Voyager	-	HSM -- Heated Seat Module	Read Codes	-	
2014	RT	RT-Voyager	-	HSM -- Heated Seat Module	Erase codes	-	
2014	RT	RT-Voyager	-	HSM -- Heated Seat Module	Live Data	-	
2014	RT	RT-Voyager	-	HSM -- Heated Seat Module	Actuators	-	
2014	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2014	RT	RT-Voyager	-	HSM -- Heated Seat Module	Special Functions	Heated Steering Wheel Configuration	
2014	RT	RT-Voyager	-	PTS -- Parktronics	ECU Information	-	
2014	RT	RT-Voyager	-	PTS -- Parktronics	Read Codes	-	
2014	RT	RT-Voyager	-	PTS -- Parktronics	Erase codes	-	
2014	RT	RT-Voyager	-	PTS -- Parktronics	Live Data	-	
2014	RT	RT-Voyager	-	PTS -- Parktronics	Actuators	-	
2014	RT	RT-Voyager	-	PTS -- Parktronics	ECU Configure Information	-	
2014	RT	RT-Voyager	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2014	RT	RT-Voyager	-	PTS -- Parktronics	System Tests	System Wiring Test	
2014	RT	RT-Voyager	-	VES3 -- Last Row Screen	ECU Information	-	
2014	RT	RT-Voyager	-	VES3 -- Last Row Screen	Read Codes	-	
2014	RT	RT-Voyager	-	VES3 -- Last Row Screen	Erase codes	-	
2014	RT	RT-Voyager	-	VES3 -- Last Row Screen	Live Data	-	
2014	RT	RT-Voyager	-	VES3 -- Last Row Screen	Actuators	-	
2014	RT	RT-Voyager	-	VES3 -- Last Row Screen	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	BF	BF-Fiat 500L	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	BF	BF-Fiat 500L	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	BF	BF-Fiat 500L	-	PCM -- Powertrain Control Module	Live Data	-	
2015	BF	BF-Fiat 500L	-	PCM -- Powertrain Control Module	Actuators	-	
2015	BF	BF-Fiat 500L	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Freeze Frame	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Special Functions	Pressure Sensor Calibration	
2015	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Special Functions	Reset gear configuration	
2015	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC FGA Enable Seatbelt Minder Chime	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC FGA Enable Seatbelt Minder Chime	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Live Data	-	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Actuators	-	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	TPM FGA PROXI Configuration	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Special Functions	Update Front and Rear Axle Nominal Tire Pressure Values	
2015	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Information	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Read Codes	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Erase codes	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Live Data	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Actuators	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Rain and Automatic Lights Sensors check	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Enable Front Fog Lamp Dropout	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Configure Door Locks	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Information	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Read Codes	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Erase codes	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Live Data	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Actuators	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Rain and Automatic Lights Sensors check	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Enable Front Fog Lamp Dropout	
2015	BF	BF-Fiat 500L	-	BCM -- Body Controller	Special Functions	Configure Door Locks	
2015	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	ECU Information	-	
2015	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Read Codes	-	
2015	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Erase codes	-	
2015	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Live Data	-	
2015	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Live Data	-	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Actuators	-	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Special Functions	Audio Test	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2015	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2015	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	ECU Information	-	
2015	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Read Codes	-	
2015	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Erase codes	-	
2015	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Live Data	-	
2015	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	ECU Information	-	
2015	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Read Codes	-	
2015	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Erase codes	-	
2015	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Live Data	-	
2015	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Actuators	-	
2015	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Information	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Read Codes	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Erase codes	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Live Data	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Actuators	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Information	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Read Codes	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Erase codes	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Live Data	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Actuators	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2015	CM	CM-Viaggio	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	ECU Information	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Read Codes	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Erase codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Live Data	-	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacemnet	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2015	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2015	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2015	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2015	CM	CM-Viaggio	-	PAM -- Park Assist Module	ECU Information	-	
2015	CM	CM-Viaggio	-	PAM -- Park Assist Module	Read Codes	-	
2015	CM	CM-Viaggio	-	PAM -- Park Assist Module	Erase codes	-	
2015	CM	CM-Viaggio	-	PAM -- Park Assist Module	Live Data	-	
2015	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2015	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2015	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	ECU Information	-	
2015	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2015	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2015	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Live Data	-	
2015	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2015	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2015	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2015	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2015	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	ECU Information	-	
2015	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Read Codes	-	
2015	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Erase codes	-	
2015	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Live Data	-	
2015	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	ECU Information	-	
2015	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Read Codes	-	
2015	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Erase codes	-	
2015	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Live Data	-	
2015	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Actuators	-	
2015	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	ECU Information	-	
2015	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Read Codes	-	
2015	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Erase codes	-	
2015	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Live Data	-	
2015	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Actuators	-	
2015	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2015	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2015	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Actuators	-	
2015	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2015	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Information	-	
2015	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Read Codes	-	
2015	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Erase codes	-	
2015	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Live Data	-	
2015	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2015	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	ECU Information	-	
2015	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Read Codes	-	
2015	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Erase codes	-	
2015	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Live Data	-	
2015	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Actuators	-	
2015	CM	CM-Viaggio	-	EDM -- External Disc Module	ECU Information	-	
2015	CM	CM-Viaggio	-	EDM -- External Disc Module	Read Codes	-	
2015	CM	CM-Viaggio	-	EDM -- External Disc Module	Erase codes	-	
2015	CM	CM-Viaggio	-	EDM -- External Disc Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learned functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Motorised throttle learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Motorised throttle replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Live Data	-	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Actuators	-	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Clutch Replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	ECO function switch Replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Pump Relay Replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electro valve replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	Special Functions	Tunnel lever Replacement	
2015	DB	DB-Doblo	-	TCM -- Transmission Control Module	System Tests	Self - learnt functions reset	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Special Functions	Pressure sensor calibration	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Special Functions	Inlet Valve Calibration	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Special Functions	Pilot Valve calibration	
2015	DB	DB-Doblo	-	ABS -- Anti Lock Brakes	Special Functions	Steering angle sensor calibration	
2015	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	DB	DB-Doblo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Instrument Panel Cluster Replacement	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2015	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Live Data	-	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Actuators	-	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	ECU SERIAL NUMBER Management	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Rolls Test	
2015	DB	DB-Doblo	-	TPM -- Tire Pressure Monitor	Special Functions	Write Front and Rear axle nominal tire pressure	
2015	DB	DB-Doblo	-	BCM -- Body Controller	ECU Information	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Read Codes	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Erase codes	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Live Data	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Actuators	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	ECU Configure Information	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Program Keys	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2015	DB	DB-Doblo	-	BCM -- Body Controller	ECU Information	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Read Codes	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Erase codes	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Live Data	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Actuators	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	ECU Configure Information	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Program Keys	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2015	DB	DB-Doblo	-	BCM -- Body Controller	ECU Information	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Read Codes	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Erase codes	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Live Data	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Actuators	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	ECU Configure Information	-	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Body Blinking Lights Configuration	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	Program Keys	
2015	DB	DB-Doblo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2015	DB	DB-Doblo	-	RADIO -- Radio	ECU Information	-	
2015	DB	DB-Doblo	-	RADIO -- Radio	Read Codes	-	
2015	DB	DB-Doblo	-	RADIO -- Radio	Erase codes	-	
2015	DB	DB-Doblo	-	RADIO -- Radio	Live Data	-	
2015	DB	DB-Doblo	-	RADIO -- Radio	Actuators	-	
2015	DB	DB-Doblo	-	RADIO -- Radio	ECU Configure Information	-	
2015	DB	DB-Doblo	-	RADIO -- Radio	Special Functions	Audio test for subwoofer specific	
2015	DB	DB-Doblo	-	RADIO -- Radio	Special Functions	Power on and disable user inputs	
2015	DB	DB-Doblo	-	RADIO -- Radio	Special Functions	Reset Parameters to Default	
2015	DB	DB-Doblo	-	RADIO -- Radio	System Tests	Power Down	
2015	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	DB	DB-Doblo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Flap actuators learning test	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio Test	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2015	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	ECU Information	-	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Read Codes	-	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Erase codes	-	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Live Data	-	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Enabling	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trail ECU absence	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Special Functions	Trail ECU presence	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	ECU Information	-	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Read Codes	-	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Erase codes	-	
2015	DB	DB-Doblo	-	PAM -- Park Assist Module	Live Data	-	
2015	DB	DB-Doblo	-	AHM -- Additional Heater Module	ECU Information	-	
2015	DB	DB-Doblo	-	AHM -- Additional Heater Module	Read Codes	-	
2015	DB	DB-Doblo	-	AHM -- Additional Heater Module	Erase codes	-	
2015	DB	DB-Doblo	-	AHM -- Additional Heater Module	Live Data	-	
2015	DB	DB-Doblo	-	AHM -- Additional Heater Module	Actuators	-	
2015	DB	DB-Doblo	-	AHM -- Additional Heater Module	Special Functions	Self-Learning Working Mode	
2015	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2015	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2015	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2015	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Live Data	-	
2015	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Actuators	-	
2015	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Special Functions	Audio System Test	
2015	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Special Functions	ECU Restart routine	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	ESIM Forced Monitor Test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fan cooling activation	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	MultiAir Rolling Finger Replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil Temperature Sensor Replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Replacement UNIAIR module	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Supercharging system components replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Waste Gate valve command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s reprogramming	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Downstream lambda probe replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	EGR low pressure valve replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	NOx replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Upstream lambda probe replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	EGR low pressure valve test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Read second level micro safety reset event	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	EGR high pressure valve replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Electrical Variable Geometry Turbo and/or turbo position sensor Replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Electrical VTG actuator test	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Read second level micro safety reset event	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Information	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Read Codes	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Erase codes	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Live Data	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Event Data	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Quick learn	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	TCM VIN Verification	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Value Body Solenoid Learn	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Information	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Read Codes	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Erase codes	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Live Data	-	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Range selection electrovalve command (PPVS)	
2015	FB	FB-500X	-	DTCM -- Drive Train Control Module	ECU Information	-	
2015	FB	FB-500X	-	DTCM -- Drive Train Control Module	Read Codes	-	
2015	FB	FB-500X	-	DTCM -- Drive Train Control Module	Erase codes	-	
2015	FB	FB-500X	-	DTCM -- Drive Train Control Module	Live Data	-	
2015	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	2WD Dyno Mode	
2015	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	On Demand Self Test	
2015	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	PTU Replacement	
2015	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	RDU Replacement	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Pressure Sensor Calibration	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Electric Park Brake management	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	TPMS Calibration	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	ECU Substitution	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Pressure Sensor Calibration	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Electric Park Brake management	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	TPMS Calibration	
2015	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	ECU Substitution	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2015	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2015	FB	FB-500X	-	BCM -- Body Controller	ECU Information	-	
2015	FB	FB-500X	-	BCM -- Body Controller	Read Codes	-	
2015	FB	FB-500X	-	BCM -- Body Controller	Erase codes	-	
2015	FB	FB-500X	-	BCM -- Body Controller	Live Data	-	
2015	FB	FB-500X	-	BCM -- Body Controller	Actuators	-	
2015	FB	FB-500X	-	BCM -- Body Controller	ECU Configure Information	-	
2015	FB	FB-500X	-	BCM -- Body Controller	ECU Information	-	
2015	FB	FB-500X	-	BCM -- Body Controller	Read Codes	-	
2015	FB	FB-500X	-	BCM -- Body Controller	Erase codes	-	
2015	FB	FB-500X	-	BCM -- Body Controller	Live Data	-	
2015	FB	FB-500X	-	BCM -- Body Controller	Actuators	-	
2015	FB	FB-500X	-	BCM -- Body Controller	ECU Configure Information	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2015	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2015	FB	FB-500X	-	AMP -- Amplifier	ECU Information	-	
2015	FB	FB-500X	-	AMP -- Amplifier	Read Codes	-	
2015	FB	FB-500X	-	AMP -- Amplifier	Erase codes	-	
2015	FB	FB-500X	-	AMP -- Amplifier	Live Data	-	
2015	FB	FB-500X	-	AMP -- Amplifier	Actuators	-	
2015	FB	FB-500X	-	AMP -- Amplifier	ECU Configure Information	-	
2015	FB	FB-500X	-	AMP -- Amplifier	System Tests	Audio Measure AC+DC	
2015	FB	FB-500X	-	AMP -- Amplifier	System Tests	Output Short Test	
2015	FB	FB-500X	-	AMP -- Amplifier	System Tests	Tone Test	
2015	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	ECU Information	-	
2015	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2015	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2015	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2015	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2015	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2015	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2015	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2015	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2015	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2015	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2015	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2015	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2015	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2015	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2015	FB	FB-500X	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2015	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2015	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2015	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Live Data	-	
2015	FB	FB-500X	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2015	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Special Functions	Service Single Pole Calibration	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	ECU Information	-	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	Read Codes	-	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	Erase codes	-	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	Live Data	-	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	Actuators	-	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Audio signal detection	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Power Down	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Power on and Disable User Input	
2015	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Clutch Pedal Learn	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset ECU	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2015	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	





**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	FF	FF-500	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	FF	FF-500	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	FF	FF-500	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	FF	FF-500	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	FF	FF-500	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	FF	FF-500	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	FF	FF-500	-	ABS -- Anti Lock Brakes	Special Functions	ABS Static Test	
2015	FF	FF-500	-	ABS -- Anti Lock Brakes	System Tests	Longitudinal G-Sensor Calibration Test	
2015	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	FF	FF-500	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Enable Seatbelt Minder Chime	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	Proxi Configuration	
2015	FF	FF-500	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Live Data	-	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Actuators	-	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Sensor Rolls Test Result	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Clear TPM Warnings	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	TPM FGA PROXI Configuration	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	Special Functions	Update Front and Rear Axle Nominal Tire Pressure Values	
2015	FF	FF-500	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2015	FF	FF-500	-	BCM -- Body Controller	ECU Information	-	
2015	FF	FF-500	-	BCM -- Body Controller	Read Codes	-	
2015	FF	FF-500	-	BCM -- Body Controller	Erase codes	-	
2015	FF	FF-500	-	BCM -- Body Controller	Live Data	-	
2015	FF	FF-500	-	BCM -- Body Controller	Actuators	-	
2015	FF	FF-500	-	BCM -- Body Controller	ECU Configure Information	-	
2015	FF	FF-500	-	BCM -- Body Controller	Special Functions	Erase and Program Keys	
2015	FF	FF-500	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2015	FF	FF-500	-	BCM -- Body Controller	Special Functions	Initialize Power Top	
2015	FF	FF-500	-	EPS -- Electric Power Steering	ECU Information	-	
2015	FF	FF-500	-	EPS -- Electric Power Steering	Read Codes	-	
2015	FF	FF-500	-	EPS -- Electric Power Steering	Erase codes	-	
2015	FF	FF-500	-	EPS -- Electric Power Steering	Live Data	-	
2015	FF	FF-500	-	EPS -- Electric Power Steering	Special Functions	Clear Steering Pull Compensation	
2015	FF	FF-500	-	EPS -- Electric Power Steering	Special Functions	Initialize EPS	
2015	FF	FF-500	-	PTS -- Parktronics	ECU Information	-	
2015	FF	FF-500	-	PTS -- Parktronics	Read Codes	-	
2015	FF	FF-500	-	PTS -- Parktronics	Erase codes	-	
2015	FF	FF-500	-	PTS -- Parktronics	Live Data	-	
2015	FF	FF-500	-	RADIO -- Radio	ECU Information	-	
2015	FF	FF-500	-	RADIO -- Radio	Read Codes	-	
2015	FF	FF-500	-	RADIO -- Radio	Erase codes	-	
2015	FF	FF-500	-	RADIO -- Radio	Live Data	-	
2015	FF	FF-500	-	RADIO -- Radio	Special Functions	RADIO PROXI Configuration	
2015	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	FF	FF-500	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	FF	FF-500	-	CTM -- Convergence Telematic Module	ECU Information	-	
2015	FF	FF-500	-	CTM -- Convergence Telematic Module	Read Codes	-	
2015	FF	FF-500	-	CTM -- Convergence Telematic Module	Erase codes	-	
2015	FF	FF-500	-	CTM -- Convergence Telematic Module	Live Data	-	
2015	FF	FF-500	-	CTM -- Convergence Telematic Module	Actuators	-	
2015	FF	FF-500	-	CTM -- Convergence Telematic Module	Special Functions	CTM Proxi Configuration	
2015	FF	FF-500	-	CTM -- Convergence Telematic Module	System Tests	Audio System Test	
2015	FF	FF-500	-	VTM -- Vehicle Tracking Module	ECU Information	-	
2015	FF	FF-500	-	VTM -- Vehicle Tracking Module	Read Codes	-	
2015	FF	FF-500	-	VTM -- Vehicle Tracking Module	Erase codes	-	
2015	FF	FF-500	-	VTM -- Vehicle Tracking Module	Live Data	-	
2015	FF	FF-500	-	VTM -- Vehicle Tracking Module	Special Functions	VTM transport mode status	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	ECU Information	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Read Codes	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Erase codes	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Live Data	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Actuators	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	ECU Information	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Read Codes	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Erase codes	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Live Data	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Actuators	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	ECU Information	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Read Codes	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Erase codes	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Live Data	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Actuators	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	ECU Information	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Read Codes	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Erase codes	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Live Data	-	
2015	GA	GA-Giulia	-	ECM -- Engine Control Module	Actuators	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	GA	GA-Giulia	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	GA	GA-Giulia	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	GA	GA-Giulia	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	GA	GA-Giulia	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	GA	GA-Giulia	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	GA	GA-Giulia	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	GA	GA-Giulia	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2015	GA	GA-Giulia	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2015	GA	GA-Giulia	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2015	GA	GA-Giulia	-	ETM -- Entertainment Telematic Module	Live Data	-	
2015	GA	GA-Giulia	-	ETM -- Entertainment Telematic Module	Actuators	-	
2015	GA	GA-Giulia	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2015	GA	GA-Giulia	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2015	GA	GA-Giulia	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2015	GA	GA-Giulia	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2015	GA	GA-Giulia	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2015	GA	GA-Giulia	-	AFLS -- Adaptive Front Lighting System	ECU Configure Information	-	
2015	GA	GA-Giulia	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2015	GA	GA-Giulia	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2015	GA	GA-Giulia	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2015	GA	GA-Giulia	-	ACC -- Adaptive Cruise Control	Live Data	-	
2015	GA	GA-Giulia	-	ACC -- Adaptive Cruise Control	Actuators	-	
2015	GA	GA-Giulia	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	Read Codes	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	Erase codes	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	ECU Information	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	Read Codes	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	Erase codes	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	Live Data	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	ECU Information	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	Read Codes	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	Erase codes	-	
2015	GA	GA-Giulia	-	PAM -- Park Assist Module	Live Data	-	
2015	GA	GA-Giulia	-	ESM -- Electronic Shifter	ECU Information	-	
2015	GA	GA-Giulia	-	ESM -- Electronic Shifter	Read Codes	-	
2015	GA	GA-Giulia	-	ESM -- Electronic Shifter	Erase codes	-	
2015	GA	GA-Giulia	-	ESM -- Electronic Shifter	Live Data	-	
2015	GA	GA-Giulia	-	ESM -- Electronic Shifter	Actuators	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	ECU Information	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	Read Codes	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	Erase codes	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	Live Data	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	Actuators	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	ECU Configure Information	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	ECU Information	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	Read Codes	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	Erase codes	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	Live Data	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	Actuators	-	
2015	GA	GA-Giulia	-	AMP -- Amplifier	ECU Configure Information	-	
2015	GA	GA-Giulia	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2015	GA	GA-Giulia	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2015	GA	GA-Giulia	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2015	GA	GA-Giulia	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2015	GA	GA-Giulia	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2015	GA	GA-Giulia	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2015	GA	GA-Giulia	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2015	GA	GA-Giulia	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2015	GA	GA-Giulia	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2015	GA	GA-Giulia	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2015	GA	GA-Giulia	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2015	GA	GA-Giulia	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2015	GA	GA-Giulia	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2015	GA	GA-Giulia	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2015	GA	GA-Giulia	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2015	GA	GA-Giulia	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2015	GA	GA-Giulia	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2015	GA	GA-Giulia	-	TTM -- Trailer tow module	ECU Information	-	
2015	GA	GA-Giulia	-	TTM -- Trailer tow module	Read Codes	-	
2015	GA	GA-Giulia	-	TTM -- Trailer tow module	Erase codes	-	
2015	GA	GA-Giulia	-	TTM -- Trailer tow module	Live Data	-	
2015	GA	GA-Giulia	-	TTM -- Trailer tow module	Actuators	-	
2015	GA	GA-Giulia	-	TBM -- Telematic Gateway Radio	ECU Information	-	
2015	GA	GA-Giulia	-	TBM -- Telematic Gateway Radio	Read Codes	-	
2015	GA	GA-Giulia	-	TBM -- Telematic Gateway Radio	Erase codes	-	
2015	GA	GA-Giulia	-	TBM -- Telematic Gateway Radio	Live Data	-	
2015	GA	GA-Giulia	-	TBM -- Telematic Gateway Radio	Actuators	-	
2015	GA	GA-Giulia	-	TBM -- Telematic Gateway Radio	ECU Configure Information	-	
2015	GA	GA-Giulia	-	AAML -- Active Aerodynamic Module Left	ECU Information	-	
2015	GA	GA-Giulia	-	AAML -- Active Aerodynamic Module Left	Read Codes	-	
2015	GA	GA-Giulia	-	AAML -- Active Aerodynamic Module Left	Erase codes	-	
2015	GA	GA-Giulia	-	AAML -- Active Aerodynamic Module Left	Live Data	-	
2015	GA	GA-Giulia	-	AAMR -- Active Aerodynamic Module Right	ECU Information	-	
2015	GA	GA-Giulia	-	AAMR -- Active Aerodynamic Module Right	Read Codes	-	
2015	GA	GA-Giulia	-	AAMR -- Active Aerodynamic Module Right	Erase codes	-	
2015	GA	GA-Giulia	-	AAMR -- Active Aerodynamic Module Right	Live Data	-	
2015	GA	GA-Giulia	-	ANC -- Active Noise Cancelation	Read Codes	-	
2015	GA	GA-Giulia	-	ANC -- Active Noise Cancelation	Erase codes	-	
2015	GA	GA-Giulia	-	ANC -- Active Noise Cancelation	ECU Information	-	
2015	GA	GA-Giulia	-	ANC -- Active Noise Cancelation	ECU Configure Information	-	
2015	GA	GA-Giulia	-	ANC -- Active Noise Cancelation	Actuators	-	
2015	GA	GA-Giulia	-	ANC -- Active Noise Cancelation	Live Data	-	
2015	GA	GA-Giulia	-	CDCM -- Chassis Domain Control Module	ECU Information	-	
2015	GA	GA-Giulia	-	CDCM -- Chassis Domain Control Module	Read Codes	-	
2015	GA	GA-Giulia	-	CDCM -- Chassis Domain Control Module	Erase codes	-	
2015	GA	GA-Giulia	-	CDCM -- Chassis Domain Control Module	Live Data	-	
2015	GA	GA-Giulia	-	CDCM -- Chassis Domain Control Module	Actuators	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	ECU Information	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Read Codes	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Erase codes	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Live Data	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Actuators	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	ECU Configure Information	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	ECU Information	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Read Codes	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Erase codes	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Live Data	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Actuators	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	ECU Information	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Read Codes	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Erase codes	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Live Data	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Actuators	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	ECU Configure Information	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	ECU Information	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Read Codes	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Erase codes	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Live Data	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	Actuators	-	
2015	GA	GA-Giulia	-	ECM2 -- Engine Control Module 2	ECU Configure Information	-	
2015	GA	GA-Giulia	-	EMCM -- Entertainment Multimedia Control Module	ECU Information	-	
2015	GA	GA-Giulia	-	EMCM -- Entertainment Multimedia Control Module	Read Codes	-	
2015	GA	GA-Giulia	-	EMCM -- Entertainment Multimedia Control Module	Erase codes	-	
2015	GA	GA-Giulia	-	EMCM -- Entertainment Multimedia Control Module	Live Data	-	
2015	GA	GA-Giulia	-	EMCM -- Entertainment Multimedia Control Module	Actuators	-	
2015	GA	GA-Giulia	-	EMCM -- Entertainment Multimedia Control Module	ECU Configure Information	-	
2015	GA	GA-Giulia	-	TMM -- Track Mapping Module	Read Codes	-	
2015	GA	GA-Giulia	-	TMM -- Track Mapping Module	Erase codes	-	
2015	GA	GA-Giulia	-	TVM -- Torque Vectoring Module	ECU Information	-	
2015	GA	GA-Giulia	-	TVM -- Torque Vectoring Module	Read Codes	-	
2015	GA	GA-Giulia	-	TVM -- Torque Vectoring Module	Erase codes	-	
2015	GA	GA-Giulia	-	TVM -- Torque Vectoring Module	Live Data	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Event Data	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test (Non-EFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	O2 System Heater Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Live Data	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Actuators	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Option	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2015	JF	JF-Freemont	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Information	-	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Read Codes	-	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Erase codes	-	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Live Data	-	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Actuators	-	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Event Data	-	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2015	JF	JF-Freemont	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2015	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Information	-	
2015	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Read Codes	-	
2015	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Erase codes	-	
2015	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Live Data	-	
2015	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Actuators	-	
2015	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2015	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2015	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2015	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Special Functions	Rollover Detection	
2015	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2015	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Live Data	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Live Data	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2015	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2015	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Change country code	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Change country code	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Calibration	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size(JF)	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Program Tire Size(LX)	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2015	JF	JF-Freemont	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2015	JF	JF-Freemont	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2015	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Information	-	
2015	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Read Codes	-	
2015	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Erase codes	-	
2015	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Live Data	-	
2015	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Configure Information	-	
2015	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	Enable/Disable Front Seat Video	
2015	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Special Functions	TGW Tone Test	
2015	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	System Tests	Anti-theft Override Test	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2015	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2015	JF	JF-Freemont	-	PTS -- Parktronics	ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	JF	JF-Freemont	-	PTS -- Parktronics	Read Codes	-	
2015	JF	JF-Freemont	-	PTS -- Parktronics	Erase codes	-	
2015	JF	JF-Freemont	-	PTS -- Parktronics	Live Data	-	
2015	JF	JF-Freemont	-	PTS -- Parktronics	Actuators	-	
2015	JF	JF-Freemont	-	PTS -- Parktronics	ECU Configure Information	-	
2015	JF	JF-Freemont	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2015	JF	JF-Freemont	-	PTS -- Parktronics	System Tests	System Wiring Test	
2015	JF	JF-Freemont	-	ICS -- Integrated Center Stack	ECU Information	-	
2015	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Read Codes	-	
2015	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Erase codes	-	
2015	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Live Data	-	
2015	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Actuators	-	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2015	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2015	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	ECU Information	-	
2015	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Read Codes	-	
2015	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Erase codes	-	
2015	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Live Data	-	
2015	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Information	-	
2015	JF	JF-Freemont	-	DDM -- Driver Door Module	Read Codes	-	
2015	JF	JF-Freemont	-	DDM -- Driver Door Module	Erase codes	-	
2015	JF	JF-Freemont	-	DDM -- Driver Door Module	Live Data	-	
2015	JF	JF-Freemont	-	DDM -- Driver Door Module	Actuators	-	
2015	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Information	-	
2015	JF	JF-Freemont	-	PDM -- Passenger Door Module	Read Codes	-	
2015	JF	JF-Freemont	-	PDM -- Passenger Door Module	Erase codes	-	
2015	JF	JF-Freemont	-	PDM -- Passenger Door Module	Live Data	-	
2015	JF	JF-Freemont	-	PDM -- Passenger Door Module	Actuators	-	
2015	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize Siren	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Self Test	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM and Siren Communication Test	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Siren Test	
2015	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	System Tests	Ultrasonic Motion Detection Test	
2015	JF	JF-Freemont	-	AMP -- Amplifier	ECU Information	-	
2015	JF	JF-Freemont	-	AMP -- Amplifier	Read Codes	-	
2015	JF	JF-Freemont	-	AMP -- Amplifier	Erase codes	-	
2015	JF	JF-Freemont	-	AMP -- Amplifier	Live Data	-	
2015	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Input Test	
2015	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Microphone Tone Test	
2015	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Microphone Output Short Test	
2015	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Output Short Test	
2015	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Software Test	
2015	JF	JF-Freemont	-	AMP -- Amplifier	System Tests	AMP Tone Test	
2015	JF	JF-Freemont	-	HFM -- Hands Free Module	ECU Information	-	
2015	JF	JF-Freemont	-	HFM -- Hands Free Module	Read Codes	-	
2015	JF	JF-Freemont	-	HFM -- Hands Free Module	Erase codes	-	
2015	JF	JF-Freemont	-	HFM -- Hands Free Module	Live Data	-	
2015	JF	JF-Freemont	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2015	JF	JF-Freemont	-	VES3 -- Last Row Screen	ECU Information	-	
2015	JF	JF-Freemont	-	VES3 -- Last Row Screen	Read Codes	-	
2015	JF	JF-Freemont	-	VES3 -- Last Row Screen	Erase codes	-	
2015	JF	JF-Freemont	-	VES3 -- Last Row Screen	Live Data	-	
2015	JF	JF-Freemont	-	VES3 -- Last Row Screen	Actuators	-	
2015	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Information	-	
2015	JF	JF-Freemont	-	HSM -- Heated Seat Module	Read Codes	-	
2015	JF	JF-Freemont	-	HSM -- Heated Seat Module	Erase codes	-	
2015	JF	JF-Freemont	-	HSM -- Heated Seat Module	Live Data	-	
2015	JF	JF-Freemont	-	HSM -- Heated Seat Module	Actuators	-	
2015	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2015	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2015	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2015	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2015	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2015	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2015	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	ECU Information	-	
2015	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	Read Codes	-	
2015	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	Erase codes	-	
2015	JF	JF-Freemont	-	VTM -- Vehicle Tracking Module	Live Data	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Event Data	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Live Data	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Actuators	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Air Flow Meter Replace	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Compression Tes	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	DPF Reset Optiont	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	ECU Replacement Without Value Transfer	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Injector Quantity Adjustment	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor replace	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Program Variant Coding	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of Lambda Values	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Oil Change Indicator	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Zero Fuel Quantity Calibration	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Service Diesel Particulate Filter Regeneration	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Clear DEF Pump Learned Offset Values	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	O2 Sensor Replace	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset Error Free Operation Time to 40 Hours	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of O2 Values	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Reset of SCR Long Term Adaptation Factor	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	SCR System Catalyst Reset	
2015	LX	LX-Thema	-	PCM -- Powertrain Control Module	Special Functions	Throttle Valve Learn	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Event Data	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	QuickLearn	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Event Data	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	QuickLearn	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Information	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Read Codes	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Erase codes	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Live Data	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Initialize EGS-52	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Store Learned Adaptives	
2015	LX	LX-Thema	-	TCM -- Transmission Control Module	Special Functions	Reset Learned Adaptives	
2015	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	LX	LX-Thema	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2015	LX	LX-Thema	-	ABS -- Anti Lock Brakes	Special Functions	Brake Pedal Calibration	
2015	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2015	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2015	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2015	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2015	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2015	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2015	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2015	LX	LX-Thema	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2015	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2015	LX	LX-Thema	-	IPC -- Instrument Panel Cluster	System Tests	IPC Self Test	
2015	LX	LX-Thema	-	PTS -- Parktronics	ECU Information	-	
2015	LX	LX-Thema	-	PTS -- Parktronics	Read Codes	-	
2015	LX	LX-Thema	-	PTS -- Parktronics	Erase codes	-	
2015	LX	LX-Thema	-	PTS -- Parktronics	Live Data	-	
2015	LX	LX-Thema	-	PTS -- Parktronics	ECU Configure Information	-	
2015	LX	LX-Thema	-	PTS -- Parktronics	System Tests	System Wiring Test	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2015	LX	LX-Thema	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2015	LX	LX-Thema	-	DDM -- Driver Door Module	ECU Information	-	
2015	LX	LX-Thema	-	DDM -- Driver Door Module	Read Codes	-	
2015	LX	LX-Thema	-	DDM -- Driver Door Module	Erase codes	-	
2015	LX	LX-Thema	-	DDM -- Driver Door Module	Live Data	-	
2015	LX	LX-Thema	-	DDM -- Driver Door Module	Actuators	-	
2015	LX	LX-Thema	-	DDM -- Driver Door Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	ADCM -- Active Damping Control Module	ECU Information	-	
2015	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Read Codes	-	
2015	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Erase codes	-	
2015	LX	LX-Thema	-	ADCM -- Active Damping Control Module	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2015	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2015	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2015	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Live Data	-	
2015	LX	LX-Thema	-	ACC -- Adaptive Cruise Control	Special Functions	ACC Aim Mode - Auto Alignment	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Information	-	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Read Codes	-	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Erase codes	-	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Live Data	-	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Actuators	-	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Erase Ignition FOBs	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	View Recent Multi-Module VIN handshake Immobilizer Failures	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	RF-HUB Replace	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	Special Functions	Program Ignition FOBs	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Locate Learned Keys	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Door Handle Verification Test	
2015	LX	LX-Thema	-	RFH -- Radio Frequency Hub	System Tests	Immobilizer Antenna Test	
2015	LX	LX-Thema	-	HSM -- Heated Seat Module	ECU Information	-	
2015	LX	LX-Thema	-	HSM -- Heated Seat Module	Read Codes	-	
2015	LX	LX-Thema	-	HSM -- Heated Seat Module	Erase codes	-	
2015	LX	LX-Thema	-	HSM -- Heated Seat Module	Live Data	-	
2015	LX	LX-Thema	-	HSM -- Heated Seat Module	Actuators	-	
2015	LX	LX-Thema	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2015	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2015	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2015	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2015	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2015	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2015	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2015	LX	LX-Thema	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize Siren	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Self Test	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM and Siren Communication Test	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	ITM Siren Test	
2015	LX	LX-Thema	-	ITM -- Intrusion Transceiver Module	System Tests	Ultrasonic Motion Detection Test	
2015	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2015	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2015	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2015	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2015	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Actuators	-	
2015	LX	LX-Thema	-	AFLS -- Adaptive Front Lighting System	Special Functions	AFLS Calibration	
2015	LX	LX-Thema	-	RADIO -- Radio	ECU Information	-	
2015	LX	LX-Thema	-	RADIO -- Radio	Read Codes	-	
2015	LX	LX-Thema	-	RADIO -- Radio	Erase codes	-	
2015	LX	LX-Thema	-	RADIO -- Radio	Live Data	-	
2015	LX	LX-Thema	-	RADIO -- Radio	Actuators	-	
2015	LX	LX-Thema	-	RADIO -- Radio	ECU Configure Information	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Live Data	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Live Data	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	Special Functions	TPM Sensor Position Parameter Update	
2015	LX	LX-Thema	-	TPM -- Tire Pressure Monitor	System Tests	Sensor Rolls Test	
2015	LX	LX-Thema	-	BCM -- Body Controller	ECU Information	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Read Codes	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Erase codes	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Live Data	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Actuators	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	ECU Configure Information	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	ECU Configure Information	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Change country code	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Calibration	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size (JF)	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size (LX)	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2015	LX	LX-Thema	-	BCM -- Body Controller	ECU Information	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Read Codes	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Erase codes	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Live Data	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Actuators	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	LX	LX-Thema	-	BCM -- Body Controller	ECU Configure Information	-	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto Door Lock	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Auto High Beam Aim Test	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Change country code	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Calibration	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Light Rain Sensor Re-Adaption	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size(JF)	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Program Tire Size(LX)	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable	
2015	LX	LX-Thema	-	BCM -- Body Controller	Special Functions	Update Pressure Thresholds	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last Successful Remote Start Event Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Last VTA Trigger Cause Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Abort Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Enable Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View Remote Start Inhibit Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	View VTA Enable Data	
2015	LX	LX-Thema	-	BCM -- Body Controller	System Tests	Display LIN Part Numbers and Serial Numbers	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Actuators	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	ECU Information	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Read Codes	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Erase codes	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Live Data	-	
2015	LX	LX-Thema	-	ESM -- Electronic Shifter	Actuators	-	
2015	LX	LX-Thema	-	AMP -- Amplifier	ECU Information	-	
2015	LX	LX-Thema	-	AMP -- Amplifier	Read Codes	-	
2015	LX	LX-Thema	-	AMP -- Amplifier	Erase codes	-	
2015	LX	LX-Thema	-	AMP -- Amplifier	Live Data	-	
2015	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Input Test	
2015	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Microphone Tone Test	
2015	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Microphone Output Short Test	
2015	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Output Short Test	
2015	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Software Test	
2015	LX	LX-Thema	-	AMP -- Amplifier	System Tests	AMP Tone Test	
2015	LX	LX-Thema	-	SCCM -- Steering Column Control Module	ECU Information	-	
2015	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Read Codes	-	
2015	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Erase codes	-	
2015	LX	LX-Thema	-	SCCM -- Steering Column Control Module	Live Data	-	
2015	LX	LX-Thema	-	SCCM -- Steering Column Control Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	PDM -- Passenger Door Module	ECU Information	-	
2015	LX	LX-Thema	-	PDM -- Passenger Door Module	Read Codes	-	
2015	LX	LX-Thema	-	PDM -- Passenger Door Module	Erase codes	-	
2015	LX	LX-Thema	-	PDM -- Passenger Door Module	Live Data	-	
2015	LX	LX-Thema	-	PDM -- Passenger Door Module	Actuators	-	
2015	LX	LX-Thema	-	PDM -- Passenger Door Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	FFCM -- Forward Facing Camera Module	ECU Information	-	
2015	LX	LX-Thema	-	FFCM -- Forward Facing Camera Module	Read Codes	-	
2015	LX	LX-Thema	-	FFCM -- Forward Facing Camera Module	Erase codes	-	
2015	LX	LX-Thema	-	FFCM -- Forward Facing Camera Module	Live Data	-	
2015	LX	LX-Thema	-	FFCM -- Forward Facing Camera Module	ECU Information	-	
2015	LX	LX-Thema	-	FFCM -- Forward Facing Camera Module	Read Codes	-	
2015	LX	LX-Thema	-	FFCM -- Forward Facing Camera Module	Erase codes	-	
2015	LX	LX-Thema	-	FFCM -- Forward Facing Camera Module	Live Data	-	
2015	LX	LX-Thema	-	EPS -- Electric Power Steering	ECU Information	-	
2015	LX	LX-Thema	-	EPS -- Electric Power Steering	Read Codes	-	
2015	LX	LX-Thema	-	EPS -- Electric Power Steering	Erase codes	-	
2015	LX	LX-Thema	-	EPS -- Electric Power Steering	Live Data	-	
2015	LX	LX-Thema	-	EPS -- Electric Power Steering	ECU Information	-	
2015	LX	LX-Thema	-	EPS -- Electric Power Steering	Read Codes	-	
2015	LX	LX-Thema	-	EPS -- Electric Power Steering	Erase codes	-	
2015	LX	LX-Thema	-	EPS -- Electric Power Steering	Live Data	-	
2015	LX	LX-Thema	-	DTCM -- Drive Train Control Module	ECU Information	-	
2015	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Read Codes	-	
2015	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Erase codes	-	
2015	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Live Data	-	
2015	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Actuators	-	
2015	LX	LX-Thema	-	DTCM -- Drive Train Control Module	Special Functions	Read Digital Encoder Channels	
2015	LX	LX-Thema	-	ICS -- Integrated Center Stack	ECU Information	-	
2015	LX	LX-Thema	-	ICS -- Integrated Center Stack	Read Codes	-	
2015	LX	LX-Thema	-	ICS -- Integrated Center Stack	Erase codes	-	
2015	LX	LX-Thema	-	ICS -- Integrated Center Stack	Live Data	-	
2015	LX	LX-Thema	-	ICS -- Integrated Center Stack	Actuators	-	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	MSMD Self Test	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Standardization	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	
2015	LX	LX-Thema	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Clutch Pedal Learn	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	ECM Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Immobilizer Unlock Function	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Alcool	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Gasoline	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Learning	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset adaptive parameter	
2015	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset vehicle configuration	











## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	Special Functions	Program Keys	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	Special Functions	Read Proxi	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	Special Functions	Write proxi procedure	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Check Antilt Sensor	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Check Siren	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Check Volumetric Sensors	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Lock doors command	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Rear Windows Washer	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Request Check	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Siren command	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Unlock doors command	
2015	NU	NU-Novo Uno FL	-	BCM -- Body Controller	System Tests	Windshield Washer	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Live Data	-	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit Bleed	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit depressurization	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Learn Clutches Contact Point	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Learn long acceleration Signal	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	MTA Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Quick Learn	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Replacement MTA With Value Transfer	
2015	NU	NU-Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Reset of Data group	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis X Command	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis Y Command	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Fold Mirror	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis X Command	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis Y Command	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Unfold Mirror	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis X Command	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis Y Command	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Fold Mirror	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis X Command	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis Y Command	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Unfold Mirror	
2015	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2015	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	Live Data	-	
2015	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	Special Functions	PAM Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	Special Functions	BSM Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	ABS -- Anti Lock Brakes	Special Functions	BSM Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	NU	NU-Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Special Functions	ORC Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Oil Service Reset	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Service Reset	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Write Odometer	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Proxi Alignment	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Oil Service Reset	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Service Reset	
2015	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Write Odometer	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Information	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Read Codes	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Erase codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Live Data	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Actuators	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Information	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Read Codes	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Erase codes	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Live Data	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Actuators	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2015	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacemnet	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command(1st,4th,5th,6th)	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacemnet	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command(1st,4th,5th,6th)	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2015	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2015	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2015	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2015	OT	OT-Ottimo	-	PAM -- Park Assist Module	ECU Information	-	
2015	OT	OT-Ottimo	-	PAM -- Park Assist Module	Read Codes	-	
2015	OT	OT-Ottimo	-	PAM -- Park Assist Module	Erase codes	-	
2015	OT	OT-Ottimo	-	PAM -- Park Assist Module	Live Data	-	
2015	OT	OT-Ottimo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2015	OT	OT-Ottimo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2015	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2015	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2015	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2015	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Live Data	-	
2015	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2015	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	ECU Information	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	Read Codes	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	Erase codes	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	Live Data	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	Actuators	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	ECU Information	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	Read Codes	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	Erase codes	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	Live Data	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	Actuators	-	
2015	OT	OT-Ottimo	-	RADIO -- Radio	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2015	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2015	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	ECU Information	-	
2015	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Read Codes	-	
2015	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Erase codes	-	
2015	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Live Data	-	
2015	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Information	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Read Codes	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Erase codes	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Live Data	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Actuators	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Information	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Read Codes	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Erase codes	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Live Data	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Actuators	-	
2015	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	ECU Information	-	
2015	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Read Codes	-	
2015	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Erase codes	-	
2015	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Actuators	-	
2015	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2015	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2015	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2015	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2015	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2015	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2015	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Live Data	-	
2015	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Actuators	-	
2015	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2015	OT	OT-Ottimo	-	ESM -- Electronic Shifter	ECU Information	-	
2015	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Read Codes	-	
2015	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Erase codes	-	
2015	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Live Data	-	
2015	OT	OT-Ottimo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2015	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	ECU Information	-	
2015	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Read Codes	-	
2015	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Erase codes	-	
2015	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Live Data	-	
2015	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Actuators	-	
2015	OT	OT-Ottimo	-	EDM -- External Disc Module	ECU Information	-	
2015	OT	OT-Ottimo	-	EDM -- External Disc Module	Read Codes	-	
2015	OT	OT-Ottimo	-	EDM -- External Disc Module	Erase codes	-	
2015	OT	OT-Ottimo	-	EDM -- External Disc Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learn functions reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2015	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Read Codes	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2015	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2015	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2015	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Live Data	-	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Live Data	-	
2015	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Event Data	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Diesel Particulate Filter replacement	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Fuel mean value adaption initialization	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	IMA quick calibration	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor 1 initialization	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Oxidation catalyst initialization	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Request anti-slugging for Air Condition Compressor	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	program variant coding	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure control switchover	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TIPM Enable Emissions Rolls Test mode	
2015	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Compression Test	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Information	-	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Read Codes	-	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Erase codes	-	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Live Data	-	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Actuators	-	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Event Data	-	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2015	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2015	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2015	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2015	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2015	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2015	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2015	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2015	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2015	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2015	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2015	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2015	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2015	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2015	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2015	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2015	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2015	RT	RT-Voyager	-	SUNR -- Sunroof	ECU Information	-	
2015	RT	RT-Voyager	-	SUNR -- Sunroof	Read Codes	-	
2015	RT	RT-Voyager	-	SUNR -- Sunroof	Erase codes	-	
2015	RT	RT-Voyager	-	SUNR -- Sunroof	Live Data	-	
2015	RT	RT-Voyager	-	SUNR -- Sunroof	Actuators	-	
2015	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Information	-	
2015	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Read Codes	-	
2015	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Erase codes	-	
2015	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Live Data	-	
2015	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Actuators	-	
2015	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Configure Information	-	
2015	RT	RT-Voyager	-	DMFR -- Door Module Front Right	ECU Information	-	
2015	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Read Codes	-	
2015	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Erase codes	-	
2015	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Live Data	-	
2015	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Actuators	-	
2015	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Information	-	
2015	RT	RT-Voyager	-	HSM -- Heated Seat Module	Read Codes	-	
2015	RT	RT-Voyager	-	HSM -- Heated Seat Module	Erase codes	-	
2015	RT	RT-Voyager	-	HSM -- Heated Seat Module	Live Data	-	
2015	RT	RT-Voyager	-	HSM -- Heated Seat Module	Actuators	-	
2015	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	HSM -- Heated Seat Module	Special Functions	Heated Steering Wheel Configuration	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2015	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2015	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2015	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2015	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2015	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM and Siren Communication Test	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Ultrasonic Motion Detection Test	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize ITM	
2015	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	System Tests	Siren Test	
2015	RT	RT-Voyager	-	AHBM -- Automatic High Beam	ECU Information	-	
2015	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Read Codes	-	
2015	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Erase codes	-	
2015	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Live Data	-	
2015	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Actuators	-	
2015	RT	RT-Voyager	-	AHBM -- Automatic High Beam	System Tests	Aim Test	
2015	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Information	-	
2015	RT	RT-Voyager	-	CGW -- Central Gateway	Read Codes	-	
2015	RT	RT-Voyager	-	CGW -- Central Gateway	Erase codes	-	
2015	RT	RT-Voyager	-	CGW -- Central Gateway	Live Data	-	
2015	RT	RT-Voyager	-	CGW -- Central Gateway	Actuators	-	
2015	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Configure Information	-	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	ECU Information	-	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Read Codes	-	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Erase codes	-	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Live Data	-	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Learn Side Test	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Ramp Van Configuration	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Close Test	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Open Test	
2015	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Actuate Drive Clutch Engage	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Information	-	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	Read Codes	-	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	Erase codes	-	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	Live Data	-	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	Special Functions	PEM Replace	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Locate Learned Keys	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Door Handle Verification Test	
2015	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	LF Antenna Verification Test	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Information	-	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Read Codes	-	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Erase codes	-	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Live Data	-	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Actuators	-	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Close Position	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Open Position	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Ramp Van Configuration	
2015	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	System Tests	Latch Home Sector Test	
2015	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2015	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2015	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2015	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2015	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2015	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	ECU Information	-	
2015	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Read Codes	-	
2015	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Erase codes	-	
2015	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Live Data	-	
2015	RT	RT-Voyager	-	DVD -- DVD Changer	ECU Information	-	
2015	RT	RT-Voyager	-	DVD -- DVD Changer	Read Codes	-	
2015	RT	RT-Voyager	-	DVD -- DVD Changer	Erase codes	-	
2015	RT	RT-Voyager	-	DVD -- DVD Changer	Live Data	-	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Information	-	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Read Codes	-	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Erase codes	-	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Live Data	-	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Actuators	-	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Configure Information	-	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Special Functions	Learn Latch Sector Home	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Cinch Test	
2015	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Release Test	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Cool Down Test	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Front Blower State	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Rear Blower State	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2015	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	ECU Information	-	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Read Codes	-	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Erase codes	-	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Live Data	-	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Learn Side Test	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Ramp Van Configuration	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Close Test	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Open Test	
2015	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Actuate Drive Clutch Engage	
2015	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	ECU Information	-	
2015	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Read Codes	-	
2015	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Erase codes	-	
2015	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Live Data	-	
2015	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Actuators	-	
2015	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Special Functions	HIDT Calibration	
2015	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2015	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2015	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2015	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Live Data	-	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Tire Sensor ID with TPM Tool	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Turn off Gain Mode Override	
2015	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2015	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	Actuators	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2015	RT	RT-Voyager	-	RADIO -- Radio	ECU Configure Information	-	
2015	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2015	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2015	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2015	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2015	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Information	-	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Read Codes	-	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Erase codes	-	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Live Data	-	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Actuators	-	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Configure Information	-	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Language Preference	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Update Measurement Unit	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert Minder	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Program Dealer Contact Information	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Measurement Units	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Language Preference	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert System	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	Self Test	
2015	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	CCN Self Test	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Information	-	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Read Codes	-	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Erase codes	-	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Live Data	-	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Actuators	-	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Configure Information	-	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Special Functions	Learn Latch Sector Home	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Cinch Test	
2015	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Release Test	
2015	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Information	-	
2015	RT	RT-Voyager	-	VES2 -- Second Row Screen	Read Codes	-	
2015	RT	RT-Voyager	-	VES2 -- Second Row Screen	Erase codes	-	
2015	RT	RT-Voyager	-	VES2 -- Second Row Screen	Live Data	-	
2015	RT	RT-Voyager	-	VES2 -- Second Row Screen	Actuators	-	
2015	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Configure Information	-	
2015	RT	RT-Voyager	-	VES2 -- Second Row Screen	Special Functions	Headphone Test	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Standardization	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2015	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2016	CM	CM-Viaggio	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2016	CM	CM-Viaggio	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2016	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2016	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2016	CM	CM-Viaggio	-	PAM -- Park Assist Module	ECU Information	-	
2016	CM	CM-Viaggio	-	PAM -- Park Assist Module	Read Codes	-	
2016	CM	CM-Viaggio	-	PAM -- Park Assist Module	Erase codes	-	
2016	CM	CM-Viaggio	-	PAM -- Park Assist Module	Live Data	-	
2016	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2016	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2016	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	ECU Information	-	
2016	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2016	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2016	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Live Data	-	
2016	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2016	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2016	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2016	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2016	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	ECU Information	-	
2016	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Read Codes	-	
2016	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Erase codes	-	
2016	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Live Data	-	
2016	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	ECU Information	-	
2016	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Read Codes	-	
2016	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Erase codes	-	
2016	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Live Data	-	
2016	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Actuators	-	
2016	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	ECU Information	-	
2016	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Read Codes	-	
2016	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Erase codes	-	
2016	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Live Data	-	
2016	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Actuators	-	
2016	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2016	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2016	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Actuators	-	
2016	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2016	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Information	-	
2016	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Read Codes	-	
2016	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Erase codes	-	
2016	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Live Data	-	
2016	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	ECU Information	-	
2016	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Read Codes	-	
2016	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Erase codes	-	
2016	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Live Data	-	
2016	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Actuators	-	
2016	CM	CM-Viaggio	-	EDM -- External Disc Module	ECU Information	-	
2016	CM	CM-Viaggio	-	EDM -- External Disc Module	Read Codes	-	
2016	CM	CM-Viaggio	-	EDM -- External Disc Module	Erase codes	-	
2016	CM	CM-Viaggio	-	EDM -- External Disc Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	ESIM Forced Monitor Test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fan cooling activation	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	MultiAir Rolling Finger Replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil Temperature Sensor Replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Replacement UNIAIR module	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Supercharging system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Waste Gate valve command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fan cooling activation	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	MultiAir Rolling Finger Replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil Temperature Sensor Replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Replacement UNIAIR module	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Supercharging system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Waste Gate valve command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fan cooling activation	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	MultiAir Rolling Finger Replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil Temperature Sensor Replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Replacement UNIAIR module	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Supercharging system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Waste Gate valve command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s reprogramming	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Downstream lambda probe replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	EGR low pressure valve replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	NOx replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Upstream lambda probe replacement	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Read second level micro safety reset event	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	EGR high pressure valve replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Electrical Variable Geometry Turbo and/or turbo position sensor Replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Electrical VTG actuator test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	NOx replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Read second level micro safety reset event	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Information	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Read Codes	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Erase codes	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Live Data	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Event Data	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Quick learn	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	TCM VIN Verification	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Value Body Solenoid Learn	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Information	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Read Codes	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Erase codes	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Live Data	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Range selection electrovalve command (PPVS)	
2016	FB	FB-500X	-	DTCM -- Drive Train Control Module	ECU Information	-	
2016	FB	FB-500X	-	DTCM -- Drive Train Control Module	Read Codes	-	
2016	FB	FB-500X	-	DTCM -- Drive Train Control Module	Erase codes	-	
2016	FB	FB-500X	-	DTCM -- Drive Train Control Module	Live Data	-	
2016	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	2WD Dyno Mode	
2016	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	On Demand Self Test	
2016	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	PTU Replacement	
2016	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	RDU Replacement	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Pressure Sensor Calibration	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Electric Park Brake management	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	TPMS Calibration	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	ECU Substitution	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Pressure Sensor Calibration	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Electric Park Brake management	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	TPMS Calibration	
2016	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	ECU Substitution	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2016	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2016	FB	FB-500X	-	BCM -- Body Controller	ECU Information	-	
2016	FB	FB-500X	-	BCM -- Body Controller	Read Codes	-	
2016	FB	FB-500X	-	BCM -- Body Controller	Erase codes	-	
2016	FB	FB-500X	-	BCM -- Body Controller	Live Data	-	
2016	FB	FB-500X	-	BCM -- Body Controller	Actuators	-	
2016	FB	FB-500X	-	BCM -- Body Controller	ECU Configure Information	-	
2016	FB	FB-500X	-	BCM -- Body Controller	ECU Information	-	
2016	FB	FB-500X	-	BCM -- Body Controller	Read Codes	-	
2016	FB	FB-500X	-	BCM -- Body Controller	Erase codes	-	
2016	FB	FB-500X	-	BCM -- Body Controller	Live Data	-	
2016	FB	FB-500X	-	BCM -- Body Controller	Actuators	-	
2016	FB	FB-500X	-	BCM -- Body Controller	ECU Configure Information	-	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH immobilizer antenna test	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH locate learned keys	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM sensor rolls tests	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM Update FF FR Axle Nom Tire Press Val	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left front tire sensor Id	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left rear tire sensor Id	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right front tire sensor Id	
2016	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right rear tire sensor Id	
2016	FB	FB-500X	-	ESL -- Electronic Steering Lock	ECU Information	-	
2016	FB	FB-500X	-	ESL -- Electronic Steering Lock	Read Codes	-	
2016	FB	FB-500X	-	ESL -- Electronic Steering Lock	Erase codes	-	
2016	FB	FB-500X	-	ESL -- Electronic Steering Lock	Live Data	-	
2016	FB	FB-500X	-	EPS -- Electric Power Steering	ECU Information	-	
2016	FB	FB-500X	-	EPS -- Electric Power Steering	Read Codes	-	
2016	FB	FB-500X	-	EPS -- Electric Power Steering	Erase codes	-	
2016	FB	FB-500X	-	EPS -- Electric Power Steering	Live Data	-	
2016	FB	FB-500X	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2016	FB	FB-500X	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2016	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Live Data	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Actuators	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Special Functions	Active alignment procedure: radar calibration.	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Live Data	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Actuators	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2016	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Special Functions	Active alignment procedure: radar calibration.	
2016	FB	FB-500X	-	PAM -- Park Assist Module	ECU Information	-	
2016	FB	FB-500X	-	PAM -- Park Assist Module	Read Codes	-	
2016	FB	FB-500X	-	PAM -- Park Assist Module	Erase codes	-	
2016	FB	FB-500X	-	PAM -- Park Assist Module	Live Data	-	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	FB	FB-500X	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2016	FB	FB-500X	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	FB	FB-500X	-	AMP -- Amplifier	ECU Information	-	
2016	FB	FB-500X	-	AMP -- Amplifier	Read Codes	-	
2016	FB	FB-500X	-	AMP -- Amplifier	Erase codes	-	
2016	FB	FB-500X	-	AMP -- Amplifier	Live Data	-	
2016	FB	FB-500X	-	AMP -- Amplifier	Actuators	-	
2016	FB	FB-500X	-	AMP -- Amplifier	ECU Configure Information	-	
2016	FB	FB-500X	-	AMP -- Amplifier	System Tests	Audio Measure AC+DC	
2016	FB	FB-500X	-	AMP -- Amplifier	System Tests	Output Short Test	
2016	FB	FB-500X	-	AMP -- Amplifier	System Tests	Tone Test	
2016	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	ECU Information	-	
2016	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2016	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2016	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2016	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2016	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2016	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2016	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2016	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2016	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2016	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2016	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2016	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2016	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2016	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2016	FB	FB-500X	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2016	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2016	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2016	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Live Data	-	
2016	FB	FB-500X	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2016	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Special Functions	Service Single Pole Calibration	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	ECU Information	-	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	Read Codes	-	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	Erase codes	-	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	Live Data	-	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	Actuators	-	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Audio signal detection	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Power Down	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Power on and Disable User Input	
2016	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	ECM Proxi Alignment	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Immobilizer Unlock Function	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset adaptive parameter	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset vehicle configuration	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Self learning Throttle body activation	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Information	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Read Codes	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Erase codes	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Clutch Pedal Learn	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	ECM Proxi Alignment	
2016	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	First Gear Position Value	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	ECM Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Immobilizer Unlock Function	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset adaptive parameter	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset vehicle configuration	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Self learning Throttle body activation	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Verify and Write VIN	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	ECM Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Immobilizer Unlock Function	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset adaptive parameter	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset vehicle configuration	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Self learning Throttle body activation	
2016	NU	NU~Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Verify and Write VIN	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Live Data	-	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit Bleed	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit depressurization	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Learn Clutches Contact Point	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Learn long acceleration Signal	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	MTA Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Quick Learn	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Replacement MTA With Value Transfer	
2016	NU	NU~Novo Uno FL	-	TCM -- Transmission Control Module	Special Functions	Reset of Data group	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	Special Functions	BSM Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	ABS -- Anti Lock Brakes	Special Functions	BSM Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Live Data	-	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Actuators	-	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Special Functions	FPS Reactivation	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Special Functions	Program Keys	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Special Functions	Read Proxi	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	Special Functions	Write proxi procedure	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Check Antilt Sensor	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Check Siren	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Check Volumetric Sensors	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Lock doors command	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Rear Windows Washer	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Request Check	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Siren command	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Unlock doors command	
2016	NU	NU~Novo Uno FL	-	BCM -- Body Controller	System Tests	Windshield Washer	
2016	NU	NU~Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	NU	NU~Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Special Functions	ORC Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Oil Service Reset	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Service Reset	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Write Odometer	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Oil Service Reset	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Service Reset	
2016	NU	NU~Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Write Odometer	
2016	NU	NU~Novo Uno FL	-	PAM -- Park Assist Module	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	PAM -- Park Assist Module	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	PAM -- Park Assist Module	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	PAM -- Park Assist Module	Live Data	-	
2016	NU	NU~Novo Uno FL	-	PAM -- Park Assist Module	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	PAM -- Park Assist Module	Special Functions	PAM Proxi Alignment	
2016	NU	NU~Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2016	NU	NU~Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2016	NU	NU~Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2016	NU	NU~Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2016	NU	NU~Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2016	NU	NU~Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2016	NU	NU~Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis X Command	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis Y Command	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Fold Mirror	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis X Command	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis Y Command	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Unfold Mirror	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis X Command	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis Y Command	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Fold Mirror	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis X Command	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis Y Command	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Unfold Mirror	
2016	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Information	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Read Codes	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Erase codes	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Live Data	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Actuators	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Information	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Read Codes	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Erase codes	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Live Data	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Actuators	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2016	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2016	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Static test	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2016	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2016	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2016	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2016	OT	OT-Ottimo	-	PAM -- Park Assist Module	ECU Information	-	
2016	OT	OT-Ottimo	-	PAM -- Park Assist Module	Read Codes	-	
2016	OT	OT-Ottimo	-	PAM -- Park Assist Module	Erase codes	-	
2016	OT	OT-Ottimo	-	PAM -- Park Assist Module	Live Data	-	
2016	OT	OT-Ottimo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2016	OT	OT-Ottimo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2016	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2016	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2016	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2016	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Live Data	-	
2016	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2016	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	ECU Information	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	Read Codes	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	Erase codes	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	Live Data	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	Actuators	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	ECU Information	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	Read Codes	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	Erase codes	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	Live Data	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	Actuators	-	
2016	OT	OT-Ottimo	-	RADIO -- Radio	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2016	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2016	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	ECU Information	-	
2016	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Read Codes	-	
2016	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Erase codes	-	
2016	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Live Data	-	
2016	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Information	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Read Codes	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Erase codes	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Live Data	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Actuators	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Information	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Read Codes	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Erase codes	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Live Data	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Actuators	-	
2016	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	ECU Information	-	
2016	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Read Codes	-	
2016	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Erase codes	-	
2016	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Live Data	-	
2016	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Actuators	-	
2016	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2016	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2016	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2016	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2016	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2016	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2016	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Live Data	-	
2016	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Actuators	-	
2016	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2016	OT	OT-Ottimo	-	ESM -- Electronic Shifter	ECU Information	-	
2016	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Read Codes	-	
2016	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Erase codes	-	
2016	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Live Data	-	
2016	OT	OT-Ottimo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	ECU Information	-	
2016	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Read Codes	-	
2016	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Erase codes	-	
2016	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Live Data	-	
2016	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Actuators	-	
2016	OT	OT-Ottimo	-	EDM -- External Disc Module	ECU Information	-	
2016	OT	OT-Ottimo	-	EDM -- External Disc Module	Read Codes	-	
2016	OT	OT-Ottimo	-	EDM -- External Disc Module	Erase codes	-	
2016	OT	OT-Ottimo	-	EDM -- External Disc Module	Actuators	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Oil change	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Oil change	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2016	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2016	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2016	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2016	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2016	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Special Functions	Active alignment procedure: radar calibration.	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Live Data	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Actuators	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Live Data	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Actuators	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2016	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	TPMS calibration	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2016	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2016	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Audio signal detection	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Power Down	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Power on and Disable User Input	
2016	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2016	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2016	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Live Data	-	
2016	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2016	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	ECU Information	-	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Read Codes	-	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Erase codes	-	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Live Data	-	
2016	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Diesel Particulate Filter replacement	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Fuel mean value adaption initialization	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	IMA quick calibration	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor 1 initialization	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Oxidation catalyst initialization	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Request anti-slugging for Air Condition Compressor program variant coding	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure control switchover	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TIPM Enable Emissions Rolls Test mode	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Compression Test	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Information	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Read Codes	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Erase codes	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Live Data	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Actuators	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Event Data	-	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Quicklearn (Non-RFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	TCC Break-In (Non-RFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Write Pinion Factor	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Active Grille Shutter Replaced	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Engine Auto Restart Crank Counter	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Clear Stored Accumulated Fuel Mass	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Coolant Three Way Valve Replaced	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	Special Functions	Reset VCM Adaptives	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Overdrive Switch Test (Non-RFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Neutral Gate Test(Non-EFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	02 System Heater Test	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (62TE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (62TE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (62TE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (62TE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	4th Gear Clutch Test (62TE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	1st Gear Clutch Test (Non-RFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	2nd Gear Clutch Test (Non-RFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	3rd Gear Clutch Test (Non-RFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Reverse Gear Clutch Test (Non-RFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Thermistor Test (Non-RFE)	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Active Grille Shutter Test	
2016	RT	RT-Voyager	-	PCM -- Powertrain Control Module	System Tests	Coolant Three Way Valve Test	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Information	-	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Read Codes	-	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Erase codes	-	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Live Data	-	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Actuators	-	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Event Data	-	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	TCC Break-In	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Clear Learned Variable Line Pressure (VLP) Counters	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var16)	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	Special Functions	Quicklearn (62TE - PCM Var17)	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	1st Gear Clutch Test 62TE	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	2nd Gear Clutch Test 62TE	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	3rd Gear Clutch Test 62TE	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	4th Gear Clutch Test 62TE	
2016	RT	RT-Voyager	-	TCM -- Transmission Control Module	System Tests	Reverse Gear Clutch Test (62TE)	
2016	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	Special Functions	Initialize ORC	
2016	RT	RT-Voyager	-	ORC -- AirBag/Occupant Restraint	System Tests	Activate Driver and Passenger Head Restraint	
2016	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Initialization	
2016	RT	RT-Voyager	-	ABS -- Anti Lock Brakes	Special Functions	ABS Bleed Brakes	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Live Data	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Tire Sensor ID with TPM Tool	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Turn off Gain Mode Override	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Live Data	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Tire Sensor ID with TPM Tool	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Front Tire Sensor ID	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Left Rear Tire Sensor ID	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Front Tire Sensor ID	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Program Right Rear Tire Sensor ID	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	Special Functions	Turn off Gain Mode Override	
2016	RT	RT-Voyager	-	TPM -- Tire Pressure Monitor	System Tests	TPM Sensor Rolls Test	
2016	RT	RT-Voyager	-	FSM -- Fold Stow Module	ECU Information	-	
2016	RT	RT-Voyager	-	FSM -- Fold Stow Module	Read Codes	-	
2016	RT	RT-Voyager	-	FSM -- Fold Stow Module	Erase codes	-	
2016	RT	RT-Voyager	-	FSM -- Fold Stow Module	Live Data	-	
2016	RT	RT-Voyager	-	FSM -- Fold Stow Module	Actuators	-	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize Siren	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM Initialize	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	ITM and Siren Communication Test	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Ultrasonic Motion Detection Test	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	Special Functions	Initialize ITM	
2016	RT	RT-Voyager	-	ITM -- Intrusion Transceiver Module	System Tests	Siren Test	
2016	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	ECU Information	-	
2016	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Read Codes	-	
2016	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Erase codes	-	
2016	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Live Data	-	
2016	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Actuators	-	
2016	RT	RT-Voyager	-	HIDT -- High Intensity Discharge Translator	Special Functions	HIDT Calibration	
2016	RT	RT-Voyager	-	DVD -- DVD Changer	ECU Information	-	
2016	RT	RT-Voyager	-	DVD -- DVD Changer	Read Codes	-	
2016	RT	RT-Voyager	-	DVD -- DVD Changer	Erase codes	-	
2016	RT	RT-Voyager	-	DVD -- DVD Changer	Live Data	-	
2016	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	ECU Information	-	
2016	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Read Codes	-	
2016	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Erase codes	-	
2016	RT	RT-Voyager	-	SAS -- Steering Angle Sensor	Live Data	-	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Information	-	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Read Codes	-	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Erase codes	-	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Live Data	-	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Actuators	-	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	ECU Configure Information	-	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	Special Functions	Learn Latch Sector Home	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Cinch Test	
2016	RT	RT-Voyager	-	DMRL -- Rear Door Module (Left)	System Tests	Latch Release Test	
2016	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	Actuators	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	ECU Information	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	Read Codes	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	Erase codes	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	Live Data	-	
2016	RT	RT-Voyager	-	RADIO -- Radio	ECU Configure Information	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Information	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Read Codes	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Erase codes	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Live Data	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Actuators	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	ECU Configure Information	-	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ELV Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	ESCL Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Erase All Ignition Keys	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	LRSM Re-Adaption	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Front Tire Sensor ID	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Left Rear Tire Sensor ID	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Front Tire Sensor ID	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Right Rear Tire Sensor ID	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Tire Sensor ID with TPM Tool	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Program Ignition Keys or Key FOBs	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	PCM Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Reset WIN Configuration	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	WIN Replaced	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	Special Functions	Sentry Key Immobilizer Module (SKIM)	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	Antenna Loop Test	
2016	RT	RT-Voyager	-	WCM/TPMS -- Wireless Control	System Tests	TPM Trigger Module Test	
2016	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2016	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2016	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2016	RT	RT-Voyager	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	ECU Information	-	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Read Codes	-	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Erase codes	-	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Live Data	-	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Learn Side Test	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	Special Functions	Ramp Van Configuration	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Close Test	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Sliding Door Open Test	
2016	RT	RT-Voyager	-	PSDML -- Power Sliding Doors (Left)	System Tests	Actuate Drive Clutch Engage	
2016	RT	RT-Voyager	-	AHBM -- Automatic High Beam	ECU Information	-	
2016	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Read Codes	-	
2016	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Erase codes	-	
2016	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Live Data	-	
2016	RT	RT-Voyager	-	AHBM -- Automatic High Beam	Actuators	-	
2016	RT	RT-Voyager	-	AHBM -- Automatic High Beam	System Tests	Aim Test	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Information	-	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	Read Codes	-	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	Erase codes	-	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	Live Data	-	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	ECU Configure Information	-	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	Special Functions	PEM Replace	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Locate Learned Keys	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	Door Handle Verification Test	
2016	RT	RT-Voyager	-	PEM -- Passive Entry Module	System Tests	LF Antenna Verification Test	
2016	RT	RT-Voyager	-	SUNR -- Sunroof	ECU Information	-	
2016	RT	RT-Voyager	-	SUNR -- Sunroof	Read Codes	-	
2016	RT	RT-Voyager	-	SUNR -- Sunroof	Erase codes	-	
2016	RT	RT-Voyager	-	SUNR -- Sunroof	Live Data	-	
2016	RT	RT-Voyager	-	SUNR -- Sunroof	Actuators	-	
2016	RT	RT-Voyager	-	HFM -- Hands Free Module	ECU Information	-	
2016	RT	RT-Voyager	-	HFM -- Hands Free Module	Read Codes	-	
2016	RT	RT-Voyager	-	HFM -- Hands Free Module	Erase codes	-	
2016	RT	RT-Voyager	-	HFM -- Hands Free Module	Live Data	-	
2016	RT	RT-Voyager	-	HFM -- Hands Free Module	Actuators	-	
2016	RT	RT-Voyager	-	HFM -- Hands Free Module	System Tests	HFM Self Test	
2016	RT	RT-Voyager	-	DMFR -- Door Module Front Right	ECU Information	-	
2016	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Read Codes	-	
2016	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Erase codes	-	
2016	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Live Data	-	
2016	RT	RT-Voyager	-	DMFR -- Door Module Front Right	Actuators	-	
2016	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Information	-	
2016	RT	RT-Voyager	-	HSM -- Heated Seat Module	Read Codes	-	
2016	RT	RT-Voyager	-	HSM -- Heated Seat Module	Erase codes	-	
2016	RT	RT-Voyager	-	HSM -- Heated Seat Module	Live Data	-	
2016	RT	RT-Voyager	-	HSM -- Heated Seat Module	Actuators	-	
2016	RT	RT-Voyager	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2016	RT	RT-Voyager	-	HSM -- Heated Seat Module	Special Functions	Heated Steering Wheel Configuration	
2016	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2016	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2016	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2016	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2016	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2016	RT	RT-Voyager	-	EPPM -- Electronic Pedestrian Protection Module	Special Functions	Initialize EPPM	
2016	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Information	-	
2016	RT	RT-Voyager	-	CGW -- Central Gateway	Read Codes	-	
2016	RT	RT-Voyager	-	CGW -- Central Gateway	Erase codes	-	
2016	RT	RT-Voyager	-	CGW -- Central Gateway	Live Data	-	
2016	RT	RT-Voyager	-	CGW -- Central Gateway	Actuators	-	
2016	RT	RT-Voyager	-	CGW -- Central Gateway	ECU Configure Information	-	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	ECU Information	-	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Read Codes	-	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Erase codes	-	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Live Data	-	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Learn Side Test	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	Special Functions	Ramp Van Configuration	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Close Test	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Sliding Door Open Test	
2016	RT	RT-Voyager	-	PSDMR -- Power Sliding Doors (Right)	System Tests	Actuate Drive Clutch Engage	
2016	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2016	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2016	RT	RT-Voyager	-	AMP -- Amplifier	ECU Information	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	Read Codes	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	Erase codes	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	Live Data	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	ECU Configure Information	-	
2016	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Input Test	
2016	RT	RT-Voyager	-	AMP -- Amplifier	System Tests	AMP Software Test	
2016	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2016	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2016	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2016	RT	RT-Voyager	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2016	RT	RT-Voyager	-	PTS -- Parktronics	ECU Information	-	
2016	RT	RT-Voyager	-	PTS -- Parktronics	Read Codes	-	
2016	RT	RT-Voyager	-	PTS -- Parktronics	Erase codes	-	
2016	RT	RT-Voyager	-	PTS -- Parktronics	Live Data	-	
2016	RT	RT-Voyager	-	PTS -- Parktronics	Actuators	-	
2016	RT	RT-Voyager	-	PTS -- Parktronics	ECU Configure Information	-	
2016	RT	RT-Voyager	-	PTS -- Parktronics	Special Functions	Configure License Plate Size	
2016	RT	RT-Voyager	-	PTS -- Parktronics	System Tests	System Wiring Test	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Information	-	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Read Codes	-	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Erase codes	-	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Live Data	-	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Actuators	-	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Close Position	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Calibrate Liftgate Full Open Position	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	Special Functions	Ramp Van Configuration	
2016	RT	RT-Voyager	-	PLGM -- Power Liftgate Module	System Tests	Latch Home Sector Test	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Information	-	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Read Codes	-	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Erase codes	-	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Live Data	-	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Actuators	-	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	ECU Configure Information	-	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Language Preference	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Update Measurement Unit	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert Minder	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Program Dealer Contact Information	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Change Measurement Units	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Language Preference	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	Special Functions	Seatbelt Alert System	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	Self Test	
2016	RT	RT-Voyager	-	MIC/CCN -- Mechanical Instrument Cluster	System Tests	CCN Self Test	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Information	-	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Read Codes	-	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Erase codes	-	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Live Data	-	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Actuators	-	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	ECU Configure Information	-	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	Special Functions	Learn Latch Sector Home	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Cinch Test	
2016	RT	RT-Voyager	-	DMRR -- Rear Door Module (Right)	System Tests	Latch Release Test	
2016	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Information	-	
2016	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Read Codes	-	
2016	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Erase codes	-	
2016	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Live Data	-	
2016	RT	RT-Voyager	-	DMFL -- Door Module Front Left	Actuators	-	
2016	RT	RT-Voyager	-	DMFL -- Door Module Front Left	ECU Configure Information	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Cool Down Test	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Front Blower State	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Rear Blower State	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Pass Cool Down Test Results	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	HVAC Cool Down Test	
2016	RT	RT-Voyager	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Information	-	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Read Codes	-	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Erase codes	-	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Live Data	-	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Actuators	-	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	ECU Configure Information	-	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Clear All Learned Seat Parameters	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Easy Entry/Exit	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Key Fobs Linked to Memory	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	Special Functions	Tilt Mirrors in Reverse	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Standardization	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	MSMD Self Test	
2016	RT	RT-Voyager	-	MSMD -- Plug In Hybrid Gateway Module	System Tests	Actuate Seat Recall	
2016	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Information	-	
2016	RT	RT-Voyager	-	VES2 -- Second Row Screen	Read Codes	-	
2016	RT	RT-Voyager	-	VES2 -- Second Row Screen	Erase codes	-	
2016	RT	RT-Voyager	-	VES2 -- Second Row Screen	Live Data	-	
2016	RT	RT-Voyager	-	VES2 -- Second Row Screen	Actuators	-	
2016	RT	RT-Voyager	-	VES2 -- Second Row Screen	ECU Configure Information	-	
2016	RT	RT-Voyager	-	VES2 -- Second Row Screen	Special Functions	Headphone Test	
2016	RT	RT-Voyager	-	VES3 -- Last Row Screen	ECU Information	-	
2016	RT	RT-Voyager	-	VES3 -- Last Row Screen	Read Codes	-	
2016	RT	RT-Voyager	-	VES3 -- Last Row Screen	Erase codes	-	
2016	RT	RT-Voyager	-	VES3 -- Last Row Screen	Live Data	-	
2016	RT	RT-Voyager	-	VES3 -- Last Row Screen	Actuators	-	
2016	RT	RT-Voyager	-	VES3 -- Last Row Screen	ECU Configure Information	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	ECU Information	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Read Codes	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Erase codes	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Live Data	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Actuators	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	ECU Configure Information	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Cargo Lock Relay	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Cargo Unlock Relay	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check ALSRS Sensors	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check Antilt Sensor	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check Siren	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check Volumetric Sensors	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Fps procedure	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Inclination sensor Level	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Level Ultrasonic Sensor	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Lock doors command	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Logistic mode	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Rear Left Window Smart Motor Driver	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Rear Right Window Smart Motor	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable Mode	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Request Check Line	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Request MSC from RFHM	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Siren command	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Unlock doors command	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Window Smart Motor Driver	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Window Smart Motor Passenger	
2016	TO	TO-Toro	-	BCM -- Body Controller	ECU Information	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Read Codes	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Erase codes	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Live Data	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Actuators	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	ECU Configure Information	-	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check Antilt Sensor	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check ALSRS Sensors	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Decklid Liftgate Relay	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	FPS Activate	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Lock doors command	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Modify Anti Longitudinal Tilt Sensor	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Modify Volumetric Sensor Sensibility	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Request Check Line	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Siren Check LIN	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Siren command	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Unlock doors command	
2016	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check Volumetric Sensors	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Information	-	
2016	TO	TO-Toro	-	TTM -- Trailer tow module	Read Codes	-	
2016	TO	TO-Toro	-	TTM -- Trailer tow module	Erase codes	-	
2016	TO	TO-Toro	-	TTM -- Trailer tow module	Live Data	-	
2016	TO	TO-Toro	-	TTM -- Trailer tow module	Actuators	-	
2016	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH immobilizer antenna test	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH locate learned keys	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM sensor rolls tests	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM Update FF FR Axle Nom Tire Press Val	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left front tire sensor Id	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left rear tire sensor Id	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right front tire sensor Id	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right rear tire sensor Id	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH immobilizer antenna test	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH locate learned keys	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM sensor rolls tests	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM Update FF FR Axle Nom Tire Press Val	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left front tire sensor Id	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left rear tire sensor Id	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right front tire sensor Id	
2016	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right rear tire sensor Id	
2016	TO	TO-Toro	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	TO	TO-Toro	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	TO	TO-Toro	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	TO	TO-Toro	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	TO	TO-Toro	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fuel Circuit Purge	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset adaptative parameters	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset camshaft adaptative	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Phonic Wheel Tooth Learn	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Purge Fuel Circuit	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter for ECU Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter functions	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR High Pressure Valve Offset Learn	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Electrical VGT actuator test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Stop Actuator	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Glow Plug Voltage Test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 1 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 2 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 3 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 4 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Lambda Function Reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Mission profile counter reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	NOx Storage (NSC) Catalyst Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Blinking Oil Lamp	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Driven Distance With Fuel Lamp On	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset driven distance with water temperature lamp on	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Throttle Valve Actuator (TVA) DC Motor test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	VGT cleaning and DeNOx time reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Zero Fuel Quantity Calibration	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter for ECU Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter functions	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR High Pressure Valve Offset Learn	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Electrical VGT actuator test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Stop Actuator	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Glow Plug Voltage Test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 1 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 2 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 3 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 4 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Lambda Function Reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Mission profile counter reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	NOx Storage (NSC) Catalyst Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Blinking Oil Lamp	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Driven Distance With Fuel Lamp On	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset driven distance with water temperature lamp on	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Throttle Valve Actuator (TVA) DC Motor test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	VGT cleaning and DeNOx time reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Zero Fuel Quantity Calibration	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fuel Circuit Purge	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset adaptative parameters	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset camshaft adaptative	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Phonic Wheel Tooth Learn	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Purge Fuel Circuit	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter for ECU Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter functions	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR High Pressure Valve Offset Learn	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Electrical VGT actuator test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Stop Actuator	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Glow Plug Voltage Test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 1 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 2 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 3 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 4 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Lambda Function Reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Mission profile counter reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	NOx Storage (NSC) Catalyst Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Blinking Oil Lamp	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Driven Distance With Fuel Lamp On	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset driven distance with water temperature lamp on	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Throttle Valve Actuator (TVA) DC Motor test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	VGT cleaning and DeNOx time reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Zero Fuel Quantity Calibration	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter for ECU Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter functions	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR High Pressure Valve Offset Learn	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Electrical VGT actuator test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Stop Actuator	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Glow Plug Voltage Test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 1 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 2 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 3 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 4 Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Lambda Function Reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Mission profile counter reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	NOx Storage (NSC) Catalyst Replacement	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Blinking Oil Lamp	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Driven Distance With Fuel Lamp On	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset driven distance with water temperature lamp on	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Throttle Valve Actuator (TVA) DC Motor test	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	VGT cleaning and DeNOx time reset	
2016	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Zero Fuel Quantity Calibration	
2016	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2016	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2016	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2016	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Live Data	-	
2016	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2016	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Special Functions	Service Single Pole Calibration	
2016	TO	TO-Toro	-	DMM -- Door Management Module	ECU Information	-	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Read Codes	-	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Erase codes	-	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Live Data	-	
2016	TO	TO-Toro	-	DMM -- Door Management Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Driver Mirror Axis X Command	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Driver Mirror Axis Y Command	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Fold Mirror	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Passenger Mirror Axis X Command	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Passenger Mirror Axis Y Command	
2016	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Unfold Mirror	
2016	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2016	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2016	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2016	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2016	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral Sensors Calibration	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Special Functions	Pressure sensor calibration	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Special Functions	Reset Angle Offset	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral Sensors Calibration	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Special Functions	Pressure sensor calibration	
2016	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Special Functions	Reset Angle Offset	
2016	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Information	-	
2016	TO	TO-Toro	-	EPS -- Electric Power Steering	Read Codes	-	
2016	TO	TO-Toro	-	EPS -- Electric Power Steering	Erase codes	-	
2016	TO	TO-Toro	-	EPS -- Electric Power Steering	Live Data	-	
2016	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2016	TO	TO-Toro	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Erase codes	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Live Data	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning data	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	N Position Self Learning	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Erase codes	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Live Data	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	CM	CM-Viaggio	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2017	CM	CM-Viaggio	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Information	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Read Codes	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Erase codes	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Live Data	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Actuators	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2017	CM	CM-Viaggio	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2017	CM	CM-Viaggio	-	PAM -- Park Assist Module	ECU Information	-	
2017	CM	CM-Viaggio	-	PAM -- Park Assist Module	Read Codes	-	
2017	CM	CM-Viaggio	-	PAM -- Park Assist Module	Erase codes	-	
2017	CM	CM-Viaggio	-	PAM -- Park Assist Module	Live Data	-	
2017	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2017	CM	CM-Viaggio	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2017	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	ECU Information	-	
2017	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2017	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2017	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Live Data	-	
2017	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Read Codes	-	
2017	CM	CM-Viaggio	-	CTM -- Convergence Telematic Module	Erase codes	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	ECU Information	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	Read Codes	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	Erase codes	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	Live Data	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	Actuators	-	
2017	CM	CM-Viaggio	-	RADIO -- Radio	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	ECU Information	-	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Read Codes	-	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Erase codes	-	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Live Data	-	
2017	CM	CM-Viaggio	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2017	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	ECU Information	-	
2017	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Read Codes	-	
2017	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Erase codes	-	
2017	CM	CM-Viaggio	-	SCCM -- Steering Column Control Module	Live Data	-	
2017	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Read Codes	-	
2017	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Erase codes	-	
2017	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Live Data	-	
2017	CM	CM-Viaggio	-	ICS -- Integrated Center Stack	Actuators	-	
2017	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Actuators	-	
2017	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2017	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2017	CM	CM-Viaggio	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Live Data	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Actuators	-	
2017	CM	CM-Viaggio	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2017	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Information	-	
2017	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Read Codes	-	
2017	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Erase codes	-	
2017	CM	CM-Viaggio	-	ESM -- Electronic Shifter	Live Data	-	
2017	CM	CM-Viaggio	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	ECU Information	-	
2017	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Read Codes	-	
2017	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Erase codes	-	
2017	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Live Data	-	
2017	CM	CM-Viaggio	-	ESL -- Electronic Steering Lock	Actuators	-	
2017	CM	CM-Viaggio	-	EDM -- External Disc Module	ECU Information	-	
2017	CM	CM-Viaggio	-	EDM -- External Disc Module	Read Codes	-	
2017	CM	CM-Viaggio	-	EDM -- External Disc Module	Erase codes	-	
2017	CM	CM-Viaggio	-	EDM -- External Disc Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Event Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cam Crank Relearn	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 1 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Exhaust Phaser 2 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 1 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake Phaser 2 Cleaning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Learn ETC	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Enhanced Automatic Oil Change Indicator	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Electric Vacuum Pump Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ESIM Forced Monitor Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	ETC Throttle Follower Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Injector Kill Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Purge Vapors System Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Set Engine RPM	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Freeze Frame	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air-Conditioning Self Learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Brake Switch Learn	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM Odometer	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Check PCM VIN	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clear Misfire TLC	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	ESIM Forced Monitor Test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Memory	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Reset Accelerator Pedal Adaptives	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Throttle Body Self Learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fan cooling activation	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	MultiAir Rolling Finger Replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil Temperature Sensor Replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Replacement UNIAIR module	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Supercharging system components replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Waste Gate valve command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch pedal learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Deactivation of the Power Limitation function	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fan cooling activation	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	MultiAir Rolling Finger Replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Control unit reprogramming	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel supply system components replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector/s reprogramming	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intake manifold replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Motorized throttle replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Air conditioner relay command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Motorized throttle self learning command	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self - adaptive parameters reset	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Downstream lambda probe replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	EGR low pressure valve replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	NOx replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Upstream lambda probe replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	EGR high pressure valve test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	EGR low pressure valve test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Glow plug preheating circuit test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Read second level micro safety reset event	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Self-learnt functions reset	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Read Codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Erase codes	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Live Data	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Actuators	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Air flow meter sensor replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 1 injector replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 2 injector replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 3 injector replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Cylinder 4 injector replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	EGR high pressure valve replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Electrical Variable Geometry Turbo and/or turbo position sensor Replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Electrical VTG actuator test	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector codes read	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Injector replacement (per bank)	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Neural signal learning	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	NOx replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Oil change	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter regeneration	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	Special Functions	Rail pressure sensor replacement	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	FB	FB-500X	-	PCM -- Powertrain Control Module	System Tests	Throttle valve test	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Information	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Read Codes	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Erase codes	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Live Data	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Event Data	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Quick learn	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	TCM VIN Verification	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Value Body Solenoid Learn	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Information	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Read Codes	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Erase codes	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	Live Data	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Range selection electrovalve command (PPVS)	
2017	FB	FB-500X	-	DTCM -- Drive Train Control Module	ECU Information	-	
2017	FB	FB-500X	-	DTCM -- Drive Train Control Module	Read Codes	-	
2017	FB	FB-500X	-	DTCM -- Drive Train Control Module	Erase codes	-	
2017	FB	FB-500X	-	DTCM -- Drive Train Control Module	Live Data	-	
2017	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	2WD Dyno Mode	
2017	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	On Demand Self Test	
2017	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	PTU Replacement	
2017	FB	FB-500X	-	DTCM -- Drive Train Control Module	Special Functions	RDU Replacement	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Pressure Sensor Calibration	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Electric Park Brake management	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	TPMS Calibration	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	ECU Substitution	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Pressure Sensor Calibration	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	Electric Park Brake management	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	TPMS Calibration	
2017	FB	FB-500X	-	ABS -- Anti Lock Brakes	Special Functions	ECU Substitution	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	FB	FB-500X	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2017	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2017	FB	FB-500X	-	BCM -- Body Controller	ECU Information	-	
2017	FB	FB-500X	-	BCM -- Body Controller	Read Codes	-	
2017	FB	FB-500X	-	BCM -- Body Controller	Erase codes	-	
2017	FB	FB-500X	-	BCM -- Body Controller	Live Data	-	
2017	FB	FB-500X	-	BCM -- Body Controller	Actuators	-	
2017	FB	FB-500X	-	BCM -- Body Controller	ECU Configure Information	-	
2017	FB	FB-500X	-	BCM -- Body Controller	ECU Information	-	
2017	FB	FB-500X	-	BCM -- Body Controller	Read Codes	-	
2017	FB	FB-500X	-	BCM -- Body Controller	Erase codes	-	
2017	FB	FB-500X	-	BCM -- Body Controller	Live Data	-	
2017	FB	FB-500X	-	BCM -- Body Controller	Actuators	-	
2017	FB	FB-500X	-	BCM -- Body Controller	ECU Configure Information	-	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH immobilizer antenna test	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH locate learned keys	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM sensor rolls tests	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM Update FF FR Axle Nom Tire Press Val	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left front tire sensor Id	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left rear tire sensor Id	
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right front tire sensor Id	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	FB	FB-500X	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right rear tire sensor Id	
2017	FB	FB-500X	-	ESL -- Electronic Steering Lock	ECU Information	-	
2017	FB	FB-500X	-	ESL -- Electronic Steering Lock	Read Codes	-	
2017	FB	FB-500X	-	ESL -- Electronic Steering Lock	Erase codes	-	
2017	FB	FB-500X	-	ESL -- Electronic Steering Lock	Live Data	-	
2017	FB	FB-500X	-	EPS -- Electric Power Steering	ECU Information	-	
2017	FB	FB-500X	-	EPS -- Electric Power Steering	Read Codes	-	
2017	FB	FB-500X	-	EPS -- Electric Power Steering	Erase codes	-	
2017	FB	FB-500X	-	EPS -- Electric Power Steering	Live Data	-	
2017	FB	FB-500X	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2017	FB	FB-500X	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2017	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Live Data	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Actuators	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Special Functions	Active alignment procedure: radar calibration.	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Live Data	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Actuators	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2017	FB	FB-500X	-	ACC -- Adaptive Cruise Control	Special Functions	Active alignment procedure: radar calibration.	
2017	FB	FB-500X	-	PAM -- Park Assist Module	ECU Information	-	
2017	FB	FB-500X	-	PAM -- Park Assist Module	Read Codes	-	
2017	FB	FB-500X	-	PAM -- Park Assist Module	Erase codes	-	
2017	FB	FB-500X	-	PAM -- Park Assist Module	Live Data	-	
2017	FB	FB-500X	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2017	FB	FB-500X	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Read Codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Erase codes	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Actuators	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Live Data	-	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	FB	FB-500X	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	FB	FB-500X	-	AMP -- Amplifier	ECU Information	-	
2017	FB	FB-500X	-	AMP -- Amplifier	Read Codes	-	
2017	FB	FB-500X	-	AMP -- Amplifier	Erase codes	-	
2017	FB	FB-500X	-	AMP -- Amplifier	Live Data	-	
2017	FB	FB-500X	-	AMP -- Amplifier	Actuators	-	
2017	FB	FB-500X	-	AMP -- Amplifier	ECU Configure Information	-	
2017	FB	FB-500X	-	AMP -- Amplifier	System Tests	Audio Measure AC+DC	
2017	FB	FB-500X	-	AMP -- Amplifier	System Tests	Output Short Test	
2017	FB	FB-500X	-	AMP -- Amplifier	System Tests	Tone Test	
2017	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	ECU Information	-	
2017	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2017	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2017	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2017	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2017	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2017	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2017	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2017	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2017	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2017	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2017	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2017	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2017	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2017	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2017	FB	FB-500X	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2017	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2017	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2017	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Live Data	-	
2017	FB	FB-500X	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2017	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Special Functions	Service Single Pole Calibration	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	ECU Information	-	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	Read Codes	-	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	Erase codes	-	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	Live Data	-	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	Actuators	-	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Audio signal detection	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Power Down	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Power on and Disable User Input	
2017	FB	FB-500X	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Clutch Pedal Learn	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	ECM Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Immobilizer Unlock Function	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Alcool	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Gasoline	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Learning	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset adaptive parameter	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset vehicle configuration	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Self learning Throttle body activation	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Verify and Write VIN	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Clutch Pedal Learn	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	ECM Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	First Gear Position Value	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Immobilizer Unlock Function	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Alcool	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Gasoline	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Learning	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset adaptive parameter	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset vehicle configuration	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Self learning Throttle body activation	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Verify and Write VIN	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	ECM Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Immobilizer Unlock Function	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Alcool	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Gasoline	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Impone AF Learning	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset adaptive parameter	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Reset vehicle configuration	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Self learning Throttle body activation	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Special Functions	Verify and Write VIN	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Live Data	-	
2017	NU	NU-Novo Uno FL	-	ECM -- Engine Control Module	Actuators	-	









## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	NU	NU-Novo Uno FL	-	ORC -- AirBag/Occupant Restraint	Special Functions	ORC Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Oil Service Reset	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Service Reset	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Write Odometer	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Replacement	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Oil Service Reset	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Service Reset	
2017	NU	NU-Novo Uno FL	-	IPC -- Instrument Panel Cluster	Special Functions	Write Odometer	
2017	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	Live Data	-	
2017	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	PAM -- Park Assist Module	Special Functions	PAM Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis X Command	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis Y Command	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Fold Mirror	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis X Command	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis Y Command	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Unfold Mirror	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Information	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Read Codes	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Erase codes	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Live Data	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Actuators	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	ECU Configure Information	-	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	Special Functions	DDM Proxi Alignment	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis X Command	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Driver Mirror Axis Y Command	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Fold Mirror	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis X Command	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Passenger Mirror Axis Y Command	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Unfold Mirror	
2017	NU	NU-Novo Uno FL	-	DMM -- Door Management Module	System Tests	Windows Lifter Test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Nox replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Engine replacement	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Oil change	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2017	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2017	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Read Codes	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Erase codes	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	ECU Information	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Live Data	-	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2017	PD	PD-Egea/Tip	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Live Data	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Actuators	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Live Data	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Actuators	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Live Data	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Actuators	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2017	PD	PD-Egea/Tip	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2017	PD	PD-Egea/Tip	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ACC -- Adaptive Cruise Control	Live Data	-	
2017	PD	PD-Egea/Tip	-	ACC -- Adaptive Cruise Control	Actuators	-	
2017	PD	PD-Egea/Tip	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ACC -- Adaptive Cruise Control	Special Functions	Active alignment procedure: radar calibration.	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	PD	PD-Egea/Tip	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	ECU Information	-	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	Read Codes	-	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	Erase codes	-	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	Live Data	-	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	Actuators	-	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	ECU Configure Information	-	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2017	PD	PD-Egea/Tip	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Live Data	-	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Actuators	-	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2017	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	TPMS calibration	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2017	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2017	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Audio signal detection	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Power Down	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Power on and Disable User Input	
2017	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2017	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2017	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Live Data	-	
2017	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Actuators	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2017	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Live Data	-	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	ECU Information	-	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Read Codes	-	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Erase codes	-	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Live Data	-	
2017	PD	PD-Egea/Tipo	-	EPS -- Electric Power Steering	Special Functions	Steering Angle Calibration	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Information	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Read Codes	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Erase codes	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Live Data	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Actuators	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Information	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Read Codes	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Erase codes	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Live Data	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Actuators	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2017	OT	OT-Ottimo	-	ECM -- Engine Control Module	System Tests	Self-learnt function reset	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	ECU Information	-	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Read Codes	-	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Erase codes	-	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Live Data	-	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Selection and/or engagement clutch electrovalve replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	Control unit replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	Special Functions	'SHIFTER' sensor replacement	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd, 2nd, Reverse)	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st, 4th, 5th, 6th)	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Lever release solenoid command	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) control solenoid valve command	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2017	OT	OT-Ottimo	-	TCM -- Transmission Control Module	System Tests	Rang selection electrovalve command (PPVS)	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2017	OT	OT-Ottimo	-	ABS -- Anti Lock Brakes	Special Functions	Static test	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	OT	OT-Ottimo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	ECU Replacement	
2017	OT	OT-Ottimo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Information	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Read Codes	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Erase codes	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Live Data	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Actuators	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2017	OT	OT-Ottimo	-	BCM -- Body Controller	Special Functions	Fire Protection System	
2017	OT	OT-Ottimo	-	PAM -- Park Assist Module	ECU Information	-	
2017	OT	OT-Ottimo	-	PAM -- Park Assist Module	Read Codes	-	
2017	OT	OT-Ottimo	-	PAM -- Park Assist Module	Erase codes	-	
2017	OT	OT-Ottimo	-	PAM -- Park Assist Module	Live Data	-	
2017	OT	OT-Ottimo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence disabling	
2017	OT	OT-Ottimo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2017	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2017	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2017	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2017	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Live Data	-	
2017	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2017	OT	OT-Ottimo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	ECU Information	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	Read Codes	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	Erase codes	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	Live Data	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	Actuators	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	ECU Information	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	Read Codes	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	Erase codes	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	Live Data	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	Actuators	-	
2017	OT	OT-Ottimo	-	RADIO -- Radio	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	First Passed Cool Down Test Results	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Most Recent Cool Down Test Results	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	HVAC Cool Down Test	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	System Tests	Actuator Calibration Test	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	ECU Information	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Read Codes	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Erase codes	-	
2017	OT	OT-Ottimo	-	EPS -- Electric Power Steering	Live Data	-	
2017	OT	OT-Ottimo	-	SCM -- Steering Column Control Module	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Read Codes	-	
2017	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Erase codes	-	
2017	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	Live Data	-	
2017	OT	OT-Ottimo	-	SCCM -- Steering Column Control Module	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Information	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Read Codes	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Erase codes	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Live Data	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Actuators	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Information	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Read Codes	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Erase codes	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Live Data	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	Actuators	-	
2017	OT	OT-Ottimo	-	ICS -- Integrated Center Stack	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Actuators	-	
2017	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2017	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	RFH Antenna Test	
2017	OT	OT-Ottimo	-	RFH -- Radio Frequency Hub	Special Functions	Locate Learned Keys	
2017	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	ECU Information	-	
2017	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Read Codes	-	
2017	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Erase codes	-	
2017	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Live Data	-	
2017	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Actuators	-	
2017	OT	OT-Ottimo	-	TRM -- Vehicle System Interface Module	Special Functions	Program Keys TRM 343	
2017	OT	OT-Ottimo	-	ESM -- Electronic Shifter	ECU Information	-	
2017	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Read Codes	-	
2017	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Erase codes	-	
2017	OT	OT-Ottimo	-	ESM -- Electronic Shifter	Live Data	-	
2017	OT	OT-Ottimo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	ECU Information	-	
2017	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Read Codes	-	
2017	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Erase codes	-	
2017	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Live Data	-	
2017	OT	OT-Ottimo	-	ESL -- Electronic Steering Lock	Actuators	-	
2017	OT	OT-Ottimo	-	EDM -- External Disc Module	ECU Information	-	
2017	OT	OT-Ottimo	-	EDM -- External Disc Module	Read Codes	-	
2017	OT	OT-Ottimo	-	EDM -- External Disc Module	Erase codes	-	
2017	OT	OT-Ottimo	-	EDM -- External Disc Module	Actuators	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fuel Circuit Purge	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset adaptative parameters	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset camshaft adaptative	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Phonic Wheel Tooth Learn	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Purge Fuel Circuit	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter for ECU Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter functions	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR High Pressure Valve Offset Learn	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Electrical VGT actuator test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Stop Actuator	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Glow Plug Voltage Test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 1 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 2 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 3 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 4 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Lambda Function Reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Mission profile counter reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	NOx Storage (NSC) Catalyst Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Blinking Oil Lamp	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Driven Distance With Fuel Lamp On	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset driven distance with water temperature lamp on	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Throttle Valve Actuator (TVA) DC Motor test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	VGT cleaning and DeNOx time reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Zero Fuel Quantity Calibration	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter for ECU Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter functions	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR High Pressure Valve Offset Learn	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Electrical VGT actuator test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Stop Actuator	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Glow Plug Voltage Test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 1 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 2 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 3 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 4 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Lambda Function Reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Mission profile counter reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	NOx Storage (NSC) Catalyst Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Blinking Oil Lamp	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Driven Distance With Fuel Lamp On	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset driven distance with water temperature lamp on	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Throttle Valve Actuator (TVA) DC Motor test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	VGT cleaning and DeNOx time reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Zero Fuel Quantity Calibration	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fuel Circuit Purge	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	General stop Actuator	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset adaptative parameters	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset camshaft adaptative	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Phonic Wheel Tooth Learn	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Purge Fuel Circuit	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter for ECU Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter functions	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR High Pressure Valve Offset Learn	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Electrical VGT actuator test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Stop Actuator	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Glow Plug Voltage Test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 1 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 2 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 3 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 4 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Lambda Function Reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Mission profile counter reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	NOx Storage (NSC) Catalyst Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Blinking Oil Lamp	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Driven Distance With Fuel Lamp On	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset driven distance with water temperature lamp on	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Throttle Valve Actuator (TVA) DC Motor test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	VGT cleaning and DeNOx time reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Zero Fuel Quantity Calibration	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter for ECU Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Diesel Particulate Filter functions	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR High Pressure Valve Offset Learn	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Electrical VGT actuator test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Fan activation	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Stop Actuator	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Glow Plug Voltage Test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 1 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 2 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 3 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Injection 4 Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Lambda Function Reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Mission profile counter reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	NOx Storage (NSC) Catalyst Replacement	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Blinking Oil Lamp	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset Driven Distance With Fuel Lamp On	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Reset driven distance with water temperature lamp on	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Throttle Valve Actuator (TVA) DC Motor test	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	VGT cleaning and DeNOx time reset	
2017	TO	TO-Toro	-	ECM -- Engine Control Module	Special Functions	Zero Fuel Quantity Calibration	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Erase codes	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Live Data	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning data	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	N Position Self Learning	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Erase codes	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Live Data	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Electropump drive unit replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Electropump replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Even no. gear clutch pressure sensor replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Gearbox oil accumulator replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Gearbox Replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Odd no. gear clutch position sensor replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K1) control solenoid valve command	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	System Tests	Range selection electro valve command (PPVS)	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Erase codes	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Live Data	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Event Data	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Quick learn	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Remote Start Temporary Disable Mode	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Request Check Line	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Request MSC from RFHM	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Siren command	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Unlock doors command	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Window Smart Motor Driver	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Window Smart Motor Passenger	
2017	TO	TO-Toro	-	BCM -- Body Controller	ECU Information	-	
2017	TO	TO-Toro	-	BCM -- Body Controller	Read Codes	-	
2017	TO	TO-Toro	-	BCM -- Body Controller	Erase codes	-	
2017	TO	TO-Toro	-	BCM -- Body Controller	Live Data	-	
2017	TO	TO-Toro	-	BCM -- Body Controller	Actuators	-	
2017	TO	TO-Toro	-	BCM -- Body Controller	ECU Configure Information	-	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check Antilt Sensor	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check ALSRS Sensors	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Decklid Liftgate Relay	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Exit Shipping Mode	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	FPS Activate	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Lock doors command	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Modify Anti Longitudinal Tilt Sensor	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Modify Volumetric Sensor Sensibility	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Request Check Line	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Siren Check LIN	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Siren command	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Unlock doors command	
2017	TO	TO-Toro	-	BCM -- Body Controller	Special Functions	Check Volumetric Sensors	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2017	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	ECU Information	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Read Codes	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Erase codes	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Live Data	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	ECU Information	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Read Codes	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Erase codes	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Live Data	-	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2017	TO	TO-Toro	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	TO	TO-Toro	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2017	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Information	-	
2017	TO	TO-Toro	-	EPS -- Electric Power Steering	Read Codes	-	
2017	TO	TO-Toro	-	EPS -- Electric Power Steering	Erase codes	-	
2017	TO	TO-Toro	-	EPS -- Electric Power Steering	Live Data	-	
2017	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2017	TO	TO-Toro	-	EPS -- Electric Power Steering	Special Functions	Steering angle sensor	
2017	TO	TO-Toro	-	AMP -- Amplifier	ECU Information	-	
2017	TO	TO-Toro	-	AMP -- Amplifier	Read Codes	-	
2017	TO	TO-Toro	-	AMP -- Amplifier	Erase codes	-	
2017	TO	TO-Toro	-	AMP -- Amplifier	Live Data	-	
2017	TO	TO-Toro	-	AMP -- Amplifier	Actuators	-	
2017	TO	TO-Toro	-	AMP -- Amplifier	ECU Configure Information	-	
2017	TO	TO-Toro	-	AMP -- Amplifier	System Tests	Audio Measure AC+DC	
2017	TO	TO-Toro	-	AMP -- Amplifier	System Tests	Output Short Test	
2017	TO	TO-Toro	-	AMP -- Amplifier	System Tests	Tone Test	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH immobilizer antenna test	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH locate learned keys	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM sensor rolls tests	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM Update FF FR Axle Nom Tire Press Val	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left front tire sensor Id	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left rear tire sensor Id	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right front tire sensor Id	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right rear tire sensor Id	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Audit	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Clear TPM Sensor Warnings	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	Door Handle Verification Test	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH immobilizer antenna test	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH locate learned keys	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM sensor rolls tests	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM Update FF FR Axle Nom Tire Press Val	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program left front tire sensor Id	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right front tire sensor Id	
2017	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Special Functions	RFH TPM program right rear tire sensor Id	
2017	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2017	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2017	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2017	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2017	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2017	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2017	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2017	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2017	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2017	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2017	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2017	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2017	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2017	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Live Data	-	
2017	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2017	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Special Functions	Service Single Pole Calibration	
2017	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Information	-	
2017	TO	TO-Toro	-	TTM -- Trailer tow module	Read Codes	-	
2017	TO	TO-Toro	-	TTM -- Trailer tow module	Erase codes	-	
2017	TO	TO-Toro	-	TTM -- Trailer tow module	Live Data	-	
2017	TO	TO-Toro	-	TTM -- Trailer tow module	Actuators	-	
2017	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Configure Information	-	
2017	TO	TO-Toro	-	DMM -- Door Management Module	ECU Information	-	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Read Codes	-	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Erase codes	-	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Live Data	-	
2017	TO	TO-Toro	-	DMM -- Door Management Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Driver Mirror Axis X Command	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Driver Mirror Axis Y Command	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Fold Mirror	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Passenger Mirror Axis X Command	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Passenger Mirror Axis Y Command	
2017	TO	TO-Toro	-	DMM -- Door Management Module	Special Functions	Unfold Mirror	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tip	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fuel supply system components replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector/s replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rpm sensor and/or timing chain replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Replacement of Lambda sensor	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Reset adaptive parameters	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Oil change	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2018	PD	PD-Egea/Tipò	-	ECM -- Engine Control Module	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Engine replacement	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Motorized Throttle learning	
2018	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Clear Self Learning Data	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox replacement	
2018	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Neutral Position Self-Learning	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	Special Functions	Control unit replacement	
2018	PD	PD-Egea/Tipo	-	ESM -- Electronic Shifter	System Tests	Led display test of gear lever position	
2018	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ACC -- Adaptive Cruise Control	Special Functions	Active alignment procedure: radar calibration.	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Live Data	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Actuators	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Live Data	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Actuators	-	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2018	PD	PD-Egea/Tipo	-	BCM -- Body Controller	Special Functions	PROXI alignment procedure	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	TPMS calibration	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor type test	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ABS -- Anti Lock Brakes	Special Functions	Static Test	
2018	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2018	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Actuators	-	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Audio signal detection	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Power Down	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Power on and Disable User Input	
2018	PD	PD-Egea/Tipo	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio test for subwoofer specific	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Audio video signal detection	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power Down	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Power on and disable user inputs	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	Reset Parameters to Default	
2018	PD	PD-Egea/Tipo	-	ETM -- Entertainment Telematic Module	Special Functions	UConnect Live apps installation	
2018	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	Live Data	-	
2018	PD	PD-Egea/Tipo	-	AHM -- Additional Heater Module	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Enable/Disable Seatbelt Minder	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Reset odometer	
2018	PD	PD-Egea/Tipo	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement instrument panel cluster	













## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2018	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2018	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2018	FB	FB-500X	-	DTCM -- Drive Train Control Module	ECU Information	-	
2018	FB	FB-500X	-	DTCM -- Drive Train Control Module	Read Codes	-	
2018	FB	FB-500X	-	DTCM -- Drive Train Control Module	Erase codes	-	
2018	FB	FB-500X	-	DTCM -- Drive Train Control Module	Live Data	-	
2018	FB	FB-500X	-	ESL -- Electronic Steering Lock	ECU Information	-	
2018	FB	FB-500X	-	ESL -- Electronic Steering Lock	Read Codes	-	
2018	FB	FB-500X	-	ESL -- Electronic Steering Lock	Erase codes	-	
2018	FB	FB-500X	-	ESL -- Electronic Steering Lock	Live Data	-	
2018	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2018	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2018	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2018	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2018	FB	FB-500X	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2018	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2018	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2018	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2018	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2018	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2018	FB	FB-500X	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2018	FB	FB-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2018	FB	FB-500X	-	PAM -- Park Assist Module	ECU Information	-	
2018	FB	FB-500X	-	PAM -- Park Assist Module	Read Codes	-	
2018	FB	FB-500X	-	PAM -- Park Assist Module	Erase codes	-	
2018	FB	FB-500X	-	PAM -- Park Assist Module	Live Data	-	
2018	FB	FB-500X	-	EPS -- Electric Power Steering	ECU Information	-	
2018	FB	FB-500X	-	EPS -- Electric Power Steering	Read Codes	-	
2018	FB	FB-500X	-	EPS -- Electric Power Steering	Erase codes	-	
2018	FB	FB-500X	-	EPS -- Electric Power Steering	Live Data	-	
2018	FB	FB-500X	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2018	FB	FB-500X	-	AMP -- Amplifier	ECU Information	-	
2018	FB	FB-500X	-	AMP -- Amplifier	Read Codes	-	
2018	FB	FB-500X	-	AMP -- Amplifier	Erase codes	-	
2018	FB	FB-500X	-	AMP -- Amplifier	Live Data	-	
2018	FB	FB-500X	-	AMP -- Amplifier	Actuators	-	
2018	FB	FB-500X	-	AMP -- Amplifier	ECU Configure Information	-	
2018	FB	FB-500X	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	FB	FB-500X	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	FB	FB-500X	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2018	FB	FB-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	FB	FB-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	ECU Information	-	
2018	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2018	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2018	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2018	FB	FB-500X	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2018	FB	FB-500X	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2018	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2018	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2018	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Live Data	-	
2018	FB	FB-500X	-	HALF -- Haptical Lane Feedback	Actuators	-	
2018	FB	FB-500X	-	RRM -- Radio Receiver Module	ECU Information	-	
2018	FB	FB-500X	-	RRM -- Radio Receiver Module	Read Codes	-	
2018	FB	FB-500X	-	RRM -- Radio Receiver Module	Erase codes	-	
2018	FB	FB-500X	-	RRM -- Radio Receiver Module	Live Data	-	
2018	FB	FB-500X	-	RRM -- Radio Receiver Module	Actuators	-	
2018	FB	FB-500X	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Actuators	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	ECU Information	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Read Codes	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Erase codes	-	
2018	FF	FF-500	-	PCM -- Powertrain Control Module	Live Data	-	









## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2018	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2018	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2018	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2018	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2018	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2018	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2018	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2018	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2018	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Read Codes	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Erase codes	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Live Data	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Actuators	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Read Codes	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Erase codes	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Live Data	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Actuators	-	
2018	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2018	TO	TO-Toro	-	PAM -- Park Assist Module	ECU Information	-	
2018	TO	TO-Toro	-	PAM -- Park Assist Module	Read Codes	-	
2018	TO	TO-Toro	-	PAM -- Park Assist Module	Erase codes	-	
2018	TO	TO-Toro	-	PAM -- Park Assist Module	Live Data	-	
2018	TO	TO-Toro	-	PAM -- Park Assist Module	ECU Information	-	
2018	TO	TO-Toro	-	PAM -- Park Assist Module	Read Codes	-	
2018	TO	TO-Toro	-	PAM -- Park Assist Module	Erase codes	-	
2018	TO	TO-Toro	-	PAM -- Park Assist Module	Live Data	-	
2018	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Information	-	
2018	TO	TO-Toro	-	EPS -- Electric Power Steering	Read Codes	-	
2018	TO	TO-Toro	-	EPS -- Electric Power Steering	Erase codes	-	
2018	TO	TO-Toro	-	EPS -- Electric Power Steering	Live Data	-	
2018	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2018	TO	TO-Toro	-	AMP -- Amplifier	ECU Information	-	
2018	TO	TO-Toro	-	AMP -- Amplifier	Read Codes	-	
2018	TO	TO-Toro	-	AMP -- Amplifier	Erase codes	-	
2018	TO	TO-Toro	-	AMP -- Amplifier	Live Data	-	
2018	TO	TO-Toro	-	AMP -- Amplifier	Actuators	-	
2018	TO	TO-Toro	-	AMP -- Amplifier	ECU Configure Information	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2018	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2018	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2018	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2018	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Live Data	-	
2018	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2018	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Information	-	
2018	TO	TO-Toro	-	TTM -- Trailer tow module	Read Codes	-	
2018	TO	TO-Toro	-	TTM -- Trailer tow module	Erase codes	-	
2018	TO	TO-Toro	-	TTM -- Trailer tow module	Live Data	-	
2018	TO	TO-Toro	-	TTM -- Trailer tow module	Actuators	-	
2018	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Configure Information	-	
2019	FD	FD-500X	-	ECM -- Engine Control Module	ECU Information	-	
2019	FD	FD-500X	-	ECM -- Engine Control Module	Read Codes	-	
2019	FD	FD-500X	-	ECM -- Engine Control Module	Erase codes	-	
2019	FD	FD-500X	-	ECM -- Engine Control Module	Live Data	-	
2019	FD	FD-500X	-	ECM -- Engine Control Module	Actuators	-	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2019	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2019	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2019	FD	FD-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2019	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	ECU Information	-	
2019	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2019	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2019	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2019	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2019	FD	FD-500X	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2019	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2019	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2019	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Live Data	-	
2019	FD	FD-500X	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2019	FD	FD-500X	-	RRM -- Radio Receiver Module	ECU Information	-	
2019	FD	FD-500X	-	RRM -- Radio Receiver Module	Read Codes	-	
2019	FD	FD-500X	-	RRM -- Radio Receiver Module	Erase codes	-	
2019	FD	FD-500X	-	RRM -- Radio Receiver Module	Live Data	-	
2019	FD	FD-500X	-	RRM -- Radio Receiver Module	Actuators	-	
2019	FD	FD-500X	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	BCM -- Body Controller	ECU Information	-	
2016	RE	RE-Tango/Talento	-	BCM -- Body Controller	Read Codes	-	
2016	RE	RE-Tango/Talento	-	BCM -- Body Controller	Erase codes	-	
2016	RE	RE-Tango/Talento	-	BCM -- Body Controller	Live Data	-	
2016	RE	RE-Tango/Talento	-	BCM -- Body Controller	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	RE	RE-Tango/Talento	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	RE	RE-Tango/Talento	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	RE	RE-Tango/Talento	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	RE	RE-Tango/Talento	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	RE	RE-Tango/Talento	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	RE	RE-Tango/Talento	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	RE	RE-Tango/Talento	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	RE	RE-Tango/Talento	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	RE	RE-Tango/Talento	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	PAM -- Park Assist Module	ECU Information	-	
2016	RE	RE-Tango/Talento	-	PAM -- Park Assist Module	Read Codes	-	
2016	RE	RE-Tango/Talento	-	PAM -- Park Assist Module	Erase codes	-	
2016	RE	RE-Tango/Talento	-	PAM -- Park Assist Module	Live Data	-	
2016	RE	RE-Tango/Talento	-	PAM -- Park Assist Module	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	EPS -- Electric Power Steering	ECU Information	-	
2016	RE	RE-Tango/Talento	-	EPS -- Electric Power Steering	Read Codes	-	
2016	RE	RE-Tango/Talento	-	EPS -- Electric Power Steering	Erase codes	-	
2016	RE	RE-Tango/Talento	-	EPS -- Electric Power Steering	Live Data	-	
2016	RE	RE-Tango/Talento	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	RADIO -- Radio	ECU Information	-	
2016	RE	RE-Tango/Talento	-	RADIO -- Radio	Read Codes	-	
2016	RE	RE-Tango/Talento	-	RADIO -- Radio	Erase codes	-	
2016	RE	RE-Tango/Talento	-	RADIO -- Radio	Live Data	-	
2016	RE	RE-Tango/Talento	-	RADIO -- Radio	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	RE	RE-Tango/Talento	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	RE	RE-Tango/Talento	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	RE	RE-Tango/Talento	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	RE	RE-Tango/Talento	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	DCU -- Dosing Control Unit	ECU Information	-	
2016	RE	RE-Tango/Talento	-	DCU -- Dosing Control Unit	Read Codes	-	
2016	RE	RE-Tango/Talento	-	DCU -- Dosing Control Unit	Erase codes	-	
2016	RE	RE-Tango/Talento	-	DCU -- Dosing Control Unit	Live Data	-	
2016	RE	RE-Tango/Talento	-	DCU -- Dosing Control Unit	ECU Configure Information	-	
2016	RE	RE-Tango/Talento	-	EMM -- Energy Management Module	ECU Information	-	
2016	RE	RE-Tango/Talento	-	EMM -- Energy Management Module	Read Codes	-	
2016	RE	RE-Tango/Talento	-	EMM -- Energy Management Module	Erase codes	-	
2016	RE	RE-Tango/Talento	-	EMM -- Energy Management Module	Live Data	-	
2016	BW	BW-B-Sedan SW	-	ECM -- Engine Control Module	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	ECM -- Engine Control Module	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	ECM -- Engine Control Module	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	ECM -- Engine Control Module	Live Data	-	
2016	BW	BW-B-Sedan SW	-	ECM -- Engine Control Module	Actuators	-	
2016	BW	BW-B-Sedan SW	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	TCM -- Transmission Control Module	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	TCM -- Transmission Control Module	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	TCM -- Transmission Control Module	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	TCM -- Transmission Control Module	Live Data	-	
2016	BW	BW-B-Sedan SW	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	ESM -- Electronic Shifter	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	ESM -- Electronic Shifter	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	ESM -- Electronic Shifter	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	ESM -- Electronic Shifter	Live Data	-	
2016	BW	BW-B-Sedan SW	-	ESM -- Electronic Shifter	Actuators	-	
2016	BW	BW-B-Sedan SW	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	ACC -- Adaptive Cruise Control	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	ACC -- Adaptive Cruise Control	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	ACC -- Adaptive Cruise Control	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	ACC -- Adaptive Cruise Control	Live Data	-	
2016	BW	BW-B-Sedan SW	-	ACC -- Adaptive Cruise Control	Actuators	-	
2016	BW	BW-B-Sedan SW	-	ACC -- Adaptive Cruise Control	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	BCM -- Body Controller	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	BCM -- Body Controller	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	BCM -- Body Controller	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	BCM -- Body Controller	Live Data	-	
2016	BW	BW-B-Sedan SW	-	BCM -- Body Controller	Actuators	-	
2016	BW	BW-B-Sedan SW	-	BCM -- Body Controller	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	BW	BW-B-Sedan SW	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	BW	BW-B-Sedan SW	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	BW	BW-B-Sedan SW	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	ABS -- Anti Lock Brakes	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	BW	BW-B-Sedan SW	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	BW	BW-B-Sedan SW	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	BW	BW-B-Sedan SW	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	PAM -- Park Assist Module	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	PAM -- Park Assist Module	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	PAM -- Park Assist Module	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	PAM -- Park Assist Module	Live Data	-	
2016	BW	BW-B-Sedan SW	-	EPS -- Electric Power Steering	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	EPS -- Electric Power Steering	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	EPS -- Electric Power Steering	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	EPS -- Electric Power Steering	Live Data	-	
2016	BW	BW-B-Sedan SW	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	BW	BW-B-Sedan SW	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	BW	BW-B-Sedan SW	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	BW	BW-B-Sedan SW	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	BW	BW-B-Sedan SW	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	BW	BW-B-Sedan SW	-	RRM -- Radio Receiver Module	ECU Information	-	
2016	BW	BW-B-Sedan SW	-	RRM -- Radio Receiver Module	Read Codes	-	
2016	BW	BW-B-Sedan SW	-	RRM -- Radio Receiver Module	Erase codes	-	
2016	BW	BW-B-Sedan SW	-	RRM -- Radio Receiver Module	Live Data	-	
2016	BW	BW-B-Sedan SW	-	RRM -- Radio Receiver Module	Actuators	-	
2016	BW	BW-B-Sedan SW	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2016	MM	MM-Fullback	-	ECM -- Engine Control Module	ECU Information	-	
2016	MM	MM-Fullback	-	ECM -- Engine Control Module	Read Codes	-	
2016	MM	MM-Fullback	-	ECM -- Engine Control Module	Erase codes	-	
2016	MM	MM-Fullback	-	ECM -- Engine Control Module	Live Data	-	
2016	MM	MM-Fullback	-	ECM -- Engine Control Module	Actuators	-	
2016	MM	MM-Fullback	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	MM	MM-Fullback	-	TCM -- Transmission Control Module	ECU Information	-	
2016	MM	MM-Fullback	-	TCM -- Transmission Control Module	Read Codes	-	
2016	MM	MM-Fullback	-	TCM -- Transmission Control Module	Erase codes	-	
2016	MM	MM-Fullback	-	TCM -- Transmission Control Module	Live Data	-	
2016	MM	MM-Fullback	-	TCM -- Transmission Control Module	Actuators	-	
2016	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	ECU Information	-	
2016	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	Read Codes	-	
2016	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	Erase codes	-	
2016	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	Live Data	-	
2016	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	ECU Configure Information	-	
2016	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2016	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	ECU Information	-	
2016	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	Read Codes	-	
2016	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	Erase codes	-	
2016	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	Live Data	-	
2016	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	Actuators	-	
2016	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	MM	MM-Fullback	-	SAS -- Steering Angle Sensor	ECU Information	-	
2016	MM	MM-Fullback	-	SAS -- Steering Angle Sensor	Read Codes	-	
2016	MM	MM-Fullback	-	SAS -- Steering Angle Sensor	Erase codes	-	
2016	MM	MM-Fullback	-	SAS -- Steering Angle Sensor	Live Data	-	
2016	MM	MM-Fullback	-	ESS -- Electronic Stop Start	ECU Information	-	
2016	MM	MM-Fullback	-	ESS -- Electronic Stop Start	Read Codes	-	
2016	MM	MM-Fullback	-	ESS -- Electronic Stop Start	Erase codes	-	
2016	MM	MM-Fullback	-	ESS -- Electronic Stop Start	Live Data	-	
2016	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	ECU Information	-	
2016	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	Read Codes	-	
2016	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	Erase codes	-	
2016	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	Live Data	-	
2016	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	Actuators	-	
2016	MM	MM-Fullback	-	FFCM -- Forward Facing Camera Module	ECU Information	-	
2016	MM	MM-Fullback	-	FFCM -- Forward Facing Camera Module	Read Codes	-	
2016	MM	MM-Fullback	-	FFCM -- Forward Facing Camera Module	Erase codes	-	
2016	MM	MM-Fullback	-	FFCM -- Forward Facing Camera Module	Live Data	-	
2017	MM	MM-Fullback	-	ECM -- Engine Control Module	ECU Information	-	
2017	MM	MM-Fullback	-	ECM -- Engine Control Module	Read Codes	-	
2017	MM	MM-Fullback	-	ECM -- Engine Control Module	Erase codes	-	
2017	MM	MM-Fullback	-	ECM -- Engine Control Module	Live Data	-	
2017	MM	MM-Fullback	-	ECM -- Engine Control Module	Actuators	-	
2017	MM	MM-Fullback	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	MM	MM-Fullback	-	TCM -- Transmission Control Module	ECU Information	-	
2017	MM	MM-Fullback	-	TCM -- Transmission Control Module	Read Codes	-	
2017	MM	MM-Fullback	-	TCM -- Transmission Control Module	Erase codes	-	
2017	MM	MM-Fullback	-	TCM -- Transmission Control Module	Live Data	-	
2017	MM	MM-Fullback	-	TCM -- Transmission Control Module	Actuators	-	
2017	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	ECU Information	-	
2017	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	Read Codes	-	
2017	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	Erase codes	-	
2017	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	Live Data	-	
2017	MM	MM-Fullback	-	BCMCGW -- Body Control Module And Central Gateway	ECU Configure Information	-	
2017	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2017	MM	MM-Fullback	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	MM	MM-Fullback	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	ECU Information	-	
2017	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	Read Codes	-	
2017	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	Erase codes	-	
2017	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	Live Data	-	
2017	MM	MM-Fullback	-	DTCM -- Drive Train Control Module	Actuators	-	
2017	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	MM	MM-Fullback	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	MM	MM-Fullback	-	SAS -- Steering Angle Sensor	ECU Information	-	
2017	MM	MM-Fullback	-	SAS -- Steering Angle Sensor	Read Codes	-	
2017	MM	MM-Fullback	-	SAS -- Steering Angle Sensor	Erase codes	-	
2017	MM	MM-Fullback	-	SAS -- Steering Angle Sensor	Live Data	-	
2017	MM	MM-Fullback	-	ESS -- Electronic Stop Start	ECU Information	-	
2017	MM	MM-Fullback	-	ESS -- Electronic Stop Start	Read Codes	-	
2017	MM	MM-Fullback	-	ESS -- Electronic Stop Start	Erase codes	-	
2017	MM	MM-Fullback	-	ESS -- Electronic Stop Start	Live Data	-	
2017	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	MM	MM-Fullback	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	MM	MM-Fullback	-	RFH -- Radio Frequency Hub	Actuators	-	
2017	MM	MM-Fullback	-	FFCM -- Forward Facing Camera Module	ECU Information	-	
2017	MM	MM-Fullback	-	FFCM -- Forward Facing Camera Module	Read Codes	-	
2017	MM	MM-Fullback	-	FFCM -- Forward Facing Camera Module	Erase codes	-	
2017	MM	MM-Fullback	-	FFCM -- Forward Facing Camera Module	Live Data	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	ECU Information	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Read Codes	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Erase codes	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Live Data	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Actuators	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	ECU Information	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Read Codes	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Erase codes	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Live Data	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Actuators	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Freeze Frame	-	
2017	JF	JF-Freemont	-	ECM -- Engine Control Module	Event Data	-	
2017	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Information	-	
2017	JF	JF-Freemont	-	TCM -- Transmission Control Module	Read Codes	-	
2017	JF	JF-Freemont	-	TCM -- Transmission Control Module	Erase codes	-	
2017	JF	JF-Freemont	-	TCM -- Transmission Control Module	Live Data	-	
2017	JF	JF-Freemont	-	TCM -- Transmission Control Module	Actuators	-	
2017	JF	JF-Freemont	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	ECU Information	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	Read Codes	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	Erase codes	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	Live Data	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	Actuators	-	
2017	JF	JF-Freemont	-	BCM -- Body Controller	ECU Configure Information	-	
2017	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	JF	JF-Freemont	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	JF	JF-Freemont	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Information	-	
2017	JF	JF-Freemont	-	DDM -- Driver Door Module	Read Codes	-	
2017	JF	JF-Freemont	-	DDM -- Driver Door Module	Erase codes	-	
2017	JF	JF-Freemont	-	DDM -- Driver Door Module	Live Data	-	
2017	JF	JF-Freemont	-	DDM -- Driver Door Module	Actuators	-	
2017	JF	JF-Freemont	-	DDM -- Driver Door Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Information	-	
2017	JF	JF-Freemont	-	PDM -- Passenger Door Module	Read Codes	-	
2017	JF	JF-Freemont	-	PDM -- Passenger Door Module	Erase codes	-	
2017	JF	JF-Freemont	-	PDM -- Passenger Door Module	Live Data	-	
2017	JF	JF-Freemont	-	PDM -- Passenger Door Module	Actuators	-	
2017	JF	JF-Freemont	-	PDM -- Passenger Door Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Information	-	
2017	JF	JF-Freemont	-	HSM -- Heated Seat Module	Read Codes	-	
2017	JF	JF-Freemont	-	HSM -- Heated Seat Module	Erase codes	-	
2017	JF	JF-Freemont	-	HSM -- Heated Seat Module	Live Data	-	
2017	JF	JF-Freemont	-	HSM -- Heated Seat Module	Actuators	-	
2017	JF	JF-Freemont	-	HSM -- Heated Seat Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	PTS -- Parktronics	ECU Information	-	
2017	JF	JF-Freemont	-	PTS -- Parktronics	Read Codes	-	
2017	JF	JF-Freemont	-	PTS -- Parktronics	Erase codes	-	
2017	JF	JF-Freemont	-	PTS -- Parktronics	Live Data	-	
2017	JF	JF-Freemont	-	PTS -- Parktronics	Actuators	-	
2017	JF	JF-Freemont	-	PTS -- Parktronics	ECU Configure Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Information	-	
2017	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Read Codes	-	
2017	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Erase codes	-	
2017	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Live Data	-	
2017	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	Actuators	-	
2017	JF	JF-Freemont	-	ITM -- Intrusion Transceiver Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Information	-	
2017	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Read Codes	-	
2017	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Erase codes	-	
2017	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Live Data	-	
2017	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	Actuators	-	
2017	JF	JF-Freemont	-	DTCM -- Drive Train Control Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	ICS -- Integrated Center Stack	ECU Information	-	
2017	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Read Codes	-	
2017	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Erase codes	-	
2017	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Live Data	-	
2017	JF	JF-Freemont	-	ICS -- Integrated Center Stack	Actuators	-	
2017	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	ECU Information	-	
2017	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Read Codes	-	
2017	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Erase codes	-	
2017	JF	JF-Freemont	-	SCCM -- Steering Column Control Module	Live Data	-	
2017	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	JF	JF-Freemont	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2017	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2017	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2017	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	Live Data	-	
2017	JF	JF-Freemont	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2017	JF	JF-Freemont	-	AMP -- Amplifier	ECU Information	-	
2017	JF	JF-Freemont	-	AMP -- Amplifier	Read Codes	-	
2017	JF	JF-Freemont	-	AMP -- Amplifier	Erase codes	-	
2017	JF	JF-Freemont	-	AMP -- Amplifier	Live Data	-	
2017	JF	JF-Freemont	-	HFM -- Hands Free Module	ECU Information	-	
2017	JF	JF-Freemont	-	HFM -- Hands Free Module	Read Codes	-	
2017	JF	JF-Freemont	-	HFM -- Hands Free Module	Erase codes	-	
2017	JF	JF-Freemont	-	HFM -- Hands Free Module	Live Data	-	
2017	JF	JF-Freemont	-	VES3 -- Last Row Screen	ECU Information	-	
2017	JF	JF-Freemont	-	VES3 -- Last Row Screen	Read Codes	-	
2017	JF	JF-Freemont	-	VES3 -- Last Row Screen	Erase codes	-	
2017	JF	JF-Freemont	-	VES3 -- Last Row Screen	Live Data	-	
2017	JF	JF-Freemont	-	VES3 -- Last Row Screen	Actuators	-	
2017	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Information	-	
2017	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Read Codes	-	
2017	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Erase codes	-	
2017	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	Live Data	-	
2017	JF	JF-Freemont	-	EPPM -- Electronic Pedestrian Protection Module	ECU Configure Information	-	
2017	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	JF	JF-Freemont	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	Actuators	-	
2017	JF	JF-Freemont	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2017	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Information	-	
2017	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Read Codes	-	
2017	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Erase codes	-	
2017	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	Live Data	-	
2017	JF	JF-Freemont	-	TGW -- Telematic Gateway Radio	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	ECU Information	-	
2016	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Read Codes	-	
2016	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Erase codes	-	
2016	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Live Data	-	
2016	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Actuators	-	
2016	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Freeze Frame	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Freeze Frame	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Freeze Frame	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2016	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2016	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	ECU Information	-	
2016	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Read Codes	-	
2016	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Erase codes	-	
2016	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Live Data	-	
2016	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Actuators	-	
2016	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	ECU Configure Information	-	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Information	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	Read Codes	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	Erase codes	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	Live Data	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	Actuators	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Information	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	Read Codes	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	Erase codes	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	Live Data	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	Actuators	-	
2016	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2016	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2016	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	ECU Information	-	
2016	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Read Codes	-	
2016	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Erase codes	-	
2016	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Live Data	-	
2016	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Actuators	-	
2016	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	ECU Information	-	
2016	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Read Codes	-	
2016	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Erase codes	-	
2016	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Live Data	-	
2016	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2016	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2016	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2016	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Live Data	-	
2016	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Actuators	-	
2016	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2016	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	ECU Information	-	
2016	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Read Codes	-	
2016	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Erase codes	-	
2016	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Live Data	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Live Data	-	
2016	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Actuators	-	
2016	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2016	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2016	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2016	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Live Data	-	
2016	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Actuators	-	
2016	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	ECU Information	-	
2017	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Read Codes	-	
2017	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Erase codes	-	
2017	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Live Data	-	
2017	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Actuators	-	
2017	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	ECM -- Engine Control Module	Freeze Frame	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Freeze Frame	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	ECU Information	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Read Codes	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Erase codes	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Live Data	-	
2017	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Actuators	-	
2017	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	ECU Information	-	
2017	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Read Codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2017	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Erase codes	-	
2017	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Live Data	-	
2017	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	Actuators	-	
2017	BF	BF-Fiat 500L	-	ESM -- Electronic Shifter	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Information	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	Read Codes	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	Erase codes	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	Live Data	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	Actuators	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Information	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	Read Codes	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	Erase codes	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	Live Data	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	Actuators	-	
2017	BF	BF-Fiat 500L	-	BCM -- Body Controller	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	BF	BF-Fiat 500L	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	BF	BF-Fiat 500L	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	Actuators	-	
2017	BF	BF-Fiat 500L	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	ECU Information	-	
2017	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Read Codes	-	
2017	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Erase codes	-	
2017	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Live Data	-	
2017	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2017	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2017	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2017	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Live Data	-	
2017	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	Actuators	-	
2017	BF	BF-Fiat 500L	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2017	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	ECU Information	-	
2017	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Read Codes	-	
2017	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Erase codes	-	
2017	BF	BF-Fiat 500L	-	EPS -- Electric Power Steering	Live Data	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Actuators	-	
2017	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2017	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Live Data	-	
2017	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	Actuators	-	
2017	BF	BF-Fiat 500L	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Read Codes	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Erase codes	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Live Data	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Actuators	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Freeze Frame	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Read Codes	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Erase codes	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Live Data	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Actuators	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Freeze Frame	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Read Codes	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Erase codes	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Live Data	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Actuators	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Freeze Frame	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Read Codes	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Erase codes	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Live Data	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Actuators	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Configure Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Freeze Frame	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	ECU Information	-	
2016	FF	FF-500	-	ECM -- Engine Control Module	Read Codes	-	























**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	DB	DB-Doblo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Live Data	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Actuators	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Live Data	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Actuators	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Live Data	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Actuators	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	ECU Information	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Read Codes	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Erase codes	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Live Data	-	
2018	DB	DB-Doblo	-	CTM -- Convergence Telematic Module	Actuators	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	DB	DB-Doblo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	DB	DB-Doblo	-	DCU -- Dosing Control Unit	ECU Information	-	
2018	DB	DB-Doblo	-	DCU -- Dosing Control Unit	Read Codes	-	
2018	DB	DB-Doblo	-	DCU -- Dosing Control Unit	Erase codes	-	
2018	DB	DB-Doblo	-	DCU -- Dosing Control Unit	Live Data	-	
2017	BA	BA-Spider	-	ECM -- Engine Control Module	ECU Information	-	
2017	BA	BA-Spider	-	ECM -- Engine Control Module	Read Codes	-	
2017	BA	BA-Spider	-	ECM -- Engine Control Module	Erase codes	-	
2017	BA	BA-Spider	-	ECM -- Engine Control Module	Live Data	-	
2017	BA	BA-Spider	-	ECM -- Engine Control Module	Actuators	-	
2017	BA	BA-Spider	-	ECM -- Engine Control Module	ECU Configure Information	-	
2017	BA	BA-Spider	-	BCM -- Body Controller	ECU Information	-	
2017	BA	BA-Spider	-	BCM -- Body Controller	Read Codes	-	
2017	BA	BA-Spider	-	BCM -- Body Controller	Erase codes	-	
2017	BA	BA-Spider	-	BCM -- Body Controller	Live Data	-	
2017	BA	BA-Spider	-	BCM -- Body Controller	ECU Configure Information	-	
2017	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2017	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2017	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2017	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2017	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2017	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2017	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2017	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2017	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2017	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2017	BA	BA-Spider	-	BSM -- Blind Spot Module	ECU Information	-	
2017	BA	BA-Spider	-	BSM -- Blind Spot Module	Read Codes	-	
2017	BA	BA-Spider	-	BSM -- Blind Spot Module	Erase codes	-	
2017	BA	BA-Spider	-	BSM -- Blind Spot Module	Live Data	-	
2017	BA	BA-Spider	-	BSM -- Blind Spot Module	ECU Configure Information	-	
2017	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2017	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2017	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2017	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2017	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	ECU Configure Information	-	
2017	BA	BA-Spider	-	ABS -- Anti Lock Brakes	ECU Information	-	
2017	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Read Codes	-	
2017	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Erase codes	-	
2017	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Live Data	-	
2017	BA	BA-Spider	-	EPS -- Electric Power Steering	ECU Information	-	
2017	BA	BA-Spider	-	EPS -- Electric Power Steering	Read Codes	-	
2017	BA	BA-Spider	-	EPS -- Electric Power Steering	Erase codes	-	
2017	BA	BA-Spider	-	EPS -- Electric Power Steering	Live Data	-	
2017	BA	BA-Spider	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2017	BA	BA-Spider	-	LSM -- Lighting Supply Module	ECU Information	-	
2017	BA	BA-Spider	-	LSM -- Lighting Supply Module	Read Codes	-	
2017	BA	BA-Spider	-	LSM -- Lighting Supply Module	Erase codes	-	
2017	BA	BA-Spider	-	AMP -- Amplifier	ECU Information	-	
2017	BA	BA-Spider	-	AMP -- Amplifier	Read Codes	-	
2017	BA	BA-Spider	-	AMP -- Amplifier	Erase codes	-	
2017	BA	BA-Spider	-	AMP -- Amplifier	ECU Configure Information	-	
2017	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2017	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2017	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2017	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Live Data	-	
2017	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2017	BA	BA-Spider	-	RFH -- Radio Frequency Hub	ECU Information	-	
2017	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Read Codes	-	
2017	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Erase codes	-	
2017	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Live Data	-	
2017	BA	BA-Spider	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2017	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2017	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2017	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	BA	BA-Spider	-	ECM -- Engine Control Module	ECU Information	-	
2018	BA	BA-Spider	-	ECM -- Engine Control Module	Read Codes	-	

**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3.compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	BA	BA-Spider	-	ECM -- Engine Control Module	Erase codes	-	
2018	BA	BA-Spider	-	ECM -- Engine Control Module	Live Data	-	
2018	BA	BA-Spider	-	ECM -- Engine Control Module	Actuators	-	
2018	BA	BA-Spider	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	BA	BA-Spider	-	BCM -- Body Controller	ECU Information	-	
2018	BA	BA-Spider	-	BCM -- Body Controller	Read Codes	-	
2018	BA	BA-Spider	-	BCM -- Body Controller	Erase codes	-	
2018	BA	BA-Spider	-	BCM -- Body Controller	Live Data	-	
2018	BA	BA-Spider	-	BCM -- Body Controller	ECU Configure Information	-	
2018	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2018	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2018	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2018	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2018	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2018	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2018	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2018	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2018	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2018	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2018	BA	BA-Spider	-	BSM -- Blind Spot Module	ECU Information	-	
2018	BA	BA-Spider	-	BSM -- Blind Spot Module	Read Codes	-	
2018	BA	BA-Spider	-	BSM -- Blind Spot Module	Erase codes	-	
2018	BA	BA-Spider	-	BSM -- Blind Spot Module	Live Data	-	
2018	BA	BA-Spider	-	BSM -- Blind Spot Module	ECU Configure Information	-	
2018	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2018	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2018	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2018	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2018	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	ECU Configure Information	-	
2018	BA	BA-Spider	-	ABS -- Anti Lock Brakes	ECU Information	-	
2018	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Read Codes	-	
2018	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Erase codes	-	
2018	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Live Data	-	
2018	BA	BA-Spider	-	EPS -- Electric Power Steering	ECU Information	-	
2018	BA	BA-Spider	-	EPS -- Electric Power Steering	Read Codes	-	
2018	BA	BA-Spider	-	EPS -- Electric Power Steering	Erase codes	-	
2018	BA	BA-Spider	-	EPS -- Electric Power Steering	Live Data	-	
2018	BA	BA-Spider	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2018	BA	BA-Spider	-	LSM -- Lighting Supply Module	ECU Information	-	
2018	BA	BA-Spider	-	LSM -- Lighting Supply Module	Read Codes	-	
2018	BA	BA-Spider	-	LSM -- Lighting Supply Module	Erase codes	-	
2018	BA	BA-Spider	-	AMP -- Amplifier	ECU Information	-	
2018	BA	BA-Spider	-	AMP -- Amplifier	Read Codes	-	
2018	BA	BA-Spider	-	AMP -- Amplifier	Erase codes	-	
2018	BA	BA-Spider	-	AMP -- Amplifier	ECU Configure Information	-	
2018	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2018	BA	BA-Spider	-	RFH -- Radio Frequency Hub	ECU Information	-	
2018	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Read Codes	-	
2018	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Erase codes	-	
2018	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Live Data	-	
2018	BA	BA-Spider	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2018	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2019	BA	BA-Spider	-	ECM -- Engine Control Module	ECU Information	-	
2019	BA	BA-Spider	-	ECM -- Engine Control Module	Read Codes	-	
2019	BA	BA-Spider	-	ECM -- Engine Control Module	Erase codes	-	
2019	BA	BA-Spider	-	ECM -- Engine Control Module	Live Data	-	
2019	BA	BA-Spider	-	ECM -- Engine Control Module	Actuators	-	
2019	BA	BA-Spider	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	BA	BA-Spider	-	BCM -- Body Controller	ECU Information	-	
2019	BA	BA-Spider	-	BCM -- Body Controller	Read Codes	-	
2019	BA	BA-Spider	-	BCM -- Body Controller	Erase codes	-	
2019	BA	BA-Spider	-	BCM -- Body Controller	Live Data	-	
2019	BA	BA-Spider	-	BCM -- Body Controller	ECU Configure Information	-	
2019	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2019	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2019	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2019	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2019	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2019	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2019	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2019	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2019	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2019	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2019	BA	BA-Spider	-	BSM -- Blind Spot Module	ECU Information	-	
2019	BA	BA-Spider	-	BSM -- Blind Spot Module	Read Codes	-	
2019	BA	BA-Spider	-	BSM -- Blind Spot Module	Erase codes	-	
2019	BA	BA-Spider	-	BSM -- Blind Spot Module	Live Data	-	
2019	BA	BA-Spider	-	BSM -- Blind Spot Module	ECU Configure Information	-	
2019	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2019	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2019	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2019	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2019	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	ECU Configure Information	-	
2019	BA	BA-Spider	-	ABS -- Anti Lock Brakes	ECU Information	-	
2019	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Read Codes	-	
2019	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Erase codes	-	
2019	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Live Data	-	
2019	BA	BA-Spider	-	EPS -- Electric Power Steering	ECU Information	-	
2019	BA	BA-Spider	-	EPS -- Electric Power Steering	Read Codes	-	
2019	BA	BA-Spider	-	EPS -- Electric Power Steering	Erase codes	-	
2019	BA	BA-Spider	-	EPS -- Electric Power Steering	Live Data	-	
2019	BA	BA-Spider	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2019	BA	BA-Spider	-	LSM -- Lighting Supply Module	ECU Information	-	
2019	BA	BA-Spider	-	LSM -- Lighting Supply Module	Read Codes	-	
2019	BA	BA-Spider	-	LSM -- Lighting Supply Module	Erase codes	-	
2019	BA	BA-Spider	-	AMP -- Amplifier	ECU Information	-	
2019	BA	BA-Spider	-	AMP -- Amplifier	Read Codes	-	
2019	BA	BA-Spider	-	AMP -- Amplifier	Erase codes	-	
2019	BA	BA-Spider	-	AMP -- Amplifier	ECU Configure Information	-	
2019	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2019	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2019	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2019	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2019	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2019	BA	BA-Spider	-	RFH -- Radio Frequency Hub	ECU Information	-	
2019	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Read Codes	-	
2019	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Erase codes	-	
2019	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Live Data	-	
2019	BA	BA-Spider	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2019	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2019	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2019	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2020	BA	BA-Spider	-	ECM -- Engine Control Module	ECU Information	-	
2020	BA	BA-Spider	-	ECM -- Engine Control Module	Read Codes	-	
2020	BA	BA-Spider	-	ECM -- Engine Control Module	Erase codes	-	
2020	BA	BA-Spider	-	ECM -- Engine Control Module	Live Data	-	
2020	BA	BA-Spider	-	ECM -- Engine Control Module	Actuators	-	
2020	BA	BA-Spider	-	ECM -- Engine Control Module	ECU Configure Information	-	
2020	BA	BA-Spider	-	BCM -- Body Controller	ECU Information	-	
2020	BA	BA-Spider	-	BCM -- Body Controller	Read Codes	-	
2020	BA	BA-Spider	-	BCM -- Body Controller	Erase codes	-	
2020	BA	BA-Spider	-	BCM -- Body Controller	Live Data	-	
2020	BA	BA-Spider	-	BCM -- Body Controller	ECU Configure Information	-	
2020	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2020	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2020	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2020	BA	BA-Spider	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2020	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2020	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2020	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2020	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2020	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2020	BA	BA-Spider	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2020	BA	BA-Spider	-	BSM -- Blind Spot Module	ECU Information	-	
2020	BA	BA-Spider	-	BSM -- Blind Spot Module	Read Codes	-	
2020	BA	BA-Spider	-	BSM -- Blind Spot Module	Erase codes	-	
2020	BA	BA-Spider	-	BSM -- Blind Spot Module	Live Data	-	
2020	BA	BA-Spider	-	BSM -- Blind Spot Module	ECU Configure Information	-	
2020	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	ECU Information	-	
2020	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Read Codes	-	
2020	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Erase codes	-	
2020	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	Live Data	-	
2020	BA	BA-Spider	-	AFLS -- Adaptive Front Lighting System	ECU Configure Information	-	
2020	BA	BA-Spider	-	ABS -- Anti Lock Brakes	ECU Information	-	
2020	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Read Codes	-	
2020	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Erase codes	-	
2020	BA	BA-Spider	-	ABS -- Anti Lock Brakes	Live Data	-	
2020	BA	BA-Spider	-	EPS -- Electric Power Steering	ECU Information	-	
2020	BA	BA-Spider	-	EPS -- Electric Power Steering	Read Codes	-	
2020	BA	BA-Spider	-	EPS -- Electric Power Steering	Erase codes	-	
2020	BA	BA-Spider	-	EPS -- Electric Power Steering	Live Data	-	
2020	BA	BA-Spider	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2020	BA	BA-Spider	-	LSM -- Lighting Supply Module	ECU Information	-	
2020	BA	BA-Spider	-	LSM -- Lighting Supply Module	Read Codes	-	
2020	BA	BA-Spider	-	LSM -- Lighting Supply Module	Erase codes	-	
2020	BA	BA-Spider	-	AMP -- Amplifier	ECU Information	-	
2020	BA	BA-Spider	-	AMP -- Amplifier	Read Codes	-	
2020	BA	BA-Spider	-	AMP -- Amplifier	Erase codes	-	
2020	BA	BA-Spider	-	AMP -- Amplifier	ECU Configure Information	-	
2020	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2020	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2020	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2020	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	Live Data	-	
2020	BA	BA-Spider	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2020	BA	BA-Spider	-	RFH -- Radio Frequency Hub	ECU Information	-	
2020	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Read Codes	-	
2020	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Erase codes	-	
2020	BA	BA-Spider	-	RFH -- Radio Frequency Hub	Live Data	-	
2020	BA	BA-Spider	-	RFH -- Radio Frequency Hub	ECU Configure Information	-	
2020	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2020	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2020	BA	BA-Spider	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2019	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2019	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2020	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2020	TO	TO-Toro	-	SGW -- Security Gateway Module	Read Codes	-	
2020	TO	TO-Toro	-	SGW -- Security Gateway Module	Erase codes	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Read Codes	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Erase codes	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Live Data	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Actuators	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Read Codes	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Erase codes	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Live Data	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Actuators	-	
2020	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2020	TO	TO-Toro	-	PAM -- Park Assist Module	ECU Information	-	
2020	TO	TO-Toro	-	PAM -- Park Assist Module	Read Codes	-	
2020	TO	TO-Toro	-	PAM -- Park Assist Module	Erase codes	-	
2020	TO	TO-Toro	-	PAM -- Park Assist Module	Live Data	-	
2020	TO	TO-Toro	-	PAM -- Park Assist Module	ECU Information	-	
2020	TO	TO-Toro	-	PAM -- Park Assist Module	Read Codes	-	
2020	TO	TO-Toro	-	PAM -- Park Assist Module	Erase codes	-	
2020	TO	TO-Toro	-	PAM -- Park Assist Module	Live Data	-	
2020	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Information	-	
2020	TO	TO-Toro	-	EPS -- Electric Power Steering	Read Codes	-	
2020	TO	TO-Toro	-	EPS -- Electric Power Steering	Erase codes	-	
2020	TO	TO-Toro	-	EPS -- Electric Power Steering	Live Data	-	
2020	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2020	TO	TO-Toro	-	AMP -- Amplifier	ECU Information	-	
2020	TO	TO-Toro	-	AMP -- Amplifier	Read Codes	-	
2020	TO	TO-Toro	-	AMP -- Amplifier	Erase codes	-	
2020	TO	TO-Toro	-	AMP -- Amplifier	Live Data	-	
2020	TO	TO-Toro	-	AMP -- Amplifier	Actuators	-	
2020	TO	TO-Toro	-	AMP -- Amplifier	ECU Configure Information	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2020	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2020	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2020	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2020	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2020	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2020	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2020	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Live Data	-	
2020	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2020	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Information	-	
2020	TO	TO-Toro	-	TTM -- Trailer tow module	Read Codes	-	
2020	TO	TO-Toro	-	TTM -- Trailer tow module	Erase codes	-	
2020	TO	TO-Toro	-	TTM -- Trailer tow module	Live Data	-	
2020	TO	TO-Toro	-	TTM -- Trailer tow module	Actuators	-	
2020	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Configure Information	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Actuators	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Configure Information	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	ECU Information	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Read Codes	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Erase codes	-	
2021	TO	TO-Toro	-	ECM -- Engine Control Module	Live Data	-	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2021	TO	TO-Toro	-	DMM -- Door Management Module	ECU Configure Information	-	
2021	TO	TO-Toro	-	DTCM -- Drive Train Control Module	ECU Information	-	
2021	TO	TO-Toro	-	DTCM -- Drive Train Control Module	Read Codes	-	
2021	TO	TO-Toro	-	DTCM -- Drive Train Control Module	Erase codes	-	
2021	TO	TO-Toro	-	DTCM -- Drive Train Control Module	Live Data	-	
2021	TO	TO-Toro	-	DTCM -- Drive Train Control Module	ECU Configure Information	-	
2021	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2021	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2021	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2021	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2021	TO	TO-Toro	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2021	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2021	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2021	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2021	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2021	TO	TO-Toro	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2021	TO	TO-Toro	-	SGW -- Security Gateway Module	Read Codes	-	
2021	TO	TO-Toro	-	SGW -- Security Gateway Module	Erase codes	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Live Data	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Actuators	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Live Data	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	Actuators	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2021	TO	TO-Toro	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	TO	TO-Toro	-	PAM -- Park Assist Module	ECU Information	-	
2021	TO	TO-Toro	-	PAM -- Park Assist Module	Read Codes	-	
2021	TO	TO-Toro	-	PAM -- Park Assist Module	Erase codes	-	
2021	TO	TO-Toro	-	PAM -- Park Assist Module	Live Data	-	
2021	TO	TO-Toro	-	PAM -- Park Assist Module	ECU Information	-	
2021	TO	TO-Toro	-	PAM -- Park Assist Module	Read Codes	-	
2021	TO	TO-Toro	-	PAM -- Park Assist Module	Erase codes	-	
2021	TO	TO-Toro	-	PAM -- Park Assist Module	Live Data	-	
2021	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Information	-	
2021	TO	TO-Toro	-	EPS -- Electric Power Steering	Read Codes	-	
2021	TO	TO-Toro	-	EPS -- Electric Power Steering	Erase codes	-	
2021	TO	TO-Toro	-	EPS -- Electric Power Steering	Live Data	-	
2021	TO	TO-Toro	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2021	TO	TO-Toro	-	AMP -- Amplifier	ECU Information	-	
2021	TO	TO-Toro	-	AMP -- Amplifier	Read Codes	-	
2021	TO	TO-Toro	-	AMP -- Amplifier	Erase codes	-	
2021	TO	TO-Toro	-	AMP -- Amplifier	Live Data	-	
2021	TO	TO-Toro	-	AMP -- Amplifier	Actuators	-	
2021	TO	TO-Toro	-	AMP -- Amplifier	ECU Configure Information	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Live Data	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	Actuators	-	
2021	TO	TO-Toro	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	ECU Information	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Read Codes	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Erase codes	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Live Data	-	
2021	TO	TO-Toro	-	RFH -- Radio Frequency Hub	Actuators	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Live Data	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	Actuators	-	
2021	TO	TO-Toro	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2021	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2021	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2021	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2021	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	Live Data	-	
2021	TO	TO-Toro	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2021	TO	TO-Toro	-	TTM -- Trailer tow module	ECU Information	-	
2021	TO	TO-Toro	-	TTM -- Trailer tow module	Read Codes	-	
2021	TO	TO-Toro	-	TTM -- Trailer tow module	Erase codes	-	























## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Live Data	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Actuators	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	ECU Information	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Read Codes	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Erase codes	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Live Data	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Actuators	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	ECU Information	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Read Codes	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Erase codes	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Live Data	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Actuators	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	ECU Information	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Read Codes	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Erase codes	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Live Data	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	Actuators	-	
2021	MB	MB-Mobi	-	ECM -- Engine Control Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	TCM -- Transmission Control Module	ECU Information	-	
2021	MB	MB-Mobi	-	TCM -- Transmission Control Module	Read Codes	-	
2021	MB	MB-Mobi	-	TCM -- Transmission Control Module	Erase codes	-	
2021	MB	MB-Mobi	-	TCM -- Transmission Control Module	Live Data	-	
2021	MB	MB-Mobi	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	BCM -- Body Controller	ECU Information	-	
2021	MB	MB-Mobi	-	BCM -- Body Controller	Read Codes	-	
2021	MB	MB-Mobi	-	BCM -- Body Controller	Erase codes	-	
2021	MB	MB-Mobi	-	BCM -- Body Controller	Live Data	-	
2021	MB	MB-Mobi	-	BCM -- Body Controller	Actuators	-	
2021	MB	MB-Mobi	-	BCM -- Body Controller	ECU Configure Information	-	
2021	MB	MB-Mobi	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2021	MB	MB-Mobi	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2021	MB	MB-Mobi	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2021	MB	MB-Mobi	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2021	MB	MB-Mobi	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	ECU Information	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Read Codes	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Erase codes	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Live Data	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Actuators	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	ECU Information	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Read Codes	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Erase codes	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Live Data	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Actuators	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	ECU Information	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Read Codes	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Erase codes	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Live Data	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	Actuators	-	
2021	MB	MB-Mobi	-	DMM -- Door Management Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	SGW -- Security Gateway Module	Read Codes	-	
2021	MB	MB-Mobi	-	SGW -- Security Gateway Module	Erase codes	-	
2021	MB	MB-Mobi	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	MB	MB-Mobi	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	MB	MB-Mobi	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	MB	MB-Mobi	-	PAM -- Park Assist Module	ECU Information	-	
2021	MB	MB-Mobi	-	PAM -- Park Assist Module	Read Codes	-	
2021	MB	MB-Mobi	-	PAM -- Park Assist Module	Erase codes	-	
2021	MB	MB-Mobi	-	PAM -- Park Assist Module	Live Data	-	
2021	MB	MB-Mobi	-	PAM -- Park Assist Module	ECU Configure Information	-	
2021	MB	MB-Mobi	-	EPS -- Electric Power Steering	ECU Information	-	
2021	MB	MB-Mobi	-	EPS -- Electric Power Steering	Read Codes	-	
2021	MB	MB-Mobi	-	EPS -- Electric Power Steering	Erase codes	-	
2021	MB	MB-Mobi	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2021	MB	MB-Mobi	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2021	MB	MB-Mobi	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2021	MB	MB-Mobi	-	IPC -- Instrument Panel Cluster	Live Data	-	
2021	MB	MB-Mobi	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2021	MB	MB-Mobi	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2021	MB	MB-Mobi	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2021	MB	MB-Mobi	-	IPC -- Instrument Panel Cluster	Live Data	-	
2021	MB	MB-Mobi	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2021	MB	MB-Mobi	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2021	MB	MB-Mobi	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2021	MB	MB-Mobi	-	ETM -- Entertainment Telematic Module	Live Data	-	
2021	MB	MB-Mobi	-	ETM -- Entertainment Telematic Module	Actuators	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	ECU Information	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Read Codes	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Erase codes	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Live Data	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Actuators	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	ECU Information	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Read Codes	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Erase codes	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Live Data	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Actuators	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	ECU Information	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Read Codes	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Erase codes	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Live Data	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Actuators	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	ECU Information	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Read Codes	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Erase codes	-	
2019	BG	BG-500L MCA	-	ECM -- Engine Control Module	Live Data	-	















## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2021	BG	BG-500L MCA	-	ECM -- Engine Control Module	Live Data	-	
2021	BG	BG-500L MCA	-	ECM -- Engine Control Module	Actuators	-	
2021	BG	BG-500L MCA	-	ECM -- Engine Control Module	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	ECU Information	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	Read Codes	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	Erase codes	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	Live Data	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	Actuators	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	ECU Information	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	Read Codes	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	Erase codes	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	Live Data	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	Actuators	-	
2021	BG	BG-500L MCA	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	ESM -- Electronic Shifter	Read Codes	-	
2021	BG	BG-500L MCA	-	ESM -- Electronic Shifter	Erase codes	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	ECU Information	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	Read Codes	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	Erase codes	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	Live Data	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	Actuators	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	ECU Information	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	Read Codes	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	Erase codes	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	Live Data	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	Actuators	-	
2021	BG	BG-500L MCA	-	BCM -- Body Controller	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	Actuators	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2021	BG	BG-500L MCA	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2021	BG	BG-500L MCA	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	CMM -- Instrument Panel Cluster	ECU Information	-	
2021	BG	BG-500L MCA	-	CMM -- Instrument Panel Cluster	Read Codes	-	
2021	BG	BG-500L MCA	-	CMM -- Instrument Panel Cluster	Erase codes	-	
2021	BG	BG-500L MCA	-	CMM -- Instrument Panel Cluster	Live Data	-	
2021	BG	BG-500L MCA	-	CMM -- Instrument Panel Cluster	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	SGW -- Security Gateway Module	Read Codes	-	
2021	BG	BG-500L MCA	-	SGW -- Security Gateway Module	Erase codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Live Data	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Actuators	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Live Data	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Actuators	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Live Data	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Actuators	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Live Data	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	Actuators	-	
2021	BG	BG-500L MCA	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	PAM -- Park Assist Module	ECU Information	-	
2021	BG	BG-500L MCA	-	PAM -- Park Assist Module	Read Codes	-	
2021	BG	BG-500L MCA	-	PAM -- Park Assist Module	Erase codes	-	
2021	BG	BG-500L MCA	-	PAM -- Park Assist Module	Live Data	-	
2021	BG	BG-500L MCA	-	TPM -- Tire Pressure Monitor	ECU Information	-	
2021	BG	BG-500L MCA	-	TPM -- Tire Pressure Monitor	Read Codes	-	
2021	BG	BG-500L MCA	-	TPM -- Tire Pressure Monitor	Erase codes	-	
2021	BG	BG-500L MCA	-	TPM -- Tire Pressure Monitor	Live Data	-	
2021	BG	BG-500L MCA	-	TPM -- Tire Pressure Monitor	Actuators	-	
2021	BG	BG-500L MCA	-	TPM -- Tire Pressure Monitor	ECU Configure Information	-	
2021	BG	BG-500L MCA	-	EPS -- Electric Power Steering	ECU Information	-	
2021	BG	BG-500L MCA	-	EPS -- Electric Power Steering	Read Codes	-	
2021	BG	BG-500L MCA	-	EPS -- Electric Power Steering	Erase codes	-	
2021	BG	BG-500L MCA	-	EPS -- Electric Power Steering	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2019	6H	6H-Argo	-	ECM -- Engine Control Module	ECU Information	-	
2019	6H	6H-Argo	-	ECM -- Engine Control Module	Read Codes	-	
2019	6H	6H-Argo	-	ECM -- Engine Control Module	Erase codes	-	
2019	6H	6H-Argo	-	ECM -- Engine Control Module	Live Data	-	
2019	6H	6H-Argo	-	ECM -- Engine Control Module	Actuators	-	
2019	6H	6H-Argo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	6H	6H-Argo	-	TCM -- Transmission Control Module	ECU Information	-	
2019	6H	6H-Argo	-	TCM -- Transmission Control Module	Read Codes	-	
2019	6H	6H-Argo	-	TCM -- Transmission Control Module	Erase codes	-	
2019	6H	6H-Argo	-	TCM -- Transmission Control Module	Live Data	-	
2019	6H	6H-Argo	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2019	6H	6H-Argo	-	ESM -- Electronic Shifter	Read Codes	-	
2019	6H	6H-Argo	-	ESM -- Electronic Shifter	Erase codes	-	
2019	6H	6H-Argo	-	BCM -- Body Controller	ECU Information	-	
2019	6H	6H-Argo	-	BCM -- Body Controller	Read Codes	-	
2019	6H	6H-Argo	-	BCM -- Body Controller	Erase codes	-	
2019	6H	6H-Argo	-	BCM -- Body Controller	Live Data	-	
2019	6H	6H-Argo	-	BCM -- Body Controller	Actuators	-	
2019	6H	6H-Argo	-	BCM -- Body Controller	ECU Configure Information	-	
2019	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2019	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2019	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2019	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2019	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2019	6H	6H-Argo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2019	6H	6H-Argo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2019	6H	6H-Argo	-	DMM -- Door Management Module	ECU Information	-	
2019	6H	6H-Argo	-	DMM -- Door Management Module	Read Codes	-	
2019	6H	6H-Argo	-	DMM -- Door Management Module	Erase codes	-	
2019	6H	6H-Argo	-	DMM -- Door Management Module	Live Data	-	
2019	6H	6H-Argo	-	DMM -- Door Management Module	Actuators	-	
2019	6H	6H-Argo	-	DMM -- Door Management Module	ECU Configure Information	-	
2019	6H	6H-Argo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2019	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2019	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2019	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Live Data	-	
2019	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Actuators	-	
2019	6H	6H-Argo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2019	6H	6H-Argo	-	PAM -- Park Assist Module	Read Codes	-	
2019	6H	6H-Argo	-	PAM -- Park Assist Module	Erase codes	-	
2019	6H	6H-Argo	-	EPS -- Electric Power Steering	ECU Information	-	
2019	6H	6H-Argo	-	EPS -- Electric Power Steering	Read Codes	-	
2019	6H	6H-Argo	-	EPS -- Electric Power Steering	Erase codes	-	
2019	6H	6H-Argo	-	EPS -- Electric Power Steering	Live Data	-	
2019	6H	6H-Argo	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2019	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2019	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2019	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2019	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2019	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2019	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2019	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2019	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2019	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2019	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2019	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2019	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2020	6H	6H-Argo	-	ECM -- Engine Control Module	ECU Information	-	
2020	6H	6H-Argo	-	ECM -- Engine Control Module	Read Codes	-	
2020	6H	6H-Argo	-	ECM -- Engine Control Module	Erase codes	-	
2020	6H	6H-Argo	-	ECM -- Engine Control Module	Live Data	-	
2020	6H	6H-Argo	-	ECM -- Engine Control Module	Actuators	-	
2020	6H	6H-Argo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2020	6H	6H-Argo	-	TCM -- Transmission Control Module	ECU Information	-	
2020	6H	6H-Argo	-	TCM -- Transmission Control Module	Read Codes	-	
2020	6H	6H-Argo	-	TCM -- Transmission Control Module	Erase codes	-	
2020	6H	6H-Argo	-	TCM -- Transmission Control Module	Live Data	-	
2020	6H	6H-Argo	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2020	6H	6H-Argo	-	ESM -- Electronic Shifter	Read Codes	-	
2020	6H	6H-Argo	-	ESM -- Electronic Shifter	Erase codes	-	
2020	6H	6H-Argo	-	BCM -- Body Controller	ECU Information	-	
2020	6H	6H-Argo	-	BCM -- Body Controller	Read Codes	-	
2020	6H	6H-Argo	-	BCM -- Body Controller	Erase codes	-	
2020	6H	6H-Argo	-	BCM -- Body Controller	Live Data	-	
2020	6H	6H-Argo	-	BCM -- Body Controller	Actuators	-	
2020	6H	6H-Argo	-	BCM -- Body Controller	ECU Configure Information	-	
2020	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2020	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2020	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2020	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2020	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2020	6H	6H-Argo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2020	6H	6H-Argo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2020	6H	6H-Argo	-	DMM -- Door Management Module	ECU Information	-	
2020	6H	6H-Argo	-	DMM -- Door Management Module	Read Codes	-	
2020	6H	6H-Argo	-	DMM -- Door Management Module	Erase codes	-	
2020	6H	6H-Argo	-	DMM -- Door Management Module	Live Data	-	
2020	6H	6H-Argo	-	DMM -- Door Management Module	Actuators	-	
2020	6H	6H-Argo	-	DMM -- Door Management Module	ECU Configure Information	-	
2020	6H	6H-Argo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2020	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2020	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2020	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Live Data	-	
2020	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Actuators	-	
2020	6H	6H-Argo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2020	6H	6H-Argo	-	PAM -- Park Assist Module	Read Codes	-	
2020	6H	6H-Argo	-	PAM -- Park Assist Module	Erase codes	-	
2020	6H	6H-Argo	-	EPS -- Electric Power Steering	ECU Information	-	
2020	6H	6H-Argo	-	EPS -- Electric Power Steering	Read Codes	-	
2020	6H	6H-Argo	-	EPS -- Electric Power Steering	Erase codes	-	
2020	6H	6H-Argo	-	EPS -- Electric Power Steering	Live Data	-	
2020	6H	6H-Argo	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2020	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2020	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2020	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2020	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2020	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2020	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2020	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2020	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2020	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2020	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2020	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2020	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2021	6H	6H-Argo	-	ECM -- Engine Control Module	ECU Information	-	
2021	6H	6H-Argo	-	ECM -- Engine Control Module	Read Codes	-	
2021	6H	6H-Argo	-	ECM -- Engine Control Module	Erase codes	-	
2021	6H	6H-Argo	-	ECM -- Engine Control Module	Live Data	-	
2021	6H	6H-Argo	-	ECM -- Engine Control Module	Actuators	-	
2021	6H	6H-Argo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2021	6H	6H-Argo	-	TCM -- Transmission Control Module	ECU Information	-	
2021	6H	6H-Argo	-	TCM -- Transmission Control Module	Read Codes	-	
2021	6H	6H-Argo	-	TCM -- Transmission Control Module	Erase codes	-	
2021	6H	6H-Argo	-	TCM -- Transmission Control Module	Live Data	-	
2021	6H	6H-Argo	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2021	6H	6H-Argo	-	ESM -- Electronic Shifter	Read Codes	-	
2021	6H	6H-Argo	-	ESM -- Electronic Shifter	Erase codes	-	
2021	6H	6H-Argo	-	BCM -- Body Controller	ECU Information	-	
2021	6H	6H-Argo	-	BCM -- Body Controller	Read Codes	-	
2021	6H	6H-Argo	-	BCM -- Body Controller	Erase codes	-	
2021	6H	6H-Argo	-	BCM -- Body Controller	Live Data	-	
2021	6H	6H-Argo	-	BCM -- Body Controller	Actuators	-	
2021	6H	6H-Argo	-	BCM -- Body Controller	ECU Configure Information	-	
2021	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2021	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2021	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2021	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2021	6H	6H-Argo	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2021	6H	6H-Argo	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2021	6H	6H-Argo	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2021	6H	6H-Argo	-	DMM -- Door Management Module	ECU Information	-	
2021	6H	6H-Argo	-	DMM -- Door Management Module	Read Codes	-	
2021	6H	6H-Argo	-	DMM -- Door Management Module	Erase codes	-	
2021	6H	6H-Argo	-	DMM -- Door Management Module	Live Data	-	
2021	6H	6H-Argo	-	DMM -- Door Management Module	Actuators	-	
2021	6H	6H-Argo	-	DMM -- Door Management Module	ECU Configure Information	-	
2021	6H	6H-Argo	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Live Data	-	
2021	6H	6H-Argo	-	ABS -- Anti Lock Brakes	Actuators	-	
2021	6H	6H-Argo	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2021	6H	6H-Argo	-	PAM -- Park Assist Module	Read Codes	-	
2021	6H	6H-Argo	-	PAM -- Park Assist Module	Erase codes	-	
2021	6H	6H-Argo	-	EPS -- Electric Power Steering	ECU Information	-	
2021	6H	6H-Argo	-	EPS -- Electric Power Steering	Read Codes	-	
2021	6H	6H-Argo	-	EPS -- Electric Power Steering	Erase codes	-	
2021	6H	6H-Argo	-	EPS -- Electric Power Steering	Live Data	-	
2021	6H	6H-Argo	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2021	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2021	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2021	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2021	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Live Data	-	
2021	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	Actuators	-	
2021	6H	6H-Argo	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2021	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2021	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2021	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2021	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Live Data	-	
2021	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	Actuators	-	
2021	6H	6H-Argo	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2018	6S	6S-Cronos	-	ECM -- Engine Control Module	ECU Information	-	
2018	6S	6S-Cronos	-	ECM -- Engine Control Module	Read Codes	-	
2018	6S	6S-Cronos	-	ECM -- Engine Control Module	Erase codes	-	
2018	6S	6S-Cronos	-	ECM -- Engine Control Module	Live Data	-	
2018	6S	6S-Cronos	-	ECM -- Engine Control Module	Actuators	-	
2018	6S	6S-Cronos	-	ECM -- Engine Control Module	ECU Configure Information	-	
2018	6S	6S-Cronos	-	TCM -- Transmission Control Module	ECU Information	-	
2018	6S	6S-Cronos	-	TCM -- Transmission Control Module	Read Codes	-	
2018	6S	6S-Cronos	-	TCM -- Transmission Control Module	Erase codes	-	
2018	6S	6S-Cronos	-	TCM -- Transmission Control Module	Live Data	-	
2018	6S	6S-Cronos	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2018	6S	6S-Cronos	-	ESM -- Electronic Shifter	Read Codes	-	
2018	6S	6S-Cronos	-	ESM -- Electronic Shifter	Erase codes	-	
2018	6S	6S-Cronos	-	BCM -- Body Controller	ECU Information	-	
2018	6S	6S-Cronos	-	BCM -- Body Controller	Read Codes	-	
2018	6S	6S-Cronos	-	BCM -- Body Controller	Erase codes	-	
2018	6S	6S-Cronos	-	BCM -- Body Controller	Live Data	-	
2018	6S	6S-Cronos	-	BCM -- Body Controller	Actuators	-	
2018	6S	6S-Cronos	-	BCM -- Body Controller	ECU Configure Information	-	
2018	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2018	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2018	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2018	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2018	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2018	6S	6S-Cronos	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2018	6S	6S-Cronos	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2018	6S	6S-Cronos	-	DMM -- Door Management Module	ECU Information	-	
2018	6S	6S-Cronos	-	DMM -- Door Management Module	Read Codes	-	
2018	6S	6S-Cronos	-	DMM -- Door Management Module	Erase codes	-	
2018	6S	6S-Cronos	-	DMM -- Door Management Module	Live Data	-	
2018	6S	6S-Cronos	-	DMM -- Door Management Module	Actuators	-	
2018	6S	6S-Cronos	-	DMM -- Door Management Module	ECU Configure Information	-	
2018	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	ECU Information	-	
2018	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Read Codes	-	
2018	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Erase codes	-	
2018	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Live Data	-	
2018	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Actuators	-	
2018	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2018	6S	6S-Cronos	-	PAM -- Park Assist Module	Read Codes	-	
2018	6S	6S-Cronos	-	PAM -- Park Assist Module	Erase codes	-	
2018	6S	6S-Cronos	-	EPS -- Electric Power Steering	ECU Information	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2018	6S	6S-Cronos	-	EPS -- Electric Power Steering	Read Codes	-	
2018	6S	6S-Cronos	-	EPS -- Electric Power Steering	Erase codes	-	
2018	6S	6S-Cronos	-	EPS -- Electric Power Steering	Live Data	-	
2018	6S	6S-Cronos	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2018	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2018	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2018	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2018	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Live Data	-	
2018	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Actuators	-	
2018	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2018	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2018	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2018	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2018	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Live Data	-	
2018	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Actuators	-	
2018	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2019	6S	6S-Cronos	-	ECM -- Engine Control Module	ECU Information	-	
2019	6S	6S-Cronos	-	ECM -- Engine Control Module	Read Codes	-	
2019	6S	6S-Cronos	-	ECM -- Engine Control Module	Erase codes	-	
2019	6S	6S-Cronos	-	ECM -- Engine Control Module	Live Data	-	
2019	6S	6S-Cronos	-	ECM -- Engine Control Module	Actuators	-	
2019	6S	6S-Cronos	-	ECM -- Engine Control Module	ECU Configure Information	-	
2019	6S	6S-Cronos	-	TCM -- Transmission Control Module	ECU Information	-	
2019	6S	6S-Cronos	-	TCM -- Transmission Control Module	Read Codes	-	
2019	6S	6S-Cronos	-	TCM -- Transmission Control Module	Erase codes	-	
2019	6S	6S-Cronos	-	TCM -- Transmission Control Module	Live Data	-	
2019	6S	6S-Cronos	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2019	6S	6S-Cronos	-	ESM -- Electronic Shifter	Read Codes	-	
2019	6S	6S-Cronos	-	ESM -- Electronic Shifter	Erase codes	-	
2019	6S	6S-Cronos	-	BCM -- Body Controller	ECU Information	-	
2019	6S	6S-Cronos	-	BCM -- Body Controller	Read Codes	-	
2019	6S	6S-Cronos	-	BCM -- Body Controller	Erase codes	-	
2019	6S	6S-Cronos	-	BCM -- Body Controller	Live Data	-	
2019	6S	6S-Cronos	-	BCM -- Body Controller	Actuators	-	
2019	6S	6S-Cronos	-	BCM -- Body Controller	ECU Configure Information	-	
2019	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2019	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2019	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2019	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2019	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2019	6S	6S-Cronos	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2019	6S	6S-Cronos	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2019	6S	6S-Cronos	-	DMM -- Door Management Module	ECU Information	-	
2019	6S	6S-Cronos	-	DMM -- Door Management Module	Read Codes	-	
2019	6S	6S-Cronos	-	DMM -- Door Management Module	Erase codes	-	
2019	6S	6S-Cronos	-	DMM -- Door Management Module	Live Data	-	
2019	6S	6S-Cronos	-	DMM -- Door Management Module	Actuators	-	
2019	6S	6S-Cronos	-	DMM -- Door Management Module	ECU Configure Information	-	
2019	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	ECU Information	-	
2019	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Read Codes	-	
2019	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Erase codes	-	
2019	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Live Data	-	
2019	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Actuators	-	
2019	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2019	6S	6S-Cronos	-	PAM -- Park Assist Module	Read Codes	-	
2019	6S	6S-Cronos	-	PAM -- Park Assist Module	Erase codes	-	
2019	6S	6S-Cronos	-	EPS -- Electric Power Steering	ECU Information	-	
2019	6S	6S-Cronos	-	EPS -- Electric Power Steering	Read Codes	-	
2019	6S	6S-Cronos	-	EPS -- Electric Power Steering	Erase codes	-	
2019	6S	6S-Cronos	-	EPS -- Electric Power Steering	Live Data	-	
2019	6S	6S-Cronos	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2019	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2019	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2019	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2019	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Live Data	-	
2019	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Actuators	-	
2019	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2019	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2019	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2019	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2019	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Live Data	-	
2019	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Actuators	-	
2019	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2020	6S	6S-Cronos	-	ECM -- Engine Control Module	ECU Information	-	
2020	6S	6S-Cronos	-	ECM -- Engine Control Module	Read Codes	-	
2020	6S	6S-Cronos	-	ECM -- Engine Control Module	Erase codes	-	
2020	6S	6S-Cronos	-	ECM -- Engine Control Module	Live Data	-	
2020	6S	6S-Cronos	-	ECM -- Engine Control Module	Actuators	-	
2020	6S	6S-Cronos	-	ECM -- Engine Control Module	ECU Configure Information	-	
2020	6S	6S-Cronos	-	TCM -- Transmission Control Module	ECU Information	-	
2020	6S	6S-Cronos	-	TCM -- Transmission Control Module	Read Codes	-	
2020	6S	6S-Cronos	-	TCM -- Transmission Control Module	Erase codes	-	
2020	6S	6S-Cronos	-	TCM -- Transmission Control Module	Live Data	-	
2020	6S	6S-Cronos	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2020	6S	6S-Cronos	-	ESM -- Electronic Shifter	Read Codes	-	
2020	6S	6S-Cronos	-	ESM -- Electronic Shifter	Erase codes	-	
2020	6S	6S-Cronos	-	BCM -- Body Controller	ECU Information	-	
2020	6S	6S-Cronos	-	BCM -- Body Controller	Read Codes	-	
2020	6S	6S-Cronos	-	BCM -- Body Controller	Erase codes	-	
2020	6S	6S-Cronos	-	BCM -- Body Controller	Live Data	-	
2020	6S	6S-Cronos	-	BCM -- Body Controller	Actuators	-	
2020	6S	6S-Cronos	-	BCM -- Body Controller	ECU Configure Information	-	
2020	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2020	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2020	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2020	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2020	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2020	6S	6S-Cronos	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2020	6S	6S-Cronos	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2020	6S	6S-Cronos	-	DMM -- Door Management Module	ECU Information	-	
2020	6S	6S-Cronos	-	DMM -- Door Management Module	Read Codes	-	
2020	6S	6S-Cronos	-	DMM -- Door Management Module	Erase codes	-	
2020	6S	6S-Cronos	-	DMM -- Door Management Module	Live Data	-	
2020	6S	6S-Cronos	-	DMM -- Door Management Module	Actuators	-	
2020	6S	6S-Cronos	-	DMM -- Door Management Module	ECU Configure Information	-	
2020	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	ECU Information	-	
2020	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Read Codes	-	
2020	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Erase codes	-	
2020	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2020	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Actuators	-	
2020	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2020	6S	6S-Cronos	-	PAM -- Park Assist Module	Read Codes	-	
2020	6S	6S-Cronos	-	PAM -- Park Assist Module	Erase codes	-	
2020	6S	6S-Cronos	-	EPS -- Electric Power Steering	ECU Information	-	
2020	6S	6S-Cronos	-	EPS -- Electric Power Steering	Read Codes	-	
2020	6S	6S-Cronos	-	EPS -- Electric Power Steering	Erase codes	-	
2020	6S	6S-Cronos	-	EPS -- Electric Power Steering	Live Data	-	
2020	6S	6S-Cronos	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2020	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2020	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2020	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2020	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Live Data	-	
2020	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Actuators	-	
2020	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2020	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2020	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2020	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2020	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Live Data	-	
2020	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Actuators	-	
2020	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2021	6S	6S-Cronos	-	ECM -- Engine Control Module	ECU Information	-	
2021	6S	6S-Cronos	-	ECM -- Engine Control Module	Read Codes	-	
2021	6S	6S-Cronos	-	ECM -- Engine Control Module	Erase codes	-	
2021	6S	6S-Cronos	-	ECM -- Engine Control Module	Live Data	-	
2021	6S	6S-Cronos	-	ECM -- Engine Control Module	Actuators	-	
2021	6S	6S-Cronos	-	ECM -- Engine Control Module	ECU Configure Information	-	
2021	6S	6S-Cronos	-	TCM -- Transmission Control Module	ECU Information	-	
2021	6S	6S-Cronos	-	TCM -- Transmission Control Module	Read Codes	-	
2021	6S	6S-Cronos	-	TCM -- Transmission Control Module	Erase codes	-	
2021	6S	6S-Cronos	-	TCM -- Transmission Control Module	Live Data	-	
2021	6S	6S-Cronos	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2021	6S	6S-Cronos	-	ESM -- Electronic Shifter	Read Codes	-	
2021	6S	6S-Cronos	-	ESM -- Electronic Shifter	Erase codes	-	
2021	6S	6S-Cronos	-	BCM -- Body Controller	ECU Information	-	
2021	6S	6S-Cronos	-	BCM -- Body Controller	Read Codes	-	
2021	6S	6S-Cronos	-	BCM -- Body Controller	Erase codes	-	
2021	6S	6S-Cronos	-	BCM -- Body Controller	Live Data	-	
2021	6S	6S-Cronos	-	BCM -- Body Controller	Actuators	-	
2021	6S	6S-Cronos	-	BCM -- Body Controller	ECU Configure Information	-	
2021	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	ECU Information	-	
2021	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Read Codes	-	
2021	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Erase codes	-	
2021	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	Live Data	-	
2021	6S	6S-Cronos	-	ORC -- AirBag/Occupant Restraint	ECU Configure Information	-	
2021	6S	6S-Cronos	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2021	6S	6S-Cronos	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2021	6S	6S-Cronos	-	DMM -- Door Management Module	ECU Information	-	
2021	6S	6S-Cronos	-	DMM -- Door Management Module	Read Codes	-	
2021	6S	6S-Cronos	-	DMM -- Door Management Module	Erase codes	-	
2021	6S	6S-Cronos	-	DMM -- Door Management Module	Live Data	-	
2021	6S	6S-Cronos	-	DMM -- Door Management Module	Actuators	-	
2021	6S	6S-Cronos	-	DMM -- Door Management Module	ECU Configure Information	-	
2021	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	ECU Information	-	
2021	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Read Codes	-	
2021	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Erase codes	-	
2021	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Live Data	-	
2021	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	Actuators	-	
2021	6S	6S-Cronos	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2021	6S	6S-Cronos	-	PAM -- Park Assist Module	Read Codes	-	
2021	6S	6S-Cronos	-	PAM -- Park Assist Module	Erase codes	-	
2021	6S	6S-Cronos	-	EPS -- Electric Power Steering	ECU Information	-	
2021	6S	6S-Cronos	-	EPS -- Electric Power Steering	Read Codes	-	
2021	6S	6S-Cronos	-	EPS -- Electric Power Steering	Erase codes	-	
2021	6S	6S-Cronos	-	EPS -- Electric Power Steering	Live Data	-	
2021	6S	6S-Cronos	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2021	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2021	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2021	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2021	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Live Data	-	
2021	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	Actuators	-	
2021	6S	6S-Cronos	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2021	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2021	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2021	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2021	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Live Data	-	
2021	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	Actuators	-	
2021	6S	6S-Cronos	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	ECU Information	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Read Codes	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Erase codes	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Live Data	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Actuators	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	ECU Configure Information	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	ECU Information	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Read Codes	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Erase codes	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Live Data	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Actuators	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	ECU Configure Information	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	ECU Information	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Read Codes	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Erase codes	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Live Data	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Actuators	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	ECU Configure Information	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	ECU Information	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Read Codes	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Erase codes	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Live Data	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	Actuators	-	
2020	FD	FD-500X	-	ECM -- Engine Control Module	ECU Configure Information	-	
2020	FD	FD-500X	-	TCM -- Transmission Control Module	ECU Information	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Information	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	Read Codes	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	Erase codes	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	Live Data	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	Actuators	-	
2020	FD	FD-500X	-	HVAC -- Heat, Ventilation and A/C	ECU Configure Information	-	
2020	FD	FD-500X	-	DTCM -- Drive Train Control Module	ECU Information	-	
2020	FD	FD-500X	-	DTCM -- Drive Train Control Module	Read Codes	-	
2020	FD	FD-500X	-	DTCM -- Drive Train Control Module	Erase codes	-	
2020	FD	FD-500X	-	DTCM -- Drive Train Control Module	Live Data	-	
2020	FD	FD-500X	-	ESL -- Electronic Steering Lock	ECU Information	-	
2020	FD	FD-500X	-	ESL -- Electronic Steering Lock	Read Codes	-	
2020	FD	FD-500X	-	ESL -- Electronic Steering Lock	Erase codes	-	
2020	FD	FD-500X	-	ESL -- Electronic Steering Lock	Live Data	-	
2020	FD	FD-500X	-	LBSS -- Left Blind Spot Sensor	ECU Information	-	
2020	FD	FD-500X	-	LBSS -- Left Blind Spot Sensor	Read Codes	-	
2020	FD	FD-500X	-	LBSS -- Left Blind Spot Sensor	Erase codes	-	
2020	FD	FD-500X	-	LBSS -- Left Blind Spot Sensor	Live Data	-	
2020	FD	FD-500X	-	LBSS -- Left Blind Spot Sensor	Actuators	-	
2020	FD	FD-500X	-	RBSS -- Right Blind Spot Sensor	ECU Information	-	
2020	FD	FD-500X	-	RBSS -- Right Blind Spot Sensor	Read Codes	-	
2020	FD	FD-500X	-	RBSS -- Right Blind Spot Sensor	Erase codes	-	
2020	FD	FD-500X	-	RBSS -- Right Blind Spot Sensor	Live Data	-	
2020	FD	FD-500X	-	RBSS -- Right Blind Spot Sensor	Actuators	-	
2020	FD	FD-500X	-	SGW -- Security Gateway Module	Read Codes	-	
2020	FD	FD-500X	-	SGW -- Security Gateway Module	Erase codes	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	ECU Information	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	Read Codes	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	Erase codes	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	Live Data	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	Actuators	-	
2020	FD	FD-500X	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2020	FD	FD-500X	-	PAM -- Park Assist Module	ECU Information	-	
2020	FD	FD-500X	-	PAM -- Park Assist Module	Read Codes	-	
2020	FD	FD-500X	-	PAM -- Park Assist Module	Erase codes	-	
2020	FD	FD-500X	-	PAM -- Park Assist Module	Live Data	-	
2020	FD	FD-500X	-	EPS -- Electric Power Steering	ECU Information	-	
2020	FD	FD-500X	-	EPS -- Electric Power Steering	Read Codes	-	
2020	FD	FD-500X	-	EPS -- Electric Power Steering	Erase codes	-	
2020	FD	FD-500X	-	EPS -- Electric Power Steering	Live Data	-	
2020	FD	FD-500X	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2020	FD	FD-500X	-	AMP -- Amplifier	ECU Information	-	
2020	FD	FD-500X	-	AMP -- Amplifier	Read Codes	-	
2020	FD	FD-500X	-	AMP -- Amplifier	Erase codes	-	
2020	FD	FD-500X	-	AMP -- Amplifier	Live Data	-	
2020	FD	FD-500X	-	AMP -- Amplifier	Actuators	-	
2020	FD	FD-500X	-	AMP -- Amplifier	ECU Configure Information	-	
2020	FD	FD-500X	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2020	FD	FD-500X	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2020	FD	FD-500X	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2020	FD	FD-500X	-	IPC -- Instrument Panel Cluster	Live Data	-	
2020	FD	FD-500X	-	IPC -- Instrument Panel Cluster	Actuators	-	
2020	FD	FD-500X	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2020	FD	FD-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2020	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2020	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	ECU Information	-	
2020	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2020	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2020	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2020	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2020	FD	FD-500X	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2020	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2020	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2020	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Live Data	-	
2020	FD	FD-500X	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2020	FD	FD-500X	-	RRM -- Radio Receiver Module	ECU Information	-	
2020	FD	FD-500X	-	RRM -- Radio Receiver Module	Read Codes	-	
2020	FD	FD-500X	-	RRM -- Radio Receiver Module	Erase codes	-	
2020	FD	FD-500X	-	RRM -- Radio Receiver Module	Live Data	-	
2020	FD	FD-500X	-	RRM -- Radio Receiver Module	Actuators	-	
2020	FD	FD-500X	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2020	FD	FD-500X	-	DCU -- Dosing Control Unit	ECU Information	-	
2020	FD	FD-500X	-	DCU -- Dosing Control Unit	Read Codes	-	
2020	FD	FD-500X	-	DCU -- Dosing Control Unit	Erase codes	-	
2020	FD	FD-500X	-	DCU -- Dosing Control Unit	Live Data	-	
2021	FD	FD-500X	-	ECM -- Engine Control Module	ECU Information	-	









## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2022	FD	FD-500X	-	EPS -- Electric Power Steering	ECU Information	-	
2022	FD	FD-500X	-	EPS -- Electric Power Steering	Read Codes	-	
2022	FD	FD-500X	-	EPS -- Electric Power Steering	Erase codes	-	
2022	FD	FD-500X	-	EPS -- Electric Power Steering	Live Data	-	
2022	FD	FD-500X	-	EPS -- Electric Power Steering	ECU Configure Information	-	
2022	FD	FD-500X	-	AMP -- Amplifier	ECU Information	-	
2022	FD	FD-500X	-	AMP -- Amplifier	Read Codes	-	
2022	FD	FD-500X	-	AMP -- Amplifier	Erase codes	-	
2022	FD	FD-500X	-	AMP -- Amplifier	Live Data	-	
2022	FD	FD-500X	-	AMP -- Amplifier	Actuators	-	
2022	FD	FD-500X	-	AMP -- Amplifier	ECU Configure Information	-	
2022	FD	FD-500X	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2022	FD	FD-500X	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2022	FD	FD-500X	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2022	FD	FD-500X	-	IPC -- Instrument Panel Cluster	Live Data	-	
2022	FD	FD-500X	-	IPC -- Instrument Panel Cluster	Actuators	-	
2022	FD	FD-500X	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2022	FD	FD-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	ECU Information	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Live Data	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	Actuators	-	
2022	FD	FD-500X	-	ETM -- Entertainment Telematic Module	ECU Configure Information	-	
2022	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	ECU Information	-	
2022	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Read Codes	-	
2022	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Erase codes	-	
2022	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Live Data	-	
2022	FD	FD-500X	-	CSWM -- Comfort Seat Wheel Module	Actuators	-	
2022	FD	FD-500X	-	HALF -- Haptical Lane Feedback	ECU Information	-	
2022	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Read Codes	-	
2022	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Erase codes	-	
2022	FD	FD-500X	-	HALF -- Haptical Lane Feedback	Live Data	-	
2022	FD	FD-500X	-	HALF -- Haptical Lane Feedback	ECU Configure Information	-	
2022	FD	FD-500X	-	RRM -- Radio Receiver Module	ECU Information	-	
2022	FD	FD-500X	-	RRM -- Radio Receiver Module	Read Codes	-	
2022	FD	FD-500X	-	RRM -- Radio Receiver Module	Erase codes	-	
2022	FD	FD-500X	-	RRM -- Radio Receiver Module	Live Data	-	
2022	FD	FD-500X	-	RRM -- Radio Receiver Module	Actuators	-	
2022	FD	FD-500X	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2022	FD	FD-500X	-	DCU - Dosing Control Unit	ECU Information	-	
2022	FD	FD-500X	-	DCU - Dosing Control Unit	Read Codes	-	
2022	FD	FD-500X	-	DCU - Dosing Control Unit	Erase codes	-	
2022	FD	FD-500X	-	DCU - Dosing Control Unit	Live Data	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	ECU Information	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Read Codes	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Erase codes	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Live Data	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Actuators	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	ECU Configure Information	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Motorized throttle learning	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Reset phases front	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	ECU Information	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Read Codes	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Erase codes	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Live Data	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Actuators	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	ECU Configure Information	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Motorized throttle learning	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Reset phases front	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	ECU Information	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Read Codes	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Erase codes	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Live Data	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Actuators	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	ECU Configure Information	-	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	System Tests	Self - Adaptive parameters reset	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Control unit replacement/reprogramming	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2007	CC	CC-500/Cinquecent	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	ECU Information	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Read Codes	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Erase codes	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Live Data	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Actuators	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	ECU Configure Information	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Self-learned function reset	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Motorized throttle learning	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Phonic wheel Reset	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Reset phases front	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	ECU Information	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Read Codes	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Erase codes	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Live Data	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Actuators	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	ECU Configure Information	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Fan cooling activation	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Self-adaptive parameters reset	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Self-learned function reset	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Control unit replacement/reprogramming	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Oxygen sensor and/or catalyst and/or injector replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Purge canister replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	ECU Information	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Read Codes	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Erase codes	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Live Data	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Actuators	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	ECU Configure Information	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Fan cooling activation	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Resetting distance travelled with water in diesel warning lamp ON	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Resetting distance travelled with water temperature warning lamp ON	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Self-learned function reset	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Throttle valve test	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Control unit replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Differential pressure sensor replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Injector code reading	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	NOx replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Oli change	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	ECU Information	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Read Codes	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Erase codes	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Live Data	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Actuators	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	ECU Configure Information	-	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Self-Adaptive parameters reset	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	System Tests	Self-learned function reset	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Control unit replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Multi Air Rolling Finger Replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Oli change	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Oil Temperature Sensor Replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2007	CC	CC-500/Cinquecento		ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	ECU Information	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	Read Codes	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	Erase codes	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	Live Data	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	Actuators	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	ECU Configure Information	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	Special Functions	ECU replacement	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes		Electric Park Brake management	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes		Longitudinal and Lateral sensor calibration	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes		Pressure sensor calibration	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	ECU Information	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	Read Codes	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	Erase codes	-	
2007	CC	CC-500/Cinquecento		ABS -- Anti Lock Brakes	Live Data	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2007	CC	CC-500/Cinquecento	-	ABS -- Anti Lock Brakes	Actuators	-	
2007	CC	CC-500/Cinquecento	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal/Lateral sensor calibration	
2007	CC	CC-500/Cinquecento	-	ABS -- Anti Lock Brakes		Static Test	
2007	CC	CC-500/Cinquecento	-	ABS -- Anti Lock Brakes		TPMS calibration	
2007	CC	CC-500/Cinquecento	-	RCU -- Roof Control Unit	ECU Information	-	
2007	CC	CC-500/Cinquecento	-	RCU -- Roof Control Unit	Read Codes	-	
2007	CC	CC-500/Cinquecento	-	RCU -- Roof Control Unit	Erase codes	-	
2007	CC	CC-500/Cinquecento	-	RCU -- Roof Control Unit	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Read Codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Erase codes	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Live Data	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Actuators	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	ECU Configure Information	-	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	EGR Low pressure valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Differential pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Oil change	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2009	PE	PE-Punto EVO	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	System Tests	Enable/Disable the roll bench mode	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Special Functions	Pressure sensor calibration	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Special Functions	Reset gear configuration	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	ECU Information	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Read Codes	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Erase codes	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Live Data	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Actuators	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	System Tests	Enable/Disable the roll bench mode	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Special Functions	Pressure sensor calibration	
2012	CL	CL-500L	-	ABS -- Anti Lock Brakes	Special Functions	Reset gear configuration	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learned functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Phonic wheel Reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Self learning throttle body	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Self - adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Read Codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Erase codes	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Live Data	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Actuators	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	ECU Configure Information	-	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Fan cooling activation	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	System Tests	Self-learned functions reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Adaptive parameters reset	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Neutral signal learning	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset learn flag wheel tooth	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Reset phases front	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Self learning throttle body	
2012	NP	NP-Panda	-	PCM -- Powertrain Control Module	Special Functions	Startup with CODE CARD	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Live Data	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Actuators	-	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2012	NP	NP-Panda	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2013	FF	FF-500	-	ESM -- Electronic Shifter	Read Codes	-	
2013	FF	FF-500	-	ESM -- Electronic Shifter	Erase codes	-	
2013	FF	FF-500	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2013	FF	FF-500	-	ETM -- Entertainment Telematic Module	Erase codes	-	
2013	FF	FF-500	-	PIM -- Power Inverter Module	Read Codes	-	
2013	FF	FF-500	-	PIM -- Power Inverter Module	Erase codes	-	
2013	FF	FF-500	-	RBC -- Regenerative Brake Controller	Read Codes	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Waste gate valve command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Multi Air Rolling Finger Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil Temperature Sensor Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Waste gate valve command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Multi Air Rolling Finger Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil Temperature Sensor Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	EGR Low pressure valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 1 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 2 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 3 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 4 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Differential pressure sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		EGR high pressure valve replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		EGR Low pressure valve replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Injector code reading	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Injector replacement (per bank)	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Lambda sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		NOx replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Particulate filter regeneration	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Particulate filter with integrated pre-cat replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Rail pressure sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Waste gate valve command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Multi Air Rolling Finger Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil Temperature Sensor Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	EGR Low pressure valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 1 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 2 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 3 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 4 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Differential pressure sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		EGR high pressure valve replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		EGR Low pressure valve replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Injector code reading	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Injector replacement (per bank)	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Lambda sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		NOx replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Particulate filter regeneration	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Particulate filter with integrated pre-cat replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Rail pressure sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	EGR Low pressure valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 1 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 2 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 3 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Cylinder 4 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Differential pressure sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		EGR high pressure valve replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		EGR Low pressure valve replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Injector code reading	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Injector replacement (per bank)	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Lambda sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		NOx replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Particulate filter regeneration	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Particulate filter with integrated pre-cat replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module		Rail pressure sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Self-Adaptive parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oxygen sensor and/or catalyst and/or injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Purge canister replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Self-Adaptive parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oxygen sensor and/or catalyst and/or injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Purge canister replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Waste gate valve command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Multi Air Rolling Finger Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil Temperature Sensor Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Live Data	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Actuators	-	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Waste gate valve command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Multi Air Rolling Finger Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil Temperature Sensor Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Live Data	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K1) control solenoid valve command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Range selection electro valve command (PPVS)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Electro pump drive unit replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Even gear clutch pressure sensor replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Transmission fluid accumulator replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Transmission replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Odd gear clutch position sensor replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Replacement parking system	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Live Data	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K1) control solenoid valve command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Range selection electro valve command (PPVS)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Electro pump drive unit replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Electro pump replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Even gear clutch pressure sensor replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Transmission fluid accumulator replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Transmission replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Kit replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Odd gear clutch position sensor replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Replacement parking system	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Sensors module replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	ECU Information	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Read Codes	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Erase codes	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Live Data	-	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) control solenoid valve command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K1) control solenoid valve command	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	System Tests	Range selection electro valve command (PPVS)	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	SHIFTER' Sensor replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Transmission replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2014	BU	BU-Renegade	-	TCM -- Transmission Control Module	Special Functions	Odd gear clutch position sensor replacement	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	ECU Information	-	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Read Codes	-	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Erase codes	-	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Live Data	-	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Actuators	-	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	ECU Configure Information	-	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	ECU replacement	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes		Electric Park Brake management	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes		Longitudinal and Lateral sensor calibration	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes		Pressure sensor calibration	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement Instrument Panel Cluster	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	ECU Information	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Read Codes	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Erase codes	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Live Data	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Actuators	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	ECU Configure Information	-	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement Instrument Panel Cluster	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	ECU Information	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Read Codes	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Erase codes	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Live Data	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Actuators	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	ECU Configure Information	-	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Special Functions	Power Down	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Special Functions	Power on and Disable User Inputs	
2014	BU	BU-Renegade	-	RRM -- Radio Receiver Module	Special Functions	Reset Parameters to Default	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Mechanical hydraulic test (SCR system)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	SCR dosing module test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	UREA Dosing valve release test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	UREA Emptying test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Dosing valve replacemnt	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Nox temperature sensor replacement (downstream SCR catalyst)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	SCR dosing module replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Selective Catalyst Reduction (SCR) replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Temperature sensor replacement (inlet SCR catalyst)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Read Codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Erase codes	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Live Data	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Actuators	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	ECU Configure Information	-	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2014	DC	DC-Ducato	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2014	DC	DC-Ducato	-	SGW -- Security Gateway Module	Read Codes	-	
2014	DC	DC-Ducato	-	SGW -- Security Gateway Module	Erase codes	-	
2015	FF	FF-500	-	EVCU -- Electronic Vehicle Control Unit	Read Codes	-	
2015	FF	FF-500	-	EVCU -- Electronic Vehicle Control Unit	Erase codes	-	
2015	FF	FF-500	-	BCM -- Body Controller	Read Codes	-	
2015	FF	FF-500	-	BCM -- Body Controller	Erase codes	-	
2015	FF	FF-500	-	ESM -- Electronic Shifter	Read Codes	-	
2015	FF	FF-500	-	ESM -- Electronic Shifter	Erase codes	-	
2015	FF	FF-500	-	ETM -- Entertainment Telematic Module	Read Codes	-	
2015	FF	FF-500	-	ETM -- Entertainment Telematic Module	Erase codes	-	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	FF	FF-500	-	PIM -- Power Inverter Module	Read Codes	-	
2015	FF	FF-500	-	PIM -- Power Inverter Module	Erase codes	-	
2015	FF	FF-500	-	RBC -- Regenerative Brake Controller	Read Codes	-	
2015	FF	FF-500	-	RBC -- Regenerative Brake Controller	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self adaptive parameters reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Megaknock counter reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector codes read	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self adaptive parameters reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Deactivation of the power limitation function	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Megaknock counter reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Over boost counter reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	





**Diagnostic List Fiat\_v9.10**

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self adaptive parameters reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Megaknock counter reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	





## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Speed limit setting	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Read Codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Erase codes	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Live Data	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	Actuators	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	EGR Low pressure valve test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	DB	DB-Doblo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	









## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	ECU Information	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Read Codes	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Erase codes	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Live Data	-	
2015	FB	FB-500X	-	RFH -- Radio Frequency Hub	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Replacement of variable geometry turbo and/or turbo position sensor	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Read second level micro safety reset event	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	ECU Configure Information	-	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Active Grill Shutter test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	EGR High pressure valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Fuel pump control module test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Dosing valve replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Oil change	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	ECM -- Engine Control Module	Special Functions	Temperature sensor replacement (inlet SCR catalyst)	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Actuators	-	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit control	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) Control solenoid valve command	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) Control solenoid valve command	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	System Tests	Range selection electrovalve command (PPVS)	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Electric pump drive unit replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Electric pump replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Even gear clutch pressure sensor replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Gearbox control unit replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Transmission fluid accumulator replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Transmission replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Hydraulic kit replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Odd gear clutch position sensor replacement	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Replacement parking system	
2015	PD	PD-Egea/Tipo	-	TCM -- Transmission Control Module	Special Functions	Sensor module replacement	
2015	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	ECU Information	-	
2015	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Read Codes	-	
2015	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Erase codes	-	
2015	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Live Data	-	
2015	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook Presence Disabling	
2015	PD	PD-Egea/Tipo	-	PAM -- Park Assist Module	Special Functions	Trailer Hook presence enabling	
2016	FF	FF-500	-	BCM -- Body Controller	Read Codes	-	
2016	FF	FF-500	-	BCM -- Body Controller	Erase codes	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Information	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Read Codes	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Erase codes	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	Live Data	-	
2016	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Erase codes	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Live Data	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	Actuators	-	
2016	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2017	FF	FF-500	-	BCM -- Body Controller	Read Codes	-	
2017	FF	FF-501	-	BCM -- Body Controller	Erase codes	-	
2017	FB	FB-500X	-	TCM -- Transmission Control Module	ECU Information	-	
2017	FB	FB-501X	-	TCM -- Transmission Control Module	Read Codes	-	
2017	FB	FB-502X	-	TCM -- Transmission Control Module	Erase codes	-	
2017	FB	FB-503X	-	TCM -- Transmission Control Module	Live Data	-	
2017	FB	FB-504X	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Erase codes	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Live Data	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Event Data	-	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Quick learn	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Reset Adaptive Values	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	TCM VIN Verification	
2017	TO	TO-Toro	-	TCM -- Transmission Control Module	Special Functions	Value Body Solenoid Learn	
2018	FF	TO-Toro	-	BCM -- Body Controller	Read Codes	-	
2018	FF	TO-Toro	-	BCM -- Body Controller	Erase codes	-	
2018	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Information	-	
2018	TO	TO-Toro	-	TCM -- Transmission Control Module	Read Codes	-	
2018	TO	TO-Toro	-	TCM -- Transmission Control Module	Erase codes	-	
2018	TO	TO-Toro	-	TCM -- Transmission Control Module	Live Data	-	
2018	TO	TO-Toro	-	TCM -- Transmission Control Module	ECU Configure Information	-	
2019	FF	FF-500	-	BCM -- Body Controller	Read Codes	-	
2019	FF	FF-500	-	BCM -- Body Controller	Erase codes	-	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	EGR High pressure valve replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Oil change	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	



## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Oil change	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning with engine off	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Purge canister replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Vehicle Configuration reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning with engine off	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup with CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Fuel press. Regulator replacement (high press. Pump input)	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Oil change	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Oil change	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Upstream lambda probe replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor and/or injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Purge canister replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Oil change	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Variable geometry turbo and/or turbo position Sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - adaptive parameters reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self - learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch pedal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Deactivation of the Power Limitation function	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning with engine off	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Startup CODE CARD	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Supercharging system components replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Self-learnt functions reset	
2012	CL	CL-500L	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Downstream lambda probe replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	EGR high pressure valve replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/or catalytic convertor replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Oil change	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2012	CL	CL-500L	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	

## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Bleed Hydraulic Circuit	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	ECU Replacement With Value Transfer	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit depressurization	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Learn Clutches Contact Point	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	New Actuators	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Quick Learn	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Reset of Data group	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Bleed Hydraulic Circuit	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	ECU Replacement With Value Transfer	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit depressurization	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Learn Clutches Contact Point	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	New Actuators	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Quick Learn	
2014	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Reset of Data group	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC FGA Enable Seatbelt Minder Chime	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	ECU replacement	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC FGA Enable Seatbelt Minder Chime	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	ECU replacement	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2014	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Special Functions	Trailer hook presence disabling	
2014	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Special Functions	Trailer hook presence enabling	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	EGR low pressure valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	EGR High pressure valve replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Electrical variable geometry turbo and/Or turbo position sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Waste Gate valve command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Adaptative parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/Or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the power limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/Or catalytic convertor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	MultiAir rolling finger replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil temperature sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system component replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Motorized throttle self learning command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Self-learned function reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Clutch group and/Or clutch potentiometer replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/Or catalytic convertor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neutral signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Air conditioner relay command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Waste Gate valve command	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Adaptative parameters reset	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Deactivation of the power limitation function	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor and/Or catalytic convertor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	MultiAir rolling finger replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil temperature sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Supercharging system component replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Oil change	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2014	BU	BU-Renegade	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	ECU Substitution	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	Electric Park Brake management	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	Pressure sensor calibration	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor recognition	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	ECU Substitution	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	Electric Park Brake management	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	Longitudinal and Lateral sensor calibration	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	Pressure sensor calibration	
2014	BU	BU-Renegade	-	ABS -- Anti Lock Brakes	Special Functions	Wheel speed sensor recognition	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	LIN Siren Check	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	LIN Anti-tilt Sensor Check	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	LIN Siren Check	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Lin Ultrasonic Sensors Check	
2014	BU	BU-Renegade	-	BCM -- Body Controller	Special Functions	Modify lateral anti-tilt sensor	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement Instrument Panel Cluster	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Disable seat belts reminder	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Enable seat belts reminder	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Replacement Instrument Panel Cluster	
2014	BU	BU-Renegade	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service information	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Bleed Hydraulic Circuit	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	ECU Replacement With Value Transfer	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit depressurization	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Learn Clutches Contact Point	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	New Actuators	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Quick Learn	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Reset of Data group	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Bleed Hydraulic Circuit	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	ECU Replacement With Value Transfer	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Hydraulic Circuit depressurization	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Learn Clutches Contact Point	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	New Actuators	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Quick Learn	
2015	BF	BF-Fiat 500L	-	TCM -- Transmission Control Module	Special Functions	Reset of Data group	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC FGA Enable Seatbelt Minder Chime	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	ECU replacement	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC Disable Seatbelt Minder Chime	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	IPC FGA Enable Seatbelt Minder Chime	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Service Information	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	ECU replacement	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Last service date	
2015	BF	BF-Fiat 500L	-	IPC -- Instrument Panel Cluster	Special Functions	Reset Odometer	
2015	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Special Functions	Trailer hook presence disabling	
2015	BF	BF-Fiat 500L	-	PAM -- Park Assist Module	Special Functions	Trailer hook presence enabling	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	EGR Low pressure valve test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Clutch group and/Or clutch potentiometer replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	EGR High pressure valve replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Electrical variable geometry turbo and/Or turbo position sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	







## Diagnostic List Fiat\_v9.10

Remark:  
 1. ✓ : means that the system has this function  
 2. - : means that the system does not have this function  
 3. compared with the last version, the new added function is marked in red color.

Year	Body	Vehicle	Capacity	system	Function	Sub-function	Remark
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Adaptive parameters reset	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Deactivation of the power limitation function	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Fan cooling activation	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Intake manifold replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Motorized throttle replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	MultiAir rolling finger replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Oil temperature sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Phonic wheel replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Replacement UNIAIR module	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Supercharging system component replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Timing sensor and/or cam replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	EGR high pressure valve test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	EGR Low pressure valve test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Electrical VGT actuator test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Fan cooling activation	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Glow plug preheating circuit test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water in diesel warning lamp ON	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Resetting distance travelled with Water temperature warning lamp ON	
2015	FB	FB-500X	-	ECM -- Engine Control Module	System Tests	Throttle valve test	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Air flow meter sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Clutch group and/or clutch potentiometer replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Cylinder 1 injector replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Cylinder 2 injector replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Cylinder 3 injector replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Cylinder 4 injector replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Differential Pressure Sensor Replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	EGR High pressure valve replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	EGR low pressure valve replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Electrical variable geometry turbo and/or turbo position sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Injector code reading	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Injector replacement (per bank)	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Intelligent alternator (IAM) replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Lambda sensor replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Neural signal learning	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	NOx replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Oil change	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Particulate filter regeneration	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Particulate filter with integrated pre-cat replacement	
2015	FB	FB-500X	-	ECM -- Engine Control Module	Special Functions	Rail pressure sensor replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit control	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) Control solenoid valve command	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) Control solenoid valve command	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Range selection electrovalve command (PPVS)	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Electric pump drive unit replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Electric pump replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Even gear clutch pressure sensor replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Transmission fluid accumulator replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Transmission replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Hydraulic kit replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Odd gear clutch position sensor replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Sensor module replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Electric pump drive unit control	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Even gear clutch (K2) Control solenoid valve command	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Odd gear clutch (K1) Control solenoid valve command	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	System Tests	Range selection electrovalve command (PPVS)	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Control unit reprogramming	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Electric pump drive unit replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Electric pump replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Engine control unit replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Even gear clutch pressure sensor replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Transmission fluid accumulator replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Transmission replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Hydraulic kit replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Odd and/or even gear clutch replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Odd gear clutch position sensor replacement	
2015	FB	FB-500X	-	TCM -- Transmission Control Module	Special Functions	Sensor module replacement	
2015	FB	FB-500X	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2015	FB	FB-500X	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	FB	FB-500X	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2015	FB	FB-500X	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2015	FB	FB-500X	-	BCM -- Body Controller	Special Functions	Anti-Theft information	
2015	FB	FB-500X	-	BCM -- Body Controller	Special Functions	Exit Logistic Mode	
2015	FB	FB-500X	-	BCM -- Body Controller	Special Functions	Fire Protection System Activate	
2015	FB	FB-500X	-	BCM -- Body Controller	Special Functions	LIN Line Request Check	
2015	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	
2015	FB	FB-500X	-	HVAC -- Heat, Ventilation and A/C	Special Functions	Self Learning Motor Test	