

Diagnostic List Fuwa Machinery_v5.59							
Engine type	System	Function					
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Remark(other functions)
BOSCH common rail EDC16U40	Static diagnosis data	✓	✓	✓	-	-	Oil balance matching, read freeze frame
BOSCH common rail EDC16U40	Dynamic diagnosis data	✓	-	-	✓	✓	Function test
BOSCH common rail EDCT	Static diagnosis data	✓	✓	✓	-	-	Troubleshoot guide, read freeze frame
BOSCH common rail EDCT	Dynamic diagnosis data	✓	-	-	✓	✓	Function test
DELPHI common rail system	DELPHI common rail system _12V	✓	✓	✓	✓	✓	Injector data, write VIN, leak test
DELPHI common rail system	DELPHI common rail system Euro III	✓	✓	✓	✓	✓	Injector data, write VIN, leak test
Hino Denso engine	E13CTU Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CTX Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CTM Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CTL Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CTN Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CTP Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CTR Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CTS Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CTT Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETB Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETE Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETA Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	J05DTA Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	J05DTA Engine trial	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	P11CUH Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	P11CU Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUN Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUR Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUK Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUL Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUP Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J07ETB Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J05DTC Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CVT Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUT Engine	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function

Diagnostic List Fuwa Machinery_v5.59

Remark:
 1. ✓ : means that the system has this function
 2. - : means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

Engine type	System	Function						Remark(other functions)
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test		
Hino Denso engine	J08ETN Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETT Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETL Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETU Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUU Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUM Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUS Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUB Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUA Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUB Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUC Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUD Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUE Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08DTG Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETC Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETD Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETW Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUJ Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETV Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08OTP Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CUY Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	P11CUU Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUR Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CVA Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CVB Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	P11CUV Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUP Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUS Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUL Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUT Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08EUV Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	J08ETF Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	E13CVC Engine	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	Training Board	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test and vehicle speed limit setting function
Hino Denso engine	A09C	✓	✓	✓	✓	✓	✓	function
Hino Denso engine	A09CTJ	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	A09CTK	✓	✓	✓	✓	✓	✓	Read and write injector data,boost test function
Hino Denso engine	U2 Engine	✓	✓	✓	-	-	-	-