- 1. \checkmark : means that the system has this function
- 2. -: means that the system does not have this function 3.compared with the last version, the new added function is marked in red color.

Vehicle menu		Function								
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor		
Test by System	ENGINE	√	√	√	√	√	√	√		
Test by System	TRANSMISSION	√	√	√	√	√	√	\checkmark		
Test by System	ABS	√	√	√	√	√	\checkmark	\checkmark		
Test by System	AIR BAG	√	√	√	√	-	√	√		
Test by System	BCM	√	√	√	√	√	√	√		
Test by System	METER/M&A	√	√	√	√	-	-	\checkmark		
Test by System	HVAC	√	√	√	√	√	\checkmark	√		
Test by System	ICC/ADAS	√	√	√	√	√	√	√		
Test by System	MULTI AV	√	√	√	√	√	√	√		
Test by System	EHS/PKB	√	√	√	√	-	-	_		
Test by System	MOTOR CONTROL	√	√	√	√	_	-	_		
Test by System	EPS/DAST 3	√	√	√	√	-	-	√		
Test by System	IPDM E/R	√	√	√	√	√	_	_		
Test by System	AIR PRESSURE MONITOR	√	√	√	√	√	\checkmark	√		
Test by System	BAC	√	√	√	√	-	_	_		
Test by System	SUB METER	_	√	√	√	_	-	_		
Test by System	CONVERTIBLE ROOF	√	√	√	√	√	√	√		
Test by System	HEAD LAMP LEVELIZER	√	√	√	√	√	√	\checkmark		
Test by System	e-4WD	√	√	√	√	√	_	_		
Test by System	LASER/RADAR	√	√	√	√	_	√	√		
Test by System	INTELLIGENT KEY	√	√	√	√	√	√	√		
Test by System	DIU	-	√	√	√	-	-	_		
Test by System	AUTO SLIDE DOOR	√	√	√	√	√	√	_		
Test by System	PRECRASH SEATBELT	√	√	√	√	_	√	_		
Test by System	AUTO DRIVE POS.	√	√	√	√	√	√	√		
Test by System	ALL MODE AWD/4WD	√	√	√	√	√	√	_		
Test by System	DIFF LOCK	√	√	√	√	-	_	-		
Test by System	4WAS (MAIN)/RAS/HICAS	√	√	√	√	√	-	_		

- 1. \checkmark : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu			Function								
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor			
Γest by System	SONAR	√	√	√	√	√	√	_			
Γest by System	LANE CAMERA	√	√	√	√	√	\checkmark	√			
Test by System	ADAPTIVE LIGHT	√	√	√	√	√	√	√			
est by System	AUTO SLIDE DOOR RIGHT	√	√	√	√	√	_	_			
est by System	CAN GATEWAY	√	√	√	√	_	_	_			
est by System	SHIFT	\checkmark	√	\checkmark	√	_	_	_			
est by System	EV/HEV	√	√	√	√	√	_	_			
est by System	POP UP HOOD	√	√	√	√	_	_	_			
est by System	AUTO BACK DOOR	√	√	√	√	_	√	_			
est by System	Diag Data Recorder	_	√	√	_	_	_	_			
est by System	4WAS (FRONT)	√	√	√	√	\checkmark	√	_			
est by System	E-SUS	√	√	√	√	√	\checkmark	_			
est by System	ACCELE PEDAL ACT	√	√	√	√	√	_	_			
est by System	HV BATTERY	√	√	√	√	_	_	_			
est by System	TOTAL ILLUM C/U	\checkmark	√	√	√	√	\checkmark	_			
est by System	OCCUPANT DETECTION	_	_	_	√	_	_	_			
est by System	SmFOB	√	√	√	√	_	_	_			
est by System	BRAKE	√	√	√	√	_	_	_			
est by System	SIDE RADAR LEFT	√	√	√	√	√	√	_			
est by System	ANC	√	√	√	√	_	_	_			
est by System	MULTI DISPLAY	_	√	√	√	√	_	_			
est by System	SIDE RADAR RIGHT	√	√	√	√	√	√	-			
est by System	ADCM	√	√	√	√	-	_	_			
est by System	CHARGER/PD MODULE	√	√	√	√	_	_	-			
est by System	PTC HEATER	√	√	√	√	√	√	_			
est by System	TELEMATICS	√	√	√	√	-	√	_			
est by System	HAS	√	√	√	√	_	_	_			
est by System	EMCM	√	√	√ √	1	_	_	_			
est by System	SVT	√	√	√ √	√	-	√	_			

- 1. \checkmark : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

	Vehicle menu		Function									
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor				
Test by System	BSW/BUZZER	√	√	√	√	-	-	√				
est by System	AVM	√	√	√	√	_	√	_				
est by System	CHASSIS CONTROL	√	√	√	√	_	_	_				
est by System	DAST 1	√	√	√	√	_	_	_				
est by System	DAST 2	√	√	√	√	_	_	_				
est by System	HIGH BEAM ASSIST	√	√	√	√	_	_	_				
est by System	CIU	√	√	√	√	√	√	_				
est by System	MM CONN	√	√	√	√	_	√	_				
est by System	ICC/ADAS 2	√	√	√	√	_	_	\checkmark				
est by System	Lane camera 2	√	√	√	√	_	_	_				
est by System	CAN GATEWAY3	√	√	√	√	_	_	_				
st by System	(TBD) GEN-INV	√	√	√	√	_	_	_				
est by System	CAN GATEWAY2	√	√	√	√	_	_	_				
est by System	Vehicle data transmitter	√	√	√	√	_	_	_				
est by System	Cluster	√	√	√	√	√	√	_				
est by System	NATS IMMU	√	√	√	_	_	_	_				
est by System	SMART ENTRANCE	_	√	√	√	√	√	_				
est by System	AIR LEVELIZER	√	√	√	√	√	√	_				
est by System	REARVIEW CAMERA	√	_	_	√	_	√	_				
est by System	S/BLIND CAMERA	√	_	_	√	_	√	_				
est by System	ACTIVE ENG MOUNT	√	√	√	√	√	_	_				
est by System	ACTIVE SUS	-	√	√	√	_	_	_				
est by System	ASCD	_	√	√	√	_	_	_				
est by System	HANDS FREE MODULE	√	√	√	√			_				
st by System	DISTANCE CONTROL	_	√	√	√	√	-	-				
st by System	MOTOR ASSIST	√	√	√	√	_	-	_				
st by System	IVMS	_	√	√	√	√	-	_				
est by System	TCS	_	√	√	√	√	_	_				
est by System	СНА	√	√		√		√	_				

- 1. \checkmark : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu			Function								
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor			
Test by System	VSP	√	√	√	√	_	_	_			
Test by System	FSCM	√	√	√	√	_	-	_			
Test by System	PMAS	√	√	√	√	_	-	-			
Test by System	RADIO	√	√	√	√	√	√	-			
Test by System	Left front door control unit	√	√	√	√	_	_	_			
Test by System	Right front door control unit	\checkmark	√	√	√	_	_	_			
Test by System	Siren control unit	√	√	√	√	_	_	-			
Test by System	Alarm siren	√	√	√	√	_	_	_			
Test by System	Passenger seat control unit	√	√	√	√	_	_	_			
Test by System	Intelligent battery sensor	√	√	√	√	_	_	_			
Test by System	Upper control panel cont unit	√	√	√	√	_	-	_			
Test by System	EC mirror compass	√	√	√	√	_	_	_			
Test by System	Universal garage door opener	√	√	√	√	_	_	_			
Test by System	Light&rain sensor	√	√	√	√	_	_	_			
Test by System	Overhead control panel unit	√	√	√	√	_	_	_			
Test by System	Electronic ign switch cont unit	√	√	√	√	_	-	_			
Test by System	Trailer recognition control unit	√	√	√	√	_	-	_			
Test by System	Occupant classification unit	√	√	√	√	_	_	_			
Test by System	ICC sensor	√	√	√	√	_	_	_			
Test by System	Parking assist	√	√	√	√	_	_	_			
Test by System	Steering column cont module	√	√	√	√	_	-	_			
Test by System	Steering wheeling switch pad	√	√	√	√	_	_	-			
Test by System	Radar sensor	√	√	√	√	-	-	-			
Test by System	LED H/L control module RH	√	√	√	√	-	-	-			
Test by System	LED H/L control module LH	√	√	√	√	_	-	-			
Test by System	Side radar RH	√	√	√	√	_	_	√			

- 1. \checkmark : means that the system has this function
- 2. -: means that the system does not have this function 3.compared with the last version, the new added function is marked in red color.

Vehicle menu			Function							
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function	Can Diag Support Monitor		
Test by System	Side radar LH	√	√	√	√	_	_	_		
Test by System	Front camera unit	√	√	√	√	_	_	_		
Test by System	PT cont module	√	√	√	√	_	_	_		
Test by System	H/L control module RH	√	√	√	√	_	_	_		
Test by System	H/L control module LH	√	√	√	√	_	_	_		
Test by System	(TBD)Audio Amplier Unit	√	√	√	√	_	_	_		