

## Diagnostic List kubota\_v5.12

Remark:

1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	Tractor	V2403E4	L47	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	M62	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	L44SV	Korea		√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	FT300	Japan	Rops/Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	FT280	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	FT260NE	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2203	KL40Z	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2203	KL44Z	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403	KL48ZH	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403	KL53ZH	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403	KL58ZHQ	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	L45K	Korea		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	L54K/L54C	Korea		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	L60K/L60C	Korea		√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	SL28/SL280	Japan	Rops/Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	SL35/SL350	Japan	Rops/Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	FT250ZFQ	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	SL33K/SL330K	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	M5660	North America	1G700-2646	√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	SL33T/SL330T	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	L32/SL320/SL33L	Japan	Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E5	CR-E5-LB1/LB2			√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E5	CR-E5-LB5/LB6			√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	SL60A			√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	L2602	Europe		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	SL38(MT)	Japan	Rops/Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	SL45(MT)	Japan	Rops/Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	L45H	Korea		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	SL54(MT)	Japan	Rops/Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	L6060HST	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	L5460HST	North America		√	√	√	√	√	√

## Diagnostic List kubota\_v5.12

Remark:

1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	Tractor	V2403E4	L4760HST	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	L4060HST	North America	Rops	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	L4060HST	North America	Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	L3560HST	North America	Rops	√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	L3560HST	North America	Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	SL55L	Japan	Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	V1505	F3990	North America	Auto	√	√	√	√	√	√
Diagmaster-K	Tractor	V1505	B3350	North America	CABIN_Inhibit	√	√	√	√	√	√
Diagmaster-K	Tractor	V1505	B3350	North America	ROPS	√	√	√	√	√	√
Diagmaster-K	Tractor	V1505	B3350	North America	CABIN_Auto	√	√	√	√	√	√
Diagmaster-K	Tractor	V1505	B3350	North America	CABIN_Auto1300	√	√	√	√	√	√
Diagmaster-K	Tractor	V1505	B3350			√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	MX5400	North America	Rops	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	MX5400HST	North America	Rops	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	MX6000HST	North America	Rops	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	MX5400	North America	Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	MX5400HST	North America	Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	MX6000HST	North America	Cabin	√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	L4060	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	L4760	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	L5060	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	L3560	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2203	KL37Z	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	MX4800	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	MX5200	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	L3301	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	L4701	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	D1803E4	L3901	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	MX5800	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	M5660	North America		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	SL54H/SL540H	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4T	SL60H/SL600H	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	SL38/SL380	Japan		√	√	√	√	√	√
Diagmaster-K	Tractor	V2403E4	SL41/SL410	Japan		√	√	√	√	√	√

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	Tractor	V2403E4	SL45/SL450	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	V2403E4T	SL			✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	V2403E4	SL48/SL480	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	D1803E5	L2-372	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	V2403E5	L1-452MT/L2-452MT	Europe	Cabin/Rops	✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	V2403E5	L1-452HST/L2-452HST	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	V2403E5T	L1-522MT/L2-522MT	Europe	Cabin/Rops	✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	V2403E5T	L1-552HST/L2-552HST	Europe	Cabin/Rops	✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	V2403E5T	L2-622	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	Tractor	D1803E5	L1-382	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	WheelLoader	D1803E4TDOC	R530E/R630E			✓	✓	✓	✓	✓	✓
Diagmaster-K	WheelLoader	D1803E4TDOC	R430E			✓	✓	✓	✓	✓	✓
Diagmaster-K	WheelLoader	D1803E4TDOC	R430	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	Canycom	V2403E4T	RG30C-5			✓	✓	✓	✓	✓	✓
Diagmaster-K	Combine	D1803E4	ER438N/ER338N			✓	✓	✓	✓	✓	✓
Diagmaster-K	Combine	D1803E4	ER330N			✓	✓	✓	✓	✓	✓
Diagmaster-K	Combine	D1803E4T	ER448N			✓	✓	✓	✓	✓	✓
Diagmaster-K	Combine	D1803E4T	ERH450	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	Combine	V2403E4T	WR460N	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	Excavator	D1803E5T	KX042-4a			✓	✓	✓	✓	✓	✓
Diagmaster-K	Excavator	D1803E5T	U50-5/U48-5	Europe,North America,Canada	Cabin/Rops	✓	✓	✓	✓	✓	✓
Diagmaster-K	Excavator	D1803E4T	U40-6E/RX-506			✓	✓	✓	✓	✓	✓
Diagmaster-K	Excavator	D1803E4T	KX040-4	Switzerland		✓	✓	✓	✓	✓	✓
Diagmaster-K	Excavator	D1803E4T	KX042-4	Europe	Canopy/Cabin	✓	✓	✓	✓	✓	✓
Diagmaster-K	Excavator	D1803E4TC	KX040-4	North America	CABIN	✓	✓	✓	✓	✓	✓
Diagmaster-K	Excavator	D1803E4TC	KX040-4	North America	ROPS	✓	✓	✓	✓	✓	✓
Diagmaster-K	FrontMower	V1505	F3990	North America	Inhibit	✓	✓	✓	✓	✓	✓
Diagmaster-K	Hinowa	V2403E5	KC300			✓	✓	✓	✓	✓	✓
Diagmaster-K	Maruyama	D1803E4T	TE4B-SSMR-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	Maruyama	D1803E4T	SSA-Alpha1005			✓	✓	✓	✓	✓	✓
Diagmaster-K	Maruyama	D1803E4T	SSA-F617-01			✓	✓	✓	✓	✓	✓
Diagmaster-K	Maruyama	D1803E4T	SSA-V1002C			✓	✓	✓	✓	✓	✓
Diagmaster-K	Maruyama	D1803E4	V602C			✓	✓	✓	✓	✓	✓
Diagmaster-K	Maruyama	D1803E4	SSA-Alpha605			✓	✓	✓	✓	✓	✓
Diagmaster-K	Matsuyama	D1803E4	HTP122			✓	✓	✓	✓	✓	✓
Diagmaster-K	NH	V2203	T2200KLZ	Japan		✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	NH	V2403	T2300KLZ	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	RD	V2403E4T	TE4-BB			✓	✓	✓	✓	✓	✓
Diagmaster-K	RD	D1803E4T	TE4-BB			✓	✓	✓	✓	✓	✓
Diagmaster-K	RD	V2403E4	E4-BB			✓	✓	✓	✓	✓	✓
Diagmaster-K	RD	D1803E4	E4-BB			✓	✓	✓	✓	✓	✓
Diagmaster-K	Takeuchi	V2403E4T	TL6R			✓	✓	✓	✓	✓	✓
Diagmaster-K	Takeuchi	V2403E5	TE5B-TLTU-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	Tobroco	V2403E5T	G3500			✓	✓	✓	✓	✓	✓
Diagmaster-K	Tobroco	D1803E5T	G2700			✓	✓	✓	✓	✓	✓
Diagmaster-K	Tobroco	D1803E5T	GT5048			✓	✓	✓	✓	✓	✓
Diagmaster-K	ZeroTurnMower	V1505	ZD1511	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	7822DT/6622CPT			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	S10020			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	TIE4BG-EPS1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	3650			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	Micro Apollo			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	HT23RTJ			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	TE5B-KEA-1/2			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	HR300			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	CL35			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	3650			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	9L PLUS FD20-36			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	MTP Premium			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	M58			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	XMR403			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	M65			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	KC300			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-AHFT-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-AHFT-3			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	TIE4BG-KEA1	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	TIE4B-KEA-1	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	TIE4BG-MLR1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	TIE4BG-KEA1	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TIE4BG-PTI1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	RT508			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	CB4			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	OEM	D1803E5	MTP Standard			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	CC1300			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	CC1300			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	CPCD35-KU20H			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	CPCD35-KU19G2			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	TE5B-SHF-2			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	TE5B-GNI-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	E5B-MLNK-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-JSQ-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	UPT35-W(9)3			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	C20			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	36ZT/40ZT			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	Mixokret M760			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	50ZT			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-EU-X8	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	H3			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	SQ830			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	BY510			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	3MDX			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	SWSL2023RT			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	XAS 138	Belgium		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	A25K			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	A38K			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	VT 65			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	DCA-40SSKU4F2	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	JCPT1823RT			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	IC35	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	XAS 185 Plus	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	IC20	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-EU-XS8	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	E4B-EU-X8/XP8	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	E4B-HMCH-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	R070T/PT35			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	TB86J/AB60J			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	MC120 Adv Plus			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	20kW Com. Mobile Genset			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	OEM	V2403E4TDOC	HT23RTJ			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	HA26RTJ			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	CPCD30			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	HMK62SS			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-RNS-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-KEA-1/2	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-SSSU-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-GEO-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	MIC70			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	TE5B-AMN-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	M30	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	TE5B-DYP-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	S-15R			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	TE5B-EU-XP8			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	TE5B-PMS-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-TNT-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	TE5B-KRC-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-RMKY-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	TE5B-HDM-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	Speed sprayer			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	TE5B-RMKY-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	800			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4B-AFHN-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	SS435			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	SLR-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	TE4B-KEA-1	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	TE4B-EPS-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	TE4B-DYP-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	TE4B-EU-X8	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	DD30/35			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	HX50			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	TE4B-SSMR-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	Z4			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	TE4B-WCOS-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	SSA-Alpha1005			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	SSA-F617-01			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	OEM	D1803E4T	SW504			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	SSA-V1002C			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	ARX-4	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-HAM-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-CRCH-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	AR530,LF530/730			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	E5B-HMKY-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	S-10A			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	HT23RTJ			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	E5B-EU-X8			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	E4B-ACP-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	E5B-BMG-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	E4B-KEA-1	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	E5B-AMN-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	HD13/14			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	H251			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	HA20RTJ	France		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	XMR275S			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	SF1248DK3	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	E4B-KSR-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	Site Max			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	LM2710	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-KSR-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-KSR-2			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-LMKY-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-BMG-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-BMG-2			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	40V5/50V5/60V5			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	XE55U			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	E4B-BHIH-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	J3			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	BW138			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	J2			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	BW124			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	HTP122			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	E4B-AFHN-1			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	OEM	V2403E4T	58 Series Almond Sweeper			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	E4-TXN-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	E4B-EPS-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	E4B-KEA-1/2	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	E4B-WKR-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	HM5500			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	E4B-EU-X8/XP8	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	CC1100/CC1200			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	SQ1237DK			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	E4B-BMG-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	E4B-TPMK-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	KV40CSi			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	V602C			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	IC38			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	SSA-Alpha605			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	ARX-2	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	X35NA			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V1505	T-E4B-VMR-1	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V1505	T-E4B-DWC-1	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	GS3500			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V1505	LM551			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	RT-5500			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	BC3-6560			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	T-60			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	S300			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	CPCD35			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4T	M5x	Europe		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	AIE-D1803T.DOC-CGEN			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	XATS138			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	SWL2830			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	MP653			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	AR730			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	AIE-V2403T.DOC-CGEN			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	CC1100/CC1200			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	G3500			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	TE5B-EU-XP8			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster-K	OEM	V2403E5T	TE5B-EU-X8			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	4670series			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	RT-40	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	C251H			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-EU-X8			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	E5B-EU-XP8			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	ULM270			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	60J			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403TE5BG	TE5BG2-SAE2			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	4670series(E5B)			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5	LF550/570			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	SQ1243DK			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	SQ1231DK			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4	E4B-WDDE-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	DCA-40SSKU			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4	E4B-EPS-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5	LF530/570			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	SDG40			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	TA3			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	D350AHG			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	G2700			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E5T	GT5048			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4T	TE4BG-KEA-1	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	D1803-T Power Unit			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	MCP20			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	TIE4B-KEA-1/2/3	North America		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	TIE4B-AHN-1			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	V2403 DOC-PWRU			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E4TDOC	MFD-20	Japan		✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	V2403E5T	Delta Prometheus			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	XAS 188			✓	✓	✓	✓	✓	✓
Diagmaster-K	OEM	D1803E4TDOC	XAS185			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M108S	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M108X	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M128X	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135A/M1350X	Japan,Korea		✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	Tractor	V6108	M125A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M115A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110A/M1100X	Japan,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M100A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M90A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135X	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M126X	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M108S	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110X	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M100X	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M130X	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	SMZ955/MZ957	Japan,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	SMZ875/MZ877	Japan,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	SMZ805/MZ807	Japan,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M100X	Oceania		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110X	Oceania		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110X	Asia		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110A	Asia		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M126X	Asia,Oceania,Central and South Africa		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135X	Asia,Oceania,Central and South Africa		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135A	Asia,Central and South Africa		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M108W	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	TIE3-DQ	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135GX	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M125X	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M126GX	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110GX	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M9960	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M100GX	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M9960	North America	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M8560	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M8560	North America	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135GX	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110GX	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M9960	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M9960	Europe	Rops	✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	Tractor	V3800	M8560	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M8560	Europe	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M100G	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110G	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M115G/GR115G	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M125G/GR125G	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135G/GR135G	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M8560-2	North America, Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M8560-2	North America, Europe	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR97	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR87	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR77	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M9960-2	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135GX	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M128GX	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M118GX	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110G/GR100G	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M100G/GR100G	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M4N-071/M5071N	North America, Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5101N	Europe/Australia	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5101N	Europe	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5091N	Europe/Australia	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5091N	Europe	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5091/UN	Europe/Australia	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5091/UN	Europe/Australia	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5111/UN	Europe/Australia	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5111/UN	Europe/Australia	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	F40D	4WD		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	F40C			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	F40B			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	F40D	2WD		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5091N	Europe/Australia	1 C020-1869	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	SMZ955	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	SMZ875	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	SMZ805	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110A	Japan	EGR	✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	Tractor	V3800	M100A	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M90A	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M108W	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135A	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M125A	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M115A	Japan	EGR	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-172-T2	Australia		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-152-T2	Australia		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-132-T2	Australia		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V1505CRS	LX3310	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V1505CRS	LX3310	North America	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V1505	LX-401	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V1505	LX-351	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V1505CRS	CR-TE5-D40R3			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V1505CRS	LX3310(Ver 21.12.01)	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V1505CRS	LX3310(Ver 21.12.01)	North America	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M6060	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M6060	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M7060	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M7060	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR60/MR607	Japan,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR65/MR657	Japan,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR70/MR707	Japan,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M7060	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	F38C-JP	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M4062			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M4072			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M4063	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	M4073	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR600H(KVT)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR650H(KVT)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR700H(KVT)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR627	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR677	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3307	MR737	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M6-141/M135GX3/M6-135/M135GX4	North America,Europe,Korea		✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	Tractor	V6108	M6-131/M125GX3/M125GX4	North America,Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-171	North America,Europe,Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-151	North America,Europe,Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-131	North America,Europe,Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5-111/M5-101	North America,Europe, Korea	Cabin(DS)	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5-111/M5-101	North America,Korea	Cabin(w/o DS)	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5-091/M5-086	North America,Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5-111	North America,Europe	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5-091	North America,Europe	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M6-101	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M6-111/M6-108	North America,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M6-101	Canada		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M6-111/M6-108	Canada		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M105GX3/M105GX4	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M95GX3/M95GX4	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5N-111	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5N-091	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M115GX3/M115GX4	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M6S-111/M6L-111/M1060	North America,Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-172	North America, Europe, Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-152	North America, Europe, Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-132	North America, Europe, Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M6H-101	North America		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M135GE	Japan	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M125GE	Japan	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M115GE	Japan	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M1060W	Japan	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M100GE	Japan	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M110GE	Japan	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M1010W	Japan	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M860W	Japan	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR1000(GST)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR900(GST)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR800(GST)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR1007	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR907	Korea		✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	Tractor	V3800	MR807	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR1000H(KVT)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR900H(KVT)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR800H(KVT)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	MR1050H(KVT)	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-171	North America,Europe,Japan	1G410-0502	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-131	North America,Europe,Japan	1G410-0502	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-173	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-153	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M7-133	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M6-142	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M6-132	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M6-122	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5112	Europe	CABIN	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5112	Europe	ROPS,LP	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5092	Europe	CABIN	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5092	Europe	ROPS	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M6-141 Utility	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M6-131 Utility	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	M6-121 Utility	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M6-111 Utility	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M6-101 Utility	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	TIE5-UP2			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	TIE5-VP2			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V6108	TIE5-WP2			✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V61ACU	V61-B			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V61ACU	V61-U			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V38ACU	V38Z/V38U/V38L			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V38ACU	V38U			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V38ACU	V38BB1			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V61ACU	M7002			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V61ACU	M6/MGX/MGE			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V61ACU	M7001			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V38ACU	V38L			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V38ACU	M5001/MR			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V61ACU	M7003			✓	✓	✓	✓	-	-

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	Tractor	V61ACU	M6002			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V38ACU	M5002			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V61ACU	TIE5-UP2			✓	✓	✓	✓	-	-
Diagmaster	Tractor	V3800	M5072N	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Tractor	V3800	M5072N	Europe	Rops	✓	✓	✓	✓	✓	✓
Diagmaster	WheelLoader	V2607	R630/R085	North America, Europe		✓	✓	✓	✓	✓	✓
Diagmaster	WheelLoader	V2607	R530	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	WheelLoader	V2607	R090	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	WheelLoader	V2607	R070	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	WheelLoader	V2607	R640	North America,Canada		✓	✓	✓	✓	✓	✓
Diagmaster	WheelLoader	V2607	R540	North America,Canada,Australia		✓	✓	✓	✓	✓	✓
Diagmaster	WheelLoader	V2607	R070/RP25	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER108	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER108N	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER698N	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER587N	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER112	Asia		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	WR698M	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	WRH1000	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V6108	PRO1408Y	China		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER575	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER6120	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER6100	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER590	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	WR575M	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	WR6100M	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER575K	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	DR120TI	Taiwan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	WRH1000C			✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	EX108-S / EX108Q-S			✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	EX118M / EX118MQ			✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	DR575	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	E4-CCA1			✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	TIE4H-CA2			✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	PRO100	China		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	PRO988Q-PLUS / PRO988Q-Q-PLUS	China		✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	Combine	V2607	ER470	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V2607	ER460	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	ER595K	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	DC-4JP	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	DR6130/ZR6130K	Japan,Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	DR6115	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	DR595	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V3800	WRN6100	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Combine	V38ACU	V38C			✓	✓	✓	✓	-	-
Diagmaster	CTL	V3800	SVL90-2	North America	Open Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V3800	SVL90-2	North America	Closed Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V3307	SVL75-2	North America, Oceania		✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V2607	SVL65-2	North America	Close Cab	✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V2607	SVL65-2	North America	Open Cab	✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V3307	SVL75-2C/C			✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V3307	SVL75-2			✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V2607	SVL65-2	North America	Open cab/Closed ca	✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V3800	SVL95-2S	North America, Oceania		✓	✓	✓	✓	✓	✓
Diagmaster	CTL	V3800	SVL97-2	North America,Oceania		✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V3307	KX080-4	North America	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V3307	KX080-4	Europe	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V2607	KX057-4	North America	Canopy	✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V2607	KX057/U55-0E			✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V3307	KX080-4a/KX080-4S	Europe,North America		✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V2607	KX-057S,U-55S	Korea		✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V2607	KX-057-4	Europe,Canada		✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V3307	KX080-4a2/4S2	North America, Europe		✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V2607	U56-5/KX060-5/U55-5/KX057-5	Europe,North America,Canada	Canopy	✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V2607	U56-5/KX060-5/U55-5/KX057-5	Europe,North America,Canada	Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	Excavator	V2607	U56-5/KX060-5/U55-5/KX057-5/LB45/L	Europe,North America,Canada	Canopy/Cabin	✓	✓	✓	✓	✓	✓
Diagmaster	FrontMower	V1505	F391	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V6108	GR135A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V6108	GR115A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V3800	GR110A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V3800	GR100A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V3800	GR90A	Japan		✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	MAM	V3800	GV955	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V3800	GV875	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V3800	GV805	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V3800				✓	✓	✓	✓	✓	✓
Diagmaster	MAM	V6108	GR125A	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Maruyama	V3800	BSA3000			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	DGM600MK-P	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	DGM600	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	CRMO1	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	HN1	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	DE1	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	DE2	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TI-E3B-NS1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	D20x22			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-BMG-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-DCI-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-EPS-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-MRO-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-MRO-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE4B-BGHE1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE4B-DCI-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE4B-BMG-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-EPS-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-AFHN1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-RRSH1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE4B-RRSH1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE4B-AUS-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	N115	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-DCI-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE4B-DCI-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-MAT-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	MST-700VDL	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	MW703			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	H33-4			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-EPS-3			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE4B-ANT-S1			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	OEM	V3800	TE4B-BCS-S1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE4B-ITC-1	Italy		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TGF 10900			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	Volcan V950AR			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	BSA3000			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	U-4D			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TZ704			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	CT-500	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TGF9000			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TGF7900			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	F45C5	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	CG750			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE3B-ACC1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	DIS-80VPB	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	DCA-60LSKE-D2	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	PDS400			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	Azura MC 210			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V1505CRS	XAS88			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V1505CRS	TE5B-EU-Z1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V1505CRS	Fairway305/405			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V1505CRS	LM551B			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-BMG-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-DYP-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-BMG-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-DCI-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-AEB-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-HAM-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-HAM-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-BRG-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-AIE-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-RRSH1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-TCKH1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-DMD-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-EPS-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-KSR-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-BHMK1			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	OEM	V2607	C270			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE4B-EU-Z5	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	CC7574			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	PP 4500			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	SV204			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	JT 20			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	JT10			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-AEB-1	1E906-0524		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-BRG-1	1E906-0524		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-DMD-1	1E906-0524		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-EPS-1	1E906-0524		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	HX75			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	Agri Pivot T60			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	Giant+50			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	ARS70			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE4B-ITC-1	Italy		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	P.27.6			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	H 28RTJ			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	KR-350			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TIE4B-KEA-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	XE75U			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TIE4B-BDS-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	P.27.6	North America		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TIE4B-SNY-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE5B-HLD-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-BMG-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-BMG-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-HAM-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-HAM-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-KSR-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-AMN-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE5B-AEB-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	CA1400	Europe		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	HT28RTJ			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	WL			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-EU-Z5			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	OEM	V3307	TE5B-DCI-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-DCI-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	HMK60CR			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE5B-EU-Z8			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TE5B-SMP-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	SWL3230F			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	S-22EZ			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	P48P			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	X2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	C55			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	Apollo GEN2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	Mower HR800			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	60ZT			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	ETL180			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	TT206			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	E5B-EU-Z8			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	Zeus 35.11			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	CPCD35			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	XW95F			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	SWE60UF			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V2607	CPCD35-XW98C-RT4			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	CPCD50			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	TE5B-KEA-1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3307	MST-700VDR			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	IC50-2			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	Asphalt Paver 8616	North America		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	SW754			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	AGRIFARMER			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	V3800-TIEF4B			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	PDS400S			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	ICARUS			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	R954			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	8530/8616			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TIE5B-EU-ZN4			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	AGRIFARMER(E5)			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	ICARUS(E5)			✓	✓	✓	✓	✓	✓

## Diagnostic List kubota\_v5.12

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu						Function					
Brand	Model	EngineModel	Option1	Option2	Option3	ECU Info	Read DTC	Erase DTC	Read Data	Active Test	Special Function
Diagmaster	OEM	V38ACU	V38Z/V38U/V38L			✓	✓	✓	✓	-	-
Diagmaster	OEM	V38ACU	V38BB1			✓	✓	✓	✓	-	-
Diagmaster	OEM	V38ACU	V38-E5-BB			✓	✓	✓	✓	-	-
Diagmaster	OEM	V3800	DC1317			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	V3800-TIE4B			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	V3 74 Power Unit			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	AW-370TG-4/AW-250TG-4			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE5BG2-SAE1			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	TE5BG2-SAE1	1E904-1129		✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	MC210			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	Tony 900 SR			✓	✓	✓	✓	✓	✓
Diagmaster	OEM	V3800	H26-4			✓	✓	✓	✓	✓	✓
Diagmaster	SSL	V2607	SSV65/SL1-ISO	North America		✓	✓	✓	✓	✓	✓
Diagmaster	SSL	V3307	SSV75/SL2-ISO	North America, Oceania		✓	✓	✓	✓	✓	✓
Diagmaster	SSL	V2607	SSV65			✓	✓	✓	✓	✓	✓
Diagmaster	SSL	V2607	SSV65 C			✓	✓	✓	✓	✓	✓
Diagmaster	SSL	V3307	SSV75 C			✓	✓	✓	✓	✓	✓
Diagmaster	Takeuchi	V3800	TL12	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Takeuchi	V3800	TL10	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Takeuchi	V3307	TL8	Japan		✓	✓	✓	✓	✓	✓
Diagmaster	Takeuchi	V3307	TL10V-2			✓	✓	✓	✓	✓	✓
Diagmaster	Takeuchi	V3307	TE5B-TLTU3			✓	✓	✓	✓	✓	✓
Diagmaster	Takeuchi	V3307	TE5B-TLTU1/2			✓	✓	✓	✓	✓	✓
Diagmaster	Takeuchi	V3800	TL12V-2/TL12R-2			✓	✓	✓	✓	✓	✓
Diagmaster	Takeuchi	V38ACU	V38TLTU			✓	✓	✓	✓	-	-