

Diagnostic List subaru_v7.00

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Menu | | Functions | | | | | | | |
|---------------------|-------------------------------------|------------|-----------|--------------|--------------|------------|-------------|-----------|-------------------|
| Vehicle selection | Systems | Sys. Info. | Read code | D-Check code | History code | Clear code | Data stream | Actuation | Special functions |
| All other models | Engine Control System | - | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| All other models | Transmission Control System | - | ✓ | ✓ | ✓ | ✓ | ✓ | - | ✓ |
| All other models | Brake Control System | - | ✓ | - | - | ✓ | ✓ | - | ✓ |
| All other models | Airbag System | - | ✓ | - | ✓ | ✓ | ✓ | - | ✓ |
| All other models | Tire pressure monitor | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| All other models | Integ. Unit Mode | - | ✓ | - | - | ✓ | ✓ | - | ✓ |
| All other models | Keyless Unit Mode | - | - | - | - | - | - | - | ✓ |
| All other models | CAN system | - | ✓ | - | - | ✓ | - | - | - |
| All other models | Air Condition System | - | ✓ | - | ✓ | ✓ | ✓ | - | ✓ |
| All other models | Power steering system | - | ✓ | - | - | ✓ | ✓ | - | - |
| All other models | Keyless access system | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| All other models | Automatic Light and Wiper system | - | - | - | - | - | ✓ | - | - |
| All other models | Combination Meter | - | ✓ | - | ✓ | ✓ | - | - | - |
| All other models | Auto Start Stop | - | ✓ | - | ✓ | ✓ | - | - | - |
| All other models | Automatic Headlight Leveling System | - | ✓ | - | ✓ | ✓ | - | - | - |
| All other models | Multi-function display | - | ✓ | - | ✓ | ✓ | - | - | - |
| Inspection of BRZ | Engine Control System | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Transmission Control System | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Brake Control System | - | ✓ | - | - | ✓ | ✓ | - | - |
| Inspection of BRZ | Airbag System | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Tire pressure monitor | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Integ. Unit Mode | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Occupant Detection System | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Air Condition System | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Power Steering System | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Keyless access system | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Combination Meter | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Power Window | - | ✓ | - | ✓ | ✓ | ✓ | - | - |
| Inspection of BRZ | Remote control starter | - | - | - | - | ✓ | ✓ | - | - |
| OLD PROTOCOL SYSTEM | Engine Control System | - | ✓ | ✓ | ✓ | ✓ | ✓ | - | - |
| OLD PROTOCOL SYSTEM | Transmission Control System | - | ✓ | ✓ | ✓ | ✓ | ✓ | - | - |
| OLD PROTOCOL SYSTEM | Brake Control System | - | ✓ | - | - | ✓ | ✓ | - | ✓ |
| OLD PROTOCOL SYSTEM | Cruise Control System | - | ✓ | - | - | - | ✓ | - | ✓ |