Kymco diagnostic function list_v5.10

Note:
1.The "√" mark means that this function is available on the system.
2.The "-" mark means that this function is not available in the system.
3.Updated features described in the text are highlighted in red.

Model	Sub-model	System	Manual Diagnosis	Automatic diagnosis					
				Read ECU Information	Read DTC	Clear DTC	Read Data Stream	Actuator tests	Special functions
AGILITY CITY	125i EURO 4 (2016) KL25FB	MOTOR	-	√	√	√	√	-	-
G5	125i (2010) SR25BC	INSTRUMENTATION	√	-	-	-	-	-	-
G5	125i (2010) SR25BC	MOTOR	-	√	√	√	√	-	√
GRAND DINK	125 (2005) SH25DB/DF	INSTRUMENTATION	√	-	-	-	-	-	-
GRAND DINK	125i EURO 4 (2016) SH25DU	BRAKING	-	√	√	√	√	-	-
GRAND DINK	125i EURO 4 (2016) SH25DU	MOTOR	-	√	√	√	√	-	-
K-XCT	125i (2013) SK25BA	BRAKING	-	√	√	√	√	-	-
K-XCT	125i (2013) SK25BA	INSTRUMENTATION	√	-	-	-	-	-	-
K-XCT	125i (2013) SK25BA	MOTOR	-	√	√	√	√	-	√
K-XCT	300i (2013) SK60BA	BRAKING	-	√	√	√	√	-	-
K-XCT	300i (2013) SK60BA	INSTRUMENTATION	√	-	-	-	-	-	-
K-XCT	300i (2013) SK60BA	MOTOR	√	√	√	√	√	-	√
PEOPLE	125i (2010) BF25AB	INSTRUMENTATION	√	-	-	-	-	-	-
PEOPLE	125i (2010) BF25AB	MOTOR	-	√	√	√	√	-	√
SUPER DINK / DOWNTOWN	125i (2010) SK25AC/AA	BRAKING	-	√	√	√	√	-	√
SUPER DINK / DOWNTOWN	125i (2010) SK25AC/AA	INSTRUMENTATION	√	-	-	-	-	-	-
SUPER DINK / DOWNTOWN	125i (2010) SK25AC/AA	MOTOR	-	√	√	√	√	-	√
SUPER DINK / DOWNTOWN	300i (2010) SK60AA/AE/AF	BRAKING	-	√	√	√	√	-	√
SUPER DINK / DOWNTOWN	300i (2010) SK60AA/AE/AF	INSTRUMENTATION	√	-	-	-	-	-	-
SUPER DINK / DOWNTOWN	300i (2010) SK60AA/AE/AF	MOTOR	√	√	√	√	√	-	√
SUPER DINK / DOWNTOWN	350i EURO 4 (2017) SK64GC	BRAKING	-	√	√	√	√	-	-
SUPER DINK / DOWNTOWN	350i EURO 4 (2017) SK64GC	MOTOR	-	√	√	√	√	-	-
VENOX	250i (2008) RB50AA	MOTOR	√	√	√	√	√	-	√
XCITING	250i R (2008) SB50AG	INSTRUMENTATION	√	-	-	-	-	-	-
XCITING	250i R (2008) SB50AG	MOTOR	√	√	√	√	√	-	√
XCITING	400i (2013) SK80AA	BRAKING	-	√	√	√	√	-	-
XCITING	400i (2013) SK80AA	INSTRUMENTATION	√	-	-	-	-	-	-

Kymco diagnostic function list_v5.10

Note:
1.The "√" mark means that this function is available on the system.
2.The "-" mark means that this function is not available in the system.
3.Updated features described in the text are highlighted in red.

Model	Sub-model	System	Manual Diagnosis	Automatic diagnosis					
				Read ECU Information	Read DTC	Clear DTC	Read Data Stream	Actuator tests	Special functions
XCITING	400i (2013) SK80AA	MOTOR	√	√	√	√	√	-	√
XCITING	500i R (2010) SBA0BB	BRAKING	-	√	√	√	√	-	√
XCITING	500i R (2010) SBA0BB	INSTRUMENTATION	√	-	-	-	-	-	-
XCITING	500i R (2010) SBA0BB	MOTOR	√	√	√	√	√	-	√
XCITING	500i R (2008) SBA0AG	BRAKING	-	√	√	√	√	-	√
XCITING	500i R (2008) SBA0AG	INSTRUMENTATION	√	-	-	-	-	-	-
XCITING	500i R (2008) SBA0AG	MOTOR	√	√	√	√	√	-	√
XCITING	250i (2007) SB50AE	INSTRUMENTATION	√	-	-	-	-	-	-
XCITING	250i (2007) SB50AE	MOTOR	√	√	√	√	√	-	√
XCITING	500i (2007) SAA0AE	BRAKING	-	√	√	√	√	-	√
XCITING	500i (2007) SAA0AE	INSTRUMENTATION	√	-	-	-	-	-	-
XCITING	500i (2007) SAA0AE	MOTOR	√	√	√	√	√	-	√
YAGER GT	125i (2013) SP25AD	INSTRUMENTATION	√	-	-	-	-	-	-
YAGER GT	125i (2013) SP25AD	MOTOR	-	√	√	√	√	-	√
YAGER GT	300i (2013) SH60AA	INSTRUMENTATION	√	-	-	-	-	-	-
YAGER GT	300i (2013) SH60AA	MOTOR	√	√	√	√	√	-	√