Diagnostic List Chengdu Kobelco_v5.59

Remark:
1. √ ; means that the system has this function
2. - ; means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

System	System	Function					Remark(other functions)
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	
Hino J05E	-	√	√	√	√	√	Read and write injector data
Hino J08E	-	√	√	√	√	√	Read and write injector data
Engine system	E13CTJ Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CTK Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CTM Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CTL Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CTN Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CTP Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CTR Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CTS Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CTT Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETB Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETE Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETA Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J05DUTA Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J05DUTA Engine trial	√	√	√	√	√	Read and write injector data, boost test function
Engine system	P11CUH Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	P11CUJ Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUN Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUM Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUK Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUL Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUP Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J07ETB Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05DUTC Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CVT Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUT Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETN Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETT Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETL Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETU Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function

Diagnostic List Chengdu Kobelco_v5.59

Remark:
1. √ ; means that the system has this function
2. - ; means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

System	System	Function					
		Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Remark(other functions)
Engine system	E13CIU Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CIM Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CIS Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIB Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIA Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIC Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EID Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIE Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05EDTG Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05ETC Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05ETD Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETW Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIJ Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08ETV Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05EDTF Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CUY Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	P11CUR Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIR Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CVA Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CVB Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	P11CUV Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIP Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIS Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIL Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIT Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J08EIU Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	J05ETF Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	E13CVC Engine	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	Training Board	√	√	√	√	√	Read and write injector data, boost test and vehicle speed limit setting function
Engine system	A09C	√	√	√	√	√	Read and write injector data, boost test function
Engine system	A09CTJ	√	√	√	√	√	Read and write injector data, boost test function
Engine system	A09CTK	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J05ETB Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J05ETA Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	P11CUN Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J08EIN Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J05ETG Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	P11CUP Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	E13CUV Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J08EIH Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J08EIG Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J08EIK Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	P11CUT Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	N04CUA Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J08EIM Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J05ETH Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	J08EIN Engine	√	√	√	√	√	Read and write injector data, boost test function
Engine system	P11CIU Engine	√	√	√	√	√	Read and write injector data, boost test function